



# DAIKIN Service Instructions

## DTG Gas Electric DTC Cooling/DTH Heat Pump Commercial Package Units with R-410A Refrigerant 3 - 5 Tons & Accessories



### PROP 65 WARNING FOR CALIFORNIA CONSUMERS

#### **WARNING**

Cancer and Reproductive Harm -  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

0140M00517-A



This manual is to be used by qualified, professionally trained HVAC technicians only. Daikin does not assume any responsibility for property damage or personal injury due to improper service procedures or services performed by an unqualified person.

#### **WARNING**

ONLY PERSONNEL THAT HAVE BEEN TRAINED TO INSTALL, ADJUST, SERVICE OR REPAIR (HEREINAFTER, "SERVICE") THE EQUIPMENT SPECIFIED IN THIS MANUAL SHOULD SERVICE THE EQUIPMENT. THE MANUFACTURER WILL NOT BE RESPONSIBLE FOR ANY INJURY OR PROPERTY DAMAGE ARISING FROM IMPROPER SERVICE OR SERVICE PROCEDURES. IF YOU SERVICE THIS UNIT, YOU ASSUME RESPONSIBILITY FOR ANY INJURY OR PROPERTY DAMAGE WHICH MAY RESULT. IN ADDITION, IN JURISDICTIONS THAT REQUIRE ONE OR MORE LICENSES TO SERVICE THE EQUIPMENT SPECIFIED IN THIS MANUAL, ONLY LICENSED PERSONNEL SHOULD SERVICE THE EQUIPMENT. IMPROPER INSTALLATION, ADJUSTMENT, SERVICING OR REPAIR OF THE EQUIPMENT SPECIFIED IN THIS MANUAL, OR ATTEMPTING TO INSTALL, ADJUST, SERVICE OR REPAIR THE EQUIPMENT SPECIFIED IN THIS MANUAL WITHOUT PROPER TRAINING MAY RESULT IN PRODUCT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

# TABLE OF CONTENTS

IMPORTANT INFORMATION.....	2 - 3	SERVICING.....	33 - 58
PRODUCT IDENTIFICATION.....	4 - 9	ACCESSORIES.....	59 - 63
PRODUCT DESIGN.....	10 - 13	ACCESSORIES WIRING DIAGRAMS.....	64 - 77
SYSTEM OPERATION.....	14 - 27	HEATER KITS.....	78
SCHEDULED MAINTENANCE.....	28 - 29	HEATER KIT WIRING DIAGRAMS.....	79 - 83
TROUBLESHOOTING CHARTS.....	30 - 31	UNIT WIRING DIAGRAMS.....	85 - 96
SERVICING TABLE OF CONTENTS.....	32		

## IMPORTANT INFORMATION

Pride and workmanship go into every product to provide our customers with quality products. It is possible, however, that during its lifetime a product may require service. Products should be serviced only by a qualified service technician who is familiar with the safety procedures required in the repair and who is equipped with the proper tools, parts, testing instruments and the appropriate service manual. **REVIEW ALL SERVICE INFORMATION IN THE APPROPRIATE SERVICE MANUAL BEFORE BEGINNING REPAIRS.**

## IMPORTANT NOTICES FOR CONSUMERS AND SERVICERS RECOGNIZE SAFETY SYMBOLS, WORDS AND LABELS



### WARNING

This unit should not be connected to, or used in conjunction with, any devices that are not design certified for use with this unit or have not been tested and approved by the manufacturer. Serious property damage or personal injury, reduced unit performance and/or hazardous conditions may result from the use of devices that have not been approved or certified by the manufacturer.



### WARNING

Do not store combustible materials or use gasoline or other flammable liquids or vapors in the vicinity of this appliance as property damage or personal injury could occur. Have your contractor point out and identify the various cut-off devices, switches, etc., that serves your comfort equipment.



### WARNING

#### HIGH VOLTAGE!

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



To locate an authorized servicer, please consult your telephone book or the dealer from whom you purchased this product. For further assistance, please contact:

#### CONSUMER INFORMATION LINE - DAIKIN BRAND PRODUCTS

TOLL FREE 1-855-770-5678 (U.S. only)

email us at: [customerservice@daikinac.com](mailto:customerservice@daikinac.com)

fax us at: (713) 856-1821

(Not a technical assistance line for dealers.)

Outside the U.S., call 1-713-861-2500

(Not a technical assistance line for dealers.)

Your telephone company will bill you for the call.

# IMPORTANT INFORMATION

## SAFE REFRIGERANT HANDLING

While these items will not cover every conceivable situation, they should serve as a useful guide.



### WARNING

Refrigerants are heavier than air. They can "push out" the oxygen in your lungs or in any enclosed space. To avoid possible difficulty in breathing or death:

- Never purge refrigerant into an enclosed room or space. By law, all refrigerants must be reclaimed.
- If an indoor leak is suspected, thoroughly ventilate the area before beginning work.
- Liquid refrigerant can be very cold. To avoid possible frostbite or blindness, avoid contact with refrigerant and wear gloves and goggles. If liquid refrigerant does contact your skin or eyes, seek medical help immediately.
- Always follow EPA regulations. Never burn refrigerant, as poisonous gas will be produced.



### WARNING

To avoid possible explosion:

- Never apply flame or steam to a refrigerant cylinder. If you must heat a cylinder for faster charging, partially immerse it in warm water.
- Never fill a cylinder more than 80% full of liquid refrigerant.
- Never add anything other than R-22 to an R-22 cylinder or R-410A to an R-410A cylinder. The service equipment used must be listed or certified for the type of refrigerant used.
- Store cylinders in a cool, dry place. Never use a cylinder as a platform or a roller.



### WARNING

To avoid possible injury, explosion or death, practice safe handling of refrigerants.



### WARNING

To avoid possible explosion, use only returnable (not disposable) service cylinders when removing refrigerant from a system.

- Ensure the cylinder is free of damage which could lead to a leak or explosion.
  - Ensure the hydrostatic test date does not exceed 5 years.
  - Ensure the pressure rating meets or exceeds 400 lbs.
- When in doubt, do not use cylinder.



### WARNING

The compressor POE oil for R-410A units is extremely susceptible to moisture absorption and could cause compressor failure. Do not leave system open to atmosphere any longer than necessary for installation.



### WARNING

System contaminants, improper service procedure and/or physical abuse affecting hermetic compressor electrical terminals may cause dangerous system venting.

The successful development of hermetically sealed refrigeration compressors has completely sealed the compressor's moving parts and electric motor inside a common housing, minimizing refrigerant leaks and the hazards sometimes associated with moving belts, pulleys or couplings.

Fundamental to the design of hermetic compressors is a method whereby electrical current is transmitted to the compressor motor through terminal conductors which pass through the compressor housing wall. These terminals are sealed in a dielectric material which insulates them from the housing and maintains the pressure tight integrity of the hermetic compressor. The terminals and their dielectric embedment are strongly constructed, but are vulnerable to careless compressor installation or maintenance procedures and equally vulnerable to internal electrical short circuits caused by excessive system contaminants.

In either of these instances, an electrical short between the terminal and the compressor housing may result in the loss of integrity between the terminal and its dielectric embedment. This loss may cause the terminals to be expelled, thereby venting the vaporous and liquid contents of the compressor housing and system.

A venting compressor terminal normally presents no danger to anyone, providing the terminal protective cover is properly in place.

If, however, the terminal protective cover is not properly in place, a venting terminal may discharge a combination of

- (a) hot lubricating oil and refrigerant
- (b) flammable mixture (if system is contaminated with air)

in a stream of spray which may be dangerous to anyone in the vicinity. Death or serious bodily injury could occur.

Under no circumstances is a hermetic compressor to be electrically energized and/or operated without having the terminal protective cover properly in place.

See Service Section S-17 for proper servicing.

# PRODUCT IDENTIFICATION

	D	T	G	060	090	3	B	*	*	*	A	*																																															
	1	2	3	4,5,6	7,8,9	10	11	12	13	14	15	16																																															
	<b>Revision Levels</b>																																																										
	Major & Minor																																																										
	<b>Factory-Installed Options</b>																																																										
<b>Brand</b>	D Daikin																																																										
<b>Configuraton</b>	C Standard Efficiency (6 - 25 Tons) S Standard Efficiency (3 - 5 Tons) T High Efficiency (3 - 5 Tons)																																																										
<b>Application</b>	C Cooling <sup>1</sup> G Gas Heat H Heat Pump <sup>1</sup>																																																										
<b>Nominal Cooling Capacity</b>	<table border="0"> <tr> <td>036</td> <td>3 Tons</td> <td>102</td> <td>8½ Tons</td> <td>300</td> <td>25 Tons</td> </tr> <tr> <td>048</td> <td>4 Tons</td> <td>120</td> <td>10 Tons</td> <td></td> <td></td> </tr> <tr> <td>060</td> <td>5 Tons</td> <td>150</td> <td>12½ tons</td> <td></td> <td></td> </tr> <tr> <td>072</td> <td>6 Tons</td> <td>180</td> <td>15 Tons</td> <td></td> <td></td> </tr> <tr> <td>090</td> <td>7½ Tons</td> <td>240</td> <td>20 Tons</td> <td></td> <td></td> </tr> </table>											036	3 Tons	102	8½ Tons	300	25 Tons	048	4 Tons	120	10 Tons			060	5 Tons	150	12½ tons			072	6 Tons	180	15 Tons			090	7½ Tons	240	20 Tons																				
036	3 Tons	102	8½ Tons	300	25 Tons																																																						
048	4 Tons	120	10 Tons																																																								
060	5 Tons	150	12½ tons																																																								
072	6 Tons	180	15 Tons																																																								
090	7½ Tons	240	20 Tons																																																								
<b>Nominal Heating Capacity</b>	<table border="0"> <tr> <td>Gas/Electric</td> <td>A/C H/P</td> <td>Factory-Installed</td> <td>Electric Heat</td> <td></td> <td></td> </tr> <tr> <td>045</td> <td>45,000 BTU/h</td> <td>XXX</td> <td>No Heat</td> <td></td> <td></td> </tr> <tr> <td>090</td> <td>90,000 BTU/h</td> <td>010</td> <td>10 kW</td> <td>030</td> <td>30 kW</td> </tr> <tr> <td>115</td> <td>115,000 BTU/h</td> <td>015</td> <td>15 kW</td> <td>031</td> <td>30 kW</td> </tr> <tr> <td>140</td> <td>140,000 BTU/h</td> <td>016</td> <td>15 kW</td> <td>045</td> <td>45 kW</td> </tr> <tr> <td>210</td> <td>210,000 BTU/h</td> <td>018</td> <td>18 kW</td> <td>046</td> <td>45 kW</td> </tr> <tr> <td>350</td> <td>350,000 BTU/h</td> <td>020</td> <td>20 kW</td> <td>060</td> <td>60 kW</td> </tr> <tr> <td>400</td> <td>400,000 BTU/h</td> <td>025</td> <td>25 kW</td> <td></td> <td></td> </tr> </table> <p>See product specifications for heat size(s) available for each capacity.</p>											Gas/Electric	A/C H/P	Factory-Installed	Electric Heat			045	45,000 BTU/h	XXX	No Heat			090	90,000 BTU/h	010	10 kW	030	30 kW	115	115,000 BTU/h	015	15 kW	031	30 kW	140	140,000 BTU/h	016	15 kW	045	45 kW	210	210,000 BTU/h	018	18 kW	046	45 kW	350	350,000 BTU/h	020	20 kW	060	60 kW	400	400,000 BTU/h	025	25 kW		
Gas/Electric	A/C H/P	Factory-Installed	Electric Heat																																																								
045	45,000 BTU/h	XXX	No Heat																																																								
090	90,000 BTU/h	010	10 kW	030	30 kW																																																						
115	115,000 BTU/h	015	15 kW	031	30 kW																																																						
140	140,000 BTU/h	016	15 kW	045	45 kW																																																						
210	210,000 BTU/h	018	18 kW	046	45 kW																																																						
350	350,000 BTU/h	020	20 kW	060	60 kW																																																						
400	400,000 BTU/h	025	25 kW																																																								
<b>Voltage</b>	<table border="0"> <tr> <td>1</td> <td>208-230/1/60</td> <td>4</td> <td>460/3/60</td> </tr> <tr> <td>3</td> <td>208-230/3/60</td> <td>7</td> <td>575/3/60</td> </tr> </table>											1	208-230/1/60	4	460/3/60	3	208-230/3/60	7	575/3/60																																								
1	208-230/1/60	4	460/3/60																																																								
3	208-230/3/60	7	575/3/60																																																								
<b>Supply Fan/Drive Type/Motor</b>	<table border="0"> <tr> <td>B</td> <td>Belt Drive (single speed)</td> <td>V</td> <td>Two-Speed Belt Drive (also designates 6-Ton with two-stage compressor)</td> </tr> <tr> <td>D</td> <td>Direct Drive (3-5 Tons)</td> <td>H</td> <td>High Static (single-speed Belt Drive models only)</td> </tr> </table>											B	Belt Drive (single speed)	V	Two-Speed Belt Drive (also designates 6-Ton with two-stage compressor)	D	Direct Drive (3-5 Tons)	H	High Static (single-speed Belt Drive models only)																																								
B	Belt Drive (single speed)	V	Two-Speed Belt Drive (also designates 6-Ton with two-stage compressor)																																																								
D	Direct Drive (3-5 Tons)	H	High Static (single-speed Belt Drive models only)																																																								
<b>Factory-Installed Options</b>	<table border="0"> <tr> <td>A</td> <td>Ultra Low-Leak Downflow Economizer</td> <td>R</td> <td>Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol;</td> </tr> <tr> <td>B</td> <td>DDC-BACnet protocol</td> <td></td> <td>Disconnect Switch (non-fused)</td> </tr> <tr> <td>F</td> <td>Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol</td> <td>V</td> <td>Low-Leak Downflow Economizer</td> </tr> <tr> <td>H</td> <td>Disconnect Switch (non-fused)</td> <td>W</td> <td>Low-Leak Downflow Economizer Disconnect Switch (non-fused)</td> </tr> <tr> <td>J</td> <td>Ultra Low-Leak Downflow Economizer; Disconnect Switch (non-fused)</td> <td>X</td> <td>No Options</td> </tr> <tr> <td>M</td> <td>Disconnect Switch (non-fused); DDC-BACnet protocol</td> <td></td> <td></td> </tr> </table>											A	Ultra Low-Leak Downflow Economizer	R	Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol;	B	DDC-BACnet protocol		Disconnect Switch (non-fused)	F	Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol	V	Low-Leak Downflow Economizer	H	Disconnect Switch (non-fused)	W	Low-Leak Downflow Economizer Disconnect Switch (non-fused)	J	Ultra Low-Leak Downflow Economizer; Disconnect Switch (non-fused)	X	No Options	M	Disconnect Switch (non-fused); DDC-BACnet protocol																										
A	Ultra Low-Leak Downflow Economizer	R	Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol;																																																								
B	DDC-BACnet protocol		Disconnect Switch (non-fused)																																																								
F	Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol	V	Low-Leak Downflow Economizer																																																								
H	Disconnect Switch (non-fused)	W	Low-Leak Downflow Economizer Disconnect Switch (non-fused)																																																								
J	Ultra Low-Leak Downflow Economizer; Disconnect Switch (non-fused)	X	No Options																																																								
M	Disconnect Switch (non-fused); DDC-BACnet protocol																																																										
<b>Note:</b>	Not all options available for all products.																																																										
<sup>1</sup> X=	No Options in character 13th																																																										
	<b>Factory-Installed Options</b>																																																										
	<table border="0"> <tr> <td>X</td> <td>Standard Aluminized Heat Exchanger</td> </tr> <tr> <td>S</td> <td>Stainless-Steel Heat Exchanger</td> </tr> <tr> <td>D</td> <td>Hinged Panels</td> </tr> <tr> <td>K</td> <td>Stainless-Steel Heat Exchanger; Hinged Panels</td> </tr> <tr> <td>B</td> <td>Phase Monitor</td> </tr> <tr> <td>J</td> <td>Stainless Steel Heat Exchanger; Phase Monitor</td> </tr> <tr> <td>M</td> <td>Hinged Panel; Phase Monitor</td> </tr> <tr> <td>L</td> <td>Stainless-Steel Heat Exchanger; Hinged Panels; Phase Monitor</td> </tr> </table>											X	Standard Aluminized Heat Exchanger	S	Stainless-Steel Heat Exchanger	D	Hinged Panels	K	Stainless-Steel Heat Exchanger; Hinged Panels	B	Phase Monitor	J	Stainless Steel Heat Exchanger; Phase Monitor	M	Hinged Panel; Phase Monitor	L	Stainless-Steel Heat Exchanger; Hinged Panels; Phase Monitor																																
X	Standard Aluminized Heat Exchanger																																																										
S	Stainless-Steel Heat Exchanger																																																										
D	Hinged Panels																																																										
K	Stainless-Steel Heat Exchanger; Hinged Panels																																																										
B	Phase Monitor																																																										
J	Stainless Steel Heat Exchanger; Phase Monitor																																																										
M	Hinged Panel; Phase Monitor																																																										
L	Stainless-Steel Heat Exchanger; Hinged Panels; Phase Monitor																																																										
	<b>Factory-Installed Options</b>																																																										
	<table border="0"> <tr> <td>X</td> <td>No Options</td> </tr> <tr> <td>A</td> <td>Non-powered convenience outlet</td> </tr> <tr> <td>B</td> <td>Powered convenience outlet</td> </tr> <tr> <td>C</td> <td>Low-ambient kit</td> </tr> <tr> <td>D</td> <td>Return air smoke detector</td> </tr> <tr> <td>E</td> <td>Supply air smoke detector</td> </tr> <tr> <td>F</td> <td>Non-powered convenience outlet; Low-ambient kit</td> </tr> <tr> <td>G</td> <td>Non-powered convenience outlet; Return air smoke detector</td> </tr> <tr> <td>H</td> <td>Non-powered convenience outlet; Supply air smoke detector</td> </tr> <tr> <td>J</td> <td>Non-powered convenience outlet; Return &amp; Supply air smoke detectors</td> </tr> <tr> <td>K</td> <td>Non-powered convenience outlet; Low-ambient kit; Supply air smoke detector</td> </tr> <tr> <td>L</td> <td>Non-powered convenience outlet; Low-ambient kit Return &amp; Supply air smoke detectors</td> </tr> <tr> <td>M</td> <td>Powered convenience outlet; Low-ambient kit</td> </tr> <tr> <td>N</td> <td>Powered convenience outlet; Return air smoke detector</td> </tr> <tr> <td>O</td> <td>Powered convenience outlet; Return &amp; Supply air smoke detectors</td> </tr> <tr> <td>P</td> <td>Powered convenience outlet; Supply air smoke detector</td> </tr> <tr> <td>Q</td> <td>Powered convenience outlet; Low-ambient kit; Return air smoke detector</td> </tr> <tr> <td>R</td> <td>Powered convenience outlet; Low-ambient kit; Supply air smoke detector</td> </tr> <tr> <td>T</td> <td>Powered convenience outlet; Low-ambient kit; Return &amp; Supply air smoke detectors</td> </tr> <tr> <td>U</td> <td>Non-powered convenience outlet; Low-ambient kit; Return air smoke detector</td> </tr> <tr> <td>V</td> <td>Low-ambient kit; Return air smoke detector</td> </tr> <tr> <td>W</td> <td>Low-ambient kit; Supply air smoke detector</td> </tr> <tr> <td>Y</td> <td>Low-ambient kit; Return &amp; Supply air smoke detectors</td> </tr> <tr> <td>Z</td> <td>Return &amp; Supply air smoke detectors</td> </tr> </table>											X	No Options	A	Non-powered convenience outlet	B	Powered convenience outlet	C	Low-ambient kit	D	Return air smoke detector	E	Supply air smoke detector	F	Non-powered convenience outlet; Low-ambient kit	G	Non-powered convenience outlet; Return air smoke detector	H	Non-powered convenience outlet; Supply air smoke detector	J	Non-powered convenience outlet; Return & Supply air smoke detectors	K	Non-powered convenience outlet; Low-ambient kit; Supply air smoke detector	L	Non-powered convenience outlet; Low-ambient kit Return & Supply air smoke detectors	M	Powered convenience outlet; Low-ambient kit	N	Powered convenience outlet; Return air smoke detector	O	Powered convenience outlet; Return & Supply air smoke detectors	P	Powered convenience outlet; Supply air smoke detector	Q	Powered convenience outlet; Low-ambient kit; Return air smoke detector	R	Powered convenience outlet; Low-ambient kit; Supply air smoke detector	T	Powered convenience outlet; Low-ambient kit; Return & Supply air smoke detectors	U	Non-powered convenience outlet; Low-ambient kit; Return air smoke detector	V	Low-ambient kit; Return air smoke detector	W	Low-ambient kit; Supply air smoke detector	Y	Low-ambient kit; Return & Supply air smoke detectors	Z	Return & Supply air smoke detectors
X	No Options																																																										
A	Non-powered convenience outlet																																																										
B	Powered convenience outlet																																																										
C	Low-ambient kit																																																										
D	Return air smoke detector																																																										
E	Supply air smoke detector																																																										
F	Non-powered convenience outlet; Low-ambient kit																																																										
G	Non-powered convenience outlet; Return air smoke detector																																																										
H	Non-powered convenience outlet; Supply air smoke detector																																																										
J	Non-powered convenience outlet; Return & Supply air smoke detectors																																																										
K	Non-powered convenience outlet; Low-ambient kit; Supply air smoke detector																																																										
L	Non-powered convenience outlet; Low-ambient kit Return & Supply air smoke detectors																																																										
M	Powered convenience outlet; Low-ambient kit																																																										
N	Powered convenience outlet; Return air smoke detector																																																										
O	Powered convenience outlet; Return & Supply air smoke detectors																																																										
P	Powered convenience outlet; Supply air smoke detector																																																										
Q	Powered convenience outlet; Low-ambient kit; Return air smoke detector																																																										
R	Powered convenience outlet; Low-ambient kit; Supply air smoke detector																																																										
T	Powered convenience outlet; Low-ambient kit; Return & Supply air smoke detectors																																																										
U	Non-powered convenience outlet; Low-ambient kit; Return air smoke detector																																																										
V	Low-ambient kit; Return air smoke detector																																																										
W	Low-ambient kit; Supply air smoke detector																																																										
Y	Low-ambient kit; Return & Supply air smoke detectors																																																										
Z	Return & Supply air smoke detectors																																																										

# PRODUCT IDENTIFICATION

## Factory-Installed Options

- **Stainless-Steel Heat Exchanger (Gas units only):** A tubular heat exchanger made of 409-type stainless steel is installed in the unit.
- **Low-Ambient Kit:** Allows for cooling operation at lower outdoor temperatures. On the 3- to 6-ton units, cooling operation is extended from 60°F ambient temperature to 35°F outside air temperature. On 7½ -20 ton units, cooling operation is extended from 35°F ambient temperature to 0°F outside air temperature. For 25 ton units, cooling operation is extended from 24°F ambient temperature to 0°F outside air temperature.
- **Economizers (Downflow):** Based on air conditions, can provide outside air to cool the space.
- **Electric Heat Kits (AC and heat pump units only):** Available in all voltage options.
- **Non-powered Convenience Outlet:** A 120V, 15A, GFCI outlet makes it easier for technicians to service the unit once an electrician runs power to the outlet.
- **Powered Convenience Outlet:** A 120V, 15A, GFCI outlet powered with a transformer built into the unit. When a factory-installed powered convenience outlet is installed in the equipment, the unit MCA (Min. Circuit Ampacity) will increase by 7.5A for 208/230V units, increase by 3.75A for 460V units, and by 3A for 575V units. The MOP (Max. Overcurrent Protection) device must be sized accordingly.
- **Disconnect Switch (non-fused; 3-phase units only):** A disconnect switch is installed in the unit and factory wiring will be complete from the switch to the unit. Please note that for air conditioning (DSC units) and heat pump models (DSH units), the appropriate electric heat kit must be ordered to be factory-installed along with the disconnect switch (non-fused) when it is ordered. Please note that for models with a powered convenience outlet option and a disconnect switch (non-fused) option, the power to the powered convenience outlet will be shut off when the disconnect switch (non-fused) is in the off position.
- **Return Air and/or Supply Air Smoke Detectors:** Return air and/or supply air smoke detectors are installed in the unit.
- **Hinged Access Panels:** Allows access to unit's major components. Combined with latches for easy access to control box, compressor, filters and blower motor. Available on all units.
- **Two-speed indoor fan blower models** are available on 6, 7½, 8½, 10, 12½, 15, 20 & 25 ton units. Section 6.4.3.10.b of ASHRAE Standard 90.1-2010 and Section 6.5.3.2.1.a of ASHRAE Standard 90.1-2013 require a minimum of two fan speeds. Section 140.4(m)1 of California Energy Commission Title 24 2013 contains a similar provision. When the units with the two-speed indoor fan blowers operate on a call for the first stage of cooling, the fan operates at low speed, which is 66% of full speed. When the units operate on a call for the second stage of cooling, the fan operates at full speed. In heating operation, the fan operates at full speed. During ventilation operation, the fan operates at low speed.
- **Phase Monitor:** Phase monitor (3 phase only), available for 3 - 25 ton DS, DC and DT series models. Phase monitor shall provide protection for motors and compressors against problems caused by phase loss, phase reversal and phase unbalance. Phase monitor is equipped with an LED that provides an ON or FAULT indicator.
- **DDC Controller:** DDC communicating controller, available for 3 - 25 ton DS, DC and DT series models with on-board BACnet® communication interface.

# PRODUCT IDENTIFICATION

# DTH\*\*\*XXX\*\*XXX

Daikin Commercial Multiposition Package Heat Pump	
Model	Description
DTH048XXX3DXXAAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase Direct Drive. Factory Installed Options (Standard Aluminized Heat Exchanger, Non-powered convenience outlet)
DTH(036,048,060)XXX1DXXXAA	Daikin Commercial Package Heat Pump, R410A, 208V 1 Phase, Direct Drive. Initial release of 3-5 ton High Efficient Units.
DTH(036,048,060)0103DHDPA	Daikin Commercial Package Heat Pump, R410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Hinged Panels, Powered Convenience Outlet, Supply Air Smoke Detector & Electric Heater Kit.)
DTH(036,048,060)XXX3DXXXAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Initial release of 3-Phase High Efficient Units.
DTH[048,060]0103DHDQAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options. (Disconnect Switch (non-fused), Hinged Panels, Powered Convenience Outlet, Low Ambient Kit Return air smoke detector, Electric Heater Kit)
DTH048XXX1DXDX	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options. (Hinged Panels (3-12 1/2))
DTH0600103DHDAAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Hinged Panels, Non-Powered Convenience Outlet, Electric Heater Kit)
DTH0360103DHXX-AA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Electric Heater Kit)
DTH048XXX3DVXYAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer, Low-ambient Kit; Return & Supply air smoke detectors)
DTH060XXX3DXYAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer, Low-ambient Kit; Return & Supply air smoke detectors)
DTH0480103DRXNAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Electric Heat; Ultra Low-Leak Downflow Economizer, DDC-BACnet Protocol; Disconnect Switch non-fused, Powered Convenience Outlet; Return Air Smoke Detector)
DTH048XXX3DFDXAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, DDC-BACnet Protocol; Hinged Panels)
DTH036XXX3DFDXAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, DDC-BACnet Protocol; Hinged Panels)
DTH060XXX3DFDXAA	Daikin Commercial Package Heat Pump, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, DDC-BACnet Protocol; Hinged Panels)
DTH0360103DHXJAA	Daikin Commercial Package Heat Pump, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; non-powered Convenience Outlet; Return and Supply Air Smoke Detectors)
DTH036XXX3DXXAAA DTH060XXX3DXXAAA	Daikin Commercial Package Heat Pump, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Standard Aluminized Heat Exchanger; non-powered Convenience Outlet)
DTH060XXX1DXXAAA DTH048XXX1DXXAAA DTH036XXX1DXXAAA	Daikin Commercial Package Heat Pump, R410A, 230V 1 Phase, Direct Drive. Factory Installed Options (Standard Aluminized Heat Exchanger; non-powered Convenience Outlet)
DTH048XXX1DXDAAA DTH060XXX1DXDAAA	Daikin Commercial Package Heat Pump, R410A, 230V 1 Phase, Direct Drive. Factory Installed Options (Hinged Panels; Non-powered Convenience Outlet)

*These units have R410A refrigerant*

# PRODUCT IDENTIFICATION

**DTC\*\*\*XXX\*\*XXX**

Daikin Commercial Multiposition Package Coolers	
Model	Description
DTC(036,048,060)XXX1DXXXAA	Daikin Commercial Package Cooling, R410A, 208-230V Single Phase, Direct Drive. Initial release of 3-5 ton High Efficient Units. B35
DTC(036,048,060)XXX3DXXXAA	Daikin Commercial Package Cooling, R410A, 208-230V 3 Phase, Direct Drive. Initial release of 3-Phase High Efficient Units.
DTC036XXX1DVXXAA	Daikin Commercial Package Cooling, R410A, 208-230V Single Phase, Direct Drive. Factor Installed Options (Low-Leak Downflow Economizer)
DTC[048,060]XXX1DXDXAA	Daikin Commercial Package Cooling, R410A, 208-230V Single Phase, Direct Drive. Factor Installed Options (Hinged Panels (3-12 1/2))
DTC048XXX1DXXAAA	Daikin Commercial Package Cooling, R410A, 208-230V Single Phase, Direct Drive. Factor Installed Options (Non-powered convenience outlet)
DTC060XXX3DXDCAA	Daikin Commercial Package Cooling, R410A, 208-230V 3 Phase, Direct Drive. Factor Installed Options (Non-powered convenience outlet)
DTC0600151DVDBAA	Daikin Commercial Package Cooling, R410A, 208-230V Single Phase, Direct Drive. Factor Installed Options (Low-Leak Downflow Economizer; Hinged Panels; Powered convenience outlet)
DTC036XXX3DXDXAA DTC048XXX3DXDXAA DTC060XXX3DXDXAA	Daikin Commercial Package Cooling, R410A, 230V 3 Phase, Direct Drive. Factor Installed Options (Hinged Panels)

*These units have R410A refrigerant*

# PRODUCT IDENTIFICATION

# DTG\*\*\*XXX\*\*XXX

Daikin Commercial Multiposition Package Gas Units	
Model	Description
"DTG0360451DXXXAA DTG(036,048,060)0901DXXXAA DTG0481151DXXXAA DTG0601401DXXXAA"	Daikin Commercial Package Gas, R410A, 208V 1 Phase, Direct Drive. Initial release of 3-5 ton High Efficient Units.
"DTG0360451DXSXAA DTG(036,048,060)0901DXSXAA DTG0481151DXSXAA DTG0601401DXSXAA"	Daikin Commercial Package Gas, R410A, 208V 1 Phase, Direct Drive. Factory Installed Options (Stainless Steel Heat Exchanger)
DTG (036,060)0903DHXX-AA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options(Disconnect Switch (non-fused))
"DTG0360453DXXXAA DTG(036,048,060)0903DXXXAA DTG0481153DXXXAA DTG0601403DXXXAA"	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Initial release of 3-Phase High Efficient Units.
DTG0600901DAXFAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Ultra Low Leak Downflow Economizer, Non-Powered Convenience Outlet, Low Ambient Kit)
DTG0360901DAXXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Ultra Low Leak Downflow Economizer)
DTG0360901DXSDAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Stainless Steel Heat Exchanger, Return Air Smoke Detector)
DTG(036,060)0901DHXXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Disconnect Switch(non-fused))
DTG0360903DXXBAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options(Powered Convenience Outlet)
DTG0480903DWXAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options(Low-Leak Downflow Economizer, Disconnect Switch (non-fused), Non Powered Convenience Outlet.)
DTG0601401DHXCAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Disconnect Switch(non-fused), Low Ambient Kit)
DTG0601403DHXXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options(Disconnect Switch (non-fused))
DTG0601403DWXGAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options(Low-Leak Downflow Economizer, Disconnect Switch (non-fused), Non Powered Convenience Outlet, Return & Supply Air Smoke Detector)
DTG0480901DXXAAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Standard aluminized Heat Exchanger, Non-powered convenience outlet)
DTG0360901DXDXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Hinged Door)
DTG0360453DHKCAA DTG0600903DHKCAA	Daikin Commercial Package Gas, R-410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Non-Powered Convenience Outlet)
DTG0480903DJXAAA	Daikin Commercial Package Gas, R-410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, Disconnect Switch (non-fused), Standard Aluminized Heat Exchanger, Non-Powered Convenience Outlet)
DTG0601403DJXGAA	Daikin Commercial Package Gas, R-410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, Disconnect Switch (non-fused), Standard Aluminized Heat Exchanger, Non-Powered Convenience Outlet; Return air smoke detector)
DTG0480901DVSXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options(Low-Leak Downflow Economizer, Stainless Steel Heat Exchanger)
DTG0600903DAKXAA	Daikin Commercial Package Gas, R-410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer,Stainless Steel Gas Heat Exchanger; Hinged Panels (3-12 1/2 Tons))
DTG[036,060] [045,090] 1DXXAAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Standard aluminized Heat Exchanger, Non-powered convenience outlet)
DTG0600901DVXFAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low Leak Downflow Economizer, Non-Powered Convenience Outlet, Low Ambient Kit)
DTG0601403DFXXAA	Daikin Commercial Package Gas, R-410A, 208-230V, 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer; DDC-BACnet protocol)
DTG0481153DAKAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer, SS Heat Exchanger, Hinged Panels, Non-powered Convenience Outlet)
DTG0360903DHDAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Hinged Panels, Non-powered Convenience Outlet)
DTG0480903DHDAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Hinged Panels, Non-powered Convenience Outlet)
DTG0600903DHDAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Hinged Panels, Non-powered Convenience Outlet)
DTG0360453DJSBAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Stainless Steel Heat Exchanger, Powered Convenience Outlet)
DTG0600903DRSBAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused), Stainless Steel Heat Exchanger, Powered Convenience Outlet, DDC BACnet Protocol)
DTG0600901DVDXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer, Hinged Panels)
DTG0480903DJXCAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Econo- mizer; Disconnect Switch (non-fused), Low-ambient kit)
DTG0360901DXSCAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Stainless-Steel Heat Exchanger; Low-ambient Kit)
DTG0480903DVXHAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Non-powered convenience outlet; Supply air smoke detector)

*These units have R410A refrigerant*



# PRODUCT IDENTIFICATION

DTG\*\*\*XXX\*\*XXX

Daikin Commercial Multiposition Package Gas Units	
Model	Description
DTG0600903DVXHAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Non-powered convenience outlet; Supply air smoke detector)
DTG0601401DVXUAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Non-powered convenience outlet; Low-ambient Kit; Return air smoke detector)
DTG0481153DADXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer; Hinged Panels)
DTG0360901DXKXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Stainless-Steel Heat Exchanger; Hinged Panels)
DTG0601401DVXXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer)
DTG0601403DHXAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Non-powered convenience outlet)
DTG0601403DHXAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Stainless-Steel Heat Exchanger)
DTG0360901DVDXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Hinged Panels)
DTG0360903DXKXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Stainless-Steel Heat Exchanger; Hinged Panels)
DTG0601401DVSXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Stainless-Steel Heat Exchanger)
DTG0600903DXXEAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Stainless-Steel Heat Exchanger)
DTG0360903DXSXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Stainless-Steel Heat Exchanger)
DTG0601403DXSXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Stainless-Steel Heat Exchanger)
DTG0360903DWXXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low Leak Downflow Economizer; Disconnect Switch (non-fused))
DTG0360903DWXAAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low Leak Downflow Economizer; Disconnect Switch (non-fused))
DTG0601403DAXXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low Leak Downflow Economizer)
DTG0360903DAXXAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low Leak Downflow Economizer)
DTG0480903DVXMAA	Daikin Commercial Package Gas, R410A, 208-230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Standard Aluminized Heat Exchanger; Powered Convenience Outlet; Low-ambient Kit)
DTG0481151DXDXAA	Daikin Commercial Package Gas, R410A, 208-230V 1 Phase, Direct Drive. Factory Installed Options (Hinged Panels)
DTG0601403DHXBAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; Powered Convenience outlet)
DTG0600903DWXXAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Low-Leak Downflow Economizer; Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger)
DTG0360453DHXAAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; Non-Powered Convenience outlet)
DTG0600903DJXAAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Ultra Low-Leak Downflow Economizer; Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; Non-Powered Convenience outlet)
DTG0360903DHXFAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; Non-Powered Convenience Outlet; Low-Ambient Kit)
DTG0360453DHXBAA	Daikin Commercial Package Gas, R410A, 230V 3 Phase, Direct Drive. Factory Installed Options (Disconnect Switch (non-fused); Standard Aluminized Heat Exchanger; Powered Convenience Outlet)

*These units have R410A refrigerant*

# PRODUCT DESIGN

## UNIT LOCATION



TO PREVENT POSSIBLE EQUIPMENT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, THE FOLLOWING BULLET POINTS MUST BE OBSERVED WHEN INSTALLING THE UNIT.

**IMPORTANT NOTE:** Remove wood shipping rails prior to installation of the unit.

### ALL INSTALLATIONS:

**NOTE:** Appliance is shipped from factory for vertical duct application.

Proper installation of the unit ensures trouble-free operation. Improper installation can result in problems ranging from noisy operation to property or equipment damages, dangerous conditions that could result in injury or personal property damage and that are not covered by the warranty. Give this booklet to the user and explain its provisions. The user should retain these instructions for future reference.

- For proper flame pattern within the heat exchanger and proper condensate drainage, the unit must be mounted level.
- The flue outlet must be at least 12 inches from any opening through which flue gases could enter a building, and at least three feet above any forced air inlet located within ten feet. The economizer/manual fresh air intake/motorized fresh air intake and combustion air inlet mounted on the unit are not affected by this restriction.
- To avoid possible corrosion of the heat exchanger, do not locate the unit in an area where the outdoor air (i.e. combustion air for the unit) will be frequently contaminated by compounds containing chlorine or fluorine. Common sources of such compounds include swimming pool chemicals and chlorine bleaches, paint stripper, adhesives, paints, varnishes, sealers, waxes (which are not yet dried) and solvents used during construction and remodeling. Various commercial and industrial processes may also be sources of chlorine/fluorine compounds.
- To avoid possible illness or death of the building occupants, do NOT locate outside air intake device (economizer, manual fresh air intake, motorized fresh air intake) too close to an exhaust outlet, gas vent termination, or plumbing vent outlet. For specific distances required, consult local codes.
- Allow minimum clearances from the enclosure for fire protection, proper operation, and service access (see unit clearances). These clearances must be permanently maintained.
- The combustion air inlet and flue outlet on the unit must never be obstructed. If used, do not allow the economizer/manual fresh air damper/ motorized fresh air damper to become blocked by snow or debris. In some climates or locations, it may be necessary to elevate the unit to avoid these problems.

- When the unit is heating, the temperature of the return air entering the unit must be a minimum of 55° F.

### GROUND LEVEL INSTALLATIONS ONLY:

- When the unit is installed on the ground adjacent to the building, a level concrete (or equal) base is recommended. Prepare a base that is 3" larger than the package unit footprint and a minimum of 3" thick.
- The base should also be located where no runoff of water from higher ground can collect in the unit.

### ROOF TOP INSTALLATIONS ONLY:

- To avoid possible property damage or personal injury, the roof must have sufficient structural strength to carry the weight of the unit(s) and snow or water loads as required by local codes. Consult a structural engineer to determine the weight capabilities of the roof.
- The unit may be installed directly on wood floors or on Class A, Class B, or Class C roof covering material.
- To avoid possible personal injury, a safe, flat surface for service personnel should be provided.
- As indicated on the unit data plate, a minimum clearance of 36" to any combustible material is required on the furnace access side of the unit. All combustible materials must be kept out of this area.
- This 36" clearance must also be maintained to insure proper combustion air and flue gas flow. The combustion air intake and furnace flue discharge must not be blocked for any reason, including blockage by snow.
- Adequate clearances from the furnace flue discharge to any adjacent public walkways, adjacent buildings, building openings or openable windows must be maintained in accordance with the latest edition of the National Fuel Gas Code (ANSI Z223.1)
- Minimum horizontal clearance of 48" from the furnace flue discharge to any electric meters, gas meters, regulators and relief equipment is required.

### UNIT PRECAUTIONS

- Do not stand or walk on the unit.
- Do not drill holes anywhere in panels or in the base frame of the unit except where indicated. Unit access panels provide structural support.
- Do not remove any access panels until unit has been installed on roof curb or field supplied structure.
- Do not roll unit across finished roof without prior approval of owner or architect.
- Do not skid or slide on any surface as this may damage unit base. The unit must be stored on a flat, level surface. Protect the condenser coil because it is easily damaged.

# PRODUCT DESIGN

## ROOF CURB INSTALLATIONS ONLY:

Curb installations must comply with local codes and should be done in accordance with the established guidelines of the National Roofing Contractors Association.

Proper unit installation requires that the roof curb be firmly and permanently attached to the roof structure. Check for adequate fastening method prior to setting the unit on the curb.

Full perimeter roof curbs are available from the factory and are shipped unassembled. Field assembly, squaring, leveling and mounting on the roof structure are the responsibility of the installing contractor. All required hardware necessary for the assembly of the sheet metal curb is included in the curb accessory.

### WARNING

**TO PREVENT POSSIBLE EQUIPMENT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, THE FOLLOWING BULLET POINTS MUST BE OBSERVED WHEN INSTALLING THE UNIT.**

- Sufficient structural support must be determined prior to locating and mounting the curb and package unit.
- Ductwork must be constructed using industry guidelines. The duct work must be placed into the roof curb before mounting the package unit. Our full perimeter curbs include duct connection frames to be assembled with the curb. Cantilevered type curbs are not available from the factory.
- Curb insulation, cant strips, flashing and general roofing material are furnished by the contractor.

The curbs must be supported on parallel sides by roof members. The roof members must not penetrate supply and return duct opening areas as damage to the unit might occur.


**NOTE:** The unit and curb accessories are designed to allow vertical duct installation before unit placement. Duct installation after unit placement is not recommended.

### CAUTION

**ALL CURBS LOOK SIMILAR. TO AVOID INCORRECT CURB POSITIONING, CHECK JOB PLANS CAREFULLY AND VERIFY MARKINGS ON CURB ASSEMBLY. INSTRUCTIONS MAY VARY IN CURB STYLES AND SUPERSEDES INFORMATION SHOWN.**

See the manual shipped with the roof curb for assembly and installation instructions.

## CLEARANCES



### Unit Clearances

*\*In situations that have multiple units, a 48" minimum clearance is required between the condenser coils.*

Maintain an adequate clearance around the unit for safety, service, maintenance, and proper unit operation. Leave a clearance of 48" on all sides of the unit for possible compressor removal or service access, and to ensure proper ventilation and condenser airflow. Do not install the unit beneath any obstruction. Install the unit away from all building exhausts to inhibit ingestion of exhaust air into the unit's fresh-air intake.

**NOTE:** If the 48" minimum is used on the control panel side of a DTG unit, a flue extension (MF# 220-GX-01) needs to be installed to prevent flue gas recirculation.

### PROTRUSION

Inspect curb to ensure that none of the utility services (electric) routed through the curb protrude above the curb.

## ELECTRICAL WIRING

### WARNING

**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



# PRODUCT DESIGN

## WARNING

### HIGH VOLTAGE!

TO AVOID PERSONAL INJURY OR DEATH DUE TO ELECTRICAL SHOCK, DO NOT TAMPER WITH FACTORY WIRING. THE INTERNAL POWER AND CONTROL WIRING OF THESE UNITS ARE FACTORY-INSTALLED AND HAVE BEEN THOROUGHLY TESTED PRIOR TO SHIPMENT. CONTACT YOUR LOCAL REPRESENTATIVE IF ASSISTANCE IS REQUIRED.



## CAUTION

TO PREVENT DAMAGE TO THE WIRING, PROTECT WIRING FROM SHARP EDGES. FOLLOW NATIONAL ELECTRICAL CODE AND ALL LOCAL CODES AND ORDINANCES. DO NOT ROUTE WIRES THROUGH REMOVABLE ACCESS PANELS.

## CAUTION

CONDUIT AND FITTINGS MUST BE WEATHER-TIGHT TO PREVENT WATER ENTRY INTO THE BUILDING.

For unit protection, use a fuse or HACR circuit breaker that is in excess of the circuit ampacity, but less than or equal to the maximum overcurrent protection device. DO NOT EXCEED THE MAXIMUM OVERCURRENT DEVICE SIZE SHOWN ON UNIT DATA PLATE.

All line voltage connections must be made through weatherproof fittings. All exterior power supply and ground wiring must be in approved weatherproof conduit.

The main power supply wiring to the unit and low voltage wiring to accessory controls must be done in accordance with these instructions, the latest edition of the National Electrical Code (ANSI/NFPA 70), and all local codes and ordinances. All field wiring shall conform with the temperature limitations for Type T wire (63°F/35°C rise).

The unit is factory wired for the voltage shown on the unit's data plate. Refer to model nomenclature in Appendix B for voltage requirement for your unit.

**NOTE:** If supply voltage is 208V, lead on primary of transformer must be moved from the 230V to the 208V tap. Refer to wiring diagram on unit for details.

Main power wiring should be sized for the minimum wire ampacity shown on the unit's database. Size wires in accordance with the ampacity tables in Article 310 of the National Electrical Code. If long wires are required, it may be necessary to increase the wire size to prevent excessive voltage drop. Wires should be sized for a maximum of 3% voltage drop.

## CAUTION

TO AVOID PROPERTY DAMAGE OR PERSONAL INJURY DUE TO FIRE, USE ONLY COPPER CONDUCTORS.


## CAUTION

TO PREVENT IMPROPER AND DANGEROUS OPERATION DUE TO WIRING ERRORS, LABEL ALL WIRES PRIOR TO DISCONNECTION WHEN SERVICING CONTROLS. VERIFY PROPER OPERATION AFTER SERVICING.

**NOTE:** A weather-tight disconnect switch, properly sized for the unit total load, must be field or factory installed. An external field supplied disconnect may be mounted on the exterior panel.

Ensure the data plate is not covered by the field-supplied disconnect switch.

- Some disconnect switches are not fused. Protect the power leads at the point of distribution in accordance with the unit data plate.
- The unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the latest edition of the National Electrical Code (ANSI/NFPA 70). A ground lug is provided for this purpose. Size grounding conductor in accordance with Table 250-95 of the National Electrical Code. Do not use the ground lug for connecting a neutral conductor.
- Connect power wiring to the compressor contactor closest to the entrance located within the main control box or to electrical power block, if equipped.



## Power and Low Voltage Block Connections

## WARNING

FAILURE OF UNIT DUE TO OPERATION ON IMPROPER LINE VOLTAGE OR WITH EXCESSIVE PHASE UNBALANCE CONSTITUTES PRODUCT ABUSE AND MAY CAUSE SEVERE DAMAGE TO THE UNIT ELECTRICAL COMPONENTS.

# PRODUCT DESIGN

## AREAS WITHOUT CONVENIENCE OUTLET



It is recommended that an independent 115V power source be brought to the vicinity of the roof top unit for portable lights and tools used by the service mechanic.

**NOTE:** Refer to local codes for requirements. These outlets can also be factory installed.

## UNITS INSTALLED ON ROOF TOPS

Main power and low voltage wiring may enter the unit through the condenser end of unit or through the roof curb. Install conduit connectors at the desired entrance locations. External connectors must be weatherproof. All holes in the unit base must be sealed (including those around conduit nuts) to prevent water leakage into building. All required conduit and fittings are to be field supplied.

Supply voltage to roof top unit must not vary by more than 10% of the value indicated on the unit data plate. Phase voltage unbalance must not exceed 2%. Contact your local power company for correction of improper voltage or phase unbalance.



## Electrical Entrance and Thru Curb

Unit is equipped with a Low Voltage Terminal Block and has Single Point wiring to the contactor or power block, if equipped.

## LOW VOLTAGE CONTROL WIRING

1. A 24V thermostat must be installed for unit operation. It may be purchased with the unit or field-supplied. Thermostats may be programmable or electromechanical as required.
2. Locate thermostat or remote sensor in the conditioned space where it will sense average temperature. Do not locate the device where it may be directly exposed to supply air, sunlight or other sources of heat. Follow installation instructions packaged with the thermostat.
3. Use #18 AWG wire for 24V control wiring runs not exceeding 75 feet. Use #16 AWG wire for 24V control wiring runs not exceeding 125 feet. Use #14 AWG wire for 24V control wiring runs not exceeding 200 feet. Low voltage wiring may be National Electrical Code (NEC) Class 2 where permitted by local codes.
4. Route thermostat wires from sub-base terminals to the unit. Control wiring should enter through the condenser panel opening or through curb indicated in "Electrical Entrance" figure. Connect thermostat and any accessory wiring to low voltage terminal block TB1 in the main control box.

**NOTE:** Field-supplied conduit may need to be installed depending on unit/curb configuration. Use #18 AWG solid conductor wire whenever connecting thermostat wires to terminals on sub-base. DO NOT use larger than #18 AWG wire. A transition to #18 AWG wire may be required before entering thermostat sub-base.

**NOTE:** Refer to unit wiring diagrams for thermostat hookups.

# SYSTEM OPERATION

## FOR YOUR SAFETY READ BEFORE OPERATING



### WARNING



If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burners. Do not try to light the burners by hand.

B. BEFORE OPERATING smell around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any telephone in your building.
- Immediately call your supplier from a neighbor's phone. Follow the gas suppliers instructions.

• If you cannot reach your gas supplier, call the fire department.

C. Use only your hand to move the gas control switch or knob. Never use tools. If the gas control switch or knob will not operate, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.


D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

**WARNING:** Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the user's information manual provided with this furnace. For assistance or additional information consult a qualified installer, service agency or the gas supplier.


This furnace must be installed in accordance with the manufacturers instructions and local codes. In the absence of local codes, follow the National Fuel Gas Code, ANSI Z223.1.

## OPERATING INSTRUCTIONS

1. STOP! Read the safety information above on this label.
2. Set the thermostat to lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an automatic ignition system which automatically lights the burners. Do not try to light the burners by hand.
5. Remove control access panel.
6. Move the gas control switch or knob to "OFF".



7. Wait five (5) minutes to clear out any gas. If you then smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
8. Move the gas control switch or knob to "ON".
9. Replace control access panel.
10. Turn on all electric power to the appliance.
11. Set the thermostat to the desired setting.
12. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.



For outdoor installation only.

**WARNING:** If not installed, operated and maintained in accordance with the manufacturer's instructions, this product could expose you to substances in fuel combustion which can cause death or serious illness and which are known to the State of California to cause cancer, birth defects or other reproductive harm. This product contains fiberglass insulation. Fiberglass insulation contains a chemical known by the State of California to cause cancer.

## TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to its lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Remove control access panel.
4. Move the gas control switch or knob to "OFF". Do not force.
5. Replace control access panel.


**FOR YOUR SAFETY Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

B14933-239


# SYSTEM OPERATION

DTC/DTG\*\*\*XXX\*\*XXX


## Typical Package Cooling or Package Gas



Either a thermostatic expansion valve or restrictor orifice assembly may be used depending on model. Refer to the parts catalog for the model being serviced.



### Restrictor Orifice Assembly in Cooling Operation





In the cooling mode the orifice is pushed into its seat forcing refrigerant to flow through the metered hole in the center of the orifice.

# SYSTEM OPERATION

DTH\*\*\*XXX\*\*XXX

*Typical Heat Pump System in Cooling*





# SYSTEM OPERATION


DTG\*\*\*XXX\*\*XXX

## Direct Spark Ignition (DSI) Systems


DTG units are equipped with a direct spark ignition system. Ignition is provided by 22,000 volt electronic spark. A flame sensor then monitors for the presence of flame and closes the gas valve if flame is lost.

The system may be controlled by most good heating and cooling thermostats with an adjustable heat anticipator.


**NOTE:** Some night setback thermostats that do not have a common terminal use a power robbing circuit in the off cycle to maintain the batteries. This type of thermostat may interfere with the operation of the ignition control module and should not be used.



**WARNING**



**HIGH VOLTAGE!**  
 Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



# SYSTEM OPERATION

## GAS SUPPLY PIPING



### WARNING

TO PREVENT PERSONAL INJURY OR DEATH DUE TO IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE, REFER TO THIS MANUAL. FOR ADDITIONAL ASSISTANCE OR INFORMATION, CONSULT A QUALIFIED INSTALLER, SERVICE AGENCY OR THE GAS SUPPLIER.

**IMPORTANT NOTE:** This unit is factory set to operate on natural gas at the altitudes shown on the rating plate.



### WARNING

TO AVOID PROPERTY DAMAGE, PERSONAL INJURY OR DEATH WHEN EITHER USING PROPANE GAS ALONE OR AT HIGHER ALTITUDES, OBTAIN AND INSTALL THE PROPER CONVERSION KIT(S). FAILURE TO DO SO CAN RESULT IN UNSATISFACTORY OPERATION AND/OR EQUIPMENT DAMAGE. HIGH ALTITUDE KITS ARE FOR U.S. INSTALLATIONS ONLY AND ARE NOT APPROVED FOR USE IN CANADA.

The rating plate is stamped with the model number, type of gas and gas input rating. Make sure the unit is equipped to operate on the type of gas available. Conversion to propane (LP) gas is permitted with the use of the factory authorized conversion kit (see the unit Technical Manual for the appropriate kit). For High Altitude derates, refer to the latest edition of the National Fuel Gas Code NFPA 54/ANSI Z223.1.

INLET GAS PRESSURE	
NATURAL	Min. 5.0" W.C., Max. 10.0" W.C.
PROPANE	Min. 11.0" W.C., Max. 14.0" W.C.

Inlet Gas Pressure Must Not Exceed the Maximum Value Shown in Table Above.

The minimum supply pressure should not vary from that shown in the table above because this could prevent the unit from having dependable ignition. In addition, gas input to the burners must not exceed the rated input shown on the rating plate. Overfiring of the unit could result in premature heat exchanger failure.

### PIPING

**IMPORTANT NOTE:** To avoid possible unsatisfactory operation or equipment damage due to under firing of equipment, do not undersize the natural/propane gas piping from the meter/tank to the unit. When sizing a trunk line, include all appliances on that line that could be operated simultaneously.

The rating plate is stamped with the model number, type of gas and gas input rating. Make sure the unit is equipped to operate on the type of gas available. The gas line installation must comply with local codes, or in the absence of local codes, with the latest edition of the National Fuel Gas Code NFPA 54/ANSI Z223.1.

## Natural Gas Connection

Length of Pipe in Feet	Nominal Black Pipe Size (inches)				
	1/2	3/4	1	1 1/4	1 1/2
10	132	278	520	1050	1600
20	92	190	350	730	1100
30	73	152	285	590	980
40	63	130	245	500	760
50	56	115	215	440	670
60	50	105	195	400	610
70	46	96	180	370	560
80	43	90	170	350	530
90	40	84	160	320	490
100	38	79	150	305	460

Pressure= .50 PSIG or less and Pressure Drop of 0.3" W.C.


(Based on 0.60 Specific Gravity Gas)

$$CFH = \frac{BTUH \text{ Furnace Input}}{\text{Heating Value of Gas (BTU/Cubic Foot)}}$$

Refer to the Proper Piping Practice drawing for the general layout at the unit. The following rules apply:

1. Use black iron pipe and fittings for the supply piping. The use of a flex connector and/or copper piping is permitted as long as it is in agreement with local codes.
2. Use pipe joint compound on male threads only. Pipe joint compound must be resistant to the action of the fuel used.
3. Use ground joint unions.
4. Install a drip leg to trap dirt and moisture before it can enter the gas valve. The drip leg must be a minimum of three inches long.
5. Use two pipe wrenches when making connection to the gas valve to keep it from turning.
6. Install a manual shut-off valve in a convenient location (within six feet of unit) between the meter and the unit.
7. Tighten all joints securely.
8. The unit must be connected to the building piping by one of the following methods:
  - Rigid metallic pipe and fittings
  - Semirigid metallic tubing and metallic fittings (Aluminum alloy tubing must not be used in exterior locations)
  - Listed gas appliance connectors used in accordance with the terms of their listing that are completely in the same room as the equipment
  - In the prior two methods above the connector or tubing must be protected from physical and thermal damage. Aluminum alloy tubing and connectors must be coated to protect against external corrosion when in contact with masonry, plaster or insulation or are subject to repeated wettings by liquids (water - not rain water, detergents or sewage).

# SYSTEM OPERATION



## Proper Piping Practice

**NOTE:** The unit gas supply entrance is factory sealed with plugs. Keep plugs in place until gas supply is ready to be installed. Once ready, replace the plugs with the supplied grommets and install gas supply line.

## GAS PIPING CHECKS

### CAUTION

**TO PREVENT PROPERTY DAMAGE OR PERSONAL INJURY DUE TO FIRE, THE FOLLOWING INSTRUCTIONS MUST BE PERFORMED REGARDING GAS CONNECTIONS AND PRESSURE TESTING:**

- THE UNIT AND ITS GAS CONNECTIONS MUST BE LEAK TESTED BEFORE PLACING IN OPERATION. **BECAUSE OF THE DANGER OF EXPLOSION OR FIRE, NEVER USE A MATCH OR OPEN FLAME TO TEST FOR LEAKS. NEVER EXCEED SPECIFIED PRESSURES FOR TESTING. HIGHER PRESSURE MAY DAMAGE GAS VALVE AND CAUSE OVERFIRING WHICH MAY RESULT IN PREMATURE HEAT EXCHANGE FAILURE.**
- THIS UNIT AND ITS SHUT-OFF VALVE MUST BE DISCONNECTED FROM THE GAS SUPPLY DURING ANY PRESSURE TESTING OF THAT SYSTEM AT TEST PRESSURES IN EXCESS OF 1/2 PSIG (3.48 kPa).
- THIS UNIT MUST BE ISOLATED FROM THE GAS SUPPLY SYSTEM BY CLOSING ITS MANUAL SHUT-OFF VALVE DURING ANY PRESSURE TESTING OF THE GAS SUPPLY PIPING SYSTEM AT TEST PRESSURES EQUAL TO OR LESS THAN 1/2 PSIG (3.48 kPa).

### WARNING

**TO AVOID PROPERTY DAMAGE OR PERSONAL INJURY, BE SURE THERE IS NO OPEN FLAME IN THE VICINITY DURING AIR BLEEDING.**

There will be air in the gas supply line after testing for leaks on a new installation. Therefore, the air must be bled from the line by loosening the ground joint union until pure gas is expelled. Tighten union and wait for five minutes until all gas has been dissipated in the air. Be certain there is no open flame in the vicinity during air bleeding procedure. The unit is placed in operation by closing the main electrical disconnect switch for the unit.

## PROPANE GAS INSTALLATIONS

### WARNING

**TO AVOID PROPERTY DAMAGE, PERSONAL INJURY OR DEATH DUE TO FIRE OR EXPLOSION CAUSED BY A PROPANE GAS LEAK, INSTALL A GAS DETECTING WARNING DEVICE. SINCE RUST CAN REDUCE THE LEVEL OF ODORANT IN PROPANE GAS, A GAS DETECTING WARNING DEVICE IS THE ONLY RELIABLE WAY TO DETECT A PROPANE GAS LEAK. CONTACT A LOCAL PROPANE GAS SUPPLIER ABOUT INSTALLING A GAS DETECTING WARNING DEVICE.**

**IMPORTANT NOTE:** Propane gas conversion kits must be installed to convert units to propane gas. NOx screens must be removed before converting to LP. Remove burner assembly and pull NOx screens from each burner tube. When all the screens are out, reassemble the burner assembly without the screens.


All propane gas equipment must conform to the safety standards of the National Board of Fire Underwriters (See NBFU Manual 58).

For satisfactory operation, propane gas supply pressure must be within 9.7 - 10.3 inches W.C. at the manifold with all gas appliances in operation. Maintaining proper gas pressure depends on three main factors:

1. Vaporization rate, which depends on (a) temperature of the liquid, and (b) wetted surface area of the container or containers.
2. Proper pressure regulation.
3. Pressure drop in lines between regulators, and between second stage regulator and the appliance. Pipe size required will depend on length of pipe run and total load of all appliances.

# SYSTEM OPERATION

## TYPICAL PROPANE PIPING



### WARNING

Although the unit itself cannot be installed in an excavated or confined space, the gas piping may be routed through such areas and we strongly recommend that you contact your propane supplier about installing a gas detecting warning device that would alert you to a gas leak.

- Propane gas is heavier than air and any leaking gas can settle in any low areas or confined spaces.
- Propane gas odorant may fade, making the gas undetectable except with a warning device.

An undetected gas leak will create a danger of explosion or fire. If you suspect the presence of gas, follow the instructions on page 9. Failure to do so could result in serious personal injury or death.

### PROPANE TANK SIZING (MINIMUM)

MAXIMUM GAS NEEDED TO VAPORIZE*	TANK SIZE REQUIRED IF LOWEST OUTDOOR TEMPERATURE (AVG. FOR 24 HOURS) REACHES						
	32°F	20°F	10°F	0°F	-10°F	-20°F	-30°F
125K BTU/HR (50 CFH)	115 GAL	115 GAL	115 GAL	250 GAL	250 GAL	400 GAL	600 GAL
250K BTU/HR (100 CFH)	250 GAL	250 GAL	250 GAL	400 GAL	500 GAL	1000 GAL	1500 GAL
375K BTU/HR (150 CFH)	300 GAL	400 GAL	500 GAL	500 GAL	1000 GAL	1500 GAL	2500 GAL
500K BTU/HR (200 CFH)	400 GAL	500 GAL	750 GAL	1000 GAL	1500 GAL	2000 GAL	3500 GAL
750K BTU/HR (300 CFH)	750 GAL	1000 GAL	1500 GAL	2000 GAL	2500 GAL	4000 GAL	5000 GAL

\* AVERAGE RATE/HOUR WITHDRAWAL IN 8 HOUR PERIOD

## PROPANE GAS PIPING CHARTS

Sizing Between First and Second Stage Regulator  
Maximum Propane Capacities listed are based on 1 PSIG Pressure Drop at 10 PSIG Setting. Capacities in 1,000 BTU/HR

PIPE OR TUBING LENGTH, FEET	TUBING SIZE, O.D., TYPE L					NOMINAL PIPE SIZE, SCHEDULE 40	
	3/8"	1/2"	5/8"	3/4"	7/8"	1/2"	3/4"
30	309	700	1,303	2,205	3,394	1,843	3,854
40	265	599	1,115	1,887	2,904	1,577	3,298
50	235	531	988	1,672	2,574	1,398	2,923
60	213	481	896	1,515	2,332	1,267	2,649
70	196	446	824	1,394	2,146	1,165	2,437
80	182	412	767	1,297	1,996	1,084	2,267
90	171	386	719	1,217	1,873	1,017	2,127
100	161	365	679	1,149	1,769	961	2,009
150	130	293	546	923	1,421	772	1,613
200	111	251	467	790	1,216	660	1,381
250	90	222	414	700	1,078	585	1,224
300	89	201	378	634	976	530	1,109
350	82	185	345	584	898	488	1,020
400	76	172	321	543	836	454	949

To convert to Capacities at 15 PSIG Settings -- Multiply by 1.130

To convert to Capacities at 5 PSIG Settings -- Multiply by 0.879

Sizing Between Single or Second Stage Regulator and Appliance\*  
Maximum Propane Capacities Listed are Based on 1/2" W.C. Pressure Drop at 11" W.C. Setting. Capacities in 1,000 BTU/HR

PIPE OR TUBING LENGTH, FEET	TUBING SIZE, O.D., TYPE L					NOMINAL PIPE SIZE, SCHEDULE 40				
	3/8"	1/2"	5/8"	3/4"	7/8"	1/2"	3/4"	1"	1-1/4"	1-1/2"
10	49	110	206	348	539	291	608	1,146	2,353	3,525
20	34	76	141	239	368	200	418	788	1,617	2,423
30	27	61	114	192	296	161	336	632	1,299	1,946
40	23	52	97	164	253	137	284	541	1,111	1,665
50	20	46	86	146	224	122	255	480	985	1,476
60	19	42	78	132	203	110	231	436	892	1,337
80	16	36	67	113	174	94	198	372	764	1,144
100	14	32	59	100	154	84	175	330	677	1,014
125	12	28	52	89	137	74	155	292	600	899
150	11	26	48	80	124	67	141	265	544	815
200	10	22	41	69	106	58	120	227	465	697
250	9	19	36	61	94	51	107	201	412	618
300	8	18	33	55	85	46	97	182	374	560
350	7	16	30	51	78	43	89	167	344	515
400	7	15	28	47	73	40	83	156	320	479

\*DATA IN ACCORDANCE WITH NFPA PAMPHLET NO. 54

# SYSTEM OPERATION

## ROOF TOP LOCATION AND INSTALLATION

The gas supply piping location and installation for roof top units must be in accordance with local codes or, in the absence of local codes, with ordinances of the latest edition of the National Fuel Gas Code (ANSI Z223.1).

A manual gas shut off valve must be field installed external to the roof top unit. In addition, a drip leg must be installed near the inlet connection. A ground joint union connection is required between the external shut off valve and the unit connection to the gas valve to permit removal of the burner assembly for servicing.

1. Route gas piping to unit so that it does not interfere with the removal of access panels. Support and align piping to prevent strains or misalignment of the manifold assembly.
2. All units are furnished with standard female NPT pipe connections. Connection pipe sizes for DTG036 through 060 units is 1/2" NPT on 045 to 140 mBH units. The size of the gas supply piping to the unit must be based on length of run, number of units on the system, gas characteristics, BTU requirement and available supply pressure. All piping must be done in accordance with local codes or, in the absence of local codes, with the latest edition of the National Fuel Gas Code (ANSI Z223.1).

**NOTE:** The gas connection size at the unit does NOT establish the size of the supply line.

3. These units are designed for either natural or propane (LP) gas and are specifically constructed at the factory for only one of these fuels. The fuels are NOT interchangeable. However, the furnace can be converted in the field from natural gas to LP gas with the appropriate factory kit (see unit Technical Manual for the appropriate kit). Only a qualified contractor, experienced with natural and propane gas systems, should attempt conversion. Kit instructions must be followed closely to assure safe and reliable unit operation.
4. With all units on a common line operating under full fire, natural gas main supply pressure should be adjusted to approximately 7.0" w.c., measured at the unit gas valve. If the gas pressure at the unit is greater than 10.5" w.c., the contractor must furnish and install an external type positive shut off service pressure regulator. The unit will not function satisfactorily if supply gas pressure is less than 5.5" w.c. or greater than 10.5" w.c..

**NOTE:** A minimum horizontal distance of 48" between the regulator and the furnace flue discharge is required.

5. With all units on a common line operating under full LP gas main supply pressure should be at least 11.0" w.c. and must be no greater than 13.0" w.c., measured at the unit gas valve. Unit will not function satisfactorily if supply gas pressure is less than 11.0" w.c. or greater than 13.0" w.c..

6. All pipe connections should be sealed with a pipe thread compound, which is resistant to the fuel used with the furnace. A soapy water solution should be used to check all joints for leaks. A tap is located on the entering side of the gas valve for test gauge connection to measure supply (main) gas pressure. Another tap is provided on the manifold side of the gas valve for checking manifold pressure.

### WARNING

**THIS UNIT AND ITS INDIVIDUAL SHUTOFF VALVE MUST BE DISCONNECTED FROM THE GAS SUPPLY SYSTEM DURING ANY PRESSURE TESTING OF THAT SYSTEM AT TEST PRESSURES IN EXCESS OF 1/2 PSIG (13.8" w.c.).**

### CAUTION

**THIS UNIT MUST BE ISOLATED FROM THE GAS SUPPLY PIPING SYSTEM BY CLOSING ITS INDIVIDUAL MANUAL SHUTOFF VALVE DURING ANY PRESSURE TESTING EQUAL TO OR LESS THAN 1/2 PSIG.**

7. There must be no obstruction to prevent the flow of combustion and ventilating air. A vent stack is not required and must never be used. The power venter will supply an adequate amount of combustion air as long as the air passageways are kept free of any obstructions and the recommended external unit clearances are maintained.

## CIRCULATING AIR AND FILTERS

### DUCTWORK

The supply duct from the unit through a wall may be installed without clearance. However, minimum unit clearances must be maintained (see "Clearances" section). The supply duct should be provided with an access panel large enough to inspect the air chamber downstream of the heat exchanger. A cover should be tightly attached to prevent air leaks.

Ductwork dimensions are shown in the roof curb installation manual.

If desired, supply and return duct connections to the unit may be made with flexible connections to reduce possible unit operating sound transmission.

### VENTING


**NOTE: Venting is self-contained.**

# SYSTEM OPERATION


## CONDENSATE DRAIN CONNECTION

### CONDENSATE DRAIN CONNECTION

A 3/4" female NPT drain connection is supplied on the end of the condensate pan, with an alternative connection on the bottom of the pan. An external trap must be installed for proper condensate drainage.



### Drain Pan (Side View)



### Drain Connection

Install condensate drain trap as shown. Use 3/4" drain line and fittings or larger. Do not operate without trap.

### HORIZONTAL DRAIN

Drainage of condensate directly onto the roof may be acceptable (refer to local code). It is recommended that a small drip pad of either stone, mortar, wood or metal be provided to prevent any possible damage to the roof. When using the horizontal drain connection, check the drain plug in bottom connection to ensure it is tight.

### VERTICAL DRAIN

To use the bottom drain connection, remove the drain plug from the bottom connection and install it in the horizontal connection.

### CLEANING

Due to the fact that drain pans in any air conditioning unit will have some moisture in them, algae and fungus will grow due to airborne bacteria and spores. Periodic cleaning is necessary to prevent this build-up from plugging the drain. Cleaning agent must be chlorine-free.

## STARTUP, ADJUSTMENTS, AND CHECKS

### WARNING

#### HIGH VOLTAGE!

TO AVOID PERSONAL INJURY OR DEATH DUE TO ELECTRICAL SHOCK, BOND THE FRAME OF THIS UNIT TO THE BUILDING ELECTRICAL GROUND BY USE OF THE GROUNDING TERMINAL PROVIDED OR OTHER ACCEPTABLE MEANS. DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT.



### CAUTION

TO PREVENT PROPERTY DAMAGE OR PERSONAL INJURY, Do NOT START THE UNIT UNTIL ALL NECESSARY PRE-CHECKS AND TESTS HAVE BEEN PERFORMED.

### WARNING

#### MOVING MACHINERY HAZARD!

TO PREVENT POSSIBLE PERSONAL INJURY OR DEATH, DISCONNECT POWER TO THE UNIT AND PADLOCK IN THE "OFF" POSITION BEFORE SERVICING FANS.

### CONTRACTOR RESPONSIBILITY

The installing contractor must be certain that:

- All supply and return air ductwork is in place, properly sealed, and corresponds with installation instructions.
- All thermostats are mounted and wired in accordance with installation instructions.
- All electric power, all gas, hot water or steam line connections, and the condensate drain installation have been made to each unit on the job. These main supply lines must be functional and capable of operating all units simultaneously.
- Requirements are met for venting and combustion air.
- Air filters are in place.
- Input rate and temperature rise are adjusted per rating plate.
- Return air temperature is maintained between 55°F (13°C) and 80°F (27°C).

### ROOF CURB INSTALLATION CHECK

Inspect the roof curb for correct installation. The unit and curb assembly should be level. Inspect the flashing of the roof mounting curb to the roof, especially at the corners, for good workmanship. Also check for leaks around gaskets. Note any deficiencies in a separate report and forward to the contractor.

# SYSTEM OPERATION

## OBSTRUCTIONS, FAN CLEARANCE AND WIRING

Remove any extraneous construction and shipping materials that may be found during this procedure. Rotate all fans manually to check for proper clearances and that they rotate freely. Check for bolts and screws that may have jarred loose during shipment to the job site. Retighten if necessary. Re-tighten all electrical connections.

## FIELD DUCT CONNECTIONS

Verify that all duct connections are tight and that there is no air bypass between supply and return.

## FILTER SECTION CHECK

Remove filter section access panels and check that filters are properly installed. Note airflow arrows on filter frames.

## PRE-STARTUP PRECAUTIONS

### TRANSFORMER

**NOTE:** On the 208/230 volt units only.

Ensure the transformer is set on the appropriate voltage taps. The transformer tap is set on 230v from the factory.

It is important to your safety that the unit has been properly grounded during installation. Check ground lug connection in main control box for tightness prior to closing circuit breaker or disconnect switch. Verify that supply voltage on line side of disconnect agrees with voltage on unit identification plate and is within the utilization voltage range.

**System Voltage** - That nominal voltage value assigned to a circuit or system for the purpose of designating its voltage class.

**Nameplate Voltage** - That voltage assigned to a piece of equipment for the purpose of designating its voltage class and for the purpose of defining the minimum and maximum voltage at which the equipment will operate.

## AIR FLOW ADJUSTMENTS

When the final adjustments are complete, the current draw of the motor should be checked and compared to the full load current rating of the motor. The amperage must not exceed the service factor stamped on the motor nameplate. The total airflow must not be less than that required for operation of the electric heaters or the furnace.

If an economizer is installed, check the unit operating balance with the economizer at full outside air and at minimum outside air.

**NOTE:** Never run CFM below 350 CFM per ton, evaporator freezing or poor unit performance is possible.

## PSC MOTOR

Adjust the CFM for the unit by changing the speed tap of the indoor blower motor at the heat or cool tap on the control board connection with the one of the speed taps on "M1" or "M2" (Black-High Speed, Blue-Medium Speed, Red-Low

Speed).

## EEM Motor

Adjust the CFM for the unit by changing the position of the low voltage leads on the motor terminal block. Green is for Fan Only. Yellow is for Cooling and Heat Pump Heating. Refer to Appendix A for blower performance at each speed tap. **NOTE:** If more than one lead is energized simultaneously, the motor will run at the higher speed.

## SET EVAPORATOR FAN RPM


Actual RPM's must be set and verified with a tachometer or strobe light. Refer to Appendices A and B for basic unit fan RPM. Refer also to "Airflow" section of this manual. With disconnect switch open, disconnect thermostat wires from terminals Y and W. This will prevent heating and mechanical cooling from coming on. Place a jumper wire across terminals R and G at TB1 terminal block. Close disconnect switch; evaporator fan motor will operate so RPM can be checked.

For gas heat units, the airflow must be adjusted so that the air temperature rise falls within the ranges given stated on Data Plate (see Appendix A - Blower Performance).

## ELECTRICAL INPUT CHECK

Make preliminary check of evaporator fan ampere draw and verify that motor nameplate amps are not exceeded. A final check of amp draw should be made upon completion of air balancing of the duct system.

## GAS SYSTEM



**Flame Sensor and Ignition Electrode Location**

# SYSTEM OPERATION

MAXIMUM INPUT (BTUH)	NUMBER of BURNERS	MAXIMUM BTUH/BURNER	GAS ORIFICES	
			NATURAL (Dia)	PROPANE (LP) (Dia)
45,000	2	23,000	#43	#55
90,000	4	23,000	#43	#55
115,000	5	23,000	#43	#55
140,000	6	23,000	#43	#55

## Heat Exchanger and Burner Orifice Specifications

**NOTE:** Gas appliances located more than 2000 feet above sea level must be derated 4% per 1000 feet of total elevation and that variance in gas heating value and specific gravity require change in manifold pressure to obtain rating, it is mandatory that the input be adjusted at the installation site. All installations should be made as outlined in the latest edition of the National Fuel Gas Code ANSI Z223.1, section "Procedures To Be Followed To Place An Appliance in Operation". Refer also to the "User's Information Manual" supplied with the unit for additional information on the gas furnace.

## NORMAL SEQUENCE OF OPERATION

**NOTE:** The ignition control board blower off delay is factory set at 150 seconds. This factory setting can also be set to 120 or 135 seconds by placing the jumper on the desired setting.

## HEATING

This unit has one (RS) Manual Reset Limit Control Switch. Check the limit to make sure it has not tripped. The limit may arrive at the job site tripped as a result of shipping shock.

If the ventermotor comes on, but the unit does not attempt ignition, check if the ALS (Auxiliary High Limit Control Switch) requires resetting.

1. With electricity and gas turned on, the system switch in the "HEAT" or "AUTO" position and the fan switch in the "AUTO" position, the thermostat will close the circuit between unit terminals R and W (R-W) when the temperature falls below the thermostat setting.
2. D1 on IIC energizes relay IDMR.
3. Relay IDMR energizes the ventermotor IDM.
4. Operation of the ventermotor closes the pressure switch PS located in the burner compartment. Unless excessive temperatures or shipping shock have opened high limit control ALS, power is fed to the integrated ignition control, which then initiates a 15-second pre-purge time delay. During this period, the ventermotor will clear the combustion chamber of any residual gas.

5. After the pre-purge period, the ignition control energizes the WI-C gas valve and simultaneously initiates a "three (3)-try" spark ignition sequence.
6. When the burners are ignited, a minimum one (1) micro-amp DC current will flow through the flame between the sensor electrode and the grounded burner.
7. When the controller proves that the flame has been established, it will keep the gas valve energized and discontinue the ignition spark. High stage manifold pressure will be approximately 3.5" w.c. for natural gas and 10.0" w.c. for propane (LP). Low fire natural gas is 2.0" w.c.; low fire propane 6.0" w.c.
8. If the control is unable to ignite the burners after its initial attempt, it will initiate another purge and spark sequence. A third purge and spark sequence will be initiated if the second attempt is unsuccessful. If the third attempt is unsuccessful, the controller will close the gas valve and lock itself out. It may be reset by momentarily interrupting power. This may be accomplished by briefly lowering the room thermostat set-point below room temperature, or by shutting off the main power to the unit. (See TP-105 for more details.)
9. Integrated ignition control will close its normally open contacts after a delay of approximately 30 seconds. This action energizes contactor BC and starts the supply fan motor. Operation of the supply fan circulates air across the heat exchanger and delivers heated air to the conditioned space.
10. When the space temperature rises, the thermostat will open R-W. Opening R-W will cause the gas valve to close, and the furnace to shut down.
11. The furnace has three high temperature limit controls, which can shut down the burner. They do not shut down the ventermotor.

## Unit Shutdown

1. Set the thermostat to lowest setting.
2. Turn off the electrical power supply to the unit.
3. Remove the heat exchanger door on the side of the unit by removing screws.
4. Move the gas control valve switch to the OFF position. Do not force.
5. Close manual gas shut off valve external to the unit.
6. Replace the heat exchanger door on the unit.
7. If cooling and/or air circulation will be desired, turn ON the electrical power.

## AUTOMATIC RESET HIGH LIMIT CONTROL (LS)

Located in the burner compartment on the heat exchanger, its sensing element projects through the blower section bulk-head and senses the temperature at the rear of the furnace. It will cycle the furnace off if the temperature exceeds 100°F plus maximum rise.



# SYSTEM OPERATION

## AUXILIARY HIGH LIMIT CONTROL (ALS)

Located in the blower compartment on the blower housing, it senses air temperature within the blower compartment and protects the filters from excessive temperature. It will shut down the furnace if it senses excessive temperatures.

Elevated temperatures at the control are normally caused by blower failure. The reason for the opening should be determined and repaired prior to resetting.

## MANUAL RESET FLAME ROLLOUT CONTROL (RS)

Located in the burner compartment at the top of the burner assembly, it senses high temperature that could occur if the heat exchanger tubes were plugged and the flame was rolling out instead of entering the tubes. It has a manual push-button reset that cannot be actuated until the limit control has cooled.

The reason for elevated temperatures at the control should be determined and repaired prior to resetting this manual reset control.

### WARNING

TO AVOID PROPERTY DAMAGE, PERSONAL INJURY OR DEATH DUE TO FIRE OR EXPLOSION, A QUALIFIED SERVICER MUST INVESTIGATE THE REASON FOR THE ROLLOUT PROTECTION DEVICE TO OPEN BEFORE MANUALLY RESETTING THE ROLLOUT PROTECTION DEVICE.

## NORMAL SEQUENCE OF OPERATION

### COOLING

Begin with power turned off at all disconnects.

1. Turn thermostat system switch to "Cool," and fan switch to "Auto" and turn temperature setting as high as it will go.
2. Inspect all registers and set them to the normal open position.
3. Turn on the electrical supply at the disconnect.
4. Turn the fan switch to the "ON" position. The blower should operate after a 7 second delay.
5. Turn the fan switch to "Auto" position. The blower should stop after a 65 second delay.
6. Slowly lower the cooling temperature until the unit starts. The compressor, blower and fan should now be operating. Allow the unit to run 10 minutes, make sure cool air is being supplied by the unit.
7. Turn the temperature setting to the highest position, stopping the unit. The indoor blower will continue to run for 65 seconds.
8. Turn the thermostat system switch to "OFF" and disconnect all power when servicing the unit.

### WARNING

**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



### HEAT PUMP

9. Check the cooling mode for the heat pump in the same manner as above. The reversing valve is energized when the thermostat is placed in the cooling position. A clicking sound should be noticeable from the reversing valve. By lowering the temperature setting to call for cooling, the contractor is energized. The compressor, blower and fan should then be running. After the cooling mode is checked out, turn the thermostat system switch to "OFF".
10. Turn the thermostat system switch to "HEAT" and fan switch to "AUTO".
11. Slowly raise the heating temperature setting. When the heating first stage makes contact, stop raising the temperature setting. The compressor, blower and fan should now be running with the reversing valve in the de-energized (heating) position. After giving the unit time to settle out, make sure the unit is supplying heated air.
12. If the outdoor ambient is above 80°F, the unit may trip on its high pressure cut out when on heating. The compressor should stop. The heating cycle must be thoroughly checked, so postpone the test to another day when conditions are more suitable but-DO NOT FAIL TO TEST.

If the outdoor ambient is low and the unit operates properly on the heating cycle, you may check the pressure cutout operation by blocking off the indoor return air until the unit trips.

13. If unit operates properly in the heating cycle, raise the temperature setting until the heating second stage makes contact. Supplemental resistance heat, if installed should now come on. Make sure it operates properly.

**NOTE:** If outdoor thermostats are installed the outdoor ambient must be below the set point of these thermostats for the heaters to operate. It may be necessary to jumper these thermostats to check heater operation if outdoor ambient is mild.

14. For thermostats with emergency heat switch, return to step 11. The emergency heat switch is located at the bottom of the thermostat. Move the switch to emergency heat. The heat pump will stop, the blower will continue to run, all heaters will come on and the thermostat emergency heat light will come on.
15. If checking the unit in the wintertime, when the outdoor coil is cold enough to actuate the defrost control, observe at least one defrost cycle to make sure the unit defrosts completely.

# SYSTEM OPERATION

## HEAT PUMP OPERATION

### COOLING CYCLE

When the heat pump is in the cooling cycle, it operates exactly as a Summer Air Conditioner unit. In this mode, all the charts and data for service that apply to summer air conditioning apply to the heat pump. Most apply to the heating cycle except that “condenser” becomes “evaporator”, “evaporator” becomes “condenser”, “cooling” becomes “heating”.


### HEATING CYCLE

The heat pump operates in the heating cycle by redirecting refrigerant flow through the refrigerant circuit external to the compressor. This is accomplished with through the reversing valve. Hot discharge vapor from the compressor is directed to the indoor coil (evaporator on the cooling cycle) where the heat is removed, and the vapor condenses to liquid. It then goes through the expansion device to the outdoor coil (condenser on the cooling cycle) where the liquid is evaporated, and the vapor goes to the compressor.

When the solenoid valve coil is operated either from heating to cooling or vice versa, the piston in the reversing valve to the low pressure (high pressure) reverse positions in the reversing valve.

The following figures show a schematic of a heat pump on the cooling cycle and the heating cycle. In addition to a reversing valve, a heat pump is equipped with an expansion device and check valve for the indoor coil, and similar equipment for the outdoor coil. It is also provided with a defrost control system.

The expansion devices are flowrator distributors and perform the same function on the heating cycle as on the cooling cycle. The flowrator distributors also act as check valves to allow for the reverse of refrigerant flow.




When the heat pump is on the heating cycle, the outdoor coil is functioning as an evaporator. The temperature of the refrigerant in the outdoor coil must be below the temperature of the outdoor air in order to extract heat from the air. Thus, the greater the difference in the outdoor temperature and the outdoor coil temperature, the greater the heating capacity of the heat pump. This phenomenon is a characteristic of a heat pump. It is a good practice to provide supplementary heat for all heat pump installations in areas where the temperature drops below 45° F. It is also a good practice to provide sufficient supplementary heat to handle the entire heating requirement should there be a component failure of the heat pump, such as a compressor, or refrigerant leak, etc.

Since the temperature of the refrigerant in the outdoor coil on the heating cycle is generally below freezing point, frost forms on the surfaces of the outdoor coil under certain weather conditions of temperature and relative humidity. Therefore, it is necessary to reverse the flow of the refrigerant to provide hot gas in the outdoor coil to melt the frost accumulation. This is accomplished by reversing the heat pump to the cooling cycle. At the same time, the outdoor fan stops to hasten the temperature rise of the outdoor coil and lessen the time required for defrosting. The indoor blower continues to run and the supplementary heaters are energized.

### DEFROST CONTROL

During operation the power to the circuit board is controlled by a temperature sensor, which is clamped to a feeder tube entering the outdoor coil. Defrost timing periods of 30, 60 and 90 minutes may be selected by connecting the circuit board jumper to 30, 60 and 90 respectively. Accumulation of time for the timing period selected starts when the sensor closes (approximately 31° F), and when the wall thermostat calls for heat. At the end of the timing period, the unit's defrost cycle will be initiated provided the sensor remains closed. When the sensor opens (approximately 75° F), the defrost cycle is terminated and the timing period is reset. If the defrost cycle is not terminated due to the sensor temperature, a ten minute override interrupts the unit's defrost period.



# SYSTEM OPERATION

## REFRIGERATION SYSTEM CHECKS

This unit is equipped with a piston type metering device.

Ensure the hold-down bolts on the compressor are secure and have not vibrated loose during shipment. Check that the vibration grommets have been installed and visually check all piping for damage and leaks and repair if necessary. The entire system has been factory charged and tested, making it unnecessary to field charge. Factory refrigerant charge is shown on the unit's nameplate.

To confirm charge levels or, if a leak occurs and charge needs to be added to the system, it is recommended to evacuate the system and recharge refrigerant to the unit's nameplate specifications. This unit has been rated in the cooling mode at the AHRI rated conditions of: indoor (80°F db/67°F wb) and outdoor (95°F db). While operating at this condition, the superheat should range from 9°F to 11°F for each refrigeration circuit measured at the suction service port located near the compressor.

## FINAL SYSTEM CHECKS

1. Check to see if all supply and return air grilles are adjusted and the air distribution system is balanced for the best compromise between heating and cooling.
2. Check for air leaks in the ductwork. See Sections on **Air Flow Adjustments**.
3. Make sure the unit is free of "rattles", and the tubing in the unit is free from excessive vibration. Also make sure tubes or lines are not rubbing against each other or sheet metal surfaces or edges. If so, correct the trouble.
4. Set the thermostat at the appropriate setting for cooling and heating or automatic changeover for normal use.
5. Be sure the Owner is instructed on the unit operation, filter, servicing, correct thermostat operation, etc.

# SCHEDULED MAINTENANCE

## MAINTENANCE

### WARNING

**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



### WARNING

TO PREVENT PERSONAL INJURY OR DEATH DUE TO IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE, REFER TO THIS MANUAL. FOR ADDITIONAL ASSISTANCE OR INFORMATION, CONSULT A QUALIFIED INSTALLER, SERVICE AGENCY OR THE GAS SUPPLIER.

### CAUTION

SHEET METAL PARTS, SCREWS, CLIPS AND SIMILAR ITEMS INHERENTLY HAVE SHARP EDGES, AND IT IS NECESSARY THAT THE INSTALLER AND SERVICE PERSONNEL EXERCISE CAUTION.

Preventive maintenance is the best way to avoid unnecessary expense and inconvenience. Have this system inspected at regular intervals by qualified service personnel, at least twice a year. Routine maintenance should cover the following items:

1. Tighten all belts, set screws, and wire connections.
2. Clean evaporator and condenser coils mechanically or with cold water, if necessary. Usually any fouling is only matted on the entering air face of the coil and can be removed by brushing.
3. Replace filters as needed (see below).
4. Check for blockage of condensate drain.
5. Check power and control voltages.
6. Check running amperage.
7. Check operating temperatures and pressures.
8. Check and adjust temperature and pressure controls.
9. Check and adjust damper linkages.
10. Check operation of all safety controls.
11. Examine gas furnaces (see below and the User's Information Manual).
12. Check condenser fans and tighten set screws.

## FILTERS

### CAUTION

TO PREVENT PROPERTY DAMAGE DUE TO FIRE AND LOSS OF EQUIPMENT EFFICIENCY OR EQUIPMENT DAMAGE DUE TO DUST AND LINT BUILD UP ON INTERNAL PARTS, NEVER OPERATE UNIT WITHOUT AN AIR FILTER INSTALLED IN THE RETURN AIR SYSTEM.

Every application may require a different frequency of replacement of dirty filters. Filters must be replaced at least every three (3) months during operating seasons.

Dirty filters are the most common cause of inadequate heating or cooling performance. Filter inspection should be made at least every two months; more often if necessary because of local conditions and usage.

Dirty throwaway filters should be discarded and replaced with a new, clean filter.

Disposable return air filters are supplied with this unit. See the unit Specification Sheet or Technical Manual for the correct size and part number. To remove the filters, remove the filter access panel on return side of the unit.

### CABINET FINISH MAINTENANCE

Use a fine grade automotive wax on the cabinet finish to maintain the finish's original high luster. This is especially important in installations with extended periods of direct sunlight.

### CLEAN OUTSIDE COIL (QUALIFIED SERVICER ONLY)

The coil with the outside air flowing over it should be inspected annually and cleaned as frequently as necessary to keep the finned areas free of lint, hair and debris.

### CONDENSER AND INDUCED DRAFT MOTORS

Bearings on the condenser fan motors and the combustion fan motor are permanently lubricated. No additional oiling is required.

### FLAME SENSOR (QUALIFIED SERVICER ONLY)

A drop in the flame current can be caused by a nearly invisible coating on the flame sensor. This coating, created by the fuel or combustion air supply, can be removed by carefully cleaning the flame sensor with steel wool.

**NOTE:** After cleaning, the microamp signal should be stable and in the range of 4 - 6 microamps DC.

### FLUE PASSAGES (QUALIFIED SERVICER ONLY)

At the start of each heating season, inspect and, if necessary, clean the unit flue passage.

# SCHEDULED MAINTENANCE

## INSPECTION & CLEANING

All flue product carrying areas of the furnace, its vent system, and main burners should be examined by a qualified service agency before the start of each heating season. This examination is necessary for continued safe operation. Particular attention should be given to deterioration from corrosion or other sources. This examination is accomplished in the following manner.


1. Disconnect power to the unit and remove furnace section access panel.
2. Remove burner assembly:
  - a. Disconnect the wires from the gas valve after noting which wires are connected to each terminal.
  - b. Disconnect wires from the flame rod and ignition electrode.
  - c. Disconnect the gas piping at the union.
  - d. The entire burner assembly can now be removed from the unit.

**NOTE:** Use all screws that were removed; they are necessary for safe and proper operation of the unit.

3. Inspect and periodically clean the vent outlet (bird screen) on the access panel.

**NOTE:** Periodic observation of the flame and a log of CO<sub>2</sub> measurements are recommended. This will aid in determining whether the furnace is operating efficiently or if the furnace requires cleaning.

Flames should be stable, soft and blue (dust may cause orange tips but must not be yellow). The flames must extend directly outward from the burner without curling, floating or lifting off.



- Check the burner flames for:
1. Good adjustment
  2. Stable, soft and blue
  3. Not curling, floating, or lifting off.

## Burner Flame



### WARNING

TO AVOID PERSONAL INJURY OR DEATH DUE TO ELECTRIC SHOCK, DO NOT REMOVE ANY INTERNAL COMPARTMENT COVERS OR ATTEMPT ANY ADJUSTMENT. CONTACT A QUALIFIED SERVICER AT ONCE IF AN ABNORMAL FLAME SHOULD DEVELOP.

At least once a year, prior to or during the heating season, make a visual check of the burner flames.

**NOTE:** This will involve removing and reinstalling the heat exchanger door on the unit, which is held by two screws. If you are uncertain about your ability to do this, contact a qualified servicer.

If a strong wind is blowing, it may alter the airflow pattern within the unit enough that an inspection of the burner flames is not possible.

## FUNCTIONAL PARTS

Refer to the unit Parts Catalog for a list of functional parts. Parts are available from your distributor.

# SERVICING

## COOLING ANALYSIS CHART

Complaint	No Cooling						Unsatisfactory Cooling				System Operating Pressures				Test Method Remedy	See Service Procedure Ref.	
	System will not start	Compressor will not start - fan runs	Comp. and Cond. Fan will not start	Evaporator fan will not start	Condenser fan will not start	Compressor runs - goes off on overload Compressor cycles on overload	System runs continuously - little cooling	Too cool and then too warm	Not cool enough on warm days	Certain areas too cool, others too warm	Compressor is noisy	Low suction pressure	Low head pressure	High suction pressure			High head pressure
POSSIBLE CAUSE  DOTS IN ANALYSIS GUIDE INDICATE "POSSIBLE CAUSE"	SYMPTOM																
Power Failure	•															Test Voltage	S-1
Blown Fuse	•		•	•												Inspect Fuse Size & Type	S-1
Unbalanced Power, 3PH		•				•	•									Test Voltage	S-1
Loose Connection	•			•		•										Inspect Connection - Tighten	S-2, S-3
Shorted or Broken Wires	•	•	•	•	•	•										Test Circuits With Ohmmeter	S-2, S-3
Open Fan Overload				•	•											Test Continuity of Overload	S-17A
Faulty Thermostat	•		•	•				•								Test Continuity of Thermostat & Wiring	S-3
Faulty Transformer	•		•													Check Control Circuit with Voltmeter	S-4
Shorted or Open Capacitor		•		•	•	•	•									Test Capacitor	S-15
Internal Compressor Overload Open		•														Test Continuity of Overload	S-17A
Shorted or Grounded Compressor		•				•										Test Motor Windings	S-17B
Compressor Stuck		•				•	•									Use Test Cord	S-17D
Faulty Compressor Contactor			•		•	•										Test Continuity of Coil & Contacts	S-7, S-8
Faulty Fan Relay				•												Test Continuity of Coil And Contacts	S-7
Open Control Circuit				•												Test Control Circuit with Voltmeter	S-4
Low Voltage		•				•	•									Test Voltage	S-1
Faulty Evap. Fan Motor				•								•				Repair or Replace	S-16
Shorted or Grounded Fan Motor					•									•		Test Motor Windings	S-16
Improper Cooling Anticipator						•		•								Check Resistance of Anticipator	S-3B
Shortage of Refrigerant							•	•				•	•			Test For Leaks, Add Refrigerant	S-101,103
Restricted Liquid Line							•	•				•	•	•		Remove Restriction, Replace Restricted Part	S-112
Dirty Air Filter							•	•	•			•				Inspect Filter-Clean or Replace	
Dirty Indoor Coil							•	•	•			•				Inspect Coil - Clean	
Insufficient air across Indoor Coil							•	•	•			•				Check Blower Speed and Rotation, Belt, Pulleys, Duct Static, Filter	S-200
Too much air across Indoor Coil													•			Reduce Blower Speed, Check Pulley Adjustment	
Overcharge of Refrigerant						•	•					•	•	•		Recover Part of Charge	S-113
Dirty Outdoor Coil						•	•	•	•					•		Inspect Coil - Clean	
Noncondensibles							•	•	•					•		Recover Charge, Evacuate, Recharge	S-114
Recirculation of Condensing Air							•	•	•					•		Remove Obstruction to Air Flow	
Infiltration of Outdoor Air								•	•	•						Check Windows, Doors, Vent Fans, Etc.	
Improperly Located Thermostat						•			•							Relocate Thermostat	
Air Flow Unbalanced								•		•						Readjust Air Volume Dampers	
System Undersized							•		•							Refigure Cooling Load	
Broken Internal Parts											•					Replace Compressor	S-115
Broken Valves										•		•	•			Test Compressor Efficiency	S-104
Inefficient Compressor											•		•			Test Compressor Efficiency	S-104
Expansion Device Restricted						•	•	•	•			•	•	•		Remove Restriction, Replace Expansion Device	111
Loose Hold-down Bolts														•		Tighten Bolts	
Flow rator Not Seating Properly								•				•	•			Check Flow rator & Seat or Replace Flow rator	S-111

• Cooling Cycle

# SERVICING

## GAS HEATING ANALYSIS CHART

Complaint	No Heat				Unsatisfactory Heat						Test Method Remedy	See Service Procedure Reference	
	SYMPTOM	System Will Not Start	Burner Won't Ignite	Burner Ignites-Locks Out	Burner Lights - Little or No Air Through Vents	Burner Shuts Off prior to T'Stat being Satisfied	Short Cycles	Long Cycles	Soot and/or Fumes	To Much Heat			Not Enough Heat
Power Failure		•										Test Voltage	S-1
Blown Fuse		•										Test Voltage	S-1
Loose Connection		•										Check Wiring	S-2, S-3
Shorted or Broken Wires		•										Check Wiring	S-2, S-3
No Low Voltage		•										Check Transformer	S-4
Faulty Thermostat		•				•	•		•			Check Thermostat	S-3
Faulty Transformer		•										Check Transformer	S-4
Poor or High Resistance Ground				•								Measure Ground Resistance	S-313
Improper Heat Anticipator Setting						•	•		•	•		Adjust Heat Anticipator Setting	S-3
Improper Thermostat Location						•	•		•	•		Relocate Thermostat	
Faulty Limit or Roll Out Switch			•		•							Test Control	S-300-302
Faulty Flame Sensor				•								Test Flame Sensor	S-314
Faulty Ignition Control		•	•	•	•							Test Control	S-313
Gas Valve or Gas Supply Shut Off			•									Turn Valves to On Position	S-304
Faulty Induced Draft Blower		•	•					•				Test Blower	S-303
Dirty Flame Sensor, Low uA				•								Clean Flame Sensor	S-314
Flame Sensor not in Flame, Low uA				•								Test/Adjust Position of Flame Sensor	S-314
Faulty Gas Valve			•					•		•		Replace Gas Valve	S-304
Open Auxiliary Limit			•	•	•							Check Blower Speed, Rotation, Belt, Pulleys, Duct Static, Filter	S16A,16D,200, 201
Improper Air Flow or Distribution				•	•					•		Check Blower Speed, Rotation, Belt, Pulleys, Duct Static, Filter	S16A,16D,200, 201
Faulty Blower Motor, Belt, or Pulley				•								Check Blower Speed, Rotation, Belt, Pulleys, Duct Static, Filter	S16A,16D,200, 201
Locking out on Main Limit			•		•					•		Check Limit, Gas Press., Temp. Rise, Blower Rotation, Belt, Pulleys, Duct Static, Filter	S-300, 307, 201
Delayed Ignition								•				Test for Delayed Ignition	S-308
Flashback								•				Test for Flashback	S-309
Orifice Size								•	•	•		Check Orifices	S-306
Gas Pressure			•					•	•	•		Check Gas Pressure	S-307
Cracked Heat Exchanger								•				Check Burner Flames	S-302
Stuck Gas Valve			•					•	•			Replace Gas Valve	S-304
Furnace Undersized										•		Replace with Proper Size Furnace	
Faulty Pressure Switch			•	•		•						Test Pressure Switch	S-310
Blocked or Restricted Flue								•				Check Flue/Draw down Pressure	S-310
Open Roll Out Switch			•	•								Test Control	S-302
Bouncing On Pressure Switch				•								Test Negative Pressure, Flue Blockage	S-310

# SERVICING

## Table of Contents

S-1	Checking Voltage.....	31	S-104	Checking Compressor Efficiency.....	43
S-2	Checking Wiring .....	32	S-106	Overfeeding .....	43
S-3	Checking Thermostat, Wiring & Anticipator ...	32	S-108	Checking Superheat.....	43
S-3A	Thermostat & Wiring.....	32	S-111	Fixed Orifice Restriction Devices.....	45
S-3B	Cooling Anticipator.....	32	S-112	Checking Restricted Liquid Line .....	45
S-3C	Heating Anticipator .....	32	S-113	Refrigerant Overcharge .....	45
S-4	Checking Transformer & Control Circuit.....	32	S-114	Non-condensables.....	45
S-7	Checking Contactor and/or Relays.....	33	S-115	Compressor Burnout .....	46
S-8	Checking Contactor Contacts.....	33	S-200	Checking External Static Pressure .....	46
S-9	Checking Fan Relay Contact.....	34	S-201	Checking Temperature Rise .....	47
S-11	Checking Loss of Charge Protection .....	35	S-300	Testing Primary Limit .....	47
S-12	Checking High Pressure Control .....	35	S-301	Testing Auxiliary Limit .....	48
S-13	Checking Low Pressure Control .....	35	S-302	Checking Flame Rollout Switch.....	48
S-15	Checking Capacitor .....	36	S-303	Testing Inducer Motor .....	49
S-15A	Resistance Check.....	36	S-304	Testing Gas Valve.....	49
S-15B	Capacitance Check .....	36	S-305	Checking Main Burners .....	50
S-16	Checking Motors.....	37	S-306	Checking Orifices .....	50
S-16D	Checking EEM Motors.....	37	S-307	Checking Gas Pressure.....	51
S-17	Checking Compressor Windings .....	37	S-308	Checking For Delayed Ignition .....	52
S-17A	Resistance Test .....	38	S-309	Checking for Flashback.....	52
S-17B	Ground Test .....	38	S-310	Checking Pressure Control.....	53
S-17D	Operation Test .....	39	S-311	High Altitude Application .....	53
S-18	Testing Crankcase Heater (optional item) ....	39	S-313	Testing Ignition Control Module .....	54
S-18A	Crankcase Heater Thermostat .....	39	S-314	Checking Flame Sensor .....	56
S-21	Checking Reversing Valve & Solenoid .....	39			
S-24	Testing Defrost Control .....	39			
S-25	Testing Defrost Thermostat .....	40			
S-50	Checking Heater Limit Control(s) .....	40			
S-52	Checking Heater Elements.....	41			
S-100	Refrigeration Repair Practice .....	41			
S-101	Leak Testing .....	41			
S-102	Evacuation.....	41			
S-103	Charging.....	42			



### WARNING

#### HIGH VOLTAGE!


Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.






# SERVICING

## S-1 CHECKING VOLTAGE




**WARNING**

**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Remove doors, control panel cover, etc. from unit being tested.

With power ON:



**WARNING**

**Line Voltage now present.**

2. Using a voltmeter, measure the voltage across terminals L1 and L2 of the contactor for single phase units, and L3, for 3 phase units.
3. No reading - indicates open wiring, open fuse(s) no power or etc. from unit to fused disconnect service. Repair as needed.
4. With ample voltage at line voltage connectors, energize the unit.
5. Measure the voltage with the unit starting and operating, and determine the unit Locked Rotor Voltage.

**Locked Rotor Voltage** is the actual voltage available at the compressor during starting, locked rotor, or a stalled condition. Measured voltage should be above minimum listed in chart below.

To measure Locked Rotor Voltage attach a voltmeter to the run "R" and common "C" terminals of the compressor, or to the T<sub>1</sub> and T<sub>2</sub> terminals of the contactor. Start the unit and allow the compressor to run for several seconds, then shut down the unit. Immediately attempt to restart the unit while measuring the Locked Rotor Voltage.

6. Voltmeter should read within the voltage tabulation as shown. If the voltage falls below the minimum voltage, check the line wire size. Long runs of undersized wire can cause low voltage. If wire size is adequate, notify the local power company in regards to either low or high voltage.

Unit Supply Voltage		
Voltage	Min.	Max.
208/230	198	253
460	437	506
575	546	604

Three phase units require a balanced 3 phase power supply to operate. If the percentage of voltage imbalance exceeds 3% the unit must not be operated until the voltage condition is corrected.

$$\% \text{ Voltage Imbalance} = \frac{\text{Max. Voltage Deviation From Average Voltage}}{\text{Average Voltage}} \times 100$$

To find the percentage of imbalance, measure the incoming power supply.

$$\begin{aligned} L1 - L2 &= 240V \\ L1 - L3 &= 232V \\ L2 - L3 &= 238V \\ \text{Total} &= 710V \\ \text{Avg. V} &= \frac{710}{3} = 236.7 \end{aligned}$$


To find Max. deviation:

$$\begin{aligned} 240 - 236.7 &= +3.3 \\ 232 - 236.7 &= -4.7 \\ 238 - 236.7 &= +1.3 \end{aligned}$$

Max deviation was 4.7V


$$\% \text{ Voltage Imbalance} = \frac{4.7}{236.7} = 1.99\%$$

If the percentage of imbalance had exceeded 3%, it must be determined if the imbalance is in the incoming power supply or the equipment. To do this rotate the legs of the incoming power and retest voltage as shown below.



$$\begin{aligned} L1 - L2 &= 240V \\ L1 - L3 &= 227V \\ L2 - L3 &= 238V \end{aligned}$$

Rotate all 3 incoming legs as shown.



$$\begin{aligned} L1 - L2 &= 227V \\ L1 - L3 &= 238V \\ L2 - L3 &= 240V \end{aligned}$$


By the voltage readings we see that the imbalance rotated or traveled with the switching of the incoming legs. Therefore the imbalance lies within the incoming power supply.

If the imbalance had not changed then the problem would lie within the equipment. Check for current leakage, shorted motors, etc.

# SERVICING

## S-2 CHECKING WIRING

**WARNING**  
**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Check wiring visually for signs of overheating, damaged insulation and loose connections.
2. Use an ohmmeter to check continuity of any suspected open wires.
3. If any wires must be replaced, replace with comparable gauge and insulation thickness.

## S-3 CHECKING THERMOSTAT, WIRING, AND ANTICIPATOR

THERMOSTAT WIRE SIZING CHART	
LENGTH OF RUN	MIN. COPPER WIRE GAUGE (AWG)
25 feet	18
50 feet	16
75 feet	14
100 feet	14
125 feet	12
150 feet	12

### S-3A THERMOSTAT AND WIRING

**WARNING**  
Line Voltage now present.

With power ON, thermostat calling for cooling

1. Use a voltmeter to check for 24 volts at thermostat wires C and Y in the unit control panel.
2. No voltage indicates trouble in the thermostat or wiring.
3. Check the continuity of the thermostat and wiring. Repair or replace as necessary.

#### Indoor Blower Motor

With power ON:

**WARNING**  
Line Voltage now present.

1. Set fan selector switch at thermostat to "ON" position.
2. With voltmeter, check for 24 volts at wires C and G.
3. No voltage indicates the trouble is in the thermostat or wiring.
4. Check the continuity of the thermostat and wiring. Repair or replace as necessary.

## S-3B COOLING ANTICIPATOR

The cooling anticipator is a small heater (resistor) in the thermostat. During the "off" cycle, it heats the bimetal element helping the thermostat call for the next cooling cycle. This prevents the room temperature from rising too high before the system is restarted. A properly sized anticipator should maintain room temperature within 1 1/2 to 2 degree range.

The anticipator is supplied in the thermostat and is not to be replaced. If the anticipator should fail for any reason, the thermostat must be changed.


## S-3C HEATING ANTICIPATOR

The heating anticipator is a wire-wound adjustable heater, which is energized during the "ON" cycle to help prevent overheating of the conditioned space.

The anticipator is a part of the thermostat and if it should fail for any reason, the thermostat must be replaced. See the following for recommended heater anticipator setting.

To determine the proper setting, use an ammeter to measure the current on the "W" wire going to the thermostat.


Use an amprobe as shown below. Wrap 10 turns of thermostat wire around the stationary jaw of the amprobe and divide the reading by 10.



CHECKING HEAT ANTICIPATOR AMP DRAW

## S-4 CHECKING TRANSFORMER AND CONTROL CIRCUIT

**WARNING**  
**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



# SERVICING

A step-down transformer (either 208-240, 460 or 575 volt primary to 24 volt secondary) is provided with each unit. This allows ample capacity for use with resistance heaters.

**WARNING**  
Disconnect ALL power before servicing.

1. Remove control panel cover to gain access to transformer.

With power ON:

**WARNING**  
Line Voltage now present.

2. Using a voltmeter, check voltage across secondary voltage side of transformer (R to C).
3. No voltage indicates faulty transformer, bad wiring, or bad splices.
4. Check transformer primary voltage at incoming line voltage connections and/or splices.
5. If line voltage available at primary voltage side of transformer and wiring and splices good, transformer is inoperative. Replace.

## S-7 CHECKING CONTACTOR AND/OR RELAYS

**WARNING**  
HIGH VOLTAGE!  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

The compressor contactor and other relay holding coils are wired into the low or line voltage circuits. When the control circuit is energized, the coil pulls in the normally open contacts or opens the normally closed contacts. When the coil is de-energized, springs return the contacts to their normal position.

**NOTE:** Most single phase contactors break only one side of the line (L1), leaving 115 volts to ground present at most internal components.

1. Remove the leads from the holding coil.
2. Using an ohmmeter, test across the coil terminals.

If the coil does not test continuous, replace the relay or contactor.


## S-8 CHECKING CONTACTOR CONTACTS

### SINGLE PHASE

**WARNING**  
HIGH VOLTAGE!  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

1. Disconnect the wire leads from the terminal (T) side of the contactor.
2. With power ON, energize the contactor.

**WARNING**  
Line Voltage now present.



### TESTING COMPRESSOR CONTACTOR (Single Phase)


3. Using a voltmeter, test across terminals.
    - A. L1 - L2 - No voltage. Check breaker or fuses on main power supply.
    - B. L2 - T1 - No voltage indicates CC1 contacts open.
- If a no voltage reading is obtained - replace the contactor.

### THREE PHASE

Using a voltmeter, test across terminals.

- A. L1-L2, L1-L3, and L2-L3 - If voltage is present, proceed to B. If voltage is not present, check breaker or fuses on main power supply..
- B. T1-T2, T1-T3, and T2-T3 - If voltage readings are not the same as in "A", replace contactor.

# SERVICING



---- Ohmmeter for testing holding coil  
 — Voltmeter for testing contacts

## TESTING COMPRESSOR CONTACTOR (ThreePhase)

### S-9 CHECKING FAN RELAY CONTACTS

#### DTG:

The fan relays are incorporated into the control board. See section S-313 for checking control board for single phase gas models.

#### DTC/DTH:

The Electronic Blower Time Delay Relay is used on PSC and belt driven models.



### WARNING

#### HIGH VOLTAGE!

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



#### Checking EBTD High Voltage Contacts

1. With power off, remove wires from terminals NC, COM, and NO.
2. Using a VOM, check for resistance from NO to COM. Should read open. Next, check for resistance from NC to COM. Should read closed.
3. If not as above, replace EBTD.

#### Checking EBTD Contact Operation

With power on:



### WARNING

Line Voltage now present.

1. Set the thermostat to the fan "on" position.
2. Check for 24 volts at the C and G terminals of the EBTD.

3. If no voltage present, check fan circuit from thermostat. If 24 volts present, proceed to step 4.
4. Using a VOM, check for line voltage from the purple wire at the transformer (terminal 3 on 240 volt units, terminal 2 on 208 volt units) to terminal NO on the EBTD. Should read line voltage. If no voltage present, check line voltage wiring in unit. If line voltage present, proceed to step 5.
5. Using a VOM, check for line voltage from the purple wire at the transformer (terminal 3 on 240 volt units, terminal 2 on 208 volt units) to the COM terminal on the EBTD. Should read line voltage. If not as above, replace EBTD.

PSC equipped, single phase model coolers and heat pumps have an isolation relay with a 240 volt holding coil in addition to the EBTD.



### WARNING

Disconnect ALL power before servicing.

Turn power off.

#### Testing relay holding coil

1. Remove the leads from the holding coil terminals 1 and 3.
2. Using an ohmmeter, test across the coil terminals 1.
3. If the coil does not test continuous, replace the relay.

#### Testing relay contacts



### WARNING

Disconnect ALL power before servicing.

Turn power off.

1. Using a VOM, test resistance across relay terminals 2 and 4. Should read open.
2. Turn power on.



### WARNING


Line Voltage now present.

3. Apply 240 volts to coil terminals 1 and 3.
4. Using a VOM, check for 240 volts from terminals 3 and 1 of relay. Should read 240 volts. In no voltage, check wiring from heater kit to relay. If voltage present, proceed to step 5.
5. Using a VOM, check for 240 volts from L1 at contactor to terminal 4 of relay. Should read 240 volts. Next check from L1 at contactor to terminal 2 of relay. Should read 240 volts.

If not as above, replace relay.

On the 5 ton units with the EEM motor, a standard fan relay is used.

# SERVICING

 **WARNING**  
Line Voltage now present.

3. Apply 24 volts to coil terminals 1 and 3.
4. Using a VOM, check for 24 volts from terminals 3 and 2 of relay. Should read 24 volts. If no voltage, check low voltage wiring from transformer to relay. If voltage present, proceed to step 5.
5. Using a VOM, check for 24 volts from terminals 3 and 4 of relay. Should read 24 volts.

If not as above, replace relay.

## S-11 CHECKING LOSS OF CHARGE PROTECTOR


### *(Heat Pump Models)*


The loss of charge protector senses the pressure in the liquid line and will open its contacts on a drop in pressure. The low pressure control will automatically reset itself with a rise in pressure.

The low pressure control is designed to cut-out (open) at approximately 22 PSIG. It will automatically cut-in (close) at approximately 50 PSIG.

Test for continuity using a VOM and if not as above, replace the control.

## S-12 CHECKING HIGH PRESSURE CONTROL


 **WARNING**  
**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.




The high pressure control senses the pressure in the discharge line. If abnormally high discharge pressures develop, the contacts of the control open, breaking the control circuit before the compressor motor overloads. This control is automatically reset.

1. Using an ohmmeter, check across terminals of high pressure control, with wire removed. If not continuous, the contacts are open.
3. Attach a gauge to the access fitting on the liquid line.

With power ON:

 **WARNING**  
Line Voltage now present.

4. Start the system and place a piece of cardboard in front of the condenser coil, raising the condensing pressure.
5. Check pressure at which the high pressure control cuts-out.



If it cuts-out at  $660 \text{ PSIG} \pm 10 \text{ PSIG}$ , it is operating normally (See causes for high head pressure in Service Problem Analysis Guide). If it cuts out below this pressure range, replace the control. The control should reset at  $420 \text{ PSIG} \pm 25 \text{ PSIG}$ .

## S-13 CHECKING LOW PRESSURE CONTROL

The low pressure control senses the pressure in the suction line and will open its contacts on a drop in pressure. The low pressure control will automatically reset itself with a rise in pressure.

The low pressure control is designed to cut-out (open) at approximately  $22 \text{ PSIG} \pm 7 \text{ PSIG}$ . It will automatically cut-in (close) at approximately  $50 \text{ PSIG} \pm 7 \text{ PSIG}$ .

Test for continuity using a VOM and if not as above, replace the control.

# SERVICING

## S-15 CHECKING CAPACITOR

### **CAPACITOR, RUN**

A run capacitor is wired across the auxiliary and main windings of a single phase permanent split capacitor motor. The capacitor's primary function is to reduce the line current while greatly improving the torque characteristics of a motor. This is accomplished by using the 90° phase relationship between the capacitor current and voltage in conjunction with the motor windings so that the motor will give two phase operation when connected to a single phase circuit. The capacitor also reduces the line current to the motor by improving the power factor.

### **CAPACITOR, START**

#### **SCROLL COMPRESSOR MODELS**

Hard start components are not required on Scroll compressor equipped units due to a non-replaceable check valve located in the discharge line of the compressor. However hard start kits are available and may improve low voltage starting characteristics.

This check valve closes off high side pressure to the compressor after shut down allowing equalization through the scroll flanks. Equalization requires only about one or two seconds during which time the compressor may turn backwards.

Your unit comes with a 180-second anti-short cycle to prevent the compressor from starting and running backwards.

#### **MODELS EQUIPPED WITH A HARD START DEVICE**

A start capacitor is wired in parallel with the run capacitor to increase the starting torque. The start capacitor is of the electrolytic type, rather than metallized polypropylene as used in the run capacitor.

A switching device must be wired in series with the capacitor to remove it from the electrical circuit after the compressor starts to run. Not removing the start capacitor will overheat the capacitor and burn out the compressor windings.

These capacitors have a 15,000 ohm, 2 watt resistor wired across its terminals. The object of the resistor is to discharge the capacitor under certain operating conditions, rather than having it discharge across the closing of the contacts within the switching device such as the Start Relay, and to reduce the chance of shock to the servicer. See the Servicing Section for specific information concerning capacitors.

### **RELAY, START**


A potential or voltage type relay is used to take the start capacitor out of the circuit once the motor comes up to speed. This type of relay is position sensitive. The normally closed contacts are wired in series with the start capacitor and the relay holding coil is wired parallel with the start winding. As the motor starts and comes up to speed, the increase in voltage across the start winding will energize the start relay holding coil and open the contacts to the start capacitor.

Two quick ways to test a capacitor are a resistance and a capacitance check.

## S-15A RESISTANCE CHECK

**WARNING**


**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Discharge capacitor and remove wire leads.

**WARNING**

Discharge capacitor through a 20 to 30 OHM resistor before handling.




### **TESTING CAPACITOR RESISTANCE**

2. Set an ohmmeter on its highest ohm scale and connect the leads to the capacitor -
  - a. Good Condition - indicator swings to zero and slowly returns to infinity. (Start capacitor with bleed resistor will not return to infinity. It will still read the resistance of the resistor).
  - b. Shorted - indicator swings to zero and stops there -replace.
  - c. Open - no reading - replace. (Start capacitor would read resistor resistance.)

## S-15B CAPACITANCE CHECK

Using a hookup as shown below, take the amperage and voltage readings and use them in the formula:

# SERVICING



TESTING CAPACITANCE



## WARNING

Discharge capacitor through a 20 to 30 OHM resistor before handling.

$$\text{Capacitance (MFD)} = \frac{2650 \times \text{Amperage}}{\text{Voltage}}$$

## S-16 CHECKING MOTORS

### S-16D CHECKING EEM (ENERGY EFFICIENT MOTOR) MOTORS


Applies only to units with EEM Motors

The EEM Motor is a one piece, fully encapsulated, 3 phase brushless DC (single phase AC input) motor with ball bearing construction. Unlike the ECM 2.3/2.5 motors, the EEM features an integral control module.

**Note:** The GE TECMate will not currently operate the GE EEM motor.

1. Using a voltmeter, check for 230 volts to the motor connections L and N. If 230 volts is present, proceed to step 2. If 230 volts is not present, check the line voltage circuit to the motor.
2. Using a voltmeter, check for 24 volts from terminal C to either terminal 1, 2, 3, 4, or 5, depending on which tap is being used, at the motor. If voltage present, proceed to step 3. If no voltage, check 24 volt circuit to motor.
3. If voltage was present in steps 1 and 2, the motor has failed and will need to be replaced.

**Note:** When replacing motor, ensure the belly band is between the vents on the motor and the wiring has the proper drip loop to prevent condensate from entering the motor.



## S-17 CHECKING COMPRESSOR WINDINGS



## WARNING

Hermetic compressor electrical terminal venting can be dangerous. When insulating material which supports a hermetic compressor or electrical terminal suddenly disintegrates due to physical abuse or as a result of an electrical short between the terminal and the compressor housing, the terminal may be expelled, venting the vapor and liquid contents of the compressor housing and system.

If the compressor terminal PROTECTIVE COVER and gasket (if required) are not properly in place and secured, there is a remote possibility if a terminal vents, that the vaporous and liquid discharge can be ignited, spouting flames several feet, causing potentially severe or fatal injury to anyone in its path.

This discharge can be ignited external to the compressor if the terminal cover is not properly in place and if the discharge impinges on a sufficient heat source.

Ignition of the discharge can also occur at the venting terminal or inside the compressor, if there is sufficient contaminant air present in the system and an electrical arc occurs as the terminal vents.

Ignition cannot occur at the venting terminal without the presence of contaminant air, and cannot occur externally from the venting terminal without the presence of an external ignition source.

# SERVICING

Therefore, proper evacuation of a hermetic system is essential at the time of manufacture and during servicing.

To reduce the possibility of external ignition, all open flame, electrical power, and other heat sources should be extinguished or turned off prior to servicing a system.

## S-17A RESISTANCE TEST


Each compressor is equipped with an internal overload.

The line break internal overload senses both motor amperage and winding temperature. High motor temperature or amperage heats the disc causing it to open, breaking the common circuit within the compressor on single phase units.

Heat generated within the compressor shell, usually due to recycling of the motor, high amperage or insufficient gas to cool the motor, is slow to dissipate. Allow at least three to four hours for it to cool and reset, then retest.

**⚠ WARNING**

**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.




1. Remove the leads from the compressor terminals.

**⚠ WARNING**

See warnings S-17 before removing compressor terminal cover.

2. Using an ohmmeter, test continuity between terminals S-R, C-R, and C-S, on single phase units or terminals T1, T2 and T3, on 3 phase units.



### TESTING COMPRESSOR WINDINGS

If either winding does not test continuous, replace the compressor.

**NOTE:** If an open compressor is indicated, allow ample time for the internal overload to reset before replacing compressor.

## S-17B GROUND TEST

If fuse, circuit breaker, ground fault protective device, etc., has tripped, this is a strong indication that an electrical problem exists and must be found and corrected. The circuit protective device rating must be checked, and its maximum rating should coincide with that marked on the equipment nameplate.


With the terminal protective cover in place, it is acceptable to replace the fuse or reset the circuit breaker ONE TIME ONLY to see if it was just a nuisance opening. If it opens again, DO NOT continue to reset.

**⚠ WARNING**

Disconnect ALL power before servicing.

Disconnect all power to unit, making sure that all power legs are open.

1. DO NOT remove protective terminal cover. Disconnect the three leads going to the compressor terminals at the nearest point to the compressor.
2. Identify the leads and using a Megger, Hi-Potential Ground Tester, or other suitable instrument which puts out a voltage between 300 and 1500 volts, check for a ground separately between each of the three leads and ground (such as an unpainted tube on the compressor). Do not use a low voltage output instrument such as a volt-ohmmeter.



### COMPRESSOR GROUND TEST

3. If a ground is indicated, then carefully remove the compressor terminal protective cover and inspect for loose leads or insulation breaks in the lead wires.
4. If no visual problems indicated, carefully remove the leads at the compressor terminals.

**⚠ WARNING**

Damage can occur to the glass embedded terminals if the leads are not properly removed. This can result in terminal and hot oil discharging.

Carefully retest for ground, directly between compressor terminals and ground.


5. If ground is indicated, replace the compressor.



# SERVICING

## S-17D OPERATION TEST

If the voltage, capacitor, overload and motor winding test fail to show the cause for failure:




**WARNING**  
**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

1. Remove unit wiring from disconnect switch and wire a test cord to the disconnect switch.

**NOTE:** The wire size of the test cord must equal the line wire size and the fuse must be of the proper size and type.

2. With the protective terminal cover in place, use the three leads to the compressor terminals that were disconnected at the nearest point to the compressor and connect the common, start and run clips to the respective leads.
3. Connect good capacitors of the right MFD and voltage rating into the circuit as shown.
4. With power ON, close the switch.



**WARNING**  
Line Voltage now present.

- A. If the compressor starts and continues to run, the cause for failure is somewhere else in the system.
- B. If the compressor fails to start - replace.


## S-18 TESTING CRANKCASE HEATER (OPTIONAL ITEM)

**Note:** Not all compressors use crankcase heaters.

*The crankcase heater must be energized a minimum of twenty-four (24) hours before the compressor is operated.*

Crankcase heaters are used to prevent migration or accumulation of refrigerant in the compressor crankcase during the off cycles and prevents liquid slugging or oil pumping on start up. On some models, the crankcase heater is controlled by a crankcase heater thermostat that is wired in series with the crankcase heater.

*A crankcase heater will not prevent compressor damage due to a floodback or over charge condition.*



**WARNING**  
Disconnect ALL power before servicing.

1. Disconnect the heater lead in wires.
2. Using an ohmmeter, check heater continuity - should test continuous. If not, replace.

## S-18A CHECKING CRANKCASE HEATER THERMOSTAT

**Note:** Not all models with crankcase heaters will have a crankcase heater thermostat.

1. Install a thermocouple type temperature test lead on the discharge line adjacent to the crankcase heater thermostat.
2. Check the temperature at which the control closes its contacts by lowering the temperature of the control. The crankcase heater thermostat should close at 67°F ± 5°F.
3. Check the temperature at which the control opens its contacts by raising the temperature of the control. The crankcase heater thermostat should open at 85°F ± 5°F.
4. If not as above, replace control.

## S-21 CHECKING REVERSING VALVE AND SOLENOID

Occasionally the reversing valve may stick in the heating or cooling position or in the mid-position.

When stuck in the mid-position, part of the discharge gas from the compressor is directed back to the suction side, resulting in excessively high suction pressure. An increase in the suction line temperature through the reversing valve can also be measured. Check operation of the valve by starting the system and switching the operation from COOLING to HEATING cycle.

If the valve fails to change its position, test the voltage (24V) at the valve coil terminals, while the system is on the COOLING cycle.

If no voltage is registered at the coil terminals, check the operation of the thermostat and the continuity of the connecting wiring from the "O" terminal of the thermostat to the unit.

If voltage is registered at the coil, tap the valve body lightly while switching the system from HEATING to COOLING, etc. If this fails to cause the valve to switch positions, remove the coil connector cap and test the continuity of the reversing valve solenoid coil. If the coil does not test continuous - replace it.

If the coil test continuous and 24 volts is present at the coil terminals, the valve is inoperative - replace it.

## S-24 TESTING DEFROST CONTROL

To check the defrost control for proper sequencing, proceed as follows: With power ON; unit not running.

1. Jumper defrost thermostat by placing a jumper wire across the terminals "DFT" and "R" at defrost control board.
2. Connect jumper across test pins on defrost control board.
3. Set thermostat to call for heating. System should go into defrost within 21 seconds.

# SERVICING

4. Immediately remove jumper from test pins.
5. Using VOM check for voltage across terminals "C & O". Meter should read 24 volts.
6. Using VOM check for voltage across fan terminals DF1 and DF2 on the board. You should read line voltage (208-230 VAC) indicating the relay is open in the defrost mode.
7. Using VOM check for voltage across "W2 & C" terminals on the board. You should read 24 volts.
8. If not as above, replace control board.
9. Set thermostat to off position and disconnect power before removing any jumpers or wires.

NOTE: Remove jumper across defrost thermostat before returning system to service.

## S-25 TESTING DEFROST THERMOSTAT

1. Install a thermocouple type temperature test lead on the tube adjacent to the defrost control. Insulate the lead point of contact.
2. Check the temperature at which the control closes its contacts by lowering the temperature of the control. On 2 and 2.5 ton units, it should close at  $34^{\circ}\text{F} \pm 5^{\circ}\text{F}$ . On 3 thru 5 ton units, it should close at  $31^{\circ}\text{F} \pm 3^{\circ}\text{F}$ .
3. Check the temperature at which the control opens its contacts by raising the temperature of the control. On 2 and 2.5 ton units, it should open at  $60^{\circ}\text{F} \pm 5^{\circ}\text{F}$ . On 3 thru 5 ton units, it should open at  $75^{\circ}\text{F} \pm 6^{\circ}\text{F}$ .
4. If not as above, replace control.

## TROUBLESHOOTING

THE FOLLOWING INFORMATION IS FOR USE BY QUALIFIED SERVICE AGENCY ONLY: OTHERS SHOULD NOT ATTEMPT TO SERVICE THIS EQUIPMENT.

### Common Causes of Unsatisfactory Operation of Heat Pump on the Heating Cycle.

#### **INADEQUATE AIR VOLUME THROUGH INDOOR COIL**

When a heat pump is in the heating cycle, the indoor coil is functioning as a condenser. The return air filter must always be clean, and sufficient air volume must pass through the indoor coil to prevent excessive discharge pressure, and high pressure cut out.

#### **OUTSIDE AIR INTO RETURN DUCT**

Do not introduce cold outside air into the return duct of a heat pump installation. For units with 2-speed motors, do not allow air entering the indoor coil to drop below  $65^{\circ}\text{F}$ . Air below this temperature will cause low discharge pressure, thus low suction pressure, and excessive defrost cycling resulting in low heating output. It may also cause false defrosting.

### **UNDERCHARGE**

An undercharged heat pump on the heating cycle will cause low discharge pressure resulting in low suction pressure and frost accumulation on the outdoor coil.

### **POOR "TERMINATING" SENSOR CONTACT**

The unit's defrost terminating sensor must make good thermal contact with the outdoor coil tubing. Poor contact may not terminate the unit's defrost cycle quickly enough to prevent the unit from cutting out on high discharge pressure.

### **MALFUNCTIONING REVERSING VALVE - THIS MAY BE DUE TO:**

1. **Solenoid not energized** - In order to determine if the solenoid is energized, touch the nut that holds the solenoid cover in place with a screwdriver. If the nut magnetically holds the screwdriver, the solenoid is energized and the unit is in the cooling cycle.
2. **No voltage at unit's solenoid** - Check unit voltage. If no voltage, check wiring circuit.
3. **Valve will not shift:**
  - a. **Undercharged** - check for leaks;
  - b. **Valve Body Damaged** - Replace valve;
  - c. **Unit Properly Charged** - If it is on the heating cycle, raise the discharge pressure by restricting airflow through the indoor coil. If the valve does not shift, tap it **lightly** on both ends with a screwdriver handle. **DO NOT TAP THE VALVE BODY.** If the unit is on the cooling cycle, raise the discharge pressure by restricting airflow through the outdoor coil. If the valve does not shift after the above attempts, cut the unit off and wait until the discharge and suction pressure equalize, and repeat above steps. If the valve does not shift, replace it.

## S-50 CHECKING HEATER LIMIT CONTROL(S)

### **(OPTIONAL ELECTRIC HEATERS)**

Each individual heater element is protected with an automatic rest limit control connected in series with each element to prevent overheating of components in case of low airflow. This limit control will open its circuit at approximately  $150^{\circ}\text{F}$ . to  $160^{\circ}\text{F}$  and close at approximately  $110^{\circ}\text{F}$ .



### **WARNING**

**Disconnect ALL power before servicing.**

1. Remove the wiring from the control terminals.
2. Using an ohmmeter test for continuity across the normally closed contacts. No reading indicates the control is open - replace if necessary. Make sure the limits are cool before testing.

**IF FOUND OPEN - REPLACE - DO NOT WIRE AROUND.**


# SERVICING

## S-52 CHECKING HEATER ELEMENTS

Optional electric heaters may be added, in the quantities shown in the spec sheet for each model unit, to provide electric resistance heating. Under no condition shall more heaters than the quantity shown be installed.

**WARNING**

**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Disassemble and remove the heating element(s).
2. Visually inspect the heater assembly for any breaks in the wire or broken insulators.
3. Using an ohmmeter, test the element for continuity - no reading indicates the element is open. Replace as necessary.

## S-100 REFRIGERATION REPAIR PRACTICE

**DANGER**

Always remove the refrigerant charge in a proper manner before applying heat to the system.

When repairing the refrigeration system:

**WARNING**

Disconnect ALL power before servicing.

1. Never open a system that is under vacuum. Air and moisture will be drawn in.
2. Plug or cap all openings.
3. Remove all burrs and clean the brazing surfaces of the tubing with sand cloth or paper. Brazing materials do not flow well on oxidized or oily surfaces.
4. Clean the inside of all new tubing to remove oils and pipe chips.
5. When brazing, sweep the tubing with dry nitrogen to prevent the formation of oxides on the inside surfaces.
6. Complete any repair by replacing the liquid line drier in the system, evacuate and charge.

## BRAZING MATERIALS

**Copper to Copper Joints** - Sil-Fos used without flux (alloy of 15% silver, 80% copper, and 5% phosphorous). Recommended heat 1400°F.

**Copper to Steel Joints** - Silver Solder used without a flux (alloy of 30% silver, 38% copper, 32% zinc). Recommended heat - 1200°F.

## S-101 LEAK TESTING

### (NITROGEN OR NITROGEN-TRACED)

**WARNING**

To avoid the risk of fire or explosion, never use oxygen, high pressure air or flammable gases for leak testing of a refrigeration system.

**WARNING**

To avoid possible explosion, the line from the nitrogen cylinder must include a pressure regulator and a pressure relief valve. The pressure relief valve must be set to open at no more than 150 psig.

Pressure test the system using dry nitrogen and soapy water to locate leaks. If you wish to use a leak detector, charge the system to 10 psi using the appropriate refrigerant then use nitrogen to finish charging the system to working pressure, then apply the detector to suspect areas. If leaks are found, repair them. After repair, repeat the pressure test. If no leaks exist, proceed to system evacuation.

## S-102 EVACUATION

**WARNING**

**REFRIGERANT UNDER PRESSURE!**  
Failure to follow proper procedures may cause property damage, personal injury or death.

This is the most important part of the entire service procedure. The life and efficiency of the equipment is dependent upon the thoroughness exercised by the serviceman when evacuating air (non-condensables) and moisture from the system.

Air in a system causes high condensing temperature and pressure, resulting in increased power input and reduced performance.

Moisture chemically reacts with the refrigerant oil to form corrosive acids. These acids attack motor windings and parts, causing breakdown.

# SERVICING

The equipment required to thoroughly evacuate the system is a high vacuum pump, capable of producing a vacuum equivalent to 25 microns absolute and a thermocouple vacuum gauge to give a true reading of the vacuum in the system


**NOTE:** Never use the system compressor as a vacuum pump or run when under a high vacuum. Motor damage could occur.



## WARNING

**Do not front seat the service valve(s) with the compressor open, with the suction line of the compressor closed or severely restricted.**

1. Connect the vacuum pump, vacuum tight manifold set with high vacuum hoses, thermocouple vacuum gauge and charging cylinder as shown.
2. Start the vacuum pump and open the shut off valve to the high vacuum gauge manifold only. After the compound gauge (low side) has dropped to approximately 29 inches of vacuum, open the valve to the vacuum thermocouple gauge. See that the vacuum pump will blank-off to a maximum of 25 microns. A high vacuum pump can only produce a good vacuum if its oil is non-contaminated.



## EVACUATION

3. If the vacuum pump is working properly, close the valve to the vacuum thermocouple gauge and open the high and low side valves to the high vacuum manifold set. With the valve on the charging cylinder closed, open the manifold valve to the cylinder.
4. Evacuate the system to at least 29 inches gauge before opening valve to thermocouple vacuum gauge.
5. Continue to evacuate to a maximum of 250 microns. Close valve to vacuum pump and watch rate of rise. If vacuum does not rise above 1500 microns in three to five minutes, system can be considered properly evacuated.

6. If thermocouple vacuum gauge continues to rise and levels off at about 5000 microns, moisture and non-condensables are still present. If gauge continues to rise a leak is present. Repair and re-evacuate.
7. Close valve to thermocouple vacuum gauge and vacuum pump. Shut off pump and prepare to charge.

## S-103 CHARGING



## WARNING

**REFRIGERANT UNDER PRESSURE!**

- \* Do not overcharge system with refrigerant.
  - \* Do not operate unit in a vacuum or at negative pressure.
- Failure to follow proper procedures may cause property damage, personal injury or death.**



## CAUTION

**Only use refrigerant certified to AHRI standards. Used refrigerant may cause compressor damage. The manufacturer is not responsible for damage or the need for repairs resulting from the use of unapproved refrigerant types or used or recycled refrigerant. Most portable machines cannot clean used refrigerant to meet AHRI standards.**

Charge the system with the exact amount of refrigerant.

Refer to the specification section or check the unit nameplates for the correct refrigerant charge.

**An inaccurately charged system will cause future problems.**

1. Using a quality set of charging scales, weigh the proper amount of refrigerant for the system. Allow liquid refrigerant only to enter the high side.
2. After the system will take all it will take, close the valve on the high side of the charging manifold.
3. Start the system and charge the balance of the refrigerant through the low side.

**NOTE:** R410A should be drawn out of the storage container or drum in liquid form due to its fractionation properties, but should be "Flashed" to its gas state before entering the system. There are commercially available restriction devices that fit into the system charging hose set to accomplish this. **DO NOT** charge liquid R410A into the compressor.

4. With the system still running, close the valve on the charging cylinder. At this time, you may still have some liquid refrigerant in the charging cylinder hose and will definitely have liquid in the liquid hose. Reseat the liquid line core. Slowly open the high side manifold valve and transfer the liquid refrigerant from the liquid line hose and charging cylinder hose into the suction service valve port. **CAREFUL:** Watch so that liquid refrigerant does not enter the compressor.

# SERVICING

## Final Charge Adjustment

The outdoor temperature must be 60°F or higher. Set the room thermostat to COOL, fan switch to AUTO, and set the temperature control well below room temperature.

After system has stabilized per startup instructions, compare the operating pressures and outdoor unit amp draw to the numbers listed in the technical manual. If pressures and amp draw are too low, add charge. If pressures and amp draw are too high, remove charge. Check subcooling and superheat as detailed in the following section.

5. With the system still running, remove hose and reinstall both valve caps.
6. Check system for leaks.

Due to their design, Scroll compressors are inherently more tolerant of liquid refrigerant.

**NOTE:** *Even though the compressor section of a Scroll compressor is more tolerant of liquid refrigerant, continued floodback or flooded start conditions may wash oil from the bearing surfaces causing premature bearing failure.* S-104 CHECKING COMPRESSOR EFFICIENCY

The reason for compressor inefficiency is broken or damaged suction and/or discharge valves, or scroll flanks on Scroll compressors, reducing the ability of the compressor to pump refrigerant vapor.

The condition of the valves or scroll flanks is checked in the following manner.

1. Attach gauges to the high and low side of the system.
2. Start the system and run a Cooling Performance Test.

If the test shows-

- ⇒ Below normal high side pressure.
- ⇒ Above normal low side pressure.
- ⇒ Low temperature difference across coil.
- ⇒ Low amp draw at compressor.

-and the charge is correct. The compressor is faulty - replace the compressor.

## S-104 CHECKING COMPRESSOR EFFICIENCY

The reason for compressor inefficiency is broken or damaged scroll flanks on Scroll compressors, reducing the ability of the compressor to pump refrigerant vapor.

During the "OFF" cycle, the high side pressure bleeds to the low side through the fixed orifice restriction device. Check equalization time as follows:

1. Attach a gauge manifold to the suction and liquid line dill valves.
2. Start the system and allow the pressures to stabilize.
3. Stop the system and check the time it takes for the high and low pressure gauge readings to equalize.

If it takes more than seven (7) minutes to equalize, the restrictor device is inoperative. Replace, install a liquid line drier, evacuate and recharge.

## S-106 OVERFEEDING

Overfeeding by the expansion valve results in high suction pressure, cold suction line, and possible liquid slugging of the compressor.

If these symptoms are observed:

1. Check for an overcharged unit by referring to the cooling performance charts in the technical manual.
2. Check the operation of the power element in the valve as explained in S-110 Checking Expansion Valve Operation.
3. Check for restricted or plugged equalizer tube.

## S-108 SUPERHEAT

### CHECKING SUPERHEAT

Refrigerant gas is considered superheated when its temperature is higher than the saturation temperature corresponding to its pressure. The degree of superheat equals the degrees of temperature increase above the saturation temperature at existing pressure. See Temperature - Pressure Chart .



## CAUTION

**To prevent personal injury, carefully connect and disconnect manifold gauge hoses. Escaping liquid refrigerant can cause burns. Do not vent refrigerant to atmosphere. Recover during system repair or final unit disposal.**

1. Run system at least 10 minutes to allow pressure to stabilize.
2. Temporarily install thermometer on suction (large) line near compressor with adequate contact and insulate for best possible reading.
3. Refer to the superheat table provided for proper system superheat. Add charge to lower superheat or recover charge to raise superheat.

# SERVICING

Pressure vs. Temperature Chart													
R-410A													
PSIG	°F	PSIG	°F	PSIG	°F	PSIG	°F	PSIG	°F	PSIG	°F	PSIG	°F
12	-37.7	114.0	37.8	216.0	74.3	318.0	100.2	420.0	120.7	522.0	137.6		
14	-34.7	116.0	38.7	218.0	74.9	320.0	100.7	422.0	121.0	524.0	137.9		
16	-32.0	118.0	39.5	220.0	75.5	322.0	101.1	424.0	121.4	526.0	138.3		
18	-29.4	120.0	40.5	222.0	76.1	324.0	101.6	426.0	121.7	528.0	138.6		
20	-36.9	122.0	41.3	224.0	76.7	326.0	102.0	428.0	122.1	530.0	138.9		
22	-24.5	124.0	42.2	226.0	77.2	328.0	102.4	430.0	122.5	532.0	139.2		
24	-22.2	126.0	43.0	228.0	77.8	330.0	102.9	432.0	122.8	534.0	139.5		
26	-20.0	128.0	43.8	230.0	78.4	332.0	103.3	434.0	123.2	536.0	139.8		
28	-17.9	130.0	44.7	232.0	78.9	334.0	103.7	436.0	123.5	538.0	140.1		
30	-15.8	132.0	45.5	234.0	79.5	336.0	104.2	438.0	123.9	540.0	140.4		
32	-13.8	134.0	46.3	236.0	80.0	338.0	104.6	440.0	124.2	544.0	141.0		
34	-11.9	136.0	47.1	238.0	80.6	340.0	105.1	442.0	124.6	548.0	141.6		
36	-10.1	138.0	47.9	240.0	81.1	342.0	105.4	444.0	124.9	552.0	142.1		
38	-8.3	140.0	48.7	242.0	81.6	344.0	105.8	446.0	125.3	556.0	142.7		
40	-6.5	142.0	49.5	244.0	82.2	346.0	106.3	448.0	125.6	560.0	143.3		
42	-4.5	144.0	50.3	246.0	82.7	348.0	106.6	450.0	126.0	564.0	143.9		
44	-3.2	146.0	51.1	248.0	83.3	350.0	107.1	452.0	126.3	568.0	144.5		
46	-1.6	148.0	51.8	250.0	83.8	352.0	107.5	454.0	126.6	572.0	145.0		
48	0.0	150.0	52.5	252.0	84.3	354.0	107.9	456.0	127.0	576.0	145.6		
50	1.5	152.0	53.3	254.0	84.8	356.0	108.3	458.0	127.3	580.0	146.2		
52	3.0	154.0	54.0	256.0	85.4	358.0	108.8	460.0	127.7	584.0	146.7		
54	4.5	156.0	54.8	258.0	85.9	360.0	109.2	462.0	128.0	588.0	147.3		
56	5.9	158.0	55.5	260.0	86.4	362.0	109.6	464.0	128.3	592.0	147.9		
58	7.3	160.0	56.2	262.0	86.9	364.0	110.0	466.0	128.7	596.0	148.4		
60	8.6	162.0	57.0	264.0	87.4	366.0	110.4	468.0	129.0	600.0	149.0		
62	10.0	164.0	57.7	266.0	87.9	368.0	110.8	470.0	129.3	604.0	149.5		
64	11.3	166.0	58.4	268.0	88.4	370.0	111.2	472.0	129.7	608.0	150.1		
66	12.6	168.0	59.0	270.0	88.9	372.0	111.6	474.0	130.0	612.0	150.6		
68	13.8	170.0	59.8	272.0	89.4	374.0	112.0	476.0	130.3	616.0	151.2		
70	15.1	172.0	60.5	274.0	89.9	376.0	112.4	478.0	130.7	620.0	151.7		
72	16.3	174.0	61.1	276.0	90.4	378.0	112.6	480.0	131.0	624.0	152.3		
74	17.5	176.0	61.8	278.0	90.9	380.0	113.1	482.0	131.3	628.0	152.8		
76	18.7	178.0	62.5	280.0	91.4	382.0	113.5	484.0	131.6	632.0	153.4		
78	19.8	180.0	63.1	282.0	91.9	384.0	113.9	486.0	132.0	636.0	153.9		
80	21.0	182.0	63.8	284.0	92.4	386.0	114.3	488.0	132.3	640.0	154.5		
82	22.1	184.0	64.5	286.0	92.8	388.0	114.7	490.0	132.6	644.0	155.0		
84	23.2	186.0	65.1	288.0	93.3	390.0	115.0	492.0	132.9	648.0	155.5		
86	24.3	188.0	65.8	290.0	93.8	392.0	115.5	494.0	133.3	652.0	156.1		
88	25.4	190.0	66.4	292.0	94.3	394.0	115.8	496.0	133.6	656.0	156.6		
90	26.4	192.0	67.0	294.0	94.8	396.0	116.2	498.0	133.9	660.0	157.1		
92	27.4	194.0	67.7	296.0	95.2	398.0	116.6	500.0	134.0	664.0	157.7		
94	28.5	196.0	68.3	298.0	95.7	400.0	117.0	502.0	134.5	668.0	158.2		
96	29.5	198.0	68.9	300.0	96.2	402.0	117.3	504.0	134.8	672.0	158.7		
98	30.5	200.0	69.5	302.0	96.6	404.0	117.7	506.0	135.2	676.0	159.2		
100	31.2	202.0	70.1	304.0	97.1	406.0	118.1	508.0	135.5	680.0	159.8		
102	32.2	204.0	70.7	306.0	97.5	408.0	118.5	510.0	135.8	684.0	160.3		
104	33.2	206.0	71.4	308.0	98.0	410.0	118.8	512.0	136.1	688.0	160.8		
106	34.1	208.0	72.0	310.0	98.4	412.0	119.2	514.0	136.4	692.0	161.3		
108	35.1	210.0	72.6	312.0	98.9	414.0	119.6	516.0	136.7	696.0	161.8		
110	35.5	212.0	73.2	314.0	99.3	416.0	119.9	518.0	137.0				
112	36.9	214.0	73.8	316.0	99.7	418.0	120.3	520.0	137.3				

\*Based on ALLIED SIGNAL Data

# SERVICING

Superheat Formula = Suct. Line Temp. - Sat. Suct. Temp.

Ambient Condenser Inlet Temp (°F Drybulb)	Return Air Temp. (°F Drybulb)				
	65	70	75	80	85
100	---	---	---	10	10
95	---	---	10	10	10
90	---	---	12	15	18
85	---	10	13	17	20
80	---	10	15	21	26
75	10	13	17	25	29
70	10	17	20	28	32
65	13	19	26	32	35
60	17	25	30	33	37

## SYSTEM SUPERHEAT

### EXAMPLE:

- Suction Pressure = 143
- Corresponding Temp. °F. = 50
- Thermometer on Suction Line = 59°F.

To obtain the degrees temperature of superheat, subtract 50.0 from 59.0°F.

The difference is 9° Superheat. The 9° Superheat would fall in the ± range of allowable superheat.

### S-111 FIXED ORIFICE RESTRICTION DEVICES

The fixed orifice restriction device (flowrator) used in conjunction with the indoor coil is a predetermined bore (I.D.).

It is designed to control the rate of liquid refrigerant flow into an evaporator coil.

The amount of refrigerant that flows through the fixed orifice restriction device is regulated by the pressure difference between the high and low sides of the system.

In the cooling cycle when the outdoor air temperature rises, the high side condensing pressure rises. At the same time, the cooling load on the indoor coil increases, causing the low side pressure to rise, but at a slower rate.

Since the high side pressure rises faster when the temperature increases, more refrigerant flows to the evaporator, increasing the cooling capacity of the system.

When the outdoor temperature falls, the reverse takes place. The condensing pressure falls, and the cooling loads on the indoor coil decreases, causing less refrigerant flow.

If a restriction should become evident, proceed as follows:

- Recover refrigerant charge.
- Remove the orifice assembly and clean or replace.
- Replace liquid line drier, evacuate and recharge.

### CHECKING EQUALIZATION TIME

During the "OFF" cycle, the high side pressure bleeds to the low side through the fixed orifice restriction device. Check equalization time as follows:

- Attach a gauge manifold to the suction and liquid line dill valves

- Start the system and allow the pressures to stabilize.
- Stop the system and check the time it takes for the high and low pressure gauge readings to equalize.

If it takes more than seven (7) minutes to equalize, the restriction device is inoperative. Replace, install a liquid line drier, evacuate and recharge.

### S-112 CHECKING RESTRICTED LIQUID LINE

When the system is operating, the liquid line is warm to the touch. If the liquid line is restricted, a definite temperature drop will be noticed at the point of restriction. In severe cases, frost will form at the restriction and extend down the line in the direction of the flow.

Discharge and suction pressures will be low, giving the appearance of an undercharged unit. However, the unit will have normal to high subcooling.

Locate the restriction, replace the restricted part, replace drier, evacuate and recharge.

### S-113 OVERCHARGE OF REFRIGERANT

An overcharge of refrigerant is normally indicated by an excessively high head pressure.

An evaporator coil, using an expansion valve metering device, will basically modulate and control a flooded evaporator and prevent liquid refrigerant return to the compressor.

An evaporator coil, using a fixed orifice restrictor device (flowrator) metering device, could allow liquid refrigerant to return to the compressor under extreme overcharge conditions.

Also with a fixed orifice restrictor device (flowrator) metering device, extreme cases of insufficient indoor air can cause icing of the indoor coil and liquid refrigerant return to the compressor, but the head pressure would be lower.

There are other causes for high head pressure which may be found in the "Service Problem Analysis Guide."

If other causes check out normal, an overcharge or a system containing non-condensables would be indicated.

If this system is observed:

- Start the system.
- Remove and capture small quantities of refrigerant as from the suction line access fitting until the head pressure is reduced to normal.
- Observe the system while running a cooling performance test. If a shortage of refrigerant is indicated, then the system contains non-condensables.

### S-114 NON-CONDENSABLES

If non-condensables are suspected, shut down the system and allow the pressures to equalize. Wait at least 15 minutes. Compare the pressure to the temperature of the coldest coil since this is where most of the refrigerant will be. If the pressure indicates a higher temperature than that of the coil temperature, non-condensables are present.

# SERVICING

Non-condensables are removed from the system by first removing the refrigerant charge, replacing and/or installing liquid line drier, evacuating and recharging.

## S-115 COMPRESSOR BURNOUT

When a compressor burns out, high temperature develops causing the refrigerant, oil and motor insulation to decompose forming acids and sludge.

If a compressor is suspected of being burned-out, attach a refrigerant hose to the liquid line dill valve and properly remove and dispose of the refrigerant.



### NOTICE

Violation of EPA regulations may result in fines or other penalties.

Now determine if a burn out has actually occurred. Confirm by analyzing an oil sample using a Sporlan Acid Test Kit, AK-3 or its equivalent.

Remove the compressor and obtain an oil sample from the suction stub. If the oil is not acidic, either a burnout has not occurred or the burnout is so mild that a complete clean-up is not necessary.

If acid level is unacceptable, the system must be cleaned by using the clean-up drier method.



### CAUTION

Do not allow the sludge or oil to contact the skin. Severe burns may result.

**NOTE:** Daikin does **NOT** approve the flushing method using R-11 refrigerant.

### Suction Line Drier Clean-Up Method

The POE oils used with R410A refrigerant is an excellent solvent. In the case of a burnout, the POE oils will remove any burnout residue left in the system. If not captured by the refrigerant filter, they will collect in the compressor or other system components, causing a failure of the replacement compressor and/or spread contaminants throughout the system, damaging additional components.

The suction line filter drier should be installed as close to the compressor suction fitting as possible. The filter must be accessible and be rechecked for a pressure drop after the system has operated for a time. It may be necessary to use new tubing and form as required.

**NOTE:** At least twelve (12) inches of the suction line immediately out of the compressor stub must be discarded due to burned residue and contaminates.

1. Remove the liquid line drier and expansion valve.
2. Purge all remaining components with dry nitrogen or carbon dioxide until clean.
3. Install new components **including** liquid line drier.

4. Braze all joints, leak test, evacuate, and recharge system.
5. Start up the unit and record the pressure drop across the drier.
6. Continue to run the system for a minimum of twelve (12) hours and recheck the pressure drop across the drier. Pressure drop should not exceed 6 PSIG.
7. Continue to run the system for several days, repeatedly checking pressure drop across the suction line drier. If the pressure drop never exceeds the 6 PSIG, the drier has trapped the contaminants. Remove the suction line drier from the system.
8. If the pressure drop becomes greater, then it must be replaced and steps 5 through 9 repeated until it does not exceed 6 PSIG.


**NOTICE:** Regardless, the cause for burnout must be determined and corrected before the new compressor is started.

## S-200 CHECKING EXTERNAL STATIC PRESSURE

The minimum and maximum allowable duct static pressure is found in the Technical Information Manual.

Too great of an external static pressure will result in insufficient air that can cause icing of the coil, whereas too much air can cause poor humidity control, and condensate to be pulled off the evaporator coil causing condensate leakage. Too much air can cause motor overloading and in many cases this constitutes a poorly designed system. To determine proper air movement, proceed as follows:

1. Using a draft gauge (inclined manometer) measure the static pressure of the return duct at the inlet of the unit, (Negative Pressure).



**TOTAL EXTERNAL STATIC**



# SERVICING

2. Measure the static pressure of the supply duct, (Positive Pressure).
3. Add the two readings together.

**NOTE:** Both readings may be taken simultaneously and read directly on the manometer if so desired.

4. Consult proper table for quantity of air.

If the external static pressure exceeds the minimum or maximum allowable statics, check for closed dampers, dirty filters, undersized or poorly laid out ductwork.


## S-201 CHECKING TEMPERATURE RISE

Temperature rise is related to the BTUH output of the unit and the amount of air (CFM) circulated over the heat exchanger.

All units are designed for a given range of temperature increase. This is the temperature of the air leaving the unit minus the temperature of the air entering the unit.

The more air (CFM) being delivered through a given unit the less the rise will be; so the less air (CFM) being delivered, the greater the rise. The temperature rise should be adjusted in accordance to a given unit specifications and its external static pressure.


1. Check BTUH input to unit do not exceed input rating stamped on rating plate.
2. Take entering and leaving air temperatures.
3. Select the proper speed tap or dip switch setting for direct drive units.
4. For gas heat units, the airflow must be adjusted so that the air temperature rise falls within the ranges given stated on Data Plate by adjusting the variable pitch sheave on the motor (see Blower Performance section in appropriate Technical Manual for correct pulley adjustment).
5. Take motor amperage draw to determine that the motor is not overloaded during adjustments.



**CHECKING TEMPERATURE RISE**

## S-300 TESTING PRIMARY LIMIT CONTROL

DTG units use a snap-disk type primary limit device. Sometimes referred to as "stat on a stick". The limit setting is fixed and must not be readjusted in the field.



### TESTING PRIMARY LIMIT CONTROL

Refer to the specification section to determine the proper limit cutout temperature for the model being serviced.

In all instances the limit control is wired in series with the ignition control.

If the temperature within the furnace should exceed this setting, the control will open, de-energizing the ignition control which in turn will open the electrical circuit to the gas valve.

The control will automatically reset when the temperature within the combustion chamber is sufficiently lowered.

**⚠ WARNING**

**HIGH VOLTAGE!**  
 Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

1. Remove electrical power to unit. Some units may have more than one source of power.
2. Remove the wires from the limit control terminals.
3. Using an ohmmeter, test for continuity across the two terminals.
4. If limit test open allow unit to cool and retest.
5. If still open, replace the control.


# SERVICING

## S-301 TESTING AUXILIARY LIMIT

The auxiliary limit control is a preset nonadjustable control mounted in the blower compartment area.


It is connected in series with the rollout switch wiring to the gas valve. If its temperature should be exceeded, it will open, interrupting the voltage to the gas valve causing it to open.

An additional limit (primary limit) control is required for safety control of high temperature within the furnace or ductwork.




**⚠ WARNING**

**HIGH VOLTAGE!**  
 Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Remove the wires from the auxiliary limit control terminals.
2. Using an ohmmeter, test for continuity across the two terminals. No reading indicates the control is open. Push the red reset button, test again - if still open, replace the control.
3. If limit tests open, allow unit to cool and retest.
4. If still open, replace the control.




**TESTING AUXILIARY LIMIT CONTROL**

## S-302 CHECKING FLAME ROLLOUT SWITCH

DTG units are equipped with a temperature-activated manual reset control. This control is mounted to the manifold assembly and is wired in series with the auxiliary limit and gas valve. The control is designed to open should a flame roll out occur. An over firing condition or flame impingement on the heat shield can also cause the control to open.

If the rollout control has opened, the circuit between the ignition control and gas valve will be interrupted and the ignition control module will go into lockout. The servicer should reset the ignition control by opening and closing the thermostat circuit. The servicer should look for the ignitor glowing which indicates there is power to the ignition control. The servicer should measure the voltage between each side of the rollout control and ground while the ignition control is try to power the gas valve.



## CHECKING FLAME ROLLOUT SWITCH

*Limit Switch Operation (Applies to Primary, Auxiliary, and Roll Out Limits) DSI systems.*

# SERVICING

If a limit switch opens, the indoor blower is energized on heat speed and the induced draft blower is energized. The LED on the control flashes "4" to indicate an open limit switch. The blower and inducer remain on while the limit switch is open. The gas valve is de-energized. Power to the thermostat "R" is removed while the limit switch is open.

When the limit switch re-closes, the induced draft motor runs through its post purge and the indoor blower goes through the heat off delay.

If a call for heat exists when the limit switch re-closes, the control goes through a pre-purge period and then makes an ignition attempt. The indoor blower remains on (for the delay off time) during the re-ignition attempt.

1. If no voltage is measured on either side of control indicates ignition control or wiring to control problem.
2. If voltage is measured on one side of the control and not the other, it indicates the control is open.
3. If voltage is measured on both sides of the control the wiring to gas valve or valve is at fault.

### **Service procedure with furnace not firing.**

1. Confirm that the outer door was in place and all screws tightened. (No leaks under the door.)
2. Check to see if any damage was done to the furnace especially the wiring.
3. Confirm that heat exchanger is not obstructed by feeling for discharge air from the flue hood when the combustion blower is running but the unit is not firing.

If the above steps do not suggest the reason the control has tripped the furnace should be fired.

1. Remove the heating compartment door.
2. Turn off the power or open the thermostat circuit.
3. Reset the rollout control.
4. Turn power on and put the unit into a call for heating.



## CAUTION

**Flame rollout could occur. Keep face and hands a safe distance from burner area.**

5. Look under the heat shield as the unit is running. Flames should be drawn into firing tubes.
  - a. If only one burner's flame is not drawn into the tube, that tube is restricted.
  - b. If, without the air circulation blower running, all flames are not drawn into the tubes either the collector box, combustion blower, or flue outlet is obstructed. If the combustion blower or flue outlet is obstructed, the pressure switch should have opened preventing the unit from firing, also inspect the unit pressure switch and wiring.
  - c. If the burner flame is not drawn into the tube only when the air circulation blower is running, then a cracked heat exchanger tube is present.

## S-303 TESTING INDUCER MOTOR



## WARNING

### HIGH VOLTAGE!

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Disconnect the motor wire leads from its connection point at integrated ignition control module.
  2. Using an ohmmeter, test for continuity between each of the motor leads.
  3. Touch one probe of the ohmmeter to the motor frame (ground) and the other probe in turn to each lead.
- If the windings do not test continuous or a reading is obtained to ground, replace the motor.
4. After completing check and/or replacement of induced draft blower motor.
  5. Turn on electrical power and verify proper unit operation.

## S-304 TESTING GAS VALVE

### *Direct Spark Ignition (DSI) Systems*

**TWO STAGE MODELS ONLY:** A two-stage combination redundant operator type gas valve which provides all manual and automatic control functions required for gas fired heating equipment is used.

The valve provides control of main burner gas flow, pressure regulation, and 100 percent safety shut-off.



## WARNING


### HIGH VOLTAGE!

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.




1. Ensure gas valve and main gas supply are on.
2. Using a voltmeter, check from C and M on gas valve for 24 volts to gas valve.
3. If 24 volts are present and no gas flows through the valve, replace valve.

# SERVICING




**36G22**

*For use with DTG036045 ONLY.*



**36H54**




**Honeywell VR81215 Single Stage**


## S-305 CHECKING MAIN BURNERS

The main burners are used to provide complete combustion of various fuels in a limited space, and transfer this heat of the burning process to the heat exchanger.

Proper ignition, combustion, and extinction are primarily due to burner design, orifice sizing, gas pressure, primary and secondary air, vent and proper seating of burners.



**BECKETT BURNER**



**36G54**

*For use with all 3-5 ton BA revision models except DTG036045.*


**WARNING**  
Disconnect gas and electrical power supply.

In checking main burners, look for signs of rust, oversized and undersized carry-over ports restricted with foreign material, etc.

## S-306 CHECKING ORIFICES

A predetermined fixed gas orifice is used in all of these furnaces. That is an orifice which has a fixed bore and position.

# SERVICING



The length of Dimension "A" determines the angle of Gas Stream Defraction, "B".

A dent or burr will cause severe deflection of gas stream.

No resizing should be attempted until all factors are taken into consideration such as inlet manifold gas pressure, alignment, and positioning, specific gravity and BTU content of the gas being consumed.

The only time resizing is required is when a reduction in firing rate is required for an increase in altitude.

Orifices should be treated with care in order to prevent damage. They should be removed and installed with a box-end wrench in order to prevent distortion. In no instance should an orifice be peened over and redrilled. This will change the angle or deflection of the vacuum effect or entraining of primary air, which will make it difficult to adjust the flame properly. This same problem can occur if an orifice spud of a different length is substituted.

**! WARNING**  
Disconnect gas and electrical power supply.


1. Check orifice visually for distortion and/or burrs.
2. Check orifice size with orifice sizing drills.
3. If resizing is required, a new orifice of the same physical size and angle with proper drill size opening should be installed.

## S-307 CHECKING GAS PRESSURE


Gas inlet and manifold pressures should be checked and adjusted in accordance to the type of fuel being consumed.

**! WARNING**  
Disconnect gas and electrical power supply.

1. Connect a water manometer or adequate gauge to the inlet pressure fitting of the gas valve.
2. Remove the pressure tap fitting at the manifold if provided or check at the gas valve outlet fitting and connect another manometer or gauge.




## Single Stage 36G22



## Honeywell VR81215 Single Stage

### MEASURING INLET AND MANIFOLD GAS PRESSURE

# SERVICING



## TWO-STAGE H VALVE

### MEASURING INLET AND MANIFOLD GAS PRESSURE

With Power ON:

**⚠ WARNING**  
Line Voltage now present.

- Put unit into heating cycle and turn on all other gas consuming appliances.

#### SINGLE STAGE MODELS

For **NATURAL GAS**:

- Inlet pressure should be a nominal 7" w.c.
- Manifold pressure for single stage heat models and 2 stage heat models on low stage should be 2.0" w.c. ± .3"w.c.
- Manifold pressure for single stage heat models and 2 stage heat models on high stage should be 3.5" ± .3"w.c.

For **PROPANE GAS**:

- Inlet pressure should be a nominal 11" w.c.
- Manifold pressure for 2 stage heating models on low stage should be 6" w.c.
- Manifold pressure for single stage heat models and 2 stage heat models on high stage should be 10" w.c.

## MANIFOLD GAS PRESSURE

### 2 Stage Heat Models

Gas		Range	Nominal
Natural	Low Stage	1.6 - 2.2" w.c.	2.0" w.c.
	High Stage	3.2 - 3.8" w.c.	3.5" w.c.
Propane	Low Stage	5.7 - 6.3" w.c.	6.0" w.c.
	High Stage	9.7 - 10.3" w.c.	10.0" w.c.

### Single Stage Heat Models

Gas		Range	Nominal
Natural	Single Stage	3.2 - 3.8" w.c.	3.5" w.c.
Propane	Single Stage	9.7 - 10.3" w.c.	10.0" w.c.

If operating pressures differ from chart, make necessary pressure regulator adjustments, check piping size, etc., and/or consult with local utility.

## S-308 CHECKING FOR DELAYED IGNITION

Delayed ignition is a delay in lighting a combustible mixture of gas and air which has accumulated in the combustion chamber.

When the mixture does ignite, it may explode and/or rollout causing burning in the burner venturi.

If delayed ignition should occur, the following should be checked:

- Improper gas pressure - adjust to proper pressure. (See S-307)
- Improper burner positioning - burners should be in locating slots, level front to rear and left to right.
- Carry over (lighter tube or cross lighter) obstructed - clean.
- Main burner orifice(s) deformed, or out of alignment to burner - replace.

## S-309 CHECKING FOR FLASHBACK

Flashback will also cause burning in the burner venturi, but is caused by the burning speed being greater than the gas-air flow velocity coming from a burner port.

Flashback may occur at the moment of ignition, after a burner heats up or when the burner turns off. The latter is known as extinction pop.

Since the end results of flashback and delayed ignition can be the same (burning in the burner venturi) a definite attempt should be made to determine which has occurred.

If flashback should occur, check for the following:

- Improper gas pressure - adjust to proper pressure. See S-307.
- Check burner for proper alignment and/or replace burner.
- Improper orifice size - check orifice for obstruction.

# SERVICING

## S-310 CHECKING PRESSURE CONTROL

A pressure control device is used to measure negative pressure at the induced draft blower motor inlet to detect a partial or blocked flue.

### Pressure Switch Operation (DSI Direct Spark System)


The pressure switch is ignored unless there is a call for heat. When the control receives a call for heat, the control checks to see that the pressure switch is open. If the control sees that the pressure switch is closed before the induced draft blower is energized, the LED will flash a code of "2" (to indicate the pressure switch is stuck closed) and the inducer will remain off until the pressure switch opens.

If the pressure switch opens before the ignition period, the induced draft blower will remain on and the control will stay in pre-purge until the pressure switch is closed for an entire 15 second pre-purge period. The LED will flash a code of "3" to indicate open pressure switch.

If the pressure switch opens after the gas valve has been energized, the control will de-energize the gas valve and run the indoor blower through the heat off delay. The inducer stays on until the pressure switch re-closes. Then the control makes another ignition attempt.

**WARNING**


**HIGH VOLTAGE!**  
Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Remove wires from the electrical terminals.
2. Using a VOM check from Common to NO (Normally Open) - should read open.

If switch reads as noted proceed to Step 3, otherwise replace control.

3. Remove the pressure control hose from the control and interconnect with an inclined manometer as shown:



Reconnect wires to the Common and NO terminals.

With Power ON:

**WARNING**

Line Voltage now present.

4. Energize furnace for heating cycle. The induced draft blower motor will begin to run. The inclined manometer should read approximately  $-1.2" \pm 0.3"$  W.C with no combustion.
5. Remove and check the two electrical wires and using the VOM check from Common to NO (Normally Open), it should read closed (with I.D. motor running). If not as above, replace pressure control.
6. Reconnect all wires to the control and place in heating cycle.
7. As the unit fires on high stage, the inclined manometer negative pressure will drop to  $-0.9" \pm 0.3"$  W.C.
8. If not as listed, replace control.

**Note:** the pressure switch **must** be mounted with the diaphragm in a vertical position.

## S-311 HIGH ALTITUDE APPLICATION

**IMPORTANT NOTE:** The gas/electric units naturally derate with altitude. Do not attempt to increase the firing rate by changing orifices or increasing the manifold pressure. This can cause poor combustion and equipment failure. At all altitudes, the manifold pressure must be within 0.3 inches W.C. of that listed on the nameplate for the fuel used. At all altitudes and with either fuel, the air temperature rise must be within the range listed on the unit nameplate. Refer to the Installation Manual provided with the LP kit for conversion from natural gas to propane gas and for altitude adjustments.

When this package unit is installed at high altitude, the appropriate High Altitude orifice kit may be installed. As altitude increases, there is a natural reduction in the density of both the gas fuel and combustion air. This kit will provide the proper design certified input rate within the specified altitude range. High altitude kits are not approved for use in Canada. For installations above 2,000 feet, use kit HA-02. The HA-02 kit is used for both Natural and LP gas at high altitudes.

For DTG036045, use LPT-00A propane conversion kit for propane conversions at altitudes below 2000 feet. Natural gas installations below 2000 feet do not require a kit. For other revisions on 3, 4 and 5 ton models, use LPM-06.

For propane conversion above 2000 feet, high altitude kit HA-02 is required in addition to propane conversion kit LPT-00A or LPM-06.

# SERVICING

INPUT/BURNER	HIGH ALTITUDE KIT	20,000 BTUH NAT/20,000 BTUH/L.P.							
		ELEVATION ABOVE SEA-LEVEL (FEET)							
		2000	3000	4000	4500	5000	6000	7000	8000
U.S. BURNER ORIFICE	HA-02	45/55	47/55	47/56	-	47/56	48/57	48/58	49/58
CANADA BURNER ORIFICE		45/55	-	-	48/57	-	-	-	-

INPUT/BURNER	HIGH ALTITUDE KIT	22,500 BTUH NAT/20,000 BTUH/L.P.							
		ELEVATION ABOVE SEA-LEVEL (FEET)							
		2000	3000	4000	4500	5000	6000	7000	8000
U.S. BURNER ORIFICE	HA-02	44/55	44/55	45/56	-	45/56	46/57	47/58	47/58
CANADA BURNER ORIFICE		44/55	-	-	47/57	-	-	-	-

INPUT/BURNER	HIGH ALTITUDE KIT	25,000 BTUH NAT/20,000 BTUH/L.P.							
		ELEVATION ABOVE SEA-LEVEL (FEET)							
		2000	3000	4000	4500	5000	6000	7000	8000
U.S. BURNER ORIFICE	HA-02	43/55	43/55	44/56	-	44/56	44/56	45/57	45/57
CANADA BURNER ORIFICE		43/55	-	-	46/57	-	-	-	-

## S-313 TESTING IGNITION CONTROL MODULE

**NOTE:** Failure to earth ground the unit, reversing the neutral and hot wire connection to the line (polarity), or a high resistance connection in the ground or neutral lines may cause the control to lockout due to failure to detect flame.

### WARNING

**HIGH VOLTAGE**


Wiring to this unit must be properly polarized and grounded. Disconnect ALL power before installing or servicing this unit. Multiple power sources may be present.

The ground wire must run from the unit all the way back to the electrical panel. Proper grounding can be confirmed by disconnecting the electrical power and measuring resistance between the neutral (white) connection and the burner closest to the flame sensor. Resistance should be less than 10 ohms.

### DSI Direct Spark Ignition Systems

#### NORMAL SEQUENCE OF OPERATION (DSI Direct Spark Ignition System)

1. Thermostat calls for heat by energizing "W". The control checks the pressure switch for open condition. If the pressure switch is closed the control will flash code "3" and wait for the pressure switch to open.
2. The induced draft motor is energized and the control flashes code "2" and waits for the pressure switch to close. Once the pressure switch is closed, the LED stops flashing and the control begins timing the 15 second pre-purge.



### DSI Control Board

3. The control energizes the spark igniter and gas valve for 7 seconds. If flame is established, the control goes into a 30 second heat on delay.
4. The indoor blower is energized at the heat speed after a 30 second on delay.
5. The control monitors the safety circuit inputs, flame, and thermostat during operation.
6. When the thermostat is satisfied, the gas valve is de-energized and the induced draft blower remains on for a 29 second post purge. The indoor blower remains on for the selected heat blower off delay (90, 120, or 150 seconds). Indoor blower off timing begins when thermostat call for heat ends.

### Testing Direct Spark Ignition (DSI) systems

Thermostat calling for heat (15 second prepurge time and 7 second trial for ignition).

1. Check for 230 VAC from L1 terminal of control module to L2. No voltage - check wire connections, continuity, etc.
2. Check for 24 VAC at "R" to "C" thermostat terminals.
  - a. No voltage - check 3 amp automotive type fuse on control board. A blown fuse would indicate a short in the 24 VAC circuit (thermostat or limit circuit).
  - b. Voltage Present - check limit, auxiliary limit and rollout (S-300, S-301 and S-302). If limit, auxiliary limit and rollout are closed, then check for 24 VAC at the gas valve terminals.

No 24 VAC at gas valve - replace Control board.



# SERVICING

## TROUBLESHOOTING

### IGNITION CONTROL ERROR CODES

The following presents probable causes of questionable unit operation. Refer to *Diagnostic Indicator Chart* for an interpretation of the signal and to this section for an explanation.

Remove the control box access panel and note the number of diagnostic LED flashes. Refer to *Diagnostic Indicator Chart* for an interpretation of the signal and to this section for an explanation.

#### Internal Control Failure

If the integrated ignition control in this unit encounters an internal fault, it will go into a "hard" lockout and turn off the diagnostic LED. If diagnostic LED indicates an internal fault, check power supply to unit for proper voltage, check all fuses, circuit breakers and wiring. Disconnect electric power for five seconds. If LED remains off after restoring power, replace control.

### ABNORMAL OPERATION - HEATING CODES

#### External Lockout (1 FLASH CODE)

An external lockout occurs if the integrated ignition control determines that a measurable combustion cannot be established within three (3) consecutive ignition attempts. If flame is not established within the seven (7) second trial for ignition, the gas valve is deenergized, 15 second inter-purge cycle is completed, and ignition is reattempted. The control will repeat this routine three times if a measurable combustion is not established. The control will then shut off the induced draft blower and go into a lockout state.

If flame is established but lost, the control will energize the circulator blower at the heat speed and then begin a new ignition sequence. If flame is established then lost on subsequent attempts, the control will recycle for four (4) consecutive ignition attempts (five attempts total) before locking out.

The diagnostic fault code is 1 flash for a lockout due to failed ignition attempts or flame dropouts. The integrated control will automatically reset after one hour, or it can be reset by removing the thermostat signal or disconnecting the electrical power supply for over five seconds. If the diagnostic LED indicates an external lockout, perform the following checks:

- *Check the supply and manifold pressures*
- *Check the gas orifices for debris*
- *Check gas valve for proper operation*
- *Check secondary limit*

A dirty filter, excessive duct static, insufficient air flow, a faulty limit, or a failed circulator blower can cause this limit to open. Check filters, total external duct static, circulator blower motor, blower motor speed tap (see wiring diagram), and limit. An interruption in electrical power during a heating cycle may also cause the auxiliary limit to open. The automatic reset secondary limit is located on top of the circulator blower assembly.

- *Check rollout limit*

If the burner flames are not properly drawn into the heat exchanger, the flame rollout protection device will open. Possible causes are restricted or blocked flue passages, blocked or cracked heat exchanger, a failed induced draft blower, or insufficient combustion air. The rollout protection device is a manual reset limit located on the burner bracket. The cause of the flame rollout must be determined and corrected before resetting the limit.

- *Check flame sensor*

A drop in flame signal can be caused by nearly invisible coating on the sensor. Remove the sensor and carefully clean with steel wool.

- *Check wiring*

Check wiring for opens/shorts and miswiring.

**IMPORTANT:** If you have to frequently reset your gas/electric package unit, it means that a problem exists that should be corrected. Contact a qualified servicer for further information.

#### Pressure Switch Stuck Open (2 FLASH CODE)

A pressure switch stuck open can be caused by a faulty pressure switch, faulty wiring, a disconnected or damaged hose, a blocked or restricted flue, or a faulty induced draft blower. If the control senses an open pressure switch during the pre-purge cycle, the induced draft blower only will be energized.

If the pressure switch opens after ignition has begun the gas valve is deenergized, the circulator blower heat off cycle begins, and the induced draft blower remains on. The diagnostic fault code is two flashes.

#### Pressure Switch Stuck Closed (3 FLASH CODE)

A stuck closed pressure switch can be caused by a faulty pressure switch or faulty wiring. If the control encounters a pressure switch stuck closed, the induced draft blower remains off. The diagnostic LED code for this fault is three (3) flashes.

#### Open Thermal Protection Device (4 FLASH CODE)

If the primary limit switch opens, the gas valve is immediately deenergized, the induced draft and air circulating blowers are energized. The induced draft and air circulator blowers remain energized until the limit switch recloses. The diagnostic fault code for an open limit is four (4) flashes.

A primary limit will open due to excessive supply air temperatures. This can be caused by a dirty filter, excessive duct static, insufficient air flow, or a faulty limit. Check filters, total external duct static, blower motor, blower motor speed tap (see wiring diagram), and limit. This limit will automatically reset once the temperature falls below a preset level.

#### Flame Detected with Gas Valve Closed (5 FLASH CODE)

If flame is detected with the gas valve deenergized, the combustion and air circulator blowers are energized. The diagnostic fault code is five (5) flashes for this condition. The control can be reset by removing the power supply to the unit or it will automatically reset after one hour. Miswiring is the probable cause for this fault.

# SERVICING

## ABNORMAL OPERATION - COOLING CODES

### Short Cycle Compressor Delay (6 FLASH CODE)

The automatic ignition control has a built-in feature that prevents damage to the compressor in short cycling situations. In the event of intermittent power losses or intermittent thermostat operation, the ignition control will delay output to the compressor contactor for three minutes from the time power is restored. (Compressor is off a total of three minutes). The diagnostic LED will flash six (6) times to indicate the compressor contactor output is being delayed.

**NOTE:** Some electronic thermostats also have a built-in compressor short cycle timer that may be longer than the three minute delay given above. If you are using an electronic thermostat and the compressor has not started after three minutes, wait an additional five minutes to allow the thermostat to complete its short cycle delay time.

## S-314 CHECKING FLAME SENSOR

A flame sensing device is used in conjunction with the ignition control module to prove combustion. If a microamp signal is not present the control will de-energize the gas valve and "retry" for ignition or lockout.

### DSI Direct Spark Ignition Systems




#### WARNING

##### HIGH VOLTAGE!

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Disconnect the flame sensor wire from terminal FS of the ignition control module.



#### Flame Sensor

2. Connect a microamp meter in series with this wire and terminal FS.
3. Be sure the negative side of the meter is to the wire and the positive of the meter is to terminal FS.
4. Turn on Power.



#### WARNING

Line Voltage now present.

5. With Power ON, Place the unit into a heating cycle.
6. As soon as flame is established a microamp reading should be evident once proof of flame (microamp reading) is established, the hot surface ignitor will be de-energized.
7. The microamp reading should be 4 - 6 microamps.
8. If the microamp current is less than 0.5 microamp the control will lockout and flash a code of 1 flash after attempting to reestablish flame sense.
9. If the microamp reading is less than the minimum specified, check for high resistance wiring connections, the distance (3/16") between the sensor and burner, flame sensor connections, dirty flame sensor or poor grounding.
10. If no reading, check for continuity on all components and if good - replace ignition control module.

**NOTE: Contaminated fuel or combustion air can create a nearly invisible coating on the flame sensor. This coating works as an insulator causing a loss in the flame sense signal. If this situation occurs the flame sensor must be cleaned with steel wool. Do not use sand paper, the silicone in sand paper will further contaminate the sensor.**

# ACCESSORIES

DTC/G/H\*\*\*XXX\*\*XXX

DAIKIN COMMERCIAL PACKAGE UNIT ACCESSORIES		
Accessory Number	Description	Model Size
***HSKT036*	High Static Kits	3 Ton
***HSKT048*	High Static Kits	4 Ton
***HSKT060*	High Static Kits	5 Ton
**EHK*	Heater Kits	3-5 Ton
14CURB3672B	Roof Curb 14" Tall	3-5 Ton
14CURB3672BNP	Roof Curb 14" Tall No Insulated Panels	3-5 Ton
36DROP3672B	Supply and Return Drop	3-5 Ton
CDK36	Concentric Duct Kit	3 Ton
CDK36515	Flush Mount Concentric Duct Kit w/ Filter	3 Ton
CDK36530	Step Down Concentric Duct Kit	3 Ton
CDK36535	Step Down Concentric Duct Kit w/ Filter	3 Ton
CDK4872	Concentric Duct Kit	4-5 Ton
CDK4872515	Flush Mount Concentric Duct Kit w/ Filter	4-5 Ton
CDK4872530	Step Down Concentric Duct Kit	4-5 Ton
CDK4872535	Step Down Concentric Duct Kit w/ Filter	4-5 Ton
D25FD3672	25% Manual Fresh Air Damper	3-5 Ton
D25MFD3672	25% Motorized Fresh Air Damper	3-5 Ton
DBRD3672	Daikin Barometric Relief Damper	3-5 Ton
DDNECNJ3672B <sup>1</sup>	Downflow Jade Economizer All Fuels (MCCDANIEL METALS)	3-5 Ton
DDNECNJ3672NR <sup>1</sup>	Downflow Jade Economizer All Fuels (No Barometric Relief) (MCCDANIEL METALS)	3-5 Ton
1036609B <sup>2</sup>	Downflow Economizer (ROOFTOP SYSTEMS)	3-5 Ton
10366D09C <sup>2</sup>	Downflow Economizer (for models with DDC Control) (ROOFTOP SYSTEMS)	3-5 Ton
DDNSQRD3616	Downflow Square to Round Adapter (16" Round)	3 Ton
DDNSQRD487218	Downflow Square to Round Adapter (18" Round)	4-5 Ton
DHZEENJ3672	Horizontal Jade Economizer All Fuels	3-5 Ton
10396D09	Horizontal Economizer (for models with DDC Control)	3-5 Ton
DNBBS3672	Burglar Bar Sleeves Includes Supply and Return	3-5 Ton
DPE36722	Power Exhaust (208/230v)	3-5 Ton
DPE36724	Power Exhaust (460v)	3-5 Ton
DPE36727	Power Exhaust (575v)	3-5 Ton
3PMK01	3-Phase Monitor (for models with DDC Control)	3-5 Ton
3PMNDK01	3-Phase Monitor (Non-DDC Control models)	3-5 Ton
DFSKT01	Dirty Filter Kit (for models with DDC Control)	3-5 Ton
FSK01A	Freeze Stat Kit	All Models
GFCI	Convenience Outlet	3-5 Ton
GHRC-1	Hurricane/Seismic Clips	All Models
HAKT36300	High Altitude Kit	3-5 Ton
HAILGD03D	Hail Guard Kit	3-4 Ton
HAILGD04D	Hail Guard Kit	5 Ton
IP3672	Roof Curb Insulated Panels	3-5 Ton
IRKT-01	Isolation Relay Kit	3-5 Ton
LAKT01	Low Ambient Kit	3-5 Ton
DLAKT01	Low Ambient Kit (for models with DDC Control)	3-5 Ton
LPM-06	LP Conversion Kit	3-5 Ton
LPT-00A	LP Conversion Kit (DTG036045 only)	3 Ton
OT18-60A	Outdoor Thermostat	All Models
SPKT01	Single Point Kit - Single Phase	3-5 Ton B Chassis Only
SPKT02	Single Point Kit - Three Phase	3-5 Ton
220-GX-01	Flue Extension Kit	3-5 Ton

\*\* Complete listing of EHK kits listed on electrical data page in this manual.

\*\*\*NOTE: High static airflow requires installation of high static kit (HSKT\*\*).

<sup>1</sup> If this economizer is used for factory or field installed and power exhaust is also required, please use appropriate power exhaust: DPE36722, DPE36724, DPE36727.


<sup>2</sup> If this economizer is used for factory or field installed and power exhaust is also required, please contact RRS Rooftop Systems directly for more information and ordering accessories.

<b>DAIKIN COMMERCIAL PACKAGE UNIT DDC CONTROLS</b>	
<b>WATTMASTER / DAIKIN PART NUMBER</b>	<b>DESCRIPTION</b>
OE377-26B-00001 / PCBCG100	DDC Controller
OE255 / 0130L00110	CO <sub>2</sub> Sensor
OE361-13 / 0130L00126	CommLink 5 Communications Interface
EBC-3-F / 0130L00114 EBC-10-F / 0130L00115 EBC-50-F / 0130L00116 EBC-150-F / 0130L00117	EBC E-BUS Cable Assembly E-BUS Power & Comm 3 Ft, 10 Ft, 50 Ft, 150 Ft
MS000248	E-BUS Adapter Hub
HZ-EBC-248	E-BUS Adapter Hub with 1.5 Ft. EBC Cable
OE365-15-EBA	E-BUS Adapter Board
OE256-07 / 0130L00131	E-BUS CO <sub>2</sub> Sensor with Remote Pickup - Duct Mounted
OE256-05 / 0130L00128	E-BUS CO <sub>2</sub> Sensor - Space
OE217-02 / 0130L00118	E-BUS Digital Room Sensor - LCD Display - Temp. Only
OE217-03 / 0130L00119	E-BUS Digital Room Sensor - LCD Display - Temp & RH
OE217-04 / 0130L00127	E-BUS Digital Room Sensor - No LCD Display - Temp & RH
OE265-15 / 0130L00132	E-BUS Horizontal Outside Air Temperature & RH Sensor
OE265-16 / 0130L00133	E-BUS Vertical Outside Air Temperature & RH Sensor
OE415-02 / 0130L00122	IP Module Kit
OE364-23 / 0130L00125	MiniLink 5
OE265-13 / 0130L00106	Outdoor Air Humidity Sensor
OE250 / 0130L00108	Outdoor Air Temperature Sensor
OE368-23-LON3-G / 0130L00124	PT-Link II LON3-G
OE265-11 / 0130L00129	Space Humidity Sensor
OE213 / 0130L00107	Standard Room Sensor - W/ Override & Slide Adjust
OE230 / 0130L00112 OE231 / 0130L00113	Supply Air Temperature Sensor
OE437-03 / 0130L00130	Surge Protector
OE392-10-G / 0130L00121	System Manager Touch Screen II-G

**For complete information and installation instructions for models with DDC controls, see manual DK-DDC-TGD-01\*.**

# ACCESSORIES

## ROOF CURBS 14CURB3672




D14CURB3672				
Chassis	Models	A	B	C
#1	3 - 5 Tons	70 3/4"	37"	14"

Measurement in inches.

## DOWNFLOW SQUARE TO ROUND ADAPTERS DDNSQRD3616, DDNSQRD487218

*DNSQRD36B Shown*




Measurement in inches.

DOWNFLOW SQUARE TO ROUND ADAPTER					
MODEL	SIZE	A	B	C	D
DDNSQRD3616	16" ROUND	13.50	31.125	19.50	13.50
DDNSQRD487218	18" ROUND	13.50	31.125	19.50	19.00

# ACCESSORIES



## MOTORIZED/MANUAL FRESH AIR DAMPERS

25% FRESH AIR DAMPER			
CHASSIS	MODELS	MANUAL	MOTORIZED
#1	3 - 5 Tons	D25FD3672	D25MFD3672



## ECONOMIZERS

HORIZONTAL ECONOMIZER		
MODEL	TYPE	MODEL
DHZECNJ3672	HORIZONTAL	3-5 TON DTC/DTG/DTH




DOWNFLOW ECONOMIZER		
MODEL	TYPE	MODEL
DDNECNJ3672B	DOWNFLOW (MCDANIEL METALS)	3-5 TON DTC/DTG/DTH
DDNECNJ3672NR	DOWNFLOW W/O BAROMETRIC RELIEF (MCDANEIL METALS)	3-5 TON DTC/DTG/DTH
1036609B	DOWNFLOW (ROOFTOP SYSTEMS)	3-5 TON DTC/DTG/DTH

# ACCESSORIES


## HAIL GUARD KIT

HAIL GUARD KIT	
MODELS	KIT #
3 - 4 Tons	HAILGD03D
5 Tons	HAILGD04D



## FLUE EXTENSION KIT

FLUE EXTENSION KIT						
MODELS	KIT #	A	B	C	D	E
3 - 6 Tons	220-GX-01	3.25	2.25	6.50	2.38	24.00



# ACCESSORIES WIRING DIAGRAMS


# ECONOMIZER



WARNING

**HIGH VOLTAGE!** DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.





Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.




# ACCESSORIES WIRING DIAGRAMS

## POWERED CONV. OUTLET

**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

FOR UNITS WITH SERIALS BEFORE 1607




Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

## POWERED CONV. OUTLET



FOR UNITS WITH SERIALS 1607 AND NEWER



Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

DPE3672\*




**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



## POWER EXHAUST 3 - 6 TON



Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS




**WARNING**


**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



## PACKAGE SYSTEM WIRING DIAGRAM - 1 STAGE ELECTRIC HEAT



## PACKAGE SYSTEM WIRING DIAGRAM - 2 STAGE ELECTRIC HEAT ABOVE 10 KW



### NOTES:

- 1) "O" and "E" used on heat pumps only.
- 2) Connect wire from terminal #1 on outdoor thermostat to the white wire on package units if single stage indoor thermostat is used.

### Color Codes

R - Red  
Y - Yellow  
BL - Blue  
BR - Brown  
O - Orange  
W - White


### OT18-60A OUTDOOR THERMOSTAT

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

**WARNING**

**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



For outdoor temperatures below 0° F with 50% or higher relative humidity, set outdoor thermostat at 0° F

NOTE 1: OT18 #2 CAN BE CONNECTED BETWEEN W2 OF THERMOSTAT AND BROWN WIRE IF DESIRED.

- COLOR CODES
- R --RED
  - Y --YELLOW
  - BL-BLUE
  - BR-BROWN
  - O --ORANGE
  - W -WHITE
  - G --GREEN


**OT18-60A OUTDOOR THERMOSTAT**

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

**WARNING**

**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**



**NOTICE: The cut out speed & hard start settings are factory preset. Changing those settings may cause early motor failure.**


## LOW AMBIENT FOR DTC/DTG 3 - 5 TON

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

**WARNING**

**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**




## SMOKE DETECTOR

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

 <b>WARNING</b>	<b>HIGH VOLTAGE!</b> DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.	
--	---	---



## DISCONNECT MODULE

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.




# ACCESSORIES WIRING DIAGRAMS



**WARNING**

**HIGH VOLTAGE!**  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.






## 3 PHASE MONITOR

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# ACCESSORIES WIRING DIAGRAMS

**WARNING**


**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**



## 3 PHASE MONITOR

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

**WARNING** HIGH VOLTAGE!  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



## 3 PHASE MONITOR


Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



**WARNING**

**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**





## LOW AMBIENT


Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



**WARNING**

**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**





## SMOKE DETECTOR

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

<b>HEATER KITS</b>	
<b>Part Number</b>	<b>Description</b>
EHK1-10	10 KW Electric Heat Kit, 240V Single Phase
EHK1-15	15 KW Electric Heat Kit, 240V Single Phase
EHK1 -18	18 KW Electric Heat Kit, 240V Single Phase (FOR 4 TON ONLY)
EHK1-20	20 KW Electric Heat Kit, 240V Single Phase

### MINIMUM AIRFLOW FOR ELECTRIC HEAT

<b>Unit</b>	<b>HEATER KIT MODEL NUMBER</b>	<b>MINIMUM CFM</b>
3 ton	EHK*-10	1250
	EHK*-15	1250
4 ton	EHK*-10	1300
	EHK*-15	1400
	EHK*-18	1400
5 ton	EHK*-10	1700
	EHK*-15	1700
	EHK*-20	1800



### ATTENTION INSTALLING PERSONNEL

Use only the heater kit specified for each model as dictated by the table above.

# HEATER KIT WIRING DIAGRAMS


EHK1-10



**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.





**EHK1 - 10 HEAT KIT - 10 KW**

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# HEATER KIT WIRING DIAGRAMS


# EHK1-15



**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.





## EHK1 - 15 HEAT KIT - 15 KW

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.




# HEATER KIT WIRING DIAGRAMS

EHK1-18/20

**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



**EHK1 - 18 HEAT KIT - 18 KW**

**EHK1 - 20 HEAT KIT - 20 KW**

**EHK\*-18 KITS**  
**FOR USE WITH 4 TON UNITS ONLY.**


Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# HEATER KIT WIRING DIAGRAMS

# EHK\*-10/EHK\*-15

**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



MODEL -  
 EHK3-10, EHK3-15, EHK3-16  
 EHK4-10, EHK4-15, EHK4-16  
 EHK7-10, EHK7-15, EHK7-16

COMPONENT CODE  
 PC = 9 PIN CONNECTOR  
 HTR = HEATER ELEMENT  
 TL = THERMAL LIMIT  
 RS = RELAY/SEQUENCER  
 FL = FUSE LINK  
 OP = OVERLOAD PROTECTION  
 CT = CONTACTOR

WIRING CODE:  
 HIGH VOLTAGE   
 LOW VOLTAGE

0140L04066-A

**EHK3-10 HEAT KITS - 10 KW, EHK3-15 HEAT KITS - 15 KW**  
**EHK4-10 HEAT KITS - 10 KW, EHK4-15 HEAT KITS - 15 KW**  
**EHK7-10 HEAT KITS - 10 KW, EHK7-15 HEAT KITS - 15 KW**

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# HEATER KIT WIRING DIAGRAMS


# EHK\*-18/EHK\*-20



**WARNING**

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.





**EHK3 - 18 HEAT KIT - 18KW**  
**EHK4 - 18 HEAT KIT - 18KW**  
**EHK7 - 18 HEAT KIT - 18KW**

**EHK3 - 20 HEAT KIT - 20KW**  
**EHK4 - 20 HEAT KIT - 20KW**  
**EHK7 - 20 HEAT KIT - 20KW**

**EHK\*-18 KITS**  
**FOR USE WITH 4 TON UNITS**  
**ONLY.**

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

**DTC COMMERCIAL  
3-5 Ton Packaged Air Conditioner Unit  
WIRING DIAGRAMS**


**For units with DDC control see manual  
RSD6412018\* for wiring diagrams**





**DTH COMMERCIAL  
3-5 Ton Packaged Heat Pump Unit  
WIRING DIAGRAMS**

**For units with DDC control see manual  
RSD6412018\* for wiring diagrams**



**WARNING**


HIGH VOLTAGE!  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



# UNIT WIRING DIAGRAMS

# DTH036-060XXX3D\*\*\*A\*



### COMPONENT LEGEND

- C CONTACTOR
- CCR COMPRESSOR CONTACTOR RELAY
- CH CRANKCASE HEATER
- CHS CRANKCASE HEATER SWITCH
- COMP COMPRESSOR MOTOR
- CM CONDENSER MOTOR
- DC DEFROST CONTROL
- DFT DEFROST THERMOSTAT
- ECON ECONOMIZER
- EM EVAPORATOR MOTOR
- GND EQUIPMENT GROUND
- HPS HIGH PRESSURE SWITCH
- HVDR HIGH VOLTAGE DEFROST RELAY
- LPS LOW PRESSURE SWITCH
- LVDR LOW VOLTAGE DEFROST RELAY
- LVJB LOW VOLTAGE JUNCTION BOX
- PLF FEMALE PLUG / CONNECTOR
- RVC REVERSING VALVE COIL
- RCCF RUN CAPACITOR FOR CONDENSER FAN
- TB1 TERMINAL BLOCK (24V SIGNAL)
- TR TRANSFORMER
- RV REVERSING VALVE

### NOTES:

1. REPLACEMENT WIRE MUST BE SAME SIZE AND TYPE INSULATION AS ORIGINAL (AT LEAST 105°C) USE COPPER CONDUCTOR ONLY.
2. TO CHANGE EVAPORATOR MOTOR SPEED MOVE WHITE AND YELLOW LEADS FROM "3" AND "4" TO "4" AND "5". IF BOTH LEADS ARE ENERGIZED, THE HIGHER SPEED SETTING IS USED.
3. FOR 208 VOLT TRANSFORMER OPERATION MOVE BLACK WIRES FROM TERMINAL 3 TO TERMINAL 2 ON TRANSFORMER.
4. USE COPPER CONDUCTORS ONLY
- ++ USE N.E.C. CLASS 2 WIRE
5. ECONOMIZER PLUG LOCATED IN THE RETURN AIR COMPARTMENT. REMOVE MALE PLUG AND ATTACH FEMALE PLUG TO ECONOMIZER ACCESSORY
6. CRANKCASE HEATER AND CRANKCASE HEATER SWITCH FACTORY EQUIPPED WHEN REQUIRED. SEE UNIT RATING PLATE FOR TYPE AND SIZE OF OVER CURRENT PROTECTION

- JUNCTION
- TERMINAL
- INTERNAL TO INTEGRATED CONTROL
- PLUG CONNECTION
- SWITCH (PRESS.)
- OVERCURRENT PROT. DEVICE
- EQUIPMENT GROUND
- FIELD GROUND
- FIELD SPlice
- SWITCH (TEMP)
- IGNITER

### FACTORY WIRING

- LINE VOLTAGE
- LOW VOLTAGE
- OPTIMAL HIGH VOLTAGE
- OPTIMAL LOW VOLTAGE

### FIELD WIRING

- HIGH VOLTAGE
- LOW VOLTAGE

### WIRE CODE

- BK BLACK
- BL BLUE
- BR BROWN
- GR GREEN
- RD RED
- PK PINK
- PU PURPLE
- OR ORANGE
- WH WHITE
- YL YELLOW

### THERMOSTAT ++ FIELD WIRING

- NO ECONOMIZER
- WH — W
  - GR — G
  - RD — R
  - YL — Y
  - BL — C
  - OR — O

- WITH ECONOMIZER OPTION
- WH — W
  - GR — G
  - RD — R
  - YL — Y
  - BL — C
  - OR — O

- 2 STAGE COOLING
- WH — W
  - GR — G
  - RD — R
  - YL — Y1
  - PK — Y2
  - BL — C
  - OR — O

**HIGH VOLTAGE!**  
**DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.**

**WARNING**




Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

**DTG COMMERCIAL  
3-5 Ton Packaged Gas Unit  
WIRING DIAGRAMS**

For units with DDC control see manual  
RSD6412018\* for wiring diagrams

# UNIT WIRING DIAGRAMS

DTG0360451D\*\*\*A\*



**INSTALLER/SERVICEMAN**

THE STATUS LIGHT ON THE FURNACE CONTROL MAY BE USED AS A GUIDE TO TROUBLESHOOTING THIS APPLIANCE. STATUS LIGHT CODES ARE AS FOLLOWS:

STATUS LIGHT	EQUIP. STATUS	CHECK
OFF	<b>NORMAL OPERATION</b>	
NO POWER OR INTERNAL CONTROL FAULT		CHECK INPUT POWER CHECK FUSE ON CONTROL REPLACE CONTROL
1 BLINK	IGNITION FAILURE OR OPEN ROLL-OUT SWITCH OR OPEN AUX. LIMIT SWITCH	GAS PRESSURE GAS VALVE FLAME SENSOR FLAME ROLL-OUT BAD SWITCH AUX. LIMIT OPEN
2 BLINKS	PRESSURE SWITCH OPEN	CHECK PRESSURE SWITCH
3 BLINKS	PRESSURE SWITCH CLOSED WITHOUT INDUCER ON	CHECK PRESSURE SWITCH
4 BLINKS	OPEN LIMIT SWITCH	CHECK MAIN LIMIT OPEN BAD SWITCH
5 BLINKS	FALSE FLAME SENSED	CHECK STICKING GAS VALVE
6 BLINKS	COMPRESSOR OUTPUT DELAY	CHECK 3 MIN. COMP. ANTI-CYCLE TIMER

**COMPONENT LEGEND**

- ALS AUXILIARY LIMIT SWITCH
- COMP COMPRESSOR
- CM CONDENSER MOTOR
- C CONTACTOR
- EM EVAPORATOR MOTOR
- F FUSE
- FS FLAME SENSOR
- GND EQUIPMENT GROUND
- GV GAS VALVE
- HPS HIGH PRESSURE SWITCH
- IC INTEGRATED IGNITION CONTROL
- IGN IGNITOR
- LS LOW PRESSURE SWITCH
- LIMIT SWITCH
- PLF FEMALE PLUG/CONNECTOR
- PS PRESSURE SWITCH
- RCCF RUN CAPACITOR FOR COMPRESSOR/FAN
- RS ROLL-OUT SWITCH
- TB1 TERMINAL BLOCK (24V SIGNAL)
- TR TRANSFORMER
- VM VENT MOTOR
- VMR VENT MOTOR RELAY

**NOTES**

- REPLACEMENT WIRE MUST BE THE SAME SIZE AND TYPE OF INSULATION AS ORIGINAL. (USE COPPER CONDUCTOR ONLY).
- FOR 208 VOLT TRANSFORMER OPERATION MOVE BLACK WIRE FROM TERMINAL 3 TO TERMINAL 2 ON TRANSFORMER.
- FOR DIFFERENT THAN FACTORY SPEED TAP CHANGE COOLING SPEED AT MOTOR T4 AND T5 TERMINALS. CHANGE HEATING SPEED AT MOTOR T1, T2, AND T3 TERMINALS. COOLING SPEED (YELLOW WIRE)  
T3 - LOW SPEED  
T4 - HIGH SPEED  
HEATING SPEED (WHITE WIRE)  
T1 - LOW SPEED (070)  
T2 - MED. SPEED  
T5 - HIGH SPEED (140)
- ACCESSORY ECONOMIZER OPERATION TO BLOWER HOUSING IN RETURN AIR COMPARTMENT. REMOVE MALE PLUG AND ATTACH FEMALE PLUG TO ECONOMIZER ACCESSORY.
- USE COPPER CONDUCTORS ONLY.  
++ USE NEC CLASS 2 WIRE.
- L1 AND L2 ON ICC CONTROL IS 24V INPUT.
- SPEED TAP TERMINATIONS SHOWN ON DIAGRAM ARE REPRESENTATIVE, BUT ACTUAL FACTORY SETTINGS MAY BE DIFFERENT BASED ON THE HEATING VALUE OF THE UNIT.
- FOR LOW STAGE OPERATION ONLY REMOVE WHITE JUMPER FOR 2 STAGE OPERATION. REMOVE JUMPER AND CONNECT W2 TO W2 ON THERMOSTAT.

SEE UNIT RATING PLATE FOR TYPE AND SIZE OF OVER CURRENT PROTECTION.

**FACTORY WIRING**

- LINE VOLTAGE
- - - LOW VOLTAGE
- OPTIONAL HIGH VOLTAGE
- - - OPTIONAL LOW VOLTAGE

**FIELD WIRING**

- HIGH VOLTAGE
- - - LOW VOLTAGE

**WIRE CODE**

- BK BLACK
- BL BLUE
- BR BROWN
- GR GREEN
- OR ORANGE
- PK PINK
- PU PURPLE
- RD RED
- WH WHITE
- YL YELLOW
- BL/PK BLUE WITH PINK STRIP
- YL/PK YELLOW WITH PINK STRIP

**THERMOSTAT ++ FIELD WIRING**

**NO ECONOMIZER**

- WH - W
- GR - G
- RD - R
- YL - Y
- BL - C

**TB1 STAT WITH ECONOMIZER OPTION**

- WH - W
- GR - G
- RD - R
- YL - Y
- BL - C

**TB1 STAT 2 STAGE COOLING**

- WH - W
- GR - G
- RD - R
- YL - Y1
- PK - Y2
- BL - C

240/1/60 0140L04817-A

**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



WARNING

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# UNIT WIRING DIAGRAMS

DTG[036-060]0901D\*\*\*A\*

DTG0481151D\*\*\*A\*



- COMPONENT LEGEND**
- ALS AUXILIARY LIMIT SWITCH
  - COMP COMPRESSOR
  - CM CONDENSER MOTOR
  - C CONTACTOR
  - EM EVAPORATOR MOTOR
  - F FUSE
  - FS FLAME SENSOR
  - GND EQUIPMENT GROUND
  - GV GAS VALVE
  - HPS HIGH PRESSURE SWITCH
  - HC INTEGRATED HEATING CONTROL
  - IGN IGNITOR
  - LPS LOW PRESSURE SWITCH
  - LS LIMIT SWITCH
  - PLF FEMALE PLUG/CONNECTOR
  - PS PRESSURE SWITCH
  - RS ROLLOUT SWITCH
  - TB1 TERMINAL BLOCK (24V SIGNAL)
  - TR TRANSFORMER
  - VM VENT MOTOR
  - VMR VENT MOTOR RELAY
- NOTES**
- REPLACEMENT WIRE MUST BE THE SAME SIZE AND TYPE OF INSULATION AS ORIGINAL (USE COPPER CONDUCTOR ONLY).
  - FOR 208 VOLT TRANSFORMER OPERATION MOVE BLACK WIRE FROM TERMINAL 3 TO TERMINAL 2 ON TRANSFORMER.
  - FOR DIFFERENT THAN FACTORY SPEED TAP CHANGE COOLING SPEED AT MOTOR T1 AND T2 TERMINALS. CHANGE HEATING SPEED AT MOTOR T1, T2, AND T3 TERMINALS. COOLING SPEED (YELLOW WIRE)  
T3 - LOW SPEED  
T4 - HIGH SPEED  
HEATING SPEED (WHITE WIRE)  
T1 - LOW SPEED (070)  
T2 - MED. SPEED  
T3 - HIGH SPEED (140)
  - ACCESSORY ECONOMIZER PLUG ADJACENT TO BLOWER HOUSING IN RETURN AIR COMPARTMENT. REMOVE MALE PLUG AND ATTACH FEMALE PLUG TO ECONOMIZER ACCESSORY.
  - USE COPPER CONDUCTORS ONLY.
  - ++ USE NEC CLASS 2 WIRE.
  - L1 AND L2 ON ICC CONTROL IS 24V INPUT.
  - SPEED TAP TERMINALS SHOWN ON DIAGRAM ARE REPRESENTATIVE, BUT ACTUAL FACTORY SETTINGS MAY BE DIFFERENT BASED ON THE HEATING VALUE OF THE UNIT.
  - FOR LOW STAGE OPERATION ONLY REMOVE WHITE JUMPER FOR 2 STAGE OPERATION, REMOVE JUMPER AND CONNECT W2 TO W2 ON THERMOSTAT.
- SEE UNIT RATING PLATE FOR TYPE AND SIZE OF OVERCURRENT PROTECTION

- FACTORY WIRING**
- LINE VOLTAGE
  - LOW VOLTAGE
  - OPTIONAL HIGH VOLTAGE
  - OPTIONAL LOW VOLTAGE
- FIELD WIRING**
- HIGH VOLTAGE
  - LOW VOLTAGE
- WIRE CODE**
- BK BLACK
  - BL BLUE
  - BR BROWN
  - GR GREEN
  - OR ORANGE
  - PK PINK
  - PU PURPLE
  - RD RED
  - WH WHITE
  - YL YELLOW
  - BL/PK BLUE WITH PINK STRIP
  - YL/PK YELLOW WITH PINK STRIP
- THERMOSTAT ++**
- FIELD WIRING**
- NO ECONOMIZER**
- WH --- W
  - GR --- G
  - RD --- R
  - YL --- Y
  - BL --- C
- TB1 WITH ECONOMIZER OPTION**
- WH --- W
  - GR --- G
  - RD --- R
  - YL --- Y
  - BL --- C
- TB1 2 STAGE COOLING**
- WH --- W
  - GR --- G
  - RD --- R
  - YL --- Y1
  - PK --- Y2
  - BL --- C

**INSTALLER/SERVICEMAN**

THE STATUS LIGHT ON THE FURNACE CONTROL MAY BE USED AS A GUIDE TO TROUBLESHOOTING THIS APPLIANCE. STATUS LIGHT CODES ARE AS FOLLOWS:

STATUS LIGHT	EQUIP STATUS	CHECK
ON	NORMAL OPERATION	-
OFF	NO POWER OR INTERNAL CONTROL FAULT	CHECK INPUT POWER CHECK FUSE/CONTROL REPLACE CONTROL
1 BLINK	IGNITION FAILURE OR OPEN ROLLOUT SWITCH OR OPEN AUX. LIMIT SWITCH	CHECK GAS FLOW GAS PRESSURE GAS VALVE FLAME SENSOR FLAME ROLLOUT BAD SWITCH AUX. LIMIT OPEN
2 BLINKS	PRESSURE SWITCH OPEN	CHECK PRESSURE SWITCH
3 BLINKS	PRESSURE SWITCH CLOSED WITHOUT INDICATOR ON	CHECK PRESSURE SWITCH
4 BLINKS	OPEN LIMIT SWITCH	CHECK MAIN LIMIT OPEN BAD SWITCH
5 BLINKS	FALSE FLAME SENSED	CHECK GAS VALVE
6 BLINKS	COMPRESSOR OUTPUT DELAY	3 MIN. COMP. ANTI-CYCLE TIMER

**WARNING**

HIGH VOLTAGE!  
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

2401/160 0140L04817-A


Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



# UNIT WIRING DIAGRAMS

# DTG0360453D\*\*\*A\*

## SINGLE-STAGE GAS VALVE




**WARNING**

HIGH VOLTAGE!  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

# UNIT WIRING DIAGRAMS


# DTG(036-060)\*\*\*3D\*\*\*A\*



**WARNING**


HIGH VOLTAGE!  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



**HIGH VOLTAGE!**  
 DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

**WARNING**



**COMPONENT LEGEND**  
 ALS AUXILIARY LIMIT SWITCH  
 COMP COMPRESSOR  
 CM CONDENSER MOTOR  
 C CONTACTOR  
 EM EVAPORATOR MOTOR  
 F FUSE  
 FC FAN CAPACITOR  
 FS FLAME SENSOR  
 GND EQUIPMENT GROUND  
 GV GAS VALVE  
 HPS HIGH PRESSURE SWITCH  
 IIC INTEGRATED IGNITION CONTROL  
 IGN IGNITOR  
 LS LIMIT SWITCH  
 LPS LOW PRESSURE SWITCH  
 PLF FEMALE PLUG/CONNECTOR  
 PS PRESSURE SWITCH  
 RS ROLLOUT SWITCH  
 TB1 TERMINAL BLOCK (24V SIGNAL)  
 TR TRANSFORMER  
 VM VENT MOTOR  
 VMR VENT MOTOR RELAY

**NOTES**  
 1. REPLACEMENT WIRE MUST BE THE SAME SIZE AND TYPE OF INSULATION AS ORIGINAL. (USE COPPER CONDUCTOR ONLY).  
 2. FOR 208 VOLT TRANSFORMER OPERATION MOVE BLACK WIRES FROM TERMINAL 3 TO TERMINAL 2 ON TRANSFORMER.  
 3. FOR DIFFERENT THAN FACTORY SPEED TAP, CHANGE COOLING SPEED AT MOTOR T3 AND T4 TERMINALS. CHANGE HEATING SPEED AT MOTOR T1, T2, AND T5 TERMINALS.  
**COOLING SPEED (YELLOW WIRE)**  
 T3 - LOW SPEED  
 T4 - HIGH SPEED  
**HEATING SPEED (WHITE WIRE)**  
 T1 - LOW SPEED (070)  
 T2 - MED. SPEED  
 T5 - HIGH SPEED (140)  
 4. ACCESSORY ECONOMIZER PLUG ADJACENT TO BLOWER HOUSING IN RETURN AIR COMPARTMENT. REMOVE MALE PLUG AND ATTACH FEMALE PLUG TO ECONOMIZER ACCESSORY.  
 5. USE COPPER CONDUCTORS ONLY.  
 ++ USE NEC CLASS 2 WIRE.  
 6. L1 AND L2 ON IIC CONTROL IS 24V INPUT.  
 7. SPEED TAP TERMINATIONS SHOWN ON DIAGRAM ARE REPRESENTATIVE, BUT ACTUAL FACTORY SETTINGS MAY BE DIFFERENT BASED ON THE HEATING VALUE OF THE UNIT.  
 8. FOR LOW STAGE OPERATION ONLY, REMOVE WHITE JUMPER. FOR 2 STAGE OPERATION, REMOVE JUMPER AND CONNECT W2 TO W2 ON THERMOSTAT.  
 SEE UNIT RATING PLATE FOR TYPE AND SIZE OF OVER CURRENT PROTECTION

**FACTORY WIRING**  
 — LINE VOLTAGE  
 - - - LOW VOLTAGE  
 - - - - - OPTIONAL HIGH VOLTAGE  
 - - - - - OPTIONAL LOW VOLTAGE

**FIELD WIRING**  
 - - - - - HIGH VOLTAGE  
 - - - - - LOW VOLTAGE

**WIRE CODE**  
 BK BLACK  
 BL BLUE  
 BR BROWN  
 GR GREEN  
 OR ORANGE  
 PK PINK  
 PU PURPLE  
 RD RED  
 WH WHITE  
 YL YELLOW  
 BL/PK BLUE WITH PINK STRIP  
 YL/PK YELLOW WITH PINK STRIP

**THERMOSTAT ++ FIELD WIRING**

**NO ECONOMIZER**

(W)	—	WH	—	W
(G)	—	GR	—	G
(R)	—	RD	—	R
(Y)	—	YL	—	Y
(C)	—	BL	—	C

TB1 STAT

**WITH ECONOMIZER OPTION**

(W)	—	WH	—	W
(G)	—	GR	—	G
(R)	—	RD	—	R
(Y)	—	YL	—	Y
(C)	—	BL	—	C

TB1 STAT


**2 STAGE COOLING**

(W)	—	WH	—	W
(G)	—	GR	—	G
(R)	—	RD	—	R
(Y)	—	YL	—	Y
(C)	—	BL	—	C

TB1 STAT

**INSTALLER/SERVICEMAN**  
 THE STATUS LIGHT ON THE FURNACE CONTROL MAY BE USED AS A GUIDE TO TROUBLESHOOTING THIS APPLIANCE. STATUS LIGHT CODES ARE AS FOLLOWS:

STATUS LIGHT	EQUIP. STATUS	CHECK
ON	NORMAL OPERATION	CHECK INPUT POWER CHECK FUSE ON CONTROL
OFF	NO POWER OR INTERNAL CONTROL FAILURE	REPLACE CONTROL
1 BLINK	IGNITION FAILURE OR OPEN ROLLOUT SWITCH OR OPEN AUX. LIMIT SWITCH	GAS PRESSURE GAS VALVE FLAME SENSOR FLAME ROLLOUT BAD SWITCH AUX. LIMIT OPEN
2 BLINKS	PRESSURE SWITCH OPEN	PRESSURE SWITCH
3 BLINKS	PRESSURE SWITCH CLOSED WITHOUT INDICER ON	CHECK PRESSURE SWITCH
4 BLINKS	OPEN LIMIT SWITCH	MAIN LIMIT OPEN BAD SWITCH
5 BLINKS	FALSE FLAME SENSED	STICKING GAS VALVE
6 BLINKS	COMPRESSOR OUTPUT DELAY	3 MIN. COMP. ANTI-CYCLE TIMER



230/3/60 0140L05415-B



CUSTOMER FEEDBACK

Daikin is very interested in all product comments.

Please fill out the feedback form on the following link:

<https://daikincomfort.com/contact-us>

You can also scan the QR code on the right to be directed to the feedback page.

