# **DBC** SERIES

# LIGHT COMMERCIAL PACKAGED HEATING AND COOLING UNIT

15 to 25 TON



**TE:** 15 & 20 ton model shown in picture 25 ton model has 2 fans.

#### ATTENTION INSTALLING PERSONNEL:

Prior to installation, thoroughly familiarize yourself with this Installation Manual. Observe all safety warnings. During installation or repair, caution is to be observed.

It is your responsibility to install the product safely and to educate the customer on its safe use.



These installation instructions cover the **outdoor** installation of single package heating and cooling units. See the Specification Sheet applicable to your model for information regarding accessories.

**\*NOTE:** Please contact your distributor or our website for the applicable Specification Sheet referred to in this manual.



The second of the second stands

ONLY PERSONNEL THAT HAVE BEEN TRAINED TO INSTALL, ADJUST, SERVICE OR REPAIR (HEREINAFTER, "SERVICE") THE EQUIPMENT SPECIFIED IN THIS MANUAL SHOULD SERVICE THE EQUIPMENT. THE MANUFACTURER WILL NOT BE RESPONSIBLE FOR ANY INJURY OR PROPERTY DAMAGE ARISING FROM IMPROPER SERVICE OR SERVICE PROCEDURES. IF YOU SERVICE THIS UNIT, YOU ASSUME RESPONSIBILITY FOR ANY INJURY OR PROPERTY DAMAGE WHICH MAY RESULT. IN ADDITION, IN JURISDICTIONS THAT REQUIRE ONE OR MORE LICENSES TO SERVICE THE EQUIPMENT SPECIFIED IN THIS MANUAL, ONLY LICENSED PERSONNEL SHOULD SERVICE THE EQUIPMENT. IMPROPER INSTALLATION, ADJUSTMENT, SERVICING OR REPAIR OF THE EQUIPMENT SPECIFIED IN THIS MANUAL, OR ATTEMPTING TO INSTALL, ADJUST, SERVICE OR REPAIR THE EQUIPMENT SPECIFIED IN THIS MANUAL WITHOUT PROPER TRAINING MAY RESULT IN PRODUCT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



#### Index

2
2
2
3
5
6
6
6
7
10
10
10
11
12
14

Our continuing commitment to quality products may mean a change in specifications without notice.



Appendix A Blower Performance Data15
Belt Drive - Standard15
Belt Drive - High Static16
Appendix A Economizer Pressure Drop17
Appendix B Electrical Data18
Appendix C Unit Dimensions21
Appendix D Wiring Diagrams22
Start-up Checklist

#### **REPLACEMENT PARTS**

#### **ORDERING PARTS**

When reporting shortages or damages, or ordering repair parts, give the complete unit model and serial numbers as stamped on the unit's nameplate.

Replacement parts for this appliance are available through your contractor or local distributor. Your nearest distributor can be located online at **www.daikinac.com** or by contacting:

EQUIPMENT SUPPORT DAIKIN NORTH AMERICA LLC 19001 KERMIER ROAD WALLER, TEXAS 77484 855-DAIKIN-1

SAFETY INSTRUCTIONS

#### TO THE INSTALLER

Before installing this unit, please read this manual to familiarize yourself on the specific items which must be adhered to, including maximum external static pressure to unit, air temperature rise, minimum or maximum CFM and motor speed connections.

#### Keep this literature in a safe place for future reference.





SHEET METAL PARTS, SCREWS, CLIPS AND SIMILAR ITEMS INHERENTLY HAVE SHARP EDGES, AND IT IS NECESSARY THAT THE INSTALLER AND SERVICE PERSONNEL EXERCISE CAUTION.



DO NOT CONNECT TO OR USE ANY DEVICE THAT IS NOT DESIGN CERTIFIED BY THE MANUFACTURER FOR USE WITH THIS UNIT. SERIOUS PROPERTY DAMAGE,PERSONAL INJURY, REDUCED UNIT PERFORMANCE AND/OR HAZARDOUS CONDITIONS MAY RESULT FROM THE USE OF SUCH NON-APPROVED DEVICES.



This unit must not be used as a "construction heater" during the finishing phases of construction on a new structure. This type of use may result in premature failure of the unit due to extremely low return air temperature and exposure to corrosive or very dirty atmospheres.

#### HIGH VOLTAGE!

DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.





TO PREVENT THE RISK OF PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH, DO NOT STORE COMBUSTIBLE MATERIALS OR USE GASOLINE OR OTHER FLAMMABLE LIQUIDS OR VAPORS IN THE VICINITY OF THIS APPLIANCE.

#### **GENERAL INFORMATION**

For complete information and installation instructions for models with DDC controls, see manual DK-DDC-TGD-XXX



TO PREVENT PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, DUE TO FIRE, EXPLOSIONS, SMOKE, SOOT, CONDENSATION, ELECTRIC SHOCK OR CARBON MONOXIDE, THIS UNIT MUST BE PROPERLY INSTALLED, REPAIRED, OPERATED, AND MAINTAINED.

This unit is approved for outdoor installation ONLY. Rated performance is achieved after 20 hours of operation. Rated performance is delivered at the specified airflow. See outdoor unit specification sheet for split system models or product specification sheet for packaged and light commercial models. Specification sheets can be found at <u>www.daikinac.com</u> for Daikin brand products. Within the website, please select the residential or commercial products menu and then select the submenu for the type of product to be installed, such as air conditioners or heat pumps, to access a list of product pages that each contain links to that model's specification sheet.

To assure that your unit operates safely and efficiently, it must be installed, operated, and maintained in accordance with these installation and operating instructions, all local building codes and ordinances.

#### **EPA R**EGULATIONS

IMPORTANT: THE UNITED STATES ENVIRONMENTAL PROTECTION AGENCY (EPA) HAS ISSUED VARIOUS REGULATIONS REGARDING THE INTRODUCTION AND DISPOSAL OF REFRIGERANTS IN THIS UNIT. FAILURE TO FOLLOW THESE REGULATIONS MAY HARM THE ENVIRONMENT AND CAN LEAD TO THE IMPOSITION OF SUBSTANTIAL FINES. BECAUSE REGULATIONS MAY VARY DUE TO PASSAGE OF NEW LAWS, WE SUGGEST A CERTIFIED TECHNICIAN PERFORM ANY WORK DONE ON THIS UNIT. SHOULD YOU HAVE ANY QUESTIONS PLEASE CONTACT THE LOCAL OFFICE OF THE EPA.

#### NATIONAL CODES

This product is designed and manufactured to permit installation in accordance with National Codes. It is the installer's responsibility to install the product in accordance with National Codes and/or prevailing local codes and regulations.

The heating and cooling capacities of the unit should be greater than or equal to the design heating and cooling loads of the area to be conditioned. The loads should be calculated by an approved method or in accordance with ASHRAE Guide or Manual J - Load Calculations published by the Air Conditioning Contractors of America.

#### Obtain from:

#### American National Standards Institute 25 West 43rd Street, 4th Floor New York, NY 10036

System design and installation should also, where applicable, follow information presented in accepted industry guides such as the ASHRAE Handbooks. The manufacturer assumes no responsibility for equipment installed in violation of any code or regulation. The mechanical installation of the packaged roof top units consists of making final connections between the unit and building services; supply and return duct connections; and drain connections (if required). The internal systems of the unit are completely factoryinstalled and tested prior to shipment.

Units are generally installed on a steel roof mounting curb assembly which has been shipped to the job site for installation on the roof structure prior to the arrival of the unit. The model number shown on the unit's identification plate identifies the various components of the unit such as refrigeration tonnage, heating input and voltage.

Carefully inspect the unit for damage. Any bolts or screws which may have loosened in transit must be re-tightened. In the event of damage, the receiver should:

- 1. Make notation on delivery receipt of any visible damage to shipment or container.
- 2. Notify carrier promptly and request an inspection.
- 3. In case of concealed damage, carrier should be notified as soon as possible-preferably within 5 days.
- 4. File the claim with the following supporting documents:
- a. Original Bill of Lading, certified copy, or indemnity bond.
- b. Original paid freight bill or indemnity in lieu thereof.
- c. Original invoice or certified copy thereof, showing trade and other discounts or reductions.
- d. Copy of the inspection report issued by carrier representative at the time damage is reported to the carrier. The carrier is responsible for making prompt inspection of damage and for a thorough investigation

of each claim. The distributor or manufacturer will not accept claims from dealers for transportation damage.

**NOTE:** When inspecting the unit for transportation damage, remove all packaging materials. Recycle or dispose of the packaging material according to local codes.

#### PRE-INSTALLATION CHECKS

Carefully read all instructions for the installation prior to installing unit. Ensure each step or procedure is understood and any special considerations are taken into account before starting installation. Assemble all tools, hardware and supplies needed to complete the installation. Some items may need to be purchased locally.

#### UNIT LOCATION



TO PREVENT POSSIBLE EQUIPMENT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, THE FOLLOWING BULLET POINTS MUST BE OBSERVED WHEN INSTALLING THE UNIT.

**IMPORTANT NOTE:** Remove wood shipping rails prior to installation of the unit. *See important note under Roof Curb Installation Only.* 

#### ALL INSTALLATIONS:

**IMPORTANT NOTE:** Unit should be energized 24 hours prior to compressor start up to ensure crankcase heater has sufficiently warmed the compressors. Compressor damage may occur if this step is not followed.

**NOTE:** Appliance is shipped from factory for vertical duct application.

Proper installation of the unit ensures trouble-free operation. Improper installation can result in problems ranging from noisy operation to property or equipment damages, dangerous conditions that could result in injury or personal property damage. Give this booklet to the user and explain it's provisions. The user should retain these instructions for future reference.

- For proper operation and condensate drainage, the unit must be mounted level.
- The flue outlet hood must be at least three feet above any forced air inlet located within ten feet. The economizer/ manual fresh air intake/motorized fresh air intake and combustion air inlet mounted on the unit are not affected by this restriction.
- Do not locate the unit in an area where the outdoor air (i.e. combustion air for the unit) will be frequently contaminated by compounds containing chlorine or fluorine. Common sources of such compounds include swimming pool chemicals and chlorine bleaches, paint stripper, adhesives, paints, varnishes, sealers, waxes (which are not yet dried) and solvents used during construction and remodeling. Various commercial and industrial processes may also be sources of chlorine/fluorine compounds.

- To avoid possible illness or death of the building occupants, do NOT locate outside air intake device (economizer, manual fresh air intake, motorized fresh air intake) too close to an exhaust outlet, gas vent termination, or plumbing vent outlet. For specific distances required, consult local codes.
- Allow minimum clearances from the enclosure for fire protection, proper operation, and service access (see Unit Clearances). These clearances must be permanently maintained.
- When the unit is heating, the temperature of the return air entering the unit must be between 50°F and 100°F.

#### GROUND LEVEL INSTALLATIONS ONLY:

- When the unit is installed on the ground adjacent to the building, a level concrete (or equal) base is recommended. Prepare a base that is 3" larger than the package unit footprint and a minimum of 3" thick.
- The base should also be located where no runoff of water from higher ground can collect in the unit.

#### ROOF TOP INSTALLATIONS ONLY:

- To avoid possible property damage or personal injury, the roof must have sufficient structural strength to carry the weight of the unit(s) and snow or water loads as required by local codes. Consult a structural engineer to determine the weight capabilities of the roof.
- The unit may be installed directly on wood floors or on Class A, Class B, or Class C roof covering material.
- To avoid possible personal injury, a safe, flat surface for service personnel should be provided.
- As indicated on the unit's data plate, a minimum clearance of 36" to any combustible material is required on the access side of the unit. All combustible materials must be kept out of this area.
- This 36" clearance must also be maintained to insure proper combustion air flow. The combustion air intake must not be blocked for any reason, including blockage by snow.
- Adequate clearances from the unit to any adjacent public walkways, adjacent buildings, building openings or openable windows must be maintained in accordance with National Codes.

#### **UNIT PRECAUTIONS**

- Do not stand or walk on the unit.
- Do not drill holes anywhere in panels or in the base frame of the unit (except where indicated). Unit access panels provide structural support.
- Do not remove any access panels until unit has been installed on roof curb or field supplied structure.
- Do not roll unit across finished roof without prior approval of owner or architect.
- Do not skid or slide on any surface as this may damage unit base. The unit must be stored on a flat, level surface. Protect the condenser coil because it is easily damaged.

#### ROOF CURB INSTALLATIONS ONLY:

#### Before installing this unit...

IMPORTANT NOTE: This unit has been equipped with a shipping brace under the compressor section that **MUST BE REMOVED** before installing the unit on a roof curb.

Please follow the instructions below to remove brace.

# CAUTION

When unit is suspended, boards and shipping brace will drop when screws are removed. To prevent personal injury, **STAND CLEAR**. Remove fork hole brackets, boards and shipping brace from bottom of unit before placing unit onto curb.

- 1. Remove wooden struts and shipping brace per installation instructions. *The struts are located in the fork holes and are used to protect the unit from damage while lifting with forks. The shipping brace is located underneath the unit (under compressors).* Also remove the fork hole brackets as shown in the following figure.
- 2. Locate and remove the end brackets as shown in the following graphic.



3. Lift unit per the "Rigging Details" section of this manual, observing all warnings and cautions. When unit is lifted, boards and shipping brace will drop if screws have been removed. To avoid injury, STAND CLEAR. 4. Dispose of the boards and brace appropriately.

Curb installations must comply with local codes and should be done in accordance with the established guidelines of the National Roofing Contractors Association.

Proper unit installation requires that the roof curb be firmly and permanently attached to the roof structure. Check for adequate fastening method prior to setting the unit on the curb.

Full perimeter roof curbs are available from the factory and are shipped unassembled. Field assembly, squaring, leveling and mounting on the roof structure are the responsibility of the installing contractor. All required hardware necessary for the assembly of the sheet metal curb is included in the curb accessory.



TO PREVENT POSSIBLE EQUIPMENT DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, THE FOLLOWING BULLET POINTS MUST BE OBSERVED WHEN INSTALLING THE UNIT.

- Sufficient structural support must be determined prior to locating and mounting the curb and package unit.
- Ductwork must be constructed using industry guidelines. The duct work must be placed into the roof curb before mounting the package unit. Our full perimeter curbs include duct connection frames to be assembled with the curb. Cantilevered type curbs are not available from the factory.
- Curb insulation, cant strips, flashing and general roofing material are furnished by the contractor.

The curbs must be supported on parallel sides by roof members. The roof members must not penetrate supply and return duct opening areas as damage to the unit might occur.

**NOTE:** The unit and curb accessories are designed to allow vertical duct installation <u>before</u> unit placement. Duct installation <u>after</u> unit placement is not recommended.



See the manual shipped with the roof curb for assembly and installation instructions.

**CLEARANCES** 



\*In situations that have multiple units, a 48" minimum clearance is required between the condenser coils.

#### UNIT CLEARANCES

Adequate clearance around the unit should be kept for safety, service, maintenance, and proper unit operation. A 75" clearance on the non-service side of the unit is required to facilitate possible blower assembly, shaft, wheel replacement and coil removal. \*DBG ONLY - A 75" clearance on the service is required for removal of the gas heat exchanger. This unit must not be installed beneath any obstruction. This unit should be installed remote from all building exhausts to inhibit ingestion of exhaust air into the unit's fresh air intake.



**Roof Curb Installation** 

#### **ROOF CURB POST-INSTALLATION CHECKS**

After installation, check the top of the curb, duct connection frame and duct flanges to make sure gasket has been applied properly. Gasket should be firmly applied to the top of the curb perimeter, duct flanges and any exposed duct connection frame. If gasket is loose, re-apply using strong weather resistant adhesive.

#### PROTRUSION

Inspect curb to ensure that none of the utility services (electric) routed through the curb protrude above the curb.



#### **ROOF TOP DUCT CONNECTIONS**

Install all duct connections on the unit before placing the unit on rooftop.

#### **RIGGING DETAILS**



DO NOT LIFT UNITS TWO AT A TIME. PROVISIONS FOR FORKS HAVE BEEN INCLUDED IN THE UNIT BASE FRAME. MINIMUM FORK LENGTH IS 72" TO PREVENT DAMAGE TO THE UNIT.

Provisions for forks have been included in the unit base frame. No other fork locations are approved.



To prevent possible equipment damage, property damage, personal injury or death, the following bullet points must be observed when installing the unit.

- Unit must be lifted by the four lifting holes located at the base frame corners.
- Lifting cables should be attached to the unit with shackles.
- The distance between the crane hook and the top of the unit must not be less than 60".
- Two spreader bars must span over the unit to prevent damage to the cabinet by the lift cables. Spreader bars must be of sufficient length so that cables do not come in contact with the unit during transport. Remove wood struts mounted beneath unit base frame before setting unit on roof curb. These struts are intended to protect unit base frame from fork lift damage. Removal is accomplished by extracting the sheet metal retainers and pulling the struts through the base of the unit. Refer to rigging label on the unit.

**Important:** If using bottom discharge with roof curb, ductwork should be attached to the curb prior to installing the unit. Ductwork dimensions are shown in Roof Curb Installation Instructions.

Refer to the Roof Curb Installation Instructions for proper curb installation. Curbing must be installed in compliance with the National Roofing Contractors Association Manual.

Lower unit carefully onto roof mounting curb. While rigging unit, center of gravity will cause condenser end to be lower than supply air end.



When unit is suspended, boards and shipping brace will drop when screws are removed. To prevent personal injury, **STAND CLEAR**. Remove fork hole brackets, boards and shipping brace from bottom of unit before placing unit onto curb.

To assist in determining rigging requirements, unit weights are shown as follows:



SEE CAUTION BELOW ITER OF GRAVITY LOCATIONS

DATA	DBC Weights (lbs)								
DATA	15 Tons	20 Tons	25 Tons						
Corner Weight - A	590	644	626						
Corner Weight - B	482	525	464						
Corner Weight - C	492	504	501						
Corner Weight - D	401	412	518						
Unit Shipping Weight	2080	2202	2377						
Unit Operating Weight	1965	2085	2109						
X (Inches)	60"	58"	64.3"						
Y (Inches)	40"	40"	41.3"						

NOTE: These weights are without accessories installed.



Bring condenser end of unit into alignment with the curb. With condenser end of the unit resting on curb member and using curb as a fulcrum, lower opposite end of the unit until entire unit is seated on the curb. When a rectangular cantilever curb is used, care should be taken to center the unit. Check for proper alignment and orientation of supply and return openings with duct.

**RIGGING REMOVAL** 



#### **HIGH VOLTAGE!**

TO AVOID PERSONAL INJURY OR DEATH DUE TO ELECTRICAL SHOCK, DO NOT TAMPER WITH FACTORY WIRING. THE INTERNAL POWER AND CONTROL WIRING OF THESE UNITS ARE FACTORY-INSTALLED AND HAVE BEEN THOROUGHLY TESTED PRIOR TO SHIPMENT. CONTACT YOUR LOCAL REPRESENTATIVE IF ASSISTANCE IS REQUIRED.





TO PREVENT DAMAGE TO THE WIRING, PROTECT WIRING FROM SHARP EDGES. FOLLOW NATIONAL ELECTRICAL CODE AND ALL LOCAL CODES AND ORDINANCES. DO NOT ROUTE WIRES THROUGH REMOVABLE ACCESS PANELS.

# CAUTION

# CONDUIT AND FITTINGS MUST BE WEATHER-TIGHT TO PREVENT WATER ENTRY INTO THE BUILDING.

For unit protection, use a fuse or HACR circuit breaker that is in excess of the circuit ampacity, but less than or equal to the maximum overcurrent protection device. DO NOT EXCEED THE MAXIMUM OVERCURRENT DEVICE SIZE SHOWN ON UNIT DATA PLATE.

All line voltage connections must be made through weatherproof fittings. All exterior power supply and ground wiring must be in approved weatherproof conduit.

The main power supply wiring to the unit and low voltage wiring to accessory controls must be done in accordance with these instructions, the latest edition of the National Electrical Code (ANSI/ NFPA 70), and all local codes and ordinances.

The main power supply shall be three-phase, three wire. The unit is factory wired for the voltage shown on the unit's data plate.

**NOTE:** If supply voltage is 208V, all leads on primary of transformer(s) must be moved from the 230V to the 208V tap.

Main power wiring should be sized for the minimum circuit ampacity shown on the unit's data plate. Size wires in accordance with the ampacity tables in Article 310 of the National Electrical Code. If long wires are required, it may be necessary to increase the wire size to prevent excessive voltage drop. Wires should be sized for a maximum of 3% voltage drop.



TO AVOID PROPERTY DAMAGE OR PERSONAL INJURY DUE TO FIRE, USE ONLY COPPER CONDUCTORS.

LABEL ALL WIRES PRIOR TO DISCONNECTION WHEN SERVICING CONTROLS. WIRING ERRORS CAN CAUSE IMPROPER AND DANGEROUS OPERATION. VERIFY PROPER OPERATION AFTER SERVICING.

**NOTE:** A weather-tight disconnect switch, properly sized for the unit total load, must be field or factory installed. An external field supplied disconnect may be mounted on the exterior panel.

Ensure the data plate is not covered by the field-supplied disconnect switch.

- Some disconnect switches are not fused. Protect the power leads at the point of distribution in accordance with the unit's data plate.
- The unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the latest edition of the National Electrical Code (ANSI-NFPA 70). A ground lug is provided for this purpose. Size grounding conductor in accordance with Table 250-95 of the National Electrical Code. Do not use the ground lug for connecting a neutral conductor.
- Connect power wiring to the middle contactor within the main control box or power block, if equipped.



15-20 TON TSTAT POWER AND LOW VOLTAGE TERMINAL LOCATIONS



#### 25 TON TSTAT POWER AND LOW VOLTAGE TERMINAL LOCATIONS

**NOTE:** Depending on the options installed, the location of the components may vary in some models.



15-20 TON DDC POWER AND LOW VOLTAGE TERMINAL LOCATIONS



#### 25 TON DDC POWER AND LOW VOLTAGE TERMINAL LOCATIONS

NOTE: Depending on the options installed, the location of the components may vary in some models.



Areas Without Convenience Outlet

It is recommended that an independent 115V power source be brought to the vicinity of the roof top unit for portable lights and tools used by the service mechanic.

**NOTE:** Refer to local codes for requirements. These outlets can also be factory installed.

#### UNITS INSTALLED ON ROOF TOPS

Main power and low voltage wiring may enter the unit through the side or through the roof curb. Install conduit connectors at the desired entrance locations. External connectors must be weatherproof. All holes in the unit base must be sealed (including those around conduit nuts) to prevent water leakage into building. All required conduit and fittings are to be field supplied.

Supply voltage to roof top unit must not vary by more than 10% of the value indicated on the unit's data plate. Phase voltage unbalance must not exceed 2%. Contact your local power company for correction of improper voltage or phase unbalance.



#### ELECTRICAL ENTRANCE LOCATIONS

Unit is equipped with Single Point Power Block and Low Voltage Block.

#### LOW VOLTAGE CONTROL WIRING

NOTE: For models equipped with the DDC controls option, refer to the supplemental DDC literature supplied with the unit for additional information.

- A 24V thermostat must be installed for unit operation. It may be purchased with the unit or field -supplied. Thermostats may be programmable or electromechanical as required.
- Locate thermostat or remote sensor in the conditioned space where it will sense average temperature. Do not locate the device where it may be directly exposed to supply air, sunlight or other sources of heat. Follow installation instructions packaged with the thermostat.
- 3. Use #18 AWG wire for 24V control wiring runs not exceeding 75 feet. Use #16 AWG wire for 24V control wiring runs not exceeding 125 feet. Use #14 AWG wire for 24V control wiring runs not exceeding 200 feet. Low voltage wiring may be National Electrical Code (NEC) Class 2 where permitted by local codes.
- 4. Route thermostat wires from sub-base terminals to the unit. Control wiring should enter through the duct panel (dimple marks entrance location). Connect thermostat and any accessory wiring to low voltage terminal block TB1 in the main control box.

**NOTE:** Field-supplied conduit may need to be installed depending on unit/curb configuration. Use #18 AWG solid conductor wire whenever connecting thermostat wires to terminals on sub-base. DO NOT use larger than #18 AWG wire. A transition to #18 AWG wire may be required before entering thermostat sub-base.

**NOTE:** Refer to unit wiring diagrams for thermostat hookups.

#### **CIRCULATING AIR AND FILTERS**

#### DUCTWORK

The supply duct from the unit through a wall may be installed without clearance. However, minimum unit clearances must be maintained (see "Clearances" section). The supply duct should be provided with an access panel large enough to inspect the air chamber downstream of the heat exchanger. A cover should be tightly attached to prevent air leaks.

Ductwork dimensions are shown in the roof curb installation manual.

If desired, supply and return duct connections to the unit may be made with flexible connections to reduce possible unit operating sound transmission.

#### CONDENSATE DRAIN CONNECTION

#### CONDENSATE DRAIN CONNECTION

A 1" female NPT drain connection is supplied on the end of the condensate pan, with an alternative connection on the bottom of the pan. An external trap must be installed for proper condensate drainage



Drain Pan (Side View)



**NOTE:** Trap should be deep enough to offset maximum unit static difference. A minimum 4" trap is recommended.

#### DRAIN CONNECTION

Install condensate drain trap as shown. Use 1" drain line and fittings or larger. Do not operate without trap.

#### HORIZONTAL DRAIN

Drainage of condensate directly onto the roof may be acceptable; refer to local code. It is recommended that a small drip pad of either stone, mortar, wood or metal be provided to prevent any possible damage to the roof.

#### CLEANING

Due to the fact that drain pans in any air conditioning unit will have some moisture in them, algae and fungus will grow due to airborne bacteria and spores. Periodic cleaning is necessary to prevent this build-up from plugging the drain.

#### STARTUP, ADJUSTMENTS, AND CHECKS



**PRE-STARTUP INSTRUCTIONS** 



TO PREVENT PROPERTY DAMAGE OR PERSONAL INJURY, DO NOT START THE UNIT UNTIL ALL NECESSARY PRE-CHECKS AND TESTS HAVE BEEN PERFORMED.

Prior to the beginning of Startup, Adjustments, and Checks procedures, the following steps should be completed in the building.



#### MOVING MACHINERY HAZARD!

TO PREVENT POSSIBLE PERSONAL INJURY OR DEATH, DISCONNECT POWER TO THE UNIT AND PADLOCK IN THE "**OFF**" POSITION BEFORE SERVICNG FANS.

#### HEATING STARTUP

On new installations, or if a major component has been replaced, the operation of the unit must be checked.

Check unit operation as outlined in the following instructions. If any sparking, odors, or unusual sounds are encountered, shut off electrical power and recheck for wiring errors, or obstructions in or near the blower motors. **Duct covers must be removed before operating unit.**  The Startup, Adjustments, and Checks procedure provides a stepby-step sequence which, if followed, will assure the proper startup of the equipment in the minimum amount of time. Air balancing of duct system is not considered part of this procedure. However, it is an important phase of any air conditioning system startup and should be performed upon completion of the Startup, Adjustments, and Checks procedure. The Startup, Adjustments, and Checks procedure at outside ambients below 55°F should be limited to a readiness check of the refrigeration system with the required final check and calibration left to be completed when the outside ambient rises above 55°F.

#### TEMPORARY HEATING OR COOLING

If the unit is to be used for temporary heating or cooling, a "Startup, Adjustments, and Checks" must first be performed in accordance with this manual. **After** the machines are used for temporary heating or cooling, inspect the coils, fans, and motors for unacceptable levels of construction dust and dirt and install new filters.

#### **CONTRACTOR RESPONSIBILITY**

The installing contractor must be certain that:

- All supply and return air ductwork is in place, properly sealed and corresponds with installation instructions.
- All thermostats are mounted and wired in accordance with installation instructions.
- All electric power, all gas, hot water or steam line connections, and the condensate drain installation have been made to each unit on the job. These main supply lines must be functional and capable of operating all units simultaneously.
- All filters are in place.

#### **ROOF CURB INSTALLATION CHECK**

Inspect the roof curb for correct installation. The unit and curb assembly should be level. Inspect the flashing of the roof mounting curb to the roof, especially at the corners, for good workmanship. Also check for leaks around gaskets. Note any deficiencies in a separate report and forward to the contractor.

#### **OBSTRUCTIONS, FAN CLEARANCE AND WIRING**

Remove any extraneous construction and shipping materials that may be found during this procedure. Rotate all fans manually to check for proper clearances and that they rotate freely. Check for bolts and screws that may have jarred loose during shipment to the job site. Retighten if necessary. Re-tighten all electrical connections.

#### FIELD DUCT CONNECTIONS

Verify that all duct connections are tight and that there is no air bypass between supply and return.

#### FILTER SECTION CHECK

Remove filter section access panels and check that filters are properly installed. Note airflow arrows on filter frames.

#### **PRE-STARTUP PRECAUTIONS**

It is important to your safety that the unit has been properly grounded during installation. Check ground lug connection in main control box for tightness prior to closing circuit breaker or disconnect switch. Verify that supply voltage on line side of disconnect agrees with voltage on unit identification plate and is within the utilization voltage range as indicated in Appendix C Electrical Data.

**System Voltage -** That nominal voltage value assigned to a circuit or system for the purpose of designating its voltage class.

**Nameplate Voltage -** That voltage assigned to a piece of equipment for the purpose of designating its voltage class and for the purpose of defining the minimum and maximum voltage at which the equipment will operate.

**Utilization Voltage** - The voltage of the line terminals of the equipment at which the equipment must give fully satisfactory performance. Once it is established that supply voltage will be maintained within the utilization range under all system conditions, check and calculate if an unbalanced condition exists between phases. Calculate percent voltage unbalance as follows:

#### Three Phase Models Only

3) PERCENT VOLTAGE	400 V	2) MAXIMUM VOLTAGE DEVIATIONS FROM AVERAGE VOLTAGE
UNBALANCE	= 100 X	1) AVERAGE VOLTAGE

HOW TO USE THE FORMULA:

EXAMPLE: With voltage of 220, 216, and 213

1) Average Voltage = 220+216+213=649 / 3 = 216 2) Maximum Voltage Deviations from Average Voltage = 220 - 216 = 4

3) Percent Voltage Unbalance =  $100 \times \frac{4}{216} = \frac{400}{216} = 1.8\%$ 

Percent voltage unbalance MUST NOT exceed 2%.

#### **AIRFLOW ADJUSTMENTS**

The drive on the supply fan is typically set in the middle of the RPM range. The drive motor sheave pitch diameter is field adjustable for the required airflow. Refer to the following "Drive Adjustments" section.

When the final adjustments are complete, the current draw of the motor should be checked and compared to the full load current rating of the motor. The amperage must not exceed the service factor stamped on the motor nameplate. The total airflow must not be less than that required for operation of the electric heaters or the furnace.

If an economizer is installed, check the unit operating balance with the economizer at full outside air and at minimum outside air. Upon completion of the air flow balancing, we recommend replacing the variable pitched motor sheave with a properly-sized fixed sheave. A matching fixed sheave will provide longer belt and bearing life and vibration free operation. Initially, it is best to have a variable pitched motor sheave for the purpose of airflow balancing, but once the balance has been achieved, fixed sheaves maintain alignment and minimize vibration more effectively. **NOTE:** Airflow setting below 300 CFM/ton is not recommended, as evaporator freezing or poor unit performance is possible. For 2-speed models, airflow adjustments must be made with the evaporator fan motor operating at high speed (in 2nd stage cooling or in heat mode).

#### SET EVAPORATOR FAN RPM

Actual RPM's must be set and verified with a tachometer or strobe light. Refer to Appendices A and B for basic unit fan RPM. Refer also to "Airflow" section of this manual. With disconnect switch open, disconnect thermostat wires from terminals Y and W. This will prevent heating and mechanical cooling from coming on. Place a jumper wire across terminals R and G at TB1 terminal block. Close disconnect switch; evaporator fan motor will operate so RPM can be checked.

#### EVAPORATOR FAN ROTATION CHECK (THREE PHASE MODELS ONLY)

Check that fan rotates clockwise when viewed from the drive side of unit and in accordance with rotation arrow shown on blower housing. If it does not, reverse the two incoming power cables at Single Point Power Block. In this case, repeat bearing check.

Do not attempt to change load side wiring. Internal wiring assures all motors and compressors will rotate in correct direction once evaporator fan motor rotation check has been made.

#### **ELECTRICAL INPUT CHECK**

Make preliminary check of evaporator fan ampere draw and verify that motor nameplate amps are not exceeded. A final check of amp draw should be made upon completion of air balancing of the duct system (see Appendix B).

#### BEARING CHECK

Prior to energizing any fans, check and make sure that all setscrews are tight so that bearings are properly secured to shafts.

#### TENSION AND ALIGNMENT ADJUSTMENT

Correct belt tension is very important to the life of your belt. Too loose a belt will shorten its life; too tight, premature motor and bearing failure will occur. Check you belt drive for adequate "runin" belt tension by measuring the force required to deflect the belt at the midpoint of the span length. Belt tension force can be measured using a belt tension gauge, available through most belt drive manufacturers.



\*Apply force to the center of the span.

t = Span length, inches

C = Center distance, inches

D = Larger sheave diameter, inches

d = Smaller sheave diameter, inches

h = Deflection height, inches

MODEL	TY	ΡE	SHEAVE DIAMETER	DEFLEC FORCE		DEFLECTION (in)
	BELT	DRIVE	(in)	Used New		(11)
15 Ton	B, BX	Standard	4.3 to 5.5	5.5 <u>±</u> .5	8.2 ± .5	1/4 ± 1/16
20 Ton	B. BA	Standard	4.3 to 5.5	5.5 + .5	8.2 + .5	1/4 + 1/16
25 Ton	0,0/(	Otanidard	4.0 10 0.0	0.0 <u>+</u> .0	0.2 ± .0	1/4 <u>+</u> 1/10

#### DRIVE BELT TENSION ADJUSTMENT

#### **RECOMMENDED POUNDS OF FORCE PER BELT**

New V-belts will drop rapidly during the first few hours of use. Check tension frequently during the first 24 hours of operation. Tension should fall between the minimum and maximum force. To determine the deflection distance from a normal position, measure the distance from sheave to sheave using a straightedge or a cord. This is your reference line. On multiple belt drives, an adjacent undeflected belt can be used as a reference.

#### **MOTOR SHEAVE ADJUSTMENTS**

#### VL, VM & 2VP VARIABLE PITCH KEY TYPE MOTOR SHEAVES

The driving and driven motor sheaves should be in alignment with each other and the shafts parallel.

#### VL & VM SHEAVES ADJUSTMENT

- 1. Loosen set screw "B" using a 5/32" Allen key.
- 2. Making half or full turns from closed position, adjust sheave pitch diameter for desired speed. DO NOT OPEN MORE THAN SIX FULL TURNS.
- 3. Tighten set screw "B" securely over flat.
- 4. Carefully put on belts and adjust belt tension. DO NOT FORCE BELTS OVER GROOVES.
- Ensure all keys are in place and the set screws tight before starting drive. Recheck set screws and belt tension after 24 hours service.

**NOTE:** Future adjustments should be made by loosening the belt tension and increasing or decreasing the pitch diameter of the sheave by half or full turns as required. Readjust belt tension before starting drive.



**NOTE:** Do not operate sheave with flange projecting beyond the hub end.

#### **REFRIGERATION SYSTEM**

# The unit is equipped with a thermal expansion valve as a <u>metering device</u>.

Ensure the hold-down bolts on the compressor are secure and have not vibrated loose during shipment. Check that vibration grommets have been installed. Visually check all piping for damage and leaks; repair if necessary. The entire system has been factory charged and tested, making it unnecessary to field charge. Factory charges are shown on the unit's namelate. To confirm charge levels or, if a leak occurs and charge needs to be added to the system, it is recommended to evacuate the system and recharge refrigerant to unit nameplate specifications. This unit has been rated in the cooling mode at the AHRI rated conditions of: Indoor (80°db / 67°wb) and outdoor (95°db). While operating at this condition, the subcooling should range from 12° to 15° F for each refrigeration circuit, for 15 and 20 ton models. Subcooling for 25 ton models should be from 16° to 19° F for circuit 1, and from 12° to 15° F for circuit 2.

#### START-UP PROCEDURE AND CHECKLIST

NOTE: For models equipped with the DDC controls option, refer to the supplemental DDC literature supplied with the unit for additional information.

Begin with power turned off at all disconnects.

- Turn thermostat system switch to "Cool," and fan switch to "Auto" and turn temperature setting as high as it will go.
- 2. Inspect all registers and set them to the normal open position.

- 3. Turn on the electrical supply at the disconnect.
- 4. Turn the fan switch to the "ON" position. The blower should operate in low speed after a 7-second delay.
- 5. Turn the fan switch to "Auto" position. The blower should stop after a 65 second delay.
- 6. Slowly lower the cooling temperature until first stage COOL (LOW COOL) starts. The blower, both fans, and first stage compressor should now be operating. The blower should be operating in low speed at 1175 motor rpm. Allow the unit to run 10 minutes, make sure cool air is being supplied by the unit.
- 7. Lower the cooling temperature further until second stage COOL (HIGH COOL) starts. The blower, both fans, and <u>both</u> compressors should now be operating. The blower should be operating in high speed at 1775 motor rpm. Allow the unit to run 10 minutes, make sure cool air is being supplied by the unit.
- 8. Turn the temperature setting to the highest position, stopping the unit. The indoor blower will continue to run for 65 seconds.
- 9. Turn the thermostat system switch to "OFF" and disconnect all power when servicing the unit.

#### LOW AMBIENT COOLING NOTES:

**For 15 and 20 ton models:** While in the Cooling Mode, to prevent frost from forming on the evaporator while the unit is operating in outdoor temperatures of 65°F or lower, it is recommended that a low ambient kit is used. This is strongly recommended for 2 Speed models due to the lower airflow while in the first stage of cooling. To further protect the compressor from damage during low ambient conditions, a Freezestat Kit (FSK01) can be added that turns the compressor off when the evaporator temperature drops too low.

**For 25 ton models:** The 25 ton units are equipped with a control that shuts off one condenser fan when the outdoor temperature is 44° F or below, which enables reliable cooling down to a minimum ambient temperature of 24°F. An optional Low Ambient kit, LAKT05, is required below 24° which will enable reliable cooling to occur to a minimum ambient temperature of 0°F.



#### FINAL SYSTEM CHECKS

- 10. Check to see if all supply and return air grilles are adjusted and the air distribution system is balanced for the best compromise between heating and cooling.
- 11. Check for air leaks in the ductwork. See Sections on Air Flow Adjustments.
- 12. Make sure the unit is free of "rattles", and the tubing in the unit is free from excessive vibration. Also make sure tubes or lines are not rubbing against each other or sheet metal surfaces or edges. If so, correct the trouble.
- 13. Set the thermostat at the appropriate setting for cooling and heating or automatic change over for normal use.
- 14. Be sure the Owner is instructed on the unit operation, filter, servicing, correct thermostat operation, etc.

#### MAINTENANCE





TO PREVENT PERSONAL INJURY OR DEATH DUE TO IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE, REFER TO THIS MANUAL. FOR ADDITIONAL ASSISTANCE OR INFORMATION, CONSULT A QUALIFIED INSTALLER, SERVICE AGENCY OR THE GAS SUPPLIER.



SHEET METAL PARTS, SCREWS, CLIPS AND SIMILAR ITEMS INHERENTLY HAVE SHARP EDGES, AND IT IS NECESSARY THAT THE INSTALLER AND SERVICE PERSONNEL EXERCISE CAUTION.

Preventive maintenance is the best way to avoid unnecessary expense and inconvenience. Have this system inspected at regular intervals by qualified service personnel, at least twice a year. Routine maintenance should cover the following items:

- 1. Tighten all belts, set screws, and wire connections.
- 2. Clean evaporator and condenser coils mechanically or with cold water, if necessary. Usually any fouling is only matted on the entering air face of the coil and can be removed by brushing.
- 3. Lubricate motor bearings.
- 4. Align or replace belts as needed.
- 5. Replace filters as needed (see below).
- 6. Check for blockage of condensate drain.
- 7. Check power and control voltages.
- 8. Check running amperage.
- 9. Check operating temperatures and pressures.
- 10. Check and adjust temperature and pressure controls.

- 11. Check and adjust damper linkages.
- 12. Check operation of all safety controls.
- 13. Examine gas furnaces (see below and the User's Information Manual).
- 14. Check condenser fans and tighten set screws.

#### FILTERS



TO PREVENT PROPERTY DAMAGE DUE TO FIRE AND LOSS OF EQUIPMENT EFFICIENCY OR EQUIPMENT DAMAGE DUE TO DUST AND LINT BUILD UP ON INTERNAL PARTS, NEVER OPERATE UNIT WITHOUT AN AIR FILTER INSTALLED IN THE RETURN AIR SYSTEM.

Every application may require a different frequency of replacement of dirty filters. Filters must be replaced at least every three (3) months during operating seasons.

Dirty filters are the most common cause of inadequate heating or cooling performance. Filter inspection should be made at least every two months; more often if necessary because of local conditions and usage.

Dirty throwaway filters should be discarded and replaced with a new, clean filter.

Disposable return air filters are supplied with this unit. See the unit Specification Sheet or Technical Manual for the correct size and part number. To remove the filters, remove the filter access panel on return side of the unit.

#### CABINET FINISH MAINTENANCE

Use a fine grade automotive wax on the cabinet finish to maintain the finish's original high luster. This is especially important in installations with extended periods of direct sunlight.

#### CLEAN OUTSIDE COIL (QUALIFIED SERVICER ONLY)

The coil with the outside air flowing over it should be inspected annually and cleaned as frequently as necessary to keep the finned areas free of lint, hair and debris.

#### CONDENSER FANS

Bearings on the condenser fan motors are permanently lubricated. No additional oiling is required.

#### LUBRICATION

The fan shaft bearings and the supply fan motor have grease fittings that should be lubricated during normal maintenance checks.

#### FUNCTIONAL PARTS

Refer to the unit Parts Catalog for a list of functional parts. Parts are available from your distributor.

# APPENDIX A BLOWER PERFORMANCE DATA BELT DRIVE - STANDARD

#### DCB180 STANDARD TWO-SPEED BELT DRIVE AT HIGH SPEED

		TURNS OPEN														
ESP, In H <sub>2</sub> O	C	)	1	L	2		3		4		5	5	e	5		
	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	внр		
0.2						-			I		7203	2.18	6718	1.94		
0.4							7306	2.54	6777	2.14	6257	1.80	5711	1.66		
0.6	-	1	7477	2.97	6899	2.51	6323	2.10	5716	1.72	5103	1.39				
0.8	7112	2.96	6467	2.46	5795	2.01	5101	1.61	١	1	1	1	1			
1.0	5983	2.38	5190	1.89		-			1		-	-				
1.2	4426	1.71							-			-				

#### DCB240 STANDARD TWO-SPEED BLET DRIVE AT HIGH SPEED

							TURNS	OPEN						
ESP, In H <sub>2</sub> O	(	)	1	L	2	2	3	3	4	ļ	5	5	e	5
	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP
0.2	1	-	I	I	١				1	1			9664	4.05
0.4	-		-	-	1				9570	4.08	9197	3.82	8702	3.51
0.6	-	-	-	1	1		9038	3.82	8460	3.46	7949	3.14		
0.8			8171	2.93	7630	3.70	7068	2.79						
1.0	-	-	7901	2.85	7203	3.42				-				
1.2	7344	4.35		1	1					-				

#### DCB300 STANDARD TWO-SPEED BELT DRIVE AT HIGH SPEED

		TURNS OPEN														
ESP, In H <sub>2</sub> O	C	)	1	L	2	2 3		;	4	4 5		e	5			
	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP		
0.2							10369	5.07	9748	4.41	9191	3.82	8683	3.28		
0.4			10802	6.00	10125	5.30	9484	4.62	8905	4.01	8386	3.46	7913	2.95		
0.6	10519	6.20	9821	5.47	9193	4.81	8599	4.18	8062	3.61	7582	3.10	7143	2.63		
0.8	9482	5.60	8839	4.93	8261	4.32	7714	3.74	7220	3.21	6777	2.74				
1.0	8446	5.01	7857	4.39	7329	3.83	6829	3.30								
1.2	7409	4.41	6876	3.85												

#### NOTES:

High static airflow requires installation of high static kit.

Unit factory shipped with sheave set at 2.5 turns open.

Air flow table represent dry coil with filters installed; SCFM correction factor for wet coil is 4%.

# APPENDIX A BLOWER PERFORMANCE DATA BELT DRIVE - HIGH STATIC

#### DBC180 HIGH STATIC BELT DRIVE - 2 SPEED AT HIGH SPEED

565		TURNS OPEN														
ESP (In W.C.)	(	)	1		2		;	3	4	1	Į	5				
(111 00.0.)	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP				
0.8	-										6580	4.30				
1.0	-						6930	5.14	6432	4.53	5908	3.98				
1.2					6866	5.52	6382	4.80	5916	4.24	5370	3.68				
1.4			6779	5.80	6417	5.22	5914	4.52	5307	3.89						
1.6	6685	6.06	6391	5.52	5954	4.90	5288	4.18								
1.8	6248	5.75	5782	5.09	5261	4.50										
2.0	5664	5.31	5111	4.71												
2.2	5053	4.81														

#### DBC 240 HIGH STATIC BELT DRIVE- 2 SPEED AT HIGH SPEED

500		TURNS OPEN														
ESP (In W.C.)	0		1		2		3		4	4	5					
(11 00.0.)	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP				
0.8	-								8765	6.05	8225	5.38				
1.0	-						8663	6.43	8040	5.67	7385	4.97				
1.2			8978	7.61	8583	6.90	7978	6.00	7395	5.30	6713	4.60				
1.4	8845	7.87	8474	7.26	8021	6.52	7393	5.65	6634	4.86						
1.6	8356	7.58	7989	6.89	7442	6.13	6610	5.22								
1.8	7810	7.18	7227	6.37	6576	5.62										
2.0	7080	6.64	6389	5.89												
2.2	6316	6.02														

#### DBC300 HIGH STATIC BELT DRIVE 2 SPEED AT HIGH SPEED

							TURNS	OPEN						
ESP, In H <sub>2</sub> O	0		1		2		3		4	4	5		6	
H2 <b>O</b>	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP	CFM	BHP
0.6													11409	7.12
0.8													10302	6.46
1.0											10159	6.79	9195	5.79
1.2									9990	7.11	8961	6.04	8087	5.13
1.4							9789	7.39	8686	6.25	7763	5.29	6980	4.46
1.6					9543	7.63	8357	6.40	7382	5.39	6566	4.53		
1.8					7957	6.48	6925	5.41	6077	4.53				
2.0			7667	6.68	6370	5.34								
2.2	7280	6.78												

#### NOTES:

High static airflow requires installation of high static kit.

Unit factory shipped with sheave set at 2.5 turns open.

Air flow table represent dry coil with filters installed; SCFM correction factor for wet coil is 4%.

# APPENDIX A ECONOMIZER PRESSURE DROP

	Airflow Pressure Drop of Downflow Economizer for 15 to 25 Ton Rooftop Units (100% Return Air)														
SCFM	4500	5000	5500	6000	6500	7000	7500	8000	8500	9000	9500	10000			
(In WG)	0.15	0.18	0.22	0.27	0.32	0.37	0.42	0.48	0.55	0.61	0.69	0.76			

# **APPENDIX B ELECTRICAL DATA**

Model Number	Electrical Rating	Co	mpre	ssor	Outdo	or Fan	Motor	Indoor F	an M	lotor	Optio	onal Electr	ic Heat	Optional Powered Convienience Outlet	Power	Supply
		QTY	RLA	LRA	QTY	HP	FLA	Туре	HP	FLA	Part #	KW*	FLA	FLA	MCA	MOP
											-	-	-	-	82.5/82.5	100/100
								2	7.5		-	-	-	7.2/6.5	89.7/89.0	110/110
								speed		20.3	FHK3-31	21.6/28.8	60 0/69 3	-	100/112	110/125
DBC1803S	208/230/3/60	2	25	164	3	0.33	2	Belt Drive				21.0/20.0	00.0/09.3	7.2/6.5	109/120	110/125
22010000 200, 200, 0, 00	200/200/0/00	-	25	104	5	0.55	-			20.5		32.4/43.2	90.1/104	-	138/155	,
								High			2.1.10 10	02.17 1012	5012/201	7.2/6.5	147/163	
								Static			FHK3-60	43.3/57.6	120/139	-	175/164	200/175
								<b></b>			21110 00	1010/0710	120/ 100	7.2/6.5	184/172	200/175
						2			-	-	-	-	71.3/71.3	-		
								speed		E	-	-	-	7.2/6.5	78.5/77.8	-
								Belt			EHK3-31	21.6/28.8	60.0/69.3	-	86.4/98.0	
DBC1803V	208/230/3/60	2	25	164	3	0.33	2	Drive	3	9.1				7.2/6.5	95.4/106	,
	,,,	_			-		_		-		EHK3-46	32.4/43.2	90.1/104	-	124/141	-
								Standard				, ·		7.2/6.5	133/149	
								Static			EHK3-60	43.3/57.6	120/139	-	161/150	175/175
											21110 00	1010/0710	120/ 100	7.2/6.5	170/158	175/175
											-	-	-	-	39.5	50
								2	7.5		-	-	-	3.3	42.8	50
						0.33	0.85	speed Belt Drive High			EHK4-31	28.8	34.6	-	55.2	60
DBC1804S	460/3/60	2	12.2	100	3					9.5	2111(4-51	20.0	54.0	3.3	59.3	60
00010010		-							/	5.5	EHK4-46	43.2	52	-	76.8	80
												.012	52	3.3	81	90
								Static			EHK4-60	57.6	69.3	-	81.2	90
												57.0	05.5	3.3	85.3	90
								2			-	-	-	-	34.3	45
								speed			-	-	-	3.3	37.6	45
								Belt				EHK4-31	28.8	34.6	-	48.7
DBC1804V	460/3/60	2	12.2	100	3	0.33	0.85	Drive	3	4.3	11114 51	20.0	54.0	3.3	52.8	60
00010040	400/ 5/ 00	2	12.2	100	5	0.55	0.05	DIIVC		ч.5	ЕНК4-46	43.2	52	-	70.3	80
								Standard				-13.2	52	3.3	74.5	80
								Static			EHK4-60	57.6	69.3	-	74.7	80
								Static				57.0	09.5	3.3	78.8	90
											-	-	-	-	29.7	35
								2			-	-	-	2.6	32.3	40
			9	78	3	0.33	0.67	speed			EHK7-31	28.8	28.9	-	45.5	50
DBC1807S	575/3/60	2						Belt	7.5	7.5	21107-31	20.0	20.3	2.6	48.8	50
000100/3	5,5,5,00	-		,0	5	0.55	0.07	Drive	( <sup>'.5</sup>	1.5	EHK7-46	43.2	43.4	-	63.6	70
								High			_1107 40			2.6	66.8	70
								Static			EHK7-60	57.6	57.8	-	67.2	80
												57.0	57.0	2.6	70.5	80
								2			-	-	-	-	25.7	30
						0.33	0.67	z speed			-	-	-	2.6	28.3	35
											EHK7-31	28.8	28.9	-	40.5	45
DBC1807V	575/3/60	2	9	78	2			Belt Drive	3	3.5	LUK7-31	20.0	20.3	2.6	43.8	45
20010014	575/5/50	2	9		3						EHK7-46	43.2	43.4	-	58.6	60
								Standard			LTIX /-40	43.2	43.4	2.6	61.8	70
								Static			EHK7-60	57.6	57.8	-	62.2	70
								Jidiic			ERK/-00	57.0	57.8	2.6	65.5	70

## **APPENDIX B ELECTRICAL DATA**

Model Number	Electrical Rating	Co	ompre	ssor	Outdo	or Fan	Motor	Indoor F	an M	otor	Optic	onal Electri	ic Heat	Optional Powered Convienience Outlet	Power	Supply	
		QTY	RLA	LRA	QTY	HP	FLA	Туре	HP	FLA	Part #	KW*	FLA	FLA	MCA	MOP	
											-	-	-	-	103/103	125/12	
											-	-	-	7.2/6.5	110/109	· · ·	
								2 speed			EHK3-31	21.6/28.8	60.0/69.3	-	103/112	125/12	
														7.2/6.5	110/120 138/155		
DBC2403S	DBC2403S 208/230/3/60 2	34	240	3	0.33	2	Belt Drive	7.5	20.3	EHK3-46	32.4/43.2	90.1/104	7.2/6.5	138/155	150/17		
								High						-	175/164		
								Static			EHK3-60	43.3/57.6	120/139	7.2/6.5	184/172	200/17	
												E4 1/72 0	150/172	-	175/199	200/22	
											ЕПКЭ-75	54.1/72.0	150/1/5	7.2/6.5	184/207	200/22	
											-	-	-	-	96.4/96.4		
								2			-	-	-	7.2/6.5	104/103	125/12	
								speed			EHK3-31	21.6/28.8	60.0/69.3	-	96.4/104	-	
								Belt				-		7.2/6.5	104/112		
DBC2403V	208/230/3/60	2	34	240	3	0.33	2	Drive	5	14	EHK3-46	32.4/43.2	90.1/104	- 7.2/6.5	130/147 139/156	150/150	
														-	168/156	175/175	
								Standard			EHK3-60	43.3/57.6	120/139	7.2/6.5	177/164	200/175	
								Static						-	168/191	200/225	
											EHK3-75	54.1/72.0	150/173	7.2/6.5	177/199	200/225	
		1	1								-	-	-	-	48.1	60	
											-	-	-	3.3	51.4	60	
								2			EHK4-31	28.8	34.6	-	55.2	60	
								speed	7.5		2	20.0	0.10	3.3	59.3	60	
DBC2404S	460/3/60	2	16	140	3	0.33	0.85	Belt Drive High Static		9.5	EHK4-46	43.2	52	-	76.8	80	
														3.3	81	90	
											EHK4-60	57.6	69.3	- 3.3	81.2	90 90	
								Static						- 3.3	85.3 98.5	90 110	
											EHK4-75	72	86.6	3.3	103	110	
											-	-	-	-	45.2	60	
											-	-	-	3.3	48.5	60	
								2				FUKA 24	28.8	34.6	-	51.6	60
								speed Belt			EHK4-31	20.0	54.0	3.3	55.7	60	
DBC2404V	460/3/60	2	16	140	3	0.33	0.85	Drive	5	6.6	EHK4-46	43.2	52	-	73.2	80	
DDC2404V	400/ 5/ 00	-	10	1-10	5	0.55	0.05	Direc	ľ	0.0		43.2	52	3.3	77.3	80	
								Standard			EHK4-60	57.6	69.3	-	77.5	90	
								Static						3.3	81.7	90	
											EHK4-75	72	86.6	-	94.9	110	
											-	-	-	3.3	99 38.6	110 50	
											-	-	-	2.6	38.6 41.2	50	
								2						-	41.2	50	
								speed			EHK7-31	28.8	28.9	2.6	43.3	50	
DDC34070	E7E /2 /22	<b>_</b>	12.0	107.0	_	0.22	0.07	Belt				42.2	42.4	-	63.6	70	
DBC2407S	575/3/60	2	12.9	10/.6	3	0.33	0.67	Drive	/.5	7.5	EHK7-46	43.2	43.4	2.6	66.8	70	
								High			EHK7-60	57.6	57.8	-	67.2	80	
								Static				57.0	57.0	2.6	70.5	80	
											EHK7-75	72	72.3	-	81.7	90	
					<u> </u>	<u> </u>		<u> </u>						2.6	84.9	100	
											-	-	-	-	36.3	45	
								2			-	-	-	2.6	38.9	50	
							0.67	speed			EHK7-31	28.8	28.9	- 2.6	42.6 45.9	45 50	
						0.33		Belt Drive						-	45.9 60.7	70	
DBC2407V	575/3/60	2	12.9	107.6	3						EHK7-46	43.2	43.4	2.6	64	70	
								Cham day d				<b>F7 C</b>	<b>F7</b> 0	-	64.3	70	
								Standard Static			EHK7-60	57.6	57.8	2.6	67.6	80	
											- בעעד	72	72.2	-	78.8	90	
			I								EHK7-75	72	72.3	2.6	82	90	

\* Electric Heater kW rating: Rated at 240v for 208-230v units; 480v for 460v units

# **APPENDIX B ELECTRICAL DATA**

DBC200280         208/230/340         2         8.1         2.4         1.4         4.2         5.4         7.5         1.4         1.4         1.5         1.4         1.5         1.4         1.5	Model Number	Electrical Rating	Co	ompre	ssor	Outdo	or Fan	Motor	Indoor F	an M	lotor	Optio	onal Electr	ic Heat	Optional Powered Convienience Outlet	Power	Supply		
DBC3005         289/230/340         2         48.1         29.4         49.4         29.4		_	QTY	RLA	LRA	QTY	HP	FLA	Туре	HP	FLA	Part #	KW*	FLA	FLA	MCA	MOP		
Decision         Here												-	-	-	-	138/138	175/175		
<ul> <li>Decisions</li> <li>Decisions</li> <li>Decisions</li> <li>Decisions</li> <li>Decisions</li> <li>Decisions</li> <li>Partial Partial Partia</li></ul>												-	-	-	7.2/6.5	145/144	175/175		
<ul> <li>Decloors</li> <li>Decloors</li></ul>									speed Belt			FHK3-31	21 6/28 8	60 0/69 3			1 · ·		
bit													2210/ 2010	0010/0510					
DBC3008V         Re6/1/60         P<         P         P<         P<         P         P<         P< <th< td=""><td>DBC3003S</td><td>208/230/3/60</td><td>2</td><td>48.1</td><td>245</td><td>2</td><td>1</td><td>4.2</td><td>7.5</td><td>21</td><td>EHK3-46</td><td>32.4/43.2</td><td>90.1/104</td><td></td><td></td><td>-</td></th<>	DBC3003S	208/230/3/60	2	48.1	245	2	1	4.2		7.5	21	EHK3-46	32.4/43.2	90.1/104			-		
<ul> <li>DeC3001</li> <li>DeC3001</li> <li>DeC3001</li> <li>DeC3001</li> <li>DeC3001</li> <li>P</li> <li>P</li></ul>		,, -, -,			_					-			- , -						
<ul> <li>Decomposition</li> <li>Decompo</li></ul>									_			EHK3-60	43.3/57.6	120/139					
<ul> <li>DBC3001V</li> <li>DBC301V</li> <li>DBC301V</li></ul>									Static								-		
DBC30090         208/230/360         2         48.1         24         2         1         4.2         2         4.2         1         4.2         1         4.2         1         4.2         1         4.2         1         4.2         1         4.2         1         4.2         1         4.2         1 <th1< th="">         1         <th1< th="">         1</th1<></th1<>												EHK3-75	54.1/72.0	150/173					
DBC30039         208/3303/60         2         4         4         2         3         4         2         3         4         2         3         4         4         4         2         4												_					-		
Dec30030         Partial Partindeportate Partial Partial Partial Partindeport Partial Partial																			
DBC3003V         DBC303V         PA									2								-		
DBC3005V         DBC3005V         PA         AB         PA         PA     PA												EHK3-31	21.6/28.8	60.0/69.3	7.2/6.5				
DBC30049         XB(73)(3)(4)         Z         4         5         Z         1         64(2)(4)(4)(2)(4)(4)(4)(4)(4)(4)(4)(4)(4)(4)(4)(4)(4)																			
DBC300K         460/360         2         1         4         1 <th1< th="">         1         1         &lt;</th1<>	DBC3003V	208/230/3/60	2	48.1	245	2	1	4.2	Drive	7.5	21	EHK3-46	32.4/43.2	90.1/104	7.2/6.5		-		
Decouve         Amage         Amagee         Amagee         Amagee         Amagee         Amagee         Amagee         Amagee         Amagee         Amagee         Amagee <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Chauselaurel</td> <td></td> <td></td> <td>EUW2 CO</td> <td>42 2/57 6</td> <td>420/420</td> <td></td> <td></td> <td></td>									Chauselaurel			EUW2 CO	42 2/57 6	420/420					
DBC3004         460/360         2         4.0         0        0        <												EHK3-60	43.3/57.6	120/139	7.2/6.5		1		
DBC30040460/3/6024.01.001.0 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Static</td> <td></td> <td></td> <td></td> <td>F 4 1 /72 0</td> <td>150/172</td> <td>-</td> <td>176/199</td> <td>200/225</td>									Static				F 4 1 /72 0	150/172	-	176/199	200/225		
DBC30040         460/3/60         2         4.60/60         2         4.60/60         2         4.60/60         2         4.60/60         2         4.60/60         2         4.60/60         2         4.60/60         2												ЕПК3-75	54.1/72.0	150/1/3	7.2/6.5	185/208	200/225		
DBC30045         469/3/60         2         18.6         12.5         4.8         2.5         4.6         1.4         4.6         3.2         5.5         1.6         1.7         1.6         1.7         1.8           0BC30045         460/3/60         1         0         1.6         1.7         1.6         1.7         1.6         1.7         1.8         1.7         1.9         1.8         1.7         1.9         1.8         1.7         1.9         1.8         1.7         1.9         1.1												-	-	-	-	56.1	70		
DBC30049         460/3/60         2         14.6         12         2         4         10         6         10         6         10         10           0BC30049         460/3/60         2         1.6         12         1         1         1         1         10         1         10												-	-	-	3.3	59.4	70		
DBC30040         460/3/60         2         18.6         12         2         1 <th1< th="">         1</th1<>												FHK4-31	28.8	34.6		56.1	70		
DBC30045         460/3/60         2         18.6         12         1         2.1         Dree big state         7.5         10.1         EHK4-6         43.2         5.2         3.3         81.7         90           0         0         0         0.3         0.1         0         0.1         0.1         0.0         0.1         0.0		460/3/60		18.6		2			•			2111(4 51	20.0	34.0	3.3		-		
$ \begin basis and basis $	DBC3004S		2		125		1	2.1	Drive High	7.5	10.1	EHK4-46	43.2	52					
DBC3004V         460/3/60 $2$ $4.6$ $6.6$ $6.6$ $4.6$ $6.6$ $4.6$ $6.6$					_					-	-	-	-						
DBC3004V460/3/6021.0 </td <td></td> <td></td> <td></td> <td>l</td> <td>1</td> <td></td> <td></td> <td>EHK4-60</td> <td>57.6</td> <td>69.3</td> <td></td> <td></td> <td></td>					l	1						EHK4-60	57.6	69.3					
DBC3004V         460/3/60         2         4.0         1.0 <th< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td>Static</td><td></td><td></td><td>-</td><td></td><td></td><td></td><td></td><td>-</td></th<>									Static			-					-		
DBC3004V         460/3/60         2         1.8.         1.5.         2         1.5.         2         1.5.         2         1.5.         2.5.         3.3.         3.5.         3.7.         9.0.           BBC30075         575/3/60         2         1.4.7         100         2         1         1.5.         5.5.         5.5.         1.5. <td></td> <td>EHK4-75</td> <td>72</td> <td>86.6</td> <td></td> <td></td> <td></td>												EHK4-75	72	86.6					
$ \begin begin be$																			
DBC3004V         460/3/60         2         18.6         125         2         1         2         1         2         1         2         1         2         1         2         1         1         2         1 <th1< th=""> <th1< th=""></th1<></th1<>																			
$ \begin begin be$									2								_		
DBC3004V         460/3/60         2 $1.8.6$ $2.7$ $1.8.6$ $1.7.6$ $1.7.6$ $1.7.6$ $3.3$ $3.3$ $81.7$ $90$ $1.7.6$ $1.7.6$ $1.7.6$ $1.7.6$ $1.7.6$ $1.7.6$ $1.7.6$ $3.3$ $81.7$ $90$ $1.7.6$ $1.7$														EHK4-31	28.8	34.6			
DBC3004v         460/3/60         2         18.5         12         2         1         2.1         Drive         7.5         10.1         EHK4-60         3.2         52         3.3         81.7         90           0         -         3.3         81.9         90         3.3         81.9         90           0         3.3         3.3         81.9         90         3.3         86         90           0         -         0.33         3.3         86         90         3.3         86         90           0         -         -         -         -         -         90         3.3         103         110           0         -         -         -         -         -         -         -         -         -         -         -         -         0.6         47.2         60           0         -																			
$ \begin begin be$	DBC3004V	460/3/60	2	18.6	125	2	1	2.1	Drive	7.5	10.1	EHK4-46	43.2	52	3.3				
DBC3007V575/3/60214.71010101010101010DBC3007V575/3/60214.710<									Chandard				57.0	<b>CO 3</b>	-	81.9	90		
DBC3007V575/3/60FAFF <td></td> <td>ЕНК4-60</td> <td>57.0</td> <td>69.3</td> <td>3.3</td> <td>86</td> <td>90</td>												ЕНК4-60	57.0	69.3	3.3	86	90		
$ \begin basis ba$									Static			EHK4-75	72	86.6	-	99.2	110		
$ \begin begin be$													72	00.0	3.3	103			
DBC30079         575/3/60 $2$ $4.7$ $4.6$ $2$ $5$ $6$ $ 46.4$ $50$ $28.8$ $28.8$ $28.9$ <												-	-	-					
$ \begin{tabular}{ c c c c c c c }      Becompose $ 575/3/60 $ $2$ $14.7 $ $100 $ $2$ $14.7 $ $10 $ $2$ $2$ $2$ $2$ $2$ $2$ $2$ $2$ $2$ $												-	-	-					
DBC30079 P = 14.7												EHK7-31	28.8	28.9			-		
DBC300/S       5/5/3/60       2       14.7       100       2       1       1.6       Drive High Static       7.5       8.2       EHK 7-60       43.2       43.4       2.6       67.7       70         BC3007V       5/5/3/60       2       14.7       100       2       1       1.6       Drive High Static       7.5       8.2       EHK 7-60       57.6       57.8       -       -       68.1       80         BC3007V       575/3/60       2       14.7       100       2       1       1.6       2       5       5       72       72.3       -																			
$ \begin{tabular}{ c c c c c c c c c c } & & & & & & & & & & & & & & & & & & &$	DBC3007S	575/3/60	2	14.7	100	2	1	1.6		7.5	8.2	EHK7-46	43.2	43.4					
$ \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$												<u> </u>							
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$												EHK7-60	57.6	57.8					
DBC3007V         2         1.4         1.0         2         1         1.6         0        <									Juli										
DBC3007V         575/3/60         2         14.7         100         2         1         1.6         2 speed Belt Drive Standard Static         7.5         -         -         -         -         2         2.6         44.6         50           -         -         -         -         2.6         47.2         60           -         -         -         -         2.6         49.6         60           -         -         -         2.8.8         28.9         -         -         46.4         50           -         -         -         -         -         -         64.5         70           -         -         64.5         70         -         64.5         70           -         -         67.6         57.6         57.8         -         -         68.1         80           -         -         -         67.6         57.8         -         -         68.1         80           -         -         -         -         72         72.3         2.6         85.8         100												EHK7-75	72	72.3					
DBC3007V         575/3/60         2         14.7         100         2         1         1         2         2         2         2         2         2         2         2         2         2         2         2         1         1         1         2         3         4         3         2         3         4         3         4         3         4		1										-	-	-					
DBC3007V         575/3/60         2         14.7         100         2         1         1.6 $2 \\ \text{Belt} \\ \text{Drive} \\ \text{Static} \end{pmatrix}$ $E \\ HK7-31 \\ 28.8 \\ 28.9 \\ 2$									_			-	-	-			-		
DBC3007V         2         14.7         100         2         1         1.6         speed Belt Drive Standard Static         5,5         28.8         28.9         2.6         49.6         60           BBC3007V         575/3/60         2         14.7         100         2         1         1.6         Speed Belt Drive Standard Static         7.5         8.2         28.8         28.9         2.6         49.6         60           BR/2         HK7-46         43.2         43.4         -         -         64.5         70           BR/2         HK7-46         57.6         57.8         -         -         68.1         80           BR/2         HK7-75         72         72.3         -         -         82.5         100																			
DBC3007V       575/3/60       2       14.7       100       2       1       1.6       Belt Drive Standard Static       7.5       8.2       EHK7-46       43.2       43.4        64.5       70         L       100       2       14.7       100       2       1       1.6												EHK7-31	28.8	28.9					
DBC300/V       5/5/3/60       2       14.7       100       2       1       1.6       Drive       7.5       8.2       EHK7-46       43.2       43.4       2.6       67.7       70         BC300/V       5/5/3/60       2       14.7       100       2       1       1.6       Drive       7.5       8.2       EHK7-46       43.2       43.4       2.6       67.7       70         EHK7-60       57.6       57.6       57.8       2.6       71.3       80         EHK7-75       72       72.3       -       82.5       100		E7E /2 /00	2	147	100		4	10		7 -	0 7		42.2	42.4					
Static         EHK7-60         57.6         57.8         2.6         71.3         80           EHK7-75         72         72.3         -         82.5         100	DBC3007V	5/5/3/60	2	14.7	100	2	1	1.0	Drive	1.5	8.2	8.2	EHK7-46	43.2	43.4	2.6		70	
Static         EHK7-75         72         72.3         2.6         71.3         80           2.6         85.8         100									Standard				57.6	57.8		68.1	80		
ЕНК7-75 72 72.3 <u>- 82.5 100</u> 2.6 85.8 100												2111(7-00	57.0	57.0	2.6		80		
									5.000			EHK7-75	72	72.3					
				I				400						. 1.0	2.6	85.8	100		

\* Electric Heater kW rating: Rated at 240v for 208-230v units; 480v for 460v units

UNIT	HEATER KIT	MINIMUM CFM	HEATER KIT	MINIMUM CFM	HEATER KIT	MINIMUM CFM
UNIT	MODEL NUMBER	DOWNSHOT	MODEL NUMBER	DOWNSHOT	MODEL NUMBER	DOWNSHOT
	EHK3-31	5250	EHK4-31	5250	EHK7-31	5250
15 TON	EHK3-46	5250	EHK4-46	5250	EHK7-46	5250
	EHK3-60	5250	EHK4-60	5250	EHK7-60	5250
	EHK3-31	7000	EHK4-31	7000	EHK7-31	7000
20 TON	EHK3-46	7000	EHK4-46	7000	EHK7-46	7000
25 TON	EHK3-60	7000	EHK4-60	7000	EHK7-60	7000
	EHK3-75	7000	EHK4-75	7000	EHK7-75	7000



When using electric heat kit, use of the single point kit installed in the unit is required to meet UL requirements ATTENTION INSTALLING PERSONNEL Use only the heater kit specified for each model as dictated by the table above.

### **APPENDIX C UNIT DIMENSIONS**

Model	А	В	С	D
15 Ton 20 Ton	133-1/2"	88-7/32"	50-9/32"	5-5/32"
25 Ton	133-1/2"	88-7/32"	53-9/32"	5-5/32"



VERTICAL DISCHARGE (TOP VIEW)

## APPENDIX D WIRING DIAGRAMS

HIGH VOLTAGEI DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH

WARNING







#### WIRING DIAGRAMS

DBC300\* 208-230, 460, 575 / 3 / 60 2 SPEED



#### WIRING DIAGRAMS



HIGH VOLTAGEI DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH

WARNING



Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.

HIGH VOLTAGE! DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH

WARNING



#### WIRING DIAGRAMS

HIGH VOLTAGEI DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

WARNING





HIGH VOLTAGE! DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH

WARNING



Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



# Start-up Checklist

\*Store in job file

Date:	 Location:	
Model Number:		
Serial Number:		
Technician:	 Unit #:	

<b>Pre Start-Up</b> (Check each item as completed)
Verify all packaging material has been removed.
Remove all shipping brackets per installation instructions.
Verify the job site voltage agrees with the unit serial plate.
Verify condensate connection is installed per installation instructions.
Verify proper clearance around the unit for safety, service, maintenance and proper unit operation.
Verify proper weatherproofing of all ductwork, roof curbs and electrical connections.
Check that the flue screen is in place.
Check gas piping for leaks.
Verify gas pressure to the unit is within the range specified on the serial plate.
Check to ensure that all fans, pulleys and wheels are secure.
Check for proper belt tension and alignment per installation instructions.
Check refrigerant piping for rubbing and leaks. Repair if necessary.
Check unit wiring to ensure it is not in contact with refrigerant piping or sharp metal edges.
Check all electrical connections and terminals. Tighten as needed.
Verify that the crankcase heaters have been energized for 24 hours.
Verify the scroll compressor(s) are rotating in the right direction.
Verify all accessories are installed and operating correctly.
Check filters and replace if necessary.
Verify the installation of the thermostat.



# **Start-up Checklist**

# Start-Up

(Insert the values as each item is completed.)

#### ELECTRICAL

Supply Voltage	L1 - L2	L2 - L3		L3 - L1
Circuit 1 Compressor Amps	L1	L2		L3
Circuit 2 Compressor Amps	L1	L2		L3
Blower Amps	L1	L2		L3
Condenser Fan Amps	Fan 1	Fan 2		Fan 3
BLOWER EXTERNAL STATIC PRESSURE				
Return Air Static Pressure			IN. W.C.	
Supply Air Static Pressure			IN. W.C.	
Total External Static Pressure			IN. W.C.	
Blower Wheel RPM			RPM	
TEMPERATURES				
Outdoor Air Temperature		DB		WB
Return Air Temperature		DB		WB
Cooling Supply Air Temperature		DB		WB
Heating Supply Air Temperature		DB		
PRESSURES				
Gas Inlet Pressure		IN. W.C.		
Gas Manifold Pressure		IN. W.C. (Low Fire)		IN. W.C. (High Fire)
Suction Circuit 1		PSIG		°F
Superheat (Orifice System)				°F
Suction Circuit 2		PSIG		°F
Superheat (Orifice System)				
Superneur (Onnee System)				°F
Discharge Circuit 1		PSIG		°F °F
		PSIG		
Discharge Circuit 1		PSIG PSIG		°F
Discharge Circuit 1 Subcooling (TXV System)				°F °F
Discharge Circuit 1 Subcooling (TXV System) Discharge Circuit 2				°F °F
Discharge Circuit 1 Subcooling (TXV System) Discharge Circuit 2 Subcooling (TXV System)				°F °F
Discharge Circuit 1 Subcooling (TXV System) Discharge Circuit 2 Subcooling (TXV System) (HEAT PUMP ONLY)		PSIG		°F °F °F
Discharge Circuit 1 Subcooling (TXV System) Discharge Circuit 2 Subcooling (TXV System) (HEAT PUMP ONLY) Suction Circuit 1		PSIG		°F °F °F

### THIS PAGE IS INTENTIONALLY LEFT BLANK

## THIS PAGE IS INTENTIONALLY LEFT BLANK

# THIS PAGE IS INTENTIONALLY LEFT BLANK

#### CUSTOMER FEEDBACK

Daikin is very interested in all product comments.

Please fill out the feedback form on the following link:

https://daikincomfort.com/contact-us

You can also scan the QR code on the right to be directed to the Feedback page.



Our continuing commitment to quality products may mean a change in specifications without notice.

© 2018-2020 **DAIKIN MANUFACTURING COMPANY, L.P.** 19001 Kermier Rd. Waller, Tx 77484 <u>www.daikincomfort.com</u>