EDUS041820





Engineering Data

Split Type Air Conditioners

- Heat Pump -

FTXR-T Series







Split Type Air Conditioners FTXR-T Series

Heat Pump FTXR12TVJUS FTXR18TVJUW	Heat Pump		RX09RMVJU9 RX12RMVJU9 RX18RMVJU9
---	-----------	--	--

1.	Power Supply	3
2.	Functions	4
3.	Specifications	5
4.	Dimensions	
	4.1 Indoor Unit	8
	4.2 Outdoor Unit	9
5.	Wiring Diagrams	
	5.1 Indoor Unit	
	5.2 Outdoor Unit	
6.	Piping Diagrams	
	6.1 Indoor Unit	
_	6.2 Outdoor Unit	
7.	Capacity Tables	14
	7.1 Capacity Correction Factor by the Length of Refrigerant Piping (Reference)	23
8.	Operation Limit	
0. 9.	Sound Level	
9.	9.1 Measuring Location	
	9.2 Indoor Unit	
	9.3 Outdoor Unit	
10	Electric Characteristics	
	Installation Manual	
• •	11.1 Indoor Unit	
	11.2 Outdoor Unit	
12	Operation Manual	57
	Optional Accessories	
	13.1 Option List	
	13.2 <brc944b2> Wired Remote Controller</brc944b2>	

13.3 <brcw901a03 08=""> Wired Remote Controller Cord</brcw901a03>	. 107
13.4 <brp072a43> Wireless LAN Connection Adaptor</brp072a43>	. 108
13.5 <krp413ab1s> Wiring Adaptor for Timer Clock /</krp413ab1s>	
Remote Controller	. 116
13.6 <dcs302c71> Central Remote Controller</dcs302c71>	. 120
13.7 <dcs301c71> Unified ON/OFF Controller</dcs301c71>	
13.8 <dst301ba61> Schedule Timer Controller</dst301ba61>	. 158
13.9 <krp928bb2s> Interface Adaptor for DIII-NET</krp928bb2s>	
(Residential Air Conditioner)	. 177
13.10 <kpw937e4> Air Direction Adjustment Grille</kpw937e4>	
13.11 <kpw063a4> Air Direction Adjustment Grille</kpw063a4>	
13.12 <kkg067a41> Back Protection Wire Net</kkg067a41>	. 184
13.13 <kkg063a42> Back Protection Wire Net</kkg063a42>	. 185
13.14 <ftdbhms, ftdbhml,="" keh063a4e="" keh067a41e,=""></ftdbhms,>	
Drain Pan Heater	
13.15 <kps067a41> Snow Hood (Intake Side Plate)</kps067a41>	
13.16 <kps067a42> Snow Hood (Intake Rear Plate)</kps067a42>	
13.17 <kps067a44> Snow Hood (Outlet)</kps067a44>	. 196
13.18 <kps063a41> Snow Hood (Intake Side Plate)</kps063a41>	
13.19 <kps063a44> Snow Hood (Intake Rear Plate)</kps063a44>	. 200
13.20 <kps063a47> Snow Hood (Outlet)</kps063a47>	. 202



Cautions
1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided and choose an outdoor unit with anti-corrosion treatment.

1. Power Supply

Indoor Unit	Outdoor Unit	Power Supply
FTXR09TVJUW	BX09BMVJU9	
FTXR09TVJUS		
FTXR12TVJUW		
FTXR12TVJUS		1 phase, 208 - 230 V, 60 Hz
FTXR18TVJUW	RX18RMVJU9	
FTXR18TVJUS		

Note: Power Supply Intake; Outdoor Unit

2. Functions

Category	Functions	FTXR09/12/18TVJUW(S) RX09/12/18RMVJU9	Category	Functions	FTXR09/12/18TVJUW(S) RX09/12/18RMVJU9
Basic	Inverter (with inverter power control)	•	Health &	Titanium apatite deodorizing filter	•
Functions	Operation limit for cooling	Refer to	Cleanliness	Mold proof air filter	•
	Operation limit for heating	P. 24		Wipe-clean flat panel	•
	PAM control	•	-	Washable grille	—
	Standby electricity saving	—		MOLD PROOF operation	—
Compressor	Oval scroll compressor	—		Good-sleep cooling operation	—
	Swing compressor	•	Timer	WEEKLY TIMER operation	•
	Rotary compressor	—		Count up-down ON/OFF timer	—
	Reluctance DC motor	•		24-hour ON/OFF TIMER	•
Comfortable Airflow	Power-airflow flap	—		NIGHT SET mode	•
AITIOW	Power-airflow dual flaps	•	Worry Free (Reliability &	Auto-restart (after power failure)	•
	Power-airflow diffuser	_	Durability)	Self-diagnosis (R/C)	•
	Wide-angle louvers	•		Anti-corrosion treatment of outdoor heat	•
	Auto-swing (up and down)	•		exchanger	-
	Auto-swing (right and left)	•	Flexibility	Multi-split/split type compatible indoor unit	•
	3-D airflow COMFORT AIRFLOW operation	•	-	Chargeless	32.8 ft (10 m)
Comfort	Auto fan speed	•	-	Either side drain (right or left)	•
Control	Indoor unit quiet operation	•	-	Power selection	_
	NIGHT QUIET mode (automatic)	_	-	Low outdoor temperature cooling operation	
	OUTDOOR UNIT QUIET operation (manual)	•	-	$(-15^{\circ}C)$ (5°F)	•
	INTELLIGENT EYE operation (auto energy saving)	•		Low outdoor temperature cooling operation (-20°C) (-4°F)	•*
	2-area INTELLIGENT EYE operation (comfort)	•	-	°F/°C changeover R/C temperature display	
	Quick warming function (preheating operation)	•	-	(factory setting: °F)	•
	Hot-start function	•	Remote	Wireless LAN connection (option)	•
	Automatic defrosting	•	Control	Remote control adaptor	_
	Fan stop when thermo-off in cooling	•		(normal open pulse contact) (option)	•
Operation	Automatic cooling/heating changeover	٠		Remote control adaptor	
	Program dry function	•		(normal open contact) (option)	•
	Fan only	•		DIII-NET compatible (adaptor) (option)	•
Lifestyle	POWERFUL operation (inverter)	•	Remote	Wireless	•
Convenience	HOME LEAVE operation	_	Controller	Wired (option)	•
	ECONO operation	•			
	Indoor unit ON/OFF button	•			
	Multi-colored indicator lamp	•			
	Multi-colored lamp brightness setting	•			
	Signal receiving sign	•			
	R/C with back light	•			
	Temperature display	—			

Note: • : Available

- : Not available

 \star Requires wind baffle and field settings

3. Specifications

60 Hz, 208 - 230 V

	Indoor Unit		FTXR09TVJUW		FTXR09TVJUS	
Model	Outdoor Unit			MVJU9	RX09RMVJU9	
0 "	editabol enit		Cooling	Heating	Cooling	Heating
Capacity Rated (Min. ~ Max.)		Btu/h	9,000 (4,500 ~ 10,600)	10,000 (4,100 ~ 14,600)	9,000 (4,500 ~ 10,600)	10,000 (4,100 ~ 14,600
Running current		Α	4.28 - 3.87	3.83 - 3.46	4.28 - 3.87	3.83 - 3.46
Power Consumption	(Rated)	W	819	733	819	733
Power Factor (Rated	() ()	%	92.0 - 92.0	92.0 - 92.1	92.0 - 92.0	92.0 - 92.1
EER (Rated)	/	Btu/h·W	11.00		11.00	_
COP (Rated)		W/W	_	4.00		4.00
SEER / HSPF			18.00	9.30	18.00	9.30
	Liquid	in. (mm)	φ 1/4			(6.4)
Piping Connections	Gas	in. (mm)	¢ 3/8	()		(9.5)
Drain		in. (mm)	¢ 30 (0.0)		φ 0.0 (0.0) φ 11/16 (18)	
No. of Wiring Connec			3 for Power Supply,	4 for Interunit Wiring round Wiring)	3 for Power Supply,	4 for Interunit Wiring round Wiring)
Max. Interunit Piping	Length	ft (m)		i (20)	0	(20)
Max. Interunit Height		ft (m)	49.2			(15)
U	Difference	. ,				
Chargeless Amount of Additional	Chargo of	ft (m)		(10)		(10)
Amount of Additional Refrigerant	charge of	oz/ft (g/m)	0.21	(20)	0.21	(20)
Indoor Unit		(9,11)	FTXR0	TVJUW	FTXR0	TVJUS
Front Panel Color				nite		ver
	Н		272 (7.7)	346 (9.8)	272 (7.7)	346 (9.8)
	M	cfm	208 (5.9)	258 (7.3)	208 (5.9)	258 (7.3)
Airflow Rate	1	(m ³ /min)	162 (4.6)	201 (5.7)	162 (4.6)	201 (5.7)
	SL	,	134 (3.8)	117 (3.3)	134 (3.8)	117 (3.3)
	H		1,410	1,720	1,410	1,720
	M	-	1,140	1,340	1,140	1,340
an Motor	1	rpm	940	1,100	940	1,100
	SL		820	760	820	760
	-	1		low Fan		low Fan
-an	Type Speed	Steps		Quiet, Auto		
		Sieps			5 Steps, Quiet, Auto Multi Slit Fin	
-leat Exchanger	Type		Multi Slit Fin			
leat Exchanger	Rows × Stages Fin per Inch	ò,	2 × 1	8, 21	2 × 1	8, 21
Remote Controller	r in per men		ARC466A36		ARC466A36	
Dimensions (H × W >	x D)	in. (mm)	11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)		11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)	
Packaged Dimension		in. (mm)			12-11/16 × 43-3/8 × 15-5/16 (322 × 1,101 × 389)	
Weight (Mass)		Lbs (kg)	12-11/16 × 43-3/8 × 15-5/16 (322 × 1,101 × 389) 27 (12)		27 (12)	
Gross Weight (Gross	Mace)	Lbs (kg)		(16)	36 (16)	
Sound Pressure Leve		dB(A)	38/32/25/19	41/34/28/19	38/32/25/19	41/34/28/19
Outdoor Unit						
Casing Color			RX09RMVJU9 Ivory White		RX09RMVJU9 Ivory White	
	Туре		· · · · · · · · · · · · · · · · · · ·	aled Swing Type	Ivory White Hermetically Sealed Swing Type	
Compressor	Model				,	0 /1
	Туре		1YC23AUXD FVC50K		1YC23AUXD FVC50K	
Refrigerant Oil	Charge	oz (L)		(0.375)	12.68 (0.375)	
	Type	∪∠ (∟)		10A		(0.373) 10A
Refrigerant	Charge	Lbs (kg)		(0.95)		(0.95)
Airflow Rate	Onlarge	cfm (m ³ /min)	985 (27.9)	1,130 (32)	985 (27.9)	1,130 (32)
an Motor	Н	rpm	800	910	800	910
an	Туре			peller		peller
	Туре			le Fin		le Fin
Heat Exchanger	Rows × Stages Fin per Inch	δ,		24, 17		24, 17
Dimensions (H × W >		in. (mm)	21-5/8 × 26-9/16 × 11-	3/16 (550 × 675 × 284)	21-5/8 × 26-9/16 × 11-	3/16 (550 × 675 × 284)
Packaged Dimension	,	in. (mm)		16 (629 × 830 × 407)		16 (629 × 830 × 407)
Veight (Mass)		Lbs (kg)		(27)		(27)
	Mass)	Lbs (kg)		(32)		()
Gross Weight (Gross Mass)		dB(A)	46	50	71 (32) 46 50	
Sound Pressure Leve	el					

Notes:

1. SL: The Quiet fan level of the airflow rate setting.

 When connected with multi-system outdoor unit, refer to the specifications of the multi outdoor unit to be connected.
 The data are based on the conditions of any based on the conditions of the multi outdoor unit to be

3.	The data are ba	The data are based on the conditions shown in the table below.				
	Cooling	Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB) / 75°FWB (23.9°CWB)				
	Heating	Indoor ; 70°FDB (21.1°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.33°CDB) / 43°FWB (6.11°CWB)				
I	Piping Length	25 ft (7.5 m)				

Conversion Formulae
$\begin{array}{l} \text{kcal/h} = \text{kW} \times 860 \\ \text{Btu/h} = \text{kW} \times 3412 \\ \text{cfm} = \text{m}^3/\text{min} \times 35.3 \end{array}$

60 Hz, 208 - 230 V

	Indoor Unit		FTXR12	TVJUW	FTXR12TVJUS		
Model			RX12R		RX12RMVJU9		
	Outdoor Unit	-	Cooling Heating		Cooling Heating		
Capacity Rated (Min. ~ Max.)		Btu/h	12,000 (4,500 ~ 12,800)	13,500 (4,100 ~ 15,800)	12,000 (4,500 ~ 12,800)	13,500 (4,100 ~ 15,800	
Running current		Α	5.46 - 4.94	5.60 - 5.06	5.46 - 4.94	5.60 - 5.06	
Power Consumption (F	Rated)	W	1,091	1,106	1,091	1,106	
Power Factor (Rated)		%	96.1 - 96.0	95.0 - 95.0	96.1 - 96.0	95.0 - 95.0	
EER (Rated)		Btu/h⋅W	11.00	_	11.00	_	
COP (Rated)		W/W	_	3.58		3.58	
SEER / HSPF		1	17.00	10.00	17.00	10.00	
Liquid		in. (mm)	¢ 1/4	(6.4)	o 1/4	(6.4)	
Piping Connections	Gas	in. (mm)	¢ 3/8	(9.5)	¢ 3/8	3 (9.5)	
1 0	Drain	in. (mm)	¢ 11/1	· · ·		16 (18)	
No. of Wiring Connect	ion		3 for Power Supply, (Including Gro	4 for Interunit Wiring	3 for Power Supply,	4 for Interunit Wiring round Wiring)	
Max. Interunit Piping L	ength	ft (m)	65.6	(20)	65.6	6 (20)	
Max. Interunit Height D	Difference	ft (m)	49.2	(15)	49.2	2 (15)	
Chargeless		ft (m)	32.8	(10)	32.8	3 (10)	
Amount of Additional C Refrigerant	Charge of	oz/ft (g/m)	0.21			(20)	
Indoor Unit			FTXR12	TVJUW	FTXR1	2TVJUS	
Front Panel Color			Wh	ite	Si	lver	
	Н		335 (9.5)	395 (11.2)	335 (9.5)	395 (11.2)	
	М	cfm	219 (6.2)	290 (8.2)	219 (6.2)	290 (8.2)	
Airflow Rate	L	(m ³ /min)	169 (4.8)	226 (6.4)	169 (4.8)	226 (6.4)	
	SL		131 (3.7)	131 (3.7)	131 (3.7)	131 (3.7)	
	Н		1,710	1,930	1,710	1,930	
	М	-	1,210	1,470	1,210	1,470	
an Motor	L	rpm	990	1,200	990	1,200	
	SL		820	800	820	800	
-	Туре	1	Cross Fl	ow Fan	Cross F	Flow Fan	
an	Speed	Steps	5 Steps, C	uiet, Auto	5 Steps, Quiet, Auto		
	Туре		Multi S	lit Fin	Multi	Slit Fin	
Heat Exchanger	Rows × Stages	s,	0 - 1	2 01	2 × 18, 21		
	Fin per Inch		2 × 18, 21		· ·		
Remote Controller			ARC466A36		ARC466A36		
Dimensions ($H \times W \times$		in. (mm)	11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)		11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)		
Packaged Dimensions	$(H \times W \times D)$	in. (mm)	12-11/16 × 43-3/8 × 15-5		12-11/16 × 43-3/8 × 15-5/16 (322 × 1,101 × 389)		
Weight (Mass)		Lbs (kg)	27 (,	27 (12)		
Gross Weight (Gross I		Lbs (kg)	36 (,		(16)	
Sound Pressure Level	H/M/L/SL	dB(A)	45 / 34 / 26 / 20	45 / 37 / 29 / 20	45 / 34 / 26 / 20	45 / 37 / 29 / 20	
Outdoor Unit			RX12RMVJU9		RX12RMVJU9		
Casing Color			Ivory \		Ivory White		
Compressor	Туре		Hermetically Sea		Hermetically Sealed Swing Type		
	Model		1YC23		1YC23AUXD		
Refrigerant Oil	Туре		FVC		FVC50K		
geran en	Charge	oz (L)	12.68 (,		(0.375)	
Refrigerant	Type Charge	Lbs (kg)			R-410A 2.09 (0.95)		
Airflow Rate	onargo	cfm (m ³ /min)	1,105 (31.3)	1,130 (32)	1,105 (31.3)	1,130 (32)	
an Motor	Н	rpm	890	910	890	910	
Fan	Туре	.14	Prop			peller	
	Туре					ile Fin	
Heat Exchanger	Rows × Stages	э,	Waffle Fin 2 × 24, 17		2 × 24, 17		
Dimensions ($H \times W \times I$		in. (mm)	21-5/8 × 26-9/16 × 11-3	3/16 (550 × 675 × 284)	21-5/8 × 26-9/16 × 11-	-3/16 (550 × 675 × 284)	
Packaged Dimensions	,	in. (mm)	24-3/4 × 32-11/16 × 1			16 (629 × 830 × 407)	
Weight (Mass)	. /	Lbs (kg)	60 (. ,		(27)	
Gross Weight (Gross I	Mass)	Lbs (kg)		,		(32)	
		dB(A)	71 (32) 49 51		49	(<i>)</i>	
Sound Pressure Level		UDIA	49	51	49	51	

Notes:

SL: The Quiet fan level of the airflow rate setting.
 When connected with multi-system outdoor unit, refer to the specifications of the multi outdoor unit to be

connected. The data are based on the conditions shown in the table below. 3

0.	The data are be	
	Cooling	Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB) / 75°FWB (23.9°CWB)
	Heating	Indoor ; 70°FDB (21.1°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.33°CDB) / 43°FWB (6.11°CWB)
F	Piping Length	25 ft (7.5 m)

	Conversion Formulae
	$\begin{array}{l} kcal/h = kW \times 860 \\ Btu/h = kW \times 3412 \\ cfm = m^3/min \times 35.3 \end{array}$
1	

60 Hz, 208 - 230V

	Indoor Unit		FTXR18	TVJUW	FTXR18TVJUS		
Model			RX18R		RX18RMVJU9		
mouor	Outdoor Unit		Cooling Heating		Cooling	Heating	
Capacity Rated (Min. ~ Max.)		Btu/h	18,000 (5,100 ~ 18,500)	20,000 (5,800 ~ 21,200)	18,000 (5,100 ~ 18,500)	20,000 (5,800 ~ 21,200	
Running current		А	9.29 - 8.40	8.70 - 7.87	9.29 - 8.40	8.70 - 7.87	
Power Consumption (I	Rated)	W	1,875	1,755	1,875	1,755	
Power Factor (Rated)		%	97.0 - 97.0	97.0 - 97.0	97.0 - 97.0	97.0 - 97.0	
EER (Rated)		,o Btu/h⋅W	9.60	_	9.60		
COP (Rated)		W/W		3.34		3.34	
SEER / HSPF		V V/ V V	14.50	9.80	14.50	9.80	
SELR/HOFT	Liquid	in (mm)				9.00 1 (6.4)	
	Liquid Gas	in. (mm)	φ 1/4 (6.4) φ 1/2 (12.7)			\ <i>\</i>	
Piping Connections		in. (mm)				(12.7)	
	Drain	in. (mm)	φ 11/1			16 (18)	
No. of Wiring Connect	tion		3 for Power Supply, 4 Including Gro	4 for Interunit Wiring ound Wiring)	3 for Power Supply, (Including G	4 for Interunit Wiring round Wiring)	
Vax. Interunit Piping L	_ength	ft (m)	98.4	(30)	98.4	4 (30)	
Max. Interunit Height [ft (m)	65.6			6 (20)	
Chargeless		ft (m)	32.8			3 (10)	
Amount of Additional (Refrigerant	Charge of	oz/ft (g/m)	0.21			I (20)	
ndoor Unit		(9/11)	FTXR18	TV.IIIW	ETVD1	8TVJUS	
Front Panel Color			Wh			lver	
TUTIL Fallel COlOF							
	Н	4 .	350 (9.9)	413 (11.7)	350 (9.9)	413 (11.7)	
Airflow Rate	M	cfm	275 (7.8)	332 (9.4)	275 (7.8)	332 (9.4)	
	L	(m³/min)	226 (6.4)	275 (7.8)	226 (6.4)	275 (7.8)	
	SL		208 (5.9)	208 (5.9)	208 (5.9)	208 (5.9)	
	Н		1,760	2,000	1,760	2,000	
an Motor	Μ	mm	1,440	1,660	1,440	1,660	
	L	rpm	1,230	1,420	1,230	1,420	
	SL		1,160	1,130	1,160	1,130	
_	Туре		Cross Fl	ow Fan	Cross	Flow Fan	
-an	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto		
	Туре		Multi S		,	Slit Fin	
-leat Exchanger	Rows × Stages	:					
0	Fin per Inch	.,	2 × 18	3, 21	2×1	18, 21	
Remote Controller			ARC466A36		ARC466A36		
Dimensions ($H \times W \times$	D)	in. (mm)	11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)		11-15/16 × 39-5/16 × 8-3/8 (303 × 998 × 212)		
Packaged Dimensions		in. (mm)	12-11/16 × 43-3/8 × 15-5		12-11/16 × 43-3/8 × 15-5/16 (322 × 1,101 × 389)		
Weight (Mass)	(Lbs (kg)	27 (27 (12)		
Gross Weight (Gross I	Mass)	Lbs (kg)	36 (36 (16)		
Sound Pressure Level		dB(A)	46 / 40 / 35 / 30	47 / 41 / 35 / 30	46 / 40 / 35 / 30	47/41/35/30	
Outdoor Unit			RX18RI		RX18RMVJU9		
Casing Color			lvory \				
	Туре		Hermetically Sea		Ivory White Hermetically Sealed Swing Type		
Compressor	Model		2YC3				
					2YC36PXD		
Refrigerant Oil	Туре	(1)	FVC		FVC50K		
Refrigerant Oil	Charge	oz (L)	21.98 (,	21.98 (0.650)		
<u> </u>			R-410A		R-410A 2.49 (1.13)		
Refrigerant	Type Charge	Lbs (kg)	2.49 (1.13)	2.49	(1.10)	
Refrigerant	Туре	cfm		1.13) 2,553 (72.3)	2,461 (69.7)	2,553 (72.3)	
Refrigerant Nirflow Rate	Туре		2.49 (
Refrigerant Airflow Rate	Type Charge H	cfm (m³/min)	2.49 (2,461 (69.7) 850	2,553 (72.3) 880	2,461 (69.7) 850	2,553 (72.3) 880	
Refrigerant Airflow Rate	Type Charge H Type	cfm (m³/min)	2.49 (2,461 (69.7) 850 Prop	2,553 (72.3) 880 eller	2,461 (69.7) 850 Pro	2,553 (72.3) 880 peller	
Refrigerant Airflow Rate Fan Motor	Type Charge H Type Type Rows × Stages	cfm (m³/min) rpm	2.49 (2,461 (69.7) 850	2,553 (72.3) 880 eller e Fin	2,461 (69.7) 850 Pro Waf	2,553 (72.3) 880	
Refrigerant Airflow Rate Fan Motor Fan Heat Exchanger	Type Charge H Type Type Rows × Stages Fin per Inch	cfm (m³/min) rpm	2.49 (2,461 (69.7) 850 Prop Waffle 1 × 3	2,553 (72.3) 880 eller e Fin 2, 18	2,461 (69.7) 850 Pro Waf 1 × 3	2,553 (72.3) 2,553 (72.3) 2,555 (72.3) 2,	
Refrigerant Airflow Rate Fan Motor Fan Heat Exchanger Dimensions (H × W ×	Type Charge H Type Type Rows × Stages Fin per Inch D)	cfm (m³/min) rpm	2.49 (2,461 (69.7) 850 Prop Wafflu 1 × 3 28-15/16 × 34-1/4 × 12	2,553 (72.3) 880 eller a Fin 2, 18 -5/8 (735 × 870 × 320)	2,461 (69.7) 850 Pro Waf 1 × 3 28-15/16 × 34-1/4 × 1	2,553 (72.3) 2,553 (72.3) 2,553 (72.3) 880 2,563 (72.3) 880 2,553 (72.3) 820 2,553 (72.3) 820 2,553 (72.3) 820 2,553 (72.3) 820 2,553 (72.3) 820 2,555 (72.3) 820 820 820 820 820 820 820 820	
Refrigerant Airflow Rate Fan Motor Fan Heat Exchanger Dimensions (H × W × Packaged Dimensions	Type Charge H Type Type Rows × Stages Fin per Inch D)	cfm (m ³ /min) rpm	2.49 (2,461 (69.7) 850 Prop Wafflu 1 × 32 28-15/16 × 34-1/4 × 12 31-7/8 × 41-9/16 × 17-1	2,553 (72.3) 880 eller e Fin 2, 18 -5/8 (735 × 870 × 320) /2 (810 × 1,056 × 464)	2,461 (69.7) 850 Pro Waf 1 × 3 28-15/16 × 34-1/4 × 11 31-7/8 × 41-9/16 × 17-	2,553 (72.3) 880 peller ile Fin 32, 18 2-5/8 (735 × 870 × 320) 1/2 (810 × 1,056 × 464)	
Refrigerant Airflow Rate Fan Motor Fan Heat Exchanger Dimensions (H × W × Packaged Dimensions Neight (Mass)	Type Charge H Type Type Rows × Stages Fin per Inch D) s (H × W × D)	cfm (m³/min) rpm in. (mm) in. (mm) Lbs (kg)	2.49 (2,461 (69.7) 850 Prop Waffli 1 × 3 28-15/16 × 34-1/4 × 12 31-7/8 × 41-9/16 × 17-1 97 (2,553 (72.3) 880 eller e Fin 2, 18 -5/8 (735 × 870 × 320) /2 (810 × 1,056 × 464) 44)	2,461 (69.7) 850 Pro Waf 1 × 3 28-15/16 × 34-1/4 × 1 31-7/8 × 41-9/16 × 17- 97	2,553 (72.3) 2,553 (72.3) 2,553 (72.3) 880 peller file Fin 32, 18 2-5/8 (735 × 870 × 320) 1/2 (810 × 1,056 × 464) (44)	
	Type Charge H Type Type Rows × Stages Fin per Inch D) s (H × W × D) Mass)	cfm (m ³ /min) rpm	2.49 (2,461 (69.7) 850 Prop Wafflu 1 × 32 28-15/16 × 34-1/4 × 12 31-7/8 × 41-9/16 × 17-1	2,553 (72.3) 880 eller e Fin 2, 18 -5/8 (735 × 870 × 320) /2 (810 × 1,056 × 464) 44)	2,461 (69.7) 850 Pro Waf 1 × 3 28-15/16 × 34-1/4 × 1 31-7/8 × 41-9/16 × 17- 97	2,553 (72.3) 880 peller ile Fin 32, 18 2-5/8 (735 × 870 × 320) 1/2 (810 × 1,056 × 464)	

Notes:

SL: The Quiet fan level of the airflow rate setting.
 When connected with multi-system outdoor unit, refer to the specifications of the multi outdoor unit to be

connected. The data are based on the conditions shown in the table below. 3.

0. 1110 data are be	
Cooling	Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB) / 75°FWB (23.9°CWB)
Heating	Indoor ; 70°FDB (21.1°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.33°CDB) / 43°FWB (6.11°CWB)
Piping Length	25 ft (7.5 m)

Conversion Formulae
$\label{eq:kcal/h} \begin{array}{l} kcal/h = kW \times 860 \\ Btu/h = kW \times 3412 \\ cfm = m^3 \! / \! min \times 35.3 \end{array}$

4. Dimensions

4.1 Indoor Unit

FTXR09/12TVJUW(S)



FTXR18TVJUW(S)



4.2 Outdoor Unit

RX09/12RMVJU9



RX18RMVJU9



5. Wiring Diagrams

5.1 Indoor Unit

FTXR09/12/18TVJUW(S)



3D103375A

5.2 Outdoor Unit

RX09/12RMVJU9



RX18RMVJU9



6. Piping Diagrams

6.1 Indoor Unit

FTXR09/12TVJUW(S)



4D101008A

FTXR18TVJUW(S)



4D101010A

6.2 Outdoor Unit

RX09/12RMVJU9



RX18RMVJU9



7. Capacity Tables

FTXR09TVJUW + RX09RMVJU9 FTXR09TVJUS + RX09RMVJU9

60 Hz, 208 V

Cooling

eeening	
AFR	7.7
BF	0.16

Temp: Celsius

TC, SHC, PI: kW

INDO	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10		20				30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.53	1.90	0.34	2.53	1.90	0.53	2.46	1.86	0.75	2.34	1.80	0.81	2.21	1.74	0.87	2.07	1.67	0.94
16.0	22.0	3.07	2.07	0.51	2.83	1.95	0.63	2.58	1.83	0.75	2.46	1.78	0.81	2.33	1.72	0.87	2.19	1.66	0.95
18.0	25.0	3.19	2.15	0.51	2.95	2.04	0.64	2.70	1.93	0.76	2.58	1.88	0.82	2.46	1.83	0.88	2.31	1.76	0.95
19.4	26.7	3.25	2.26	0.52	3.01	2.15	0.64	2.76	2.04	0.76	2.64	1.99	0.82	2.52	1.94	0.88	2.37	1.88	0.95
22.0	30.0	3.44	2.16	0.52	3.19	2.07	0.64	2.95	1.98	0.76	2.82	1.93	0.82	2.70	1.89	0.88	2.55	1.84	0.96
24.0	32.0	3.56	2.10	0.53	3.31	2.01	0.65	3.07	1.93	0.77	2.94	1.89	0.83	2.82	1.85	0.89	2.67	1.80	0.96

Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

INDO	DOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	8.62	6.47	0.34	8.62	6.47	0.53	8.39	6.35	0.75	7.97	6.15	0.81	7.55	5.94	0.87	7.05	5.70	0.94
60.8	71.6	10.48	7.06	0.51	9.64	6.66	0.63	8.80	6.26	0.75	8.39	6.07	0.81	7.97	5.87	0.87	7.46	5.65	0.95
64.4	77.0	10.90	7.34	0.51	10.06	6.96	0.64	9.22	6.59	0.76	8.80	6.41	0.82	8.38	6.23	0.88	7.88	6.02	0.95
67.0	80.0	11.10	7.69	0.52	10.27	7.33	0.64	9.43	6.97	0.76	9.00	6.80	0.82	8.59	6.63	0.88	8.08	6.42	0.95
71.6	86.0	11.73	7.39	0.52	10.89	7.06	0.64	10.05	6.75	0.76	9.63	6.60	0.82	9.21	6.44	0.88	8.71	6.26	0.96
75.2	89.6	12.14	7.17	0.53	11.30	6.87	0.65	10.46	6.59	0.77	10.05	6.45	0.83	9.63	6.31	0.89	9.12	6.14	0.96

Heating

9.8

AFR Temp: Celsius

TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°CW	'B)				
EDB		15	-	10	-	-5	()	(6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.40	0.53	1.68	0.56	1.96	0.59	2.25	0.61	3.04	0.72	3.31	0.74	3.84	0.79
21.1	1.31	0.55	1.60	0.57	1.88	0.60	2.16	0.63	2.94	0.73	3.21	0.76	3.74	0.81
22.0	1.28	0.55	1.56	0.58	1.84	0.61	2.13	0.63	2.90	0.74	3.16	0.76	3.70	0.81
24.0	1.24	0.56	1.53	0.58	1.81	0.61	2.09	0.64	2.86	0.75	3.12	0.77	3.66	0.82
25.0	1.23	0.56	1.51	0.59	1.79	0.61	2.07	0.64	2.84	0.75	3.10	0.77	3.64	0.82
27.0	1.19	0.57	1.48	0.59	1.76	0.62	2.04	0.65	2.80	0.76	3.06	0.78	3.59	0.83

Temp: Fahrenheit

TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.53	5.74	0.56	6.70	0.59	7.67	0.61	10.38	0.72	11.28	0.74	13.10	0.79
70.0	4.48	0.55	5.45	0.57	6.41	0.60	7.37	0.63	10.00	0.73	10.94	0.76	12.75	0.81
71.6	4.37	0.55	5.33	0.58	6.29	0.61	7.25	0.63	9.89	0.74	10.80	0.76	12.61	0.81
75.2	4.25	0.56	5.21	0.58	6.17	0.61	7.14	0.64	9.75	0.75	10.66	0.77	12.47	0.82
77.0	4.19	0.56	5.15	0.59	6.11	0.61	7.08	0.64	9.69	0.75	10.59	0.77	12.40	0.82
80.6	4.07	0.57	5.03	0.59	6.00	0.62	6.96	0.65	9.55	0.76	10.45	0.78	12.27	0.83

60 Hz, 230 V

Cooling	
AFR	7.7
BF	0.16

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.53	1.90	0.34	2.53	1.90	0.53	2.46	1.86	0.75	2.34	1.80	0.81	2.21	1.74	0.87	2.07	1.67	0.94
16.0	22.0	3.07	2.07	0.51	2.83	1.95	0.63	2.58	1.83	0.75	2.46	1.78	0.81	2.33	1.72	0.87	2.19	1.66	0.95
18.0	25.0	3.19	2.15	0.51	2.95	2.04	0.64	2.70	1.93	0.76	2.58	1.88	0.82	2.46	1.83	0.88	2.31	1.76	0.95
19.4	26.7	3.25	2.26	0.52	3.01	2.15	0.64	2.76	2.04	0.76	2.64	1.99	0.82	2.52	1.94	0.88	2.37	1.88	0.95
22.0	30.0	3.44	2.16	0.52	3.19	2.07	0.64	2.95	1.98	0.76	2.82	1.93	0.82	2.70	1.89	0.88	2.55	1.84	0.96
24.0	32.0	3.56	2.10	0.53	3.31	2.01	0.65	3.07	1.93	0.77	2.94	1.89	0.83	2.82	1.85	0.89	2.67	1.80	0.96

Temp: Fahrenheit TC, SHC: kBtu/h PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	8.62	6.47	0.34	8.62	6.47	0.53	8.39	6.35	0.75	7.97	6.15	0.81	7.55	5.94	0.87	7.05	5.70	0.94
60.8	71.6	10.48	7.06	0.51	9.64	6.66	0.63	8.80	6.26	0.75	8.39	6.07	0.81	7.97	5.87	0.87	7.46	5.65	0.95
64.4	77.0	10.90	7.34	0.51	10.06	6.96	0.64	9.22	6.59	0.76	8.80	6.41	0.82	8.38	6.23	0.88	7.88	6.02	0.95
67.0	80.0	11.10	7.69	0.52	10.27	7.33	0.64	9.43	6.97	0.76	9.00	6.80	0.82	8.59	6.63	0.88	8.08	6.42	0.95
71.6	86.0	11.73	7.39	0.52	10.89	7.06	0.64	10.05	6.75	0.76	9.63	6.60	0.82	9.21	6.44	0.88	8.71	6.26	0.96
75.2	89.6	12.14	7.17	0.53	11.30	6.87	0.65	10.46	6.59	0.77	10.05	6.45	0.83	9.63	6.31	0.89	9.12	6.14	0.96

Heating

9.8

AFR Temp: Celsius TC, PI: kW

INDOOR		OUTDOOR TEMPERATURE (°CWB)													
EDB	-	15		10	-	5	()	(6	1	0	1	8	
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	
15.0	1.40	0.53	1.68	0.56	1.96	0.59	2.25	0.61	3.04	0.72	3.31	0.74	3.84	0.79	
21.1	1.31	0.55	1.60	0.57	1.88	0.60	2.16	0.63	2.94	0.73	3.21	0.76	3.74	0.81	
22.0	1.28	0.55	1.56	0.58	1.84	0.61	2.13	0.63	2.90	0.74	3.16	0.76	3.70	0.81	
24.0	1.24	0.56	1.53	0.58	1.81	0.61	2.09	0.64	2.86	0.75	3.12	0.77	3.66	0.82	
25.0	1.23	0.56	1.51	0.59	1.79	0.61	2.07	0.64	2.84	0.75	3.10	0.77	3.64	0.82	
27.0	1.19	0.57	1.48	0.59	1.76	0.62	2.04	0.65	2.80	0.76	3.06	0.78	3.59	0.83	

Temp: Fahrenheit TC: kBtu/h

PI: kW

INDOOR	OUTDOOR TEMPERATURE (°FWB)													
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.53	5.74	0.56	6.70	0.59	7.67	0.61	10.38	0.72	11.28	0.74	13.10	0.79
70.0	4.48	0.55	5.45	0.57	6.41	0.60	7.37	0.63	10.00	0.73	10.94	0.76	12.75	0.81
71.6	4.37	0.55	5.33	0.58	6.29	0.61	7.25	0.63	9.89	0.74	10.80	0.76	12.61	0.81
75.2	4.25	0.56	5.21	0.58	6.17	0.61	7.14	0.64	9.75	0.75	10.66	0.77	12.47	0.82
77.0	4.19	0.56	5.15	0.59	6.11	0.61	7.08	0.64	9.69	0.75	10.59	0.77	12.40	0.82
80.6	4.07	0.57	5.03	0.59	6.00	0.62	6.96	0.65	9.55	0.76	10.45	0.78	12.27	0.83

Symbols:

: Airflow rate	(m³/min.)
: Bypass factor	
: Entering wet bulb temp.	(°C) / (°F)
: Entering dry bulb temp.	(°C) / (°F)
: Total capacity	(kW) / (kBtu/h)
: Sensible heat capacity	(kW) / (kBtu/h)
: Power input	(kW)
	 Bypass factor Entering wet bulb temp. Entering dry bulb temp. Total capacity Sensible heat capacity

Notes:

- shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D120261

FTXR12TVJUW + RX12RMVJU9 FTXR12TVJUS + RX12RMVJU9

60 Hz, 208 V

Cooling	
AFR	9.5
BF	0.19

Temp: Celsius

TC, SHC, PI: kW

INDO	DOR							0	UTDOO	R TEMP	ERATUR	RE (°CD	B)						
EWB	EDB		10 20					30			35			40			46		
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.01	2.26	0.32	3.01	2.26	0.52	3.01	2.26	0.82	3.01	2.26	1.00	2.97	2.24	1.16	2.67	2.09	1.17
16.0	22.0	3.86	2.56	0.55	3.79	2.53	0.84	3.46	2.37	1.00	3.30	2.29	1.08	3.13	2.21	1.16	2.82	2.07	1.17
18.0	25.0	4.28	2.79	0.69	3.95	2.63	0.85	3.62	2.48	1.01	3.46	2.41	1.09	3.29	2.33	1.17	2.96	2.19	1.17
19.4	26.7	4.36	2.90	0.69	4.03	2.76	0.85	3.70	2.61	1.01	3.54	2.54	1.09	3.38	2.47	1.17	3.04	2.33	1.17
22.0	30.0	4.61	2.78	0.69	4.28	2.65	0.86	3.95	2.52	1.02	3.78	2.46	1.10	3.62	2.40	1.18	3.25	2.26	1.17
24.0	32.0	4.77	2.70	0.70	4.44	2.57	0.86	4.11	2.46	1.02	3.95	2.40	1.10	3.78	2.34	1.18	3.39	2.21	1.17

Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

INDO	DOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.26	7.70	0.32	10.26	7.70	0.52	10.26	7.70	0.82	10.26	7.70	1.00	10.12	7.63	1.16	9.11	7.13	1.17
60.8	71.6	13.17	8.75	0.55	12.93	8.63	0.84	11.81	8.08	1.00	11.24	7.81	1.08	10.68	7.54	1.16	9.61	7.05	1.17
64.4	77.0	14.61	9.50	0.69	13.49	8.97	0.85	12.36	8.46	1.01	11.80	8.21	1.09	11.24	7.96	1.17	10.11	7.47	1.17
67.0	80.0	14.89	9.91	0.69	13.77	9.40	0.85	12.64	8.90	1.01	12.00	8.66	1.09	11.52	8.42	1.17	10.36	7.94	1.17
71.6	86.0	15.73	9.50	0.69	14.60	9.04	0.86	13.48	8.60	1.02	12.91	8.39	1.10	12.35	8.18	1.18	11.09	7.71	1.17
75.2	89.6	16.28	9.20	0.70	15.16	8.78	0.86	14.03	8.38	1.02	13.47	8.19	1.10	12.91	7.99	1.18	11.58	7.55	1.17

Heating

11.2

Temp: Celsius

AFR

TC, PI: kW

INDOOR	1	OUTDOOR TEMPERATURE (°CWB)												
EDB	-15			10	-	-5	()	(6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.80	2.27	0.84	2.65	0.88	3.03	0.92	4.10	1.08	4.45	1.12	5.17	1.19
21.1	1.77	0.82	2.15	0.86	2.53	0.91	2.91	0.95	3.96	1.11	4.32	1.14	5.03	1.22
22.0	1.72	0.83	2.10	0.87	2.48	0.91	2.86	0.96	3.91	1.12	4.26	1.15	4.98	1.23
24.0	1.68	0.84	2.06	0.88	2.44	0.92	2.82	0.96	3.85	1.13	4.21	1.16	4.92	1.24
25.0	1.65	0.85	2.03	0.89	2.41	0.93	2.79	0.97	3.82	1.13	4.18	1.17	4.90	1.24
27.0	1.61	0.85	1.99	0.90	2.37	0.94	2.75	0.98	3.77	1.14	4.13	1.18	4.84	1.25

Temp: Fahrenheit

TC: kBtu/h

PI: kW

INDOOR		OUTDOOR TEMPERATURE (°FWB)												
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.80	7.73	0.84	9.03	0.88	10.33	0.92	13.98	1.08	15.20	1.12	17.64	1.19
70.0	6.04	0.82	7.33	0.86	8.63	0.91	9.93	0.95	13.50	1.11	14.73	1.14	17.17	1.22
71.6	5.88	0.83	7.18	0.87	8.47	0.91	9.77	0.96	13.32	1.12	14.55	1.15	16.99	1.23
75.2	5.72	0.84	7.02	0.88	8.31	0.92	9.61	0.96	13.14	1.13	14.36	1.16	16.80	1.24
77.0	5.64	0.85	6.94	0.89	8.24	0.93	9.53	0.97	13.05	1.13	14.27	1.17	16.71	1.24
80.6	5.48	0.85	6.78	0.90	8.08	0.94	9.37	0.98	12.86	1.14	14.08	1.18	16.52	1.25

EDUS041820

60 Hz, 230 V

Cooling	
AFR	9.5
BF	0.19

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10 20				30			35			40			46			
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.01	2.26	0.32	3.01	2.26	0.52	3.01	2.26	0.82	3.01	2.26	1.00	2.97	2.24	1.16	2.77	2.14	1.26
16.0	22.0	3.86	2.56	0.55	3.79	2.53	0.84	3.46	2.37	1.00	3.30	2.29	1.08	3.13	2.21	1.16	2.93	2.12	1.26
18.0	25.0	4.28	2.79	0.69	3.95	2.63	0.85	3.62	2.48	1.01	3.46	2.41	1.09	3.29	2.33	1.17	3.10	2.25	1.27
19.4	26.7	4.36	2.90	0.69	4.03	2.76	0.85	3.70	2.61	1.01	3.54	2.54	1.09	3.38	2.47	1.17	3.18	2.39	1.27
22.0	30.0	4.61	2.78	0.69	4.28	2.65	0.86	3.95	2.52	1.02	3.78	2.46	1.10	3.62	2.40	1.18	3.42	2.32	1.28
24.0	32.0	4.77	2.70	0.70	4.44	2.57	0.86	4.11	2.46	1.02	3.95	2.40	1.10	3.78	2.34	1.18	3.59	2.28	1.28

Temp: Fahrenheit

. TC, SHC: kBtu/h

PI: kW

IND	OOR		OUTDOOR TEMPERATURE (°FDB)																
EWB	EDB		50	68				86			95			104			115		
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.26	7.70	0.32	10.26	7.70	0.52	10.26	7.70	0.82	10.26	7.70	1.00	10.12	7.63	1.16	9.45	7.30	1.26
60.8	71.6	13.17	8.75	0.55	12.93	8.63	0.84	11.81	8.08	1.00	11.24	7.81	1.08	10.68	7.54	1.16	10.01	7.23	1.26
64.4	77.0	14.61	9.50	0.69	13.49	8.97	0.85	12.36	8.46	1.01	11.80	8.21	1.09	11.24	7.96	1.17	10.56	7.67	1.27
67.0	80.0	14.89	9.91	0.69	13.77	9.40	0.85	12.64	8.90	1.01	12.00	8.66	1.09	11.52	8.42	1.17	10.84	8.14	1.27
71.6	86.0	15.73	9.50	0.69	14.60	9.04	0.86	13.48	8.60	1.02	12.91	8.39	1.10	12.35	8.18	1.18	11.68	7.93	1.28
75.2	89.6	16.28	9.20	0.70	15.16	8.78	0.86	14.03	8.38	1.02	13.47	8.19	1.10	12.91	7.99	1.18	12.23	7.76	1.28

Heating

AFR 11.2

Temp: Celsius

TC, PI: kW

INDOOR		OUTDOOR TEMPERATURE (°CWB)												
EDB	-15		-1	10	-	5	()	(6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.80	2.27	0.84	2.65	0.88	3.03	0.92	4.10	1.08	4.45	1.12	5.17	1.19
21.1	1.77	0.82	2.15	0.86	2.53	0.91	2.91	0.95	3.96	1.11	4.32	1.14	5.03	1.22
22.0	1.72	0.83	2.10	0.87	2.48	0.91	2.86	0.96	3.91	1.12	4.26	1.15	4.98	1.23
24.0	1.68	0.84	2.06	0.88	2.44	0.92	2.82	0.96	3.85	1.13	4.21	1.16	4.92	1.24
25.0	1.65	0.85	2.03	0.89	2.41	0.93	2.79	0.97	3.82	1.13	4.18	1.17	4.90	1.24
27.0	1.61	0.85	1.99	0.90	2.37	0.94	2.75	0.98	3.77	1.14	4.13	1.18	4.84	1.25

Temp: Fahrenheit

TC: kBtu/h

PI: kW

INDOOR		OUTDOOR TEMPERATURE (°FWB)												
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.80	7.73	0.84	9.03	0.88	10.33	0.92	13.98	1.08	15.20	1.12	17.64	1.19
70.0	6.04	0.82	7.33	0.86	8.63	0.91	9.93	0.95	13.50	1.11	14.73	1.14	17.17	1.22
71.6	5.88	0.83	7.18	0.87	8.47	0.91	9.77	0.96	13.32	1.12	14.55	1.15	16.99	1.23
75.2	5.72	0.84	7.02	0.88	8.31	0.92	9.61	0.96	13.14	1.13	14.36	1.16	16.80	1.24
77.0	5.64	0.85	6.94	0.89	8.24	0.93	9.53	0.97	13.05	1.13	14.27	1.17	16.71	1.24
80.6	5.48	0.85	6.78	0.90	8.08	0.94	9.37	0.98	12.86	1.14	14.08	1.18	16.52	1.25

Symbols:

: Airflow rate	(m³/min.)
: Bypass factor	
: Entering wet bulb temp.	(°C) / (°F)
: Entering dry bulb temp.	(°C) / (°F)
: Total capacity	(kW) / (kBtu/h)
: Sensible heat capacity	(kW) / (kBtu/h)
: Power input	(kW)
	 Bypass factor Entering wet bulb temp. Entering dry bulb temp. Total capacity Sensible heat capacity

Notes:

- shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D120262

FTXR18TVJUW + RX18RMVJU9 FTXR18TVJUS + RX18RMVJU9

60 Hz, 208 V

Cooling	
AFR	9.9
BF	0.17

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC				TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	
14.0	20.0	3.21	2.41	0.23	3.21	2.41	0.38	3.21	2.41	0.67	3.21	2.41	0.89	3.21	2.41	1.16	3.19	2.40	1.41
16.0	22.0	4.12	2.74	0.34	4.12	2.74	0.58	4.12	2.74	0.99	4.12	2.74	1.28	4.12	2.74	1.60	3.34	2.36	1.41
18.0	25.0	5.10	3.23	0.53	5.10	3.23	0.90	5.10	3.23	1.48	5.10	3.23	1.82	4.91	3.14	2.01	3.49	2.48	1.41
19.4	26.7	5.62	3.56	0.66	5.62	3.56	1.14	5.53	3.52	1.74	5.28	3.40	1.88	5.03	3.28	2.01	3.57	2.62	1.41
22.0	30.0	6.87	3.84	1.19	6.38	3.61	1.47	5.89	3.38	1.75	5.64	3.28	1.89	5.39	3.17	2.02	3.79	2.53	1.41
24.0	32.0	7.12	3.70	1.20	6.63	3.49	1.48	6.13	3.28	1.76	5.89	3.18	1.90	5.62	3.08	2.02	3.94	2.47	1.41

Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC				SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.95	8.22	0.23	10.95	8.22	0.38	10.95	8.22	0.67	10.95	8.22	0.89	10.95	8.22	1.16	10.87	8.18	1.41
60.8	71.6	14.07	9.34	0.34	14.07	9.34	0.58	14.07	9.34	0.99	14.07	9.34	1.28	14.07	9.34	1.60	11.40	8.05	1.41
64.4	77.0	17.42	11.03	0.53	17.42	11.03	0.90	17.42	11.03	1.48	17.42	11.03	1.82	16.76	10.71	2.01	11.92	8.46	1.41
67.0	80.0	19.18	12.16	0.66	19.18	12.16	1.14	18.85	12.00	1.74	18.00	11.59	1.88	17.18	11.18	2.01	12.18	8.94	1.41
71.6	86.0	23.45	13.10	1.19	21.78	12.31	1.47	20.10	11.55	1.75	19.26	11.18	1.89	18.38	10.80	2.02	12.95	8.64	1.41
75.2	89.6	24.28	12.62	1.20	22.61	11.90	1.48	20.93	11.20	1.76	20.09	10.86	1.90	19.16	10.50	2.02	13.45	8.42	1.41

Heating

11.7

Temp: Celsius

AFR

TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°CW	'В)				
EDB		15		10	-	5	()	(6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.80	1.27	3.36	1.34	3.93	1.40	4.49	1.47	6.08	1.72	6.61	1.77	7.68	1.89
21.1	2.63	1.31	3.19	1.37	3.76	1.44	4.32	1.50	5.88	1.76	6.41	1.81	7.47	1.93
22.0	2.56	1.32	3.12	1.39	3.69	1.45	4.25	1.52	5.80	1.77	6.33	1.83	7.29	1.90
24.0	2.49	1.33	3.05	1.40	3.62	1.46	4.18	1.53	5.72	1.79	6.25	1.84	6.85	1.74
25.0	2.46	1.34	3.02	1.41	3.58	1.47	4.15	1.54	5.68	1.79	6.21	1.85	6.63	1.67
27.0	2.39	1.36	2.95	1.42	3.51	1.49	4.08	1.55	5.60	1.81	6.13	1.87	6.19	1.53

Temp: Fahrenheit

TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	9.55	1.27	11.48	1.34	13.41	1.40	15.33	1.47	20.76	1.72	22.57	1.77	26.19	1.89
70.0	8.97	1.31	10.89	1.37	12.82	1.44	14.74	1.50	20.00	1.76	21.87	1.81	25.50	1.93
71.6	8.73	1.32	10.66	1.39	12.58	1.45	14.51	1.52	19.79	1.77	21.60	1.83	24.88	1.90
75.2	8.49	1.33	10.42	1.40	12.35	1.46	14.27	1.53	19.51	1.79	21.32	1.84	23.37	1.74
77.0	8.38	1.34	10.30	1.41	12.23	1.47	14.15	1.54	19.37	1.79	21.18	1.85	22.62	1.67
80.6	8.14	1.36	10.07	1.42	11.99	1.49	13.92	1.55	19.09	1.81	20.91	1.87	21.11	1.53

60 Hz, 230 V

Cooling	
AFR	9.9
BF	0.17

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC				SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.21	2.41	0.23	3.21	2.41	0.38	3.21	2.41	0.67	3.21	2.41	0.89	3.21	2.41	1.16	3.21	2.41	1.55
16.0	22.0	4.12	2.74	0.34	4.12	2.74	0.58	4.12	2.74	0.99	4.12	2.74	1.28	4.12	2.74	1.60	3.59	2.48	1.56
18.0	25.0	5.10	3.23	0.53	5.10	3.23	0.90	5.10	3.23	1.48	5.10	3.23	1.82	4.91	3.14	2.01	3.75	2.60	1.56
19.4	26.7	5.62	3.56	0.66	5.62	3.56	1.14	5.53	3.52	1.74	5.28	3.40	1.88	5.03	3.28	2.01	3.84	2.74	1.56
22.0	30.0	6.87	3.84	1.19	6.38	3.61	1.47	5.89	3.38	1.75	5.64	3.28	1.89	5.40	3.17	2.03	4.09	2.64	1.56
24.0	32.0	7.12	3.70	1.20	6.63	3.49	1.48	6.13	3.28	1.76	5.89	3.18	1.90	5.64	3.09	2.03	4.25	2.58	1.56

Temp: Fahrenheit

. TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI				TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.95	8.22	0.23	10.95	8.22	0.38	10.95	8.22	0.67	10.95	8.22	0.89	10.95	8.22	1.16	10.95	8.22	1.55
60.8	71.6	14.07	9.34	0.34	14.07	9.34	0.58	14.07	9.34	0.99	14.07	9.34	1.28	14.07	9.34	1.60	12.24	8.45	1.56
64.4	77.0	17.42	11.03	0.53	17.42	11.03	0.90	17.42	11.03	1.48	17.42	11.03	1.82	16.76	10.71	2.01	12.81	8.86	1.56
67.0	80.0	19.18	12.16	0.66	19.18	12.16	1.14	18.85	12.00	1.74	18.00	11.59	1.88	17.18	11.18	2.01	13.10	9.34	1.56
71.6	86.0	23.45	13.10	1.19	21.78	12.31	1.47	20.10	11.55	1.75	19.26	11.18	1.89	18.42	10.82	2.03	13.95	9.02	1.56
75.2	89.6	24.28	12.62	1.20	22.61	11.90	1.48	20.93	11.20	1.76	20.09	10.86	1.90	19.25	10.53	2.03	14.51	8.79	1.56

Heating

AFR 11.7

Temp: Celsius

TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUF	RE (°CW	B)				
EDB		15	-1	10	-	5	()	(6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.80	1.27	3.36	1.34	3.93	1.40	4.49	1.47	6.08	1.72	6.61	1.77	7.68	1.89
21.1	2.63	1.31	3.19	1.37	3.76	1.44	4.32	1.50	5.88	1.76	6.41	1.81	7.47	1.93
22.0	2.56	1.32	3.12	1.39	3.69	1.45	4.25	1.52	5.80	1.77	6.33	1.83	7.29	1.90
24.0	2.49	1.33	3.05	1.40	3.62	1.46	4.18	1.53	5.72	1.79	6.25	1.84	6.85	1.74
25.0	2.46	1.34	3.02	1.41	3.58	1.47	4.15	1.54	5.68	1.79	6.21	1.85	6.63	1.67
27.0	2.39	1.36	2.95	1.42	3.51	1.49	4.08	1.55	5.60	1.81	6.13	1.87	6.19	1.53

Temp: Fahrenheit

TC: kBtu/h

PI: kW

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	9.55	1.27	11.48	1.34	13.41	1.40	15.33	1.47	20.76	1.72	22.57	1.77	26.19	1.89
70.0	8.97	1.31	10.89	1.37	12.82	1.44	14.74	1.50	20.00	1.76	21.87	1.81	25.50	1.93
71.6	8.73	1.32	10.66	1.39	12.58	1.45	14.51	1.52	19.79	1.77	21.60	1.83	24.88	1.90
75.2	8.49	1.33	10.42	1.40	12.35	1.46	14.27	1.53	19.51	1.79	21.32	1.84	23.37	1.74
77.0	8.38	1.34	10.30	1.41	12.23	1.47	14.15	1.54	19.37	1.79	21.18	1.85	22.62	1.67
80.6	8.14	1.36	10.07	1.42	11.99	1.49	13.92	1.55	19.09	1.81	20.91	1.87	21.11	1.53

Symbols:

: Airflow rate	(m³/min.)
: Bypass factor	
: Entering wet bulb temp.	(°C) / (°F)
: Entering dry bulb temp.	(°C) / (°F)
: Total capacity	(kW) / (kBtu/h)
: Sensible heat capacity	(kW) / (kBtu/h)
: Power input	(kW)
	 Bypass factor Entering wet bulb temp. Entering dry bulb temp. Total capacity Sensible heat capacity

Notes:

- shows nominal (rated) capacities and power input.
 TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
 Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
 Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D120263A

7.1 Capacity Correction Factor by the Length of Refrigerant Piping (Reference)

The cooling capacity and the heating capacity of the unit have to be corrected in accordance with the length of refrigerant piping — the distance between the indoor unit and the outdoor unit.

<--- line : cooling capacity> <--- line : heating capacity>

7.1.1 09/12 Class



7.1.2 18 Class



Operation Limit 8.

RX09/12/18RMVJU9



Notes) 1, The graphs are based on the following conditions. - Equivalent piping length 25ft - Level difference Oft

2, Facility Setting (cooling at low outdoor temperature : only for RX model) This function is limited only for facilities (the target of air conditioning is equipment such as computer). Mever use it in a residence or office (The space where there is a human). Indoor fan tap should be fixed to high. • Cutting jumper 6 (J6) on the circuit board • Installing an air direction adjustment grille (wind baffle)(sold separately) : extend the operation range to −4° F(-20°C).

3D092209E

9. Sound Level

9.1 Measuring Location



- Notes: 1. Operation sound is measured in an anechoic chamber.
 - 2. The operation sound measuring method is based on JIS standard.

9.2 Indoor Unit

FTXR09TVJUW(S)



```
3D105687A
```

FTXR12TVJUW(S)





FTXR18TVJUW(S)



3D105689A

9.3 Outdoor Unit

RX09RMVJU9



RX12RMVJU9



3D106146B

RX18RMVJU9



3D108255B

10. Electric Characteristics

Unit Con	nbination		Power Supply			Compressor	O	M	IF	M
Indoor Unit	Outdoor Unit	Hz - Volts	Voltage Range	MCA	MFA	RLA	W	FLA	W	FLA
FTXR09TVJUW	RX09RMVJU9	60 - 208	Max. 60 Hz 253 V	9.0	15	7.5	39	0.10	29	0.13
FTXR09TVJUS	RYOBEINIAJOB	60 - 230	Min. 60 Hz 187 V	9.0	15	7.5	39	0.13	29	0.13
FTXR12TVJUW	RX12RMVJU9	60 - 208	Max. 60 Hz 253 V	9.1	15	7.5	39	0.15	29	0.19
FTXR12TVJUS		60 - 230	Min. 60 Hz 187 V	9.1	15	7.5	39	0.15	29	0.19
FTXR18TVJUW	RX18RMVJU9	60 - 208	Max. 60 Hz 253 V	12.8	15	10.75	110	0.38	29	0.21
FTXR18TVJUS		60 - 230	Min. 60 Hz 187 V	12.0	15	10.75	110	0.30	29	0.21

Symbols:

- MCA : Min. circuit amps (A)
- MFA : Max. fuse amps (A)
- RLA : Rated load amps (A)
- OFM : Outdoor fan motor
- IFM : Indoor fan motor
- W : Fan motor rated output (W)
- FLA : Full load amps (A)

Notes:

- 1. RLA is the max current that comes in cooling operation and heating operation.
- 2. Maximum allowable voltage variation between phases is 2%.

- Maximum allowable voltage variation between phases is 2%.
 Select wire size based on the larger value of MCA.
 Instead of a fuse, use a circuit breaker.
 Be sure to install a ground leak detector. (This unit uses an inverter, which means that a ground leak detector capable of handling high harmonics must be used in order to prevent malfunctioning of the ground leak detector.)

C: 3D120260

11.Installation Manual 11.1 Indoor Unit Contents

Safety Considerations	1
Accessories	3
Choosing an Installation Site	3
1. Indoor unit	3
2. Wireless remote controller	3
Indoor Unit Installation Diagram	4
Indoor Unit Installation	5
1. Installing the mounting plate	5
2. Drilling a wall hole and installing wall embedded pipe	5
3. Installing the indoor unit	5
4. Wiring	8
5. Drain piping	9

Refrigerant Piping Work9
1. Flaring the pipe end9
2. Refrigerant piping 10
Installation Tips 11
1. Removing and installing the upper front panel 11
2. Removing and installing the front grille 11
3. How to set the different addresses 12
4. When connecting a wireless LAN connecting adapter 12
5. When connecting to an HA system 13
Trial Operation and Testing14
1. Trial operation and testing14
2. Test items 14

Safety Considerations

Read these **Safety Considerations for Installation** carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:

	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
	Indicates situations that may result in equipment or property-damage accidents only.

🕂 DANGER -

- Refrigerant gas is heavier than air and replaces oxygen.
 A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances.
 Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

MARNING -

- Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a circuit breaker.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. Your hands may suffer burns or frostbite if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to ensure proper drainage. Improper drain piping may result in water leakage and property damage.
- Insulate piping to prevent condensation.
- · Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
 - (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight -- R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter *Refrigerant Piping Work* and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors.
- Do not install the air conditioner or heat pump in the following locations:
 - (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off or result in water
 - leakage. (b) Where corrosive gas, such as sulfurous acid gas, is
 - produced. Corroding copper pipes or soldered parts may result in refrigerant leakage.
 - (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
 - (d) Where fammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

- The indoor unit should be positioned where the unit and interunit wires (outdoor to indoor) are at least 3.3ft (1m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 3.3ft (1m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.

C Titanium apatite deodorizing B Mounting plate fixing screw (A) Mounting plate $M4 \times 1$ " (M4 $\times 25$ mm) filter 5 2 1 (C) D Wireless remote E Remote F Remote controller controller holder controller holder ₿õ₿ fixing screw (3) June 1 1 2 M3 × 13/16" (M3 × 20mm) H Indoor unit G Dry battery (J) Screw cover AAA. LR03 fixing screw 2 2 2 (alkaline) $M4 \times 1/2$ " $(M4 \times 12mm)$ (K) Insulation tape Operation (M) Installation manual manual 1 1 1 (N) Warranty 1

Accessories

Choosing an Installation Site

Before choosing the installation site, obtain user approval.

1. Indoor unit

The indoor unit should be positioned in a place where:

- 1) the restrictions on the installation requirements specified in "Indoor Unit Installation Diagram" on page 4 are met,
- 2) both the air inlet and air outlet are unobstructed,
- 3) the unit is not exposed to direct sunlight,
- 4) the unit is away from sources of heat or steam,
- 5) there is no source of machine oil vapor (this may shorten the indoor unit service life),
- 6) cool/warm air is circulated throughout the room,
- 7) the unit is away from electronic ignition type fluorescent lamps (inverter or rapid start type) as they may affect the remote controller range,
- 8) no laundry equipment is nearby.

2. Wireless remote controller

Turn on all the fluorescent lamps in the room, if any, and find a location where the remote controller signals are properly received by the indoor unit (within 19-11/16ft (6m)).

Indoor Unit Installation Diagram

A CAUTION -

- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.
- Do not place large objects near the INTELLIGENT EYE sensor. Also keep heating units or humidifiers outside the sensor's detection area.


Indoor Unit Installation

1. Installing the mounting plate

The mounting plate should be installed on a wall which can support the weight of the indoor unit.

1)Temporarily secure the mounting plate to the wall, make sure that the plate is completely level, and mark the drilling points on the wall.

2)Secure the mounting plate to the wall with screws.

Recommended mounting plate retention spots and dimensions



2. Drilling a wall hole and installing wall embedded pipe

For metal frame or metal board walls, be sure to use a wall embedded pipe and wall hole cover in the feed-through hole to prevent possible heat, electric shock, or fire.

- Be sure to caulk the gaps around the pipes with caulking material to prevent condensation.
 - 1) Drill a feed-through hole with a ϕ 2-9/16 inch (65mm) diameter through the wall at a downward angle toward the outside.
 - 2) Insert a wall embedded pipe into the hole.
 - 3) Insert a wall hole cover into wall pipe.
 - 4) After completing refrigerant piping, wiring, and drain piping, caulk the pipe hole gap with putty.



- The recommended installation method is back piping.
 - When performing bottom piping or left side piping, refer to
- "3-4. Bottom or left side piping" on page 7.Right side piping cannot be performed.

3-1. Right-back piping

- 1) Attach the drain hose to the underside of the refrigerant pipes with adhesive vinyl tape.
- 2) Wrap the refrigerant pipes and drain hose together with K insulation tape.



Outside

Caulking

(field supply)

φ2-9/16^{*}

(65mm)

Inside

Wall embedded pip

Wall hole cove (field supply)

(field supply)



A Mounting plate

3) Pass the drain hose and refrigerant pipes through the wall hole, then position the indoor unit on the (A) mounting plate hooks, using the △ markings at the top of the indoor unit as a guide.

3-2. Left-back piping

1) Replace the drain plug and drain hose.



(indoor unit fixing screws M4 \times 1/2" (M4 \times 12mm).



Indoor Unit Installation

3-3. Wall embedded piping

Follow the instructions given under left-back piping.1) Insert the drain hose to this depth so it won't be pulled out of the drain pipe.



3-4. Bottom or left side piping

- 1) Cut off the pipe port cover with a copping saw.
 - For bottom piping: On the bottom of the front grille
 - For left side piping: On the side cover (front grille side and unit side)

Apply the blade of the copping saw to the notch, and cut off the pipe port cover along the uneven inner surface.



- After cutting off the pipe port cover, perform filing. Remove the burrs along the cut section using a half round needle file.
- 3) Wrap the refrigerant pipes and drain hose together with (k) insulation tape. Then, insert the drain hose and refrigerant pipes into the wall hole after inserting them into the cut out piping hole opened.





NOTE

- Be careful not to let chips enter the driving section of the arm.
- · Be careful not to put pressure on the lower front panel.

4. Wiring

Refer to the installation manual for the outdoor unit also.

- Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
- Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.

CAUTION -



With a multi indoor unit, install as described in the installation manual supplied with the multi outdoor unit.

- Remove the upper front panel, then remove the service lid. (Refer to the opening method on page 4.)
- 2) Lift up the unit and place it on the (A) mounting plate hooks.
- Remove the front grille. (Refer to the removal method on page 11.)
- Remove the conduit mounting plate and then secure the conduit to the conduit mounting plate with the lock nut, as shown in the illustration.
- 5) Strip wire ends (3/4 inch (20mm)).
- 6) Match wire colors with terminal numbers on the indoor and outdoor unit's terminal blocks and firmly secure the wires in the corresponding terminals with the screws.
- 7) Connect the ground wire to the corresponding terminals.8) Pull the wires lightly to make sure they are securely
- connected.9) In case of connecting to an adapter system, run the remote controller cable and attach the S21.
- (Refer to "5. When connecting to an HA system" on page 13.) 10) Attach the conduit mounting plate.
- 11) Shape the wires so that the service lid fits securely.
- 12) Attach the front grille.
- 13) Attach the service lid and the upper front panel.



Electrical wiring box Conduit pipe Conduit mounting plate Lock nut

Hang indoor unit on the hooks

of mounting plate

8

Note: Recommend using AWG14, stranded and insulated wire for connections between indoor and outdoor units.

Outdoor

unit

Indoor Unit Installation

5. Drain piping

1) Connect the drain hose, as described on the right.

- 2) Remove the upper front panel and the air filters. (Refer to removal method on page 11.) Pour some water into the drain pan to check the water flows smoothly.
- 3) If drain hose extension or embedded drain piping is required, use appropriate parts that match the hose front end.





- When drain hose requires extension, obtain an extension hose with an inner diameter of 5/8 inch (16mm).
 Be sure to thermally insulate the indoor section of the extension hose.
- When connecting a rigid polyvinyl chloride pipe (nominal diameter 1/2 inch (13mm)) directly to the drain hose attached to the indoor unit as with embedded piping work, use any commercially available drain socket (nominal diameter 1/2 inch (13mm)) as a joint.





Commercially available drain socket (nominal diameter 1/2 inch (13mm))

Commercially available rigid polyvinyl chloride pipe (nominal diameter 1/2 inch (13mm))

The drain hose should be inclined downward.

No trap is permitted Do not put the end of the hose in water.

Refrigerant Piping Work

WARNING

- Do not apply mineral oil on flared part.
- Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- Never use piping which has been used for previous installations. Only use parts which are delivered with the unit.
- Never install a dryer to this R410A unit in order to guarantee its service life.
- The drying material may dissolve and damage the system.
- Incomplete flaring may result in refrigerant gas leakage.

With a multi indoor unit, install as described in the installation manual supplied with the multi outdoor unit.

1. Flaring the pipe end

- 1) Cut the pipe end with a pipe cutter.
- 2) Remove burrs with the cut surface facing downward so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.



2. Refrigerant piping

A CAUTION -

- Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
- Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a torque wrench.



Piping size	Flare nut tightening torque
O.D. 3/8 inch (9.5mm)	24-1/8-29-1/2ft • lbf (32.7-39.9N • m)
O.D. 1/2 inch (12.7mm)	36-1/2-44-1/2ft • lbf (49.5-60.3N • m)
O.D. 1/4 inch (6.4mm)	10-1/2-12-3/4ft • lbf (14.2-17.2N • m)
	O.D. 3/8 inch (9.5mm) O.D. 1/2 inch (12.7mm)

2-1. Caution on piping handling

- Protect the open end of the pipe against dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.

Be sure to place a cap. If no flare cap is available, cover the flare mouth with tape to keep dirt and water out.

2-2. Selection of copper and heat insulation materials

- When using commercial copper pipes and fittings, observe the following:
- Insulation material: Polyethylene foam Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))
- Be sure to use insulation that is designed for use with HVAC Systems.
- ACR Copper only.



• Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness
Gas side	O.D. 3/8 inch (9.5mm)	1-3/16 inch (30mm) or more		I.D. 15/32-19/32 inch (12-15mm)	
Gas side	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 9/16-5/8 inch (14-16mm)	13/32 inch (10mm) Min.
Liquid side	O.D. 1/4 inch 1-3/16 inch (30mm) (6.4mm) or more		I.D. 5/16-13/32 inch (8-10mm)		

• Use separate thermal insulation pipes for gas and liquid refrigerant pipes.

Installation Tips

1. Removing and installing the upper front panel

Removal method

- 1) Open the upper front panel.
- 2) Slide the front panel locks on the back of the front panel upward to release the locks (left and right sides).
- 3) Remove the panel shafts on both sides from the shaft holes, and dismount the upper front panel.

Back of the upper front panel Front panel shaft Shaft hole 3-1) Slide The upper front panel does not open any more than as shown in the figure. Do not force it open any further than that.

Installation method

- 1) Slide the front panel locks on the back of the front panel upward to release the locks (left and right sides).
- 2) Insert the panel shafts on both sides of the upper front panel into the shaft holes.

nt panel lock

- 3) Slide the front panel locks on each side downward to lock them.
- 4) Close the upper front panel slowly. (See Fig. 1)
- 5) Do not push on the panel to close it. (See Fig. 2)
- 6) Turn on the unit using the remote controller. Wait till the upper and lower front panels are completely open. Then, turn off the unit using the remote controller again. (See Fig. 3)
- 7) Once the both panels close completely, gently push the upper front panel to hook it into position. (See Fig. 4)

2. Removing and installing the front grille



Be sure to wear protection gloves.

Removal method

- 1) Remove the upper front panel and air filters.
- 2) Remove the service lid. (Refer to the opening method on page 4.)
- 3) Disconnect the wire harnesses from the wire clamp, and remove the wire harnesses from the connectors.
- 4) Push the lower front panel up until it stops.
- 5) Dismount the flap (large).
- 6) Open the 2 screw covers, and remove 4 screws from the front grille. (The screw covers are not factory-mounted.)





CAUTION ·

affixed to the indoor unit.

Fig. 5

Do not attempt to push closed the front panel

If the front panel must be closed by hand for some reason (remote controller not functioning owing to

lack of power supply, etc.), follow the instructions

overlapping. Internal parts may break. (See Fig. 5)

Fig. 1

Fig. 2

with the upper and lower front panels









Remove by pushing to the right while bending it slightly

- 7) Wear protection gloves and insert both hands under the front grille as shown in the figure.
- 8) Remove the front grille from the 3 upper hooks by pushing up the top side of the front grille, pull the front grille toward you by holding both ends of the front grille, and dismount the front grille.
 - If the grille is hard to remove, insert a long flat plate* through the gap in the side cover as shown in the figure, and turn the plate inwards to disengage the hooks (3 hooks each on the right and left sides) so that you can remove the grille easily. * Such as a ruler wrapped in a cloth



Upper hooks

Remote controller

Jumper

4Urn

ADDRESS EXIST

CU

(J4) (J8)

- Installation method
 - 1) Install the front grille and firmly engage the upper hooks (3 locations), right and left sides hooks (each 3 locations).

Indoor unit

JTH

Bottom of electrical wiring box

ADDRESS EXIST : 1

JA

INTELLIGENT EYE sensor

- 2) Install 4 screws of the front grille, and close the 2 screw covers.
- 3) Mount the flap (large).
- 4) Lower the lower front panel to the original position.
- 5) Attach the wire harnesses to the 2 connectors and secure the wire harnesses with the wire clamp.
- 6) Install the air filters and then mount the upper front panel.

3. How to set the different addresses

When 2 indoor units are installed in one room, the 2 wireless remote controllers can be set for different addresses. Change the address setting of one of the two units. When cutting the jumper be careful not to damage any of the surrounding parts

- 1) Remove the upper front panel and front grille. (Refer to the removal method on page 11.)
- 2) Cut the address jumper (JA) on the printed circuit board.
- 3) Cut the address jumper (J4) in the remote controller.
 - · Be careful not to cut jumper (J8).

4. When connecting a wireless LAN connecting adapter

Connection method

- 1) Remove the upper front panel. (Refer to the removal method on page 11.)
- 2) Open the cover, grab the connecting cord with your fingers and pull it out.
- 3) Remove the binding band and pull the insulation tube off the connecting cord.
- 4) Connect the wireless LAN connecting adapter.
- (For details on connection procedures, refer to the installation manual for the wireless LAN connecting adapter.)
- 5) Place the adapter case into the indoor unit and close the cover.
- 6) Install the upper front panel. (Refer to the installation method on page 11.)



Metal plate electrical wiring box cover (B)

From back side

Single tab

Pull dowr

Factory-mounted connector

Installation Tips

5. When connecting to an HA system

(wired remote controller, central remote controller etc.)

Metal plate electrical wiring box cover (A)

Screw

Removal methods for metal plate electrical wiring box covers

- 1) Remove the upper front panel and front grille. (Refer to the removal method on page 11.)
- 2) Remove the electrical wiring box. (1 screw)
- 3) Remove the 4 tabs and dismount the metal
- plate electrical wiring box cover (A).4) Pull down the hook on the metal plate electrical wiring box cover (B), and remove a single tab.
- 5) Remove the 2 tabs on the top part and dismount the metal plate electrical wiring box cover (B).

Attachment methods of connection cord

- 1) Remove the factory-mounted connector from S21.
- 2) Tie the harnesses in a bundle as shown in the figure so that the removed connector does not interfere with the printed circuit board.
- Attach the connection cord to the S21 connector and pull the harness out through the notched part in the figure.





HA connector (S21)

Attachment methods for

metal plate electrical wiring box covers

- 1) Hook the top part of the metal plate electrical wiring box cover (B) on the 2 tabs.
- 2) Press in the hook on the bottom to catch a single tab, and mount the metal plate electrical wiring box cover (B).
- Insert the connector into the hole, and hook and mount the metal plate electrical wiring box cover (A) onto the 4 tabs.
- 4) Install the electrical wiring box. (1 screw)
- 5) Install the upper front panel and front grille. (Refer to the installation method on page 11.)



Trial Operation and Testing

- **1.** Trial operation and testing
 - Trial operation should be carried out in either COOL or HEAT operation.
 - 1-1. Measure the supply voltage and make sure that it is within the specified range.
 - 1-2. In COOL operation, select the lowest programmable temperature; in HEAT operation, select the highest programmable temperature.
 - 1-3. Carry out the trial operation following the instructions in the operation manual to ensure that all functions and parts, such as the movement of the louvers, are working properly.
 - To protect the air conditioner, restart operation is disabled for 3 minutes after the system has been turned off.
 - 1-4. After trial operation is complete, set the temperature to a normal level (78°F to 82°F (26°C to 28°C) in COOL operation, 68°F to 75°F (20°C to 24°C) in HEAT operation).
 - When operating the air conditioner in COOL operation in winter, or HEAT operation in summer, set it to the trial operation mode using the following method.
 - 1) Press () to turn on the system.

2) Press both of and at the same time.

- 3) Press 🐨 , select " 7", and press 🚥 for confirmation.
- Trial operation will stop automatically after about 30 minutes.

To stop the operation, press (\bigcirc)

- Some of the functions cannot be used in the trial operation mode.
- The air conditioner draws a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
- If the circuit breaker trips to shut off the power to the air conditioner, the system will restore the original operation mode when the circuit breaker is opened again.

2. Test items

Test items	Symptom	Check
Indoor and outdoor units are installed securely.	Fall, vibration, noise	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
System is properly grounded.	Electrical leakage	
Only specified wires are used for all wiring, and all wires are connected correctly.	No operation or burn damage	
Indoor or outdoor unit's air inlet or air outlet are unobstructed.	Incomplete cooling/heating function	
Stop valves are opened.	Incomplete cooling/heating function	
Indoor unit properly receives remote controller commands.	No operation	
₩ will be displayed when the MODE button is pressed.*	No heating	
Pipes and wires are connected to the corresponding terminal blocks/ connection ports for the connected unit.	No cooling/heating	

* Check that the jumper (J8) has not been cut. If it has been cut, contact the service shop.



3P436087-1B

11.2 Outdoor Unit Contents

1
3
3
4
4
5
5
5
6
6

 4. Refrigerant piping 5. Pressure test and evacuating system 6. Refilling refrigerant 7. Refrigerant piping work 	7 8
Wiring	9
Facility Setting (cooling at low outdoor temperature)	
Trial Operation and Testing1	
1. Trial operation and testing 2. Test items	2

Safety Considerations

Read these **Safety Considerations for Installation** carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of DANGER, WARNING, CAUTION, and NOTE Symbols:

A DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
MARNING ·······	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<u>∧</u> NOTE	Indicates situations that may result in equipment or property-damage accidents only.

🕂 DANGER

- Refrigerant gas is heavier than air and replaces oxygen.
 A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death.
 Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

	1	

- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

🕂 WARNING -

- Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a circuit breaker.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. Your hands may suffer burns or frostbite if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to ensure proper drainage. Improper drain piping may result in water leakage and property damage.
- Insulate piping to prevent condensation.
- · Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
- (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight -- R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter *Refrigerant Piping Work* and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors.
- Do not install the air conditioner or heat pump in the following locations:
- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen.
 Plastic parts may deteriorate and fall off or result in water leakage.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in
- refrigerant leakage. (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of
- (d) Where flammable gas may leak, where there is carbon
- fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

- The outdoor unit should be positioned where the unit and power supply wires (breaker panel to outdoor unit) are at least 10ft (3m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 10ft (3m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.

Accessories

(A) Installation manual		1	B Drain socket		1
			This is at the botto	om of the packaging.	
© Drain cap (1) 09/12 class		4	D Drain cap (2)	09/12 class	2
	15/18/24 class	6	I	15/18/24 class	3
(E) Warranty		1			

Precautions for Selecting a Location

- 1) Choose a place solid enough to bear the weight and vibration of the unit, where the operating sound will not be amplified.
- 2) Choose a location where the hot air discharged from the unit or the operating sound will not cause a nuisance to the neighbors of the user.
- 3) Avoid locations, such as near bedrooms, where the operating sound may cause disturbance.
- 4) There must be sufficient space to carry the unit into and out of the site.
- 5) There must be sufficient space for air passage and no obstructions around the air inlet and the air outlet.
- 6) The site must not be prone to flammable gas leaks in the surrounding area.
- 7) In coastal areas or other places with a salty atmosphere or one containing sulfate gas, corrosion may shorten the life of the air conditioner.
- 8) Since water will flow from the drain of the outdoor unit, do not place under the unit anything which must be kept away from moisture.

NOTE

Cannot be installed suspended from a ceiling or stacked.

When operating the air conditioner in a low outdoor ambient temperature, be sure to follow the instructions described below.

 To prevent exposure to wind, install the outdoor unit with its suction side facing the wall.

- Never install the outdoor unit at a site where the suction side may be exposed directly to wind.
- To prevent exposure to wind, it is recommended to install a baffle plate on the air discharge side of the outdoor unit.
- In heavy snow areas, select an installation site where the snow will not affect the unit.





Install the unit high enough off the ground to prevent burying in snow.

Precautions on Installation

- · Check the strength and level of the installation surface so that the unit does not cause any operating vibrations or noise after installation.
- Fix the unit in place securely using foundation bolts, as in the figure. (Prepare 4 sets of 5/16 inch (M8) or 3/8 inch (M10) foundation bolts, nuts and washers; all separately available.)
- It is best to screw in the foundation bolts until their ends are 3/4 inch (20mm) from the foundation surface.



Outdoor Unit Installation Diagram



Appearance of outdoor units may differ from some models.

falling, use foot bolts, or wires

Installation Space Requirements

- · Position the unit on a horizontal surface. Any tilt in the unit should be 3° or less to the horizontal.
- Where a wall or other obstacle is in the path of the outdoor unit's intake or exhaust airflow, follow the installation space requirements below.
- For any of the below installation patterns, the wall height on the outlet side should be 47-1/4 inch (1200mm) or less.



Outdoor Unit Installation

1. Installing the outdoor unit

When installing the outdoor unit, refer to "Precautions for Selecting a Location" and the "Outdoor Unit Installation Diagram".
 If drain work is necessary, follow the procedures on the next page.

2. Drain work

- If the drain port is covered by a mounting base or floor surface, place additional foot bases of at least 1-1/4 inch (30mm) in height under the outdoor unit's feet.
- In cold areas, do not use a drain socket, drain caps (1,2) and a drain hose with the outdoor unit. (Drain water may freeze, impairing heating performance.)
- 1) Attach \bigodot drain cap (1) and drain cap (2).
- 2) Attach (B) drain socket.
 - When attaching B drain socket to the bottom frame, make sure to connect the drain hose to the drain socket first.

3. Flaring the pipe end

- 1) Cut the pipe end with a pipe cutter.
- Remove burrs with the cut surface facing downward, so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.



Image: Provide the state of the st	Set exactly at the positi	Set exactly at the position shown below.						
L Die A 0-0.020 inch 0.039-0.059 inch 0.059-0.079 inch		Flare tool for R410A	Convent	ional flare tool				
		Clutch-type	Clutch-type (Rigid-type)	Wing-nut type (Imperial-type)				

- Do not apply mineral oil to the flare.
- Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- Never use piping which has been used for previous installations. Only use parts which are delivered with this unit.
- Never install a dryer to this R410A unit in order to guarantee its service life.
- The drying material may dissolve and damage the system.
- Incomplete flaring may result in refrigerant gas leakage.

4. Refrigerant piping

- Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
- Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a torque wrench.

Flare nut tightening torque							
		Gas si	de				Liquid side
3/8 inch (9.5m	n)	1/2 inch (12	2.7mm)	5/8 inch (15.9mm)		1/4 inch (6.4mm)	
24-1/8-29-1/2lb	f • ft	36-1/2-44-1	/2lbf • ft	45-5/8-55-5/8lbf • ft		10-	1/2-12-3/4lbf • ft
(32.7-39.9N • r	n)	(49.5-60.3	N • m)	(61.8-7	75.4N • m)	(1	4.2-17.2 N • m)
Width across flats	11/1	6 inch (17mm)	3/4 inch	(19mm)	7/8 inch (22m	ım)	1-1/16 inch (27mm)
Valve cap tightening torque				5-3/8lbf • ft 1.9N • m)	16–20-1/4lbf (21.6-27.4N •		35-3/8-44-1/8lbf • ft (48-59.8N • m)
Service port cap tightening torque							
8−10-7/8lbf • ft (10.8-14.7N • m)							



Outdoor Unit Installation

5. Pressure test and evacuating system

- Make sure that air or any matter other than refrigerant (R410A) does not get into the refrigeration cycle.
- If refrigerant gas leaks should occur, ventilate the room as soon and as much as possible.
- R410A, as well as other refrigerants, should always be recovered and never be released directly into the environment.
- Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
- When piping work is complete, it is necessary to perform a pressure test and evacuate system with a vacuum pump.
- If using additional refrigerant, purge the air from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.
- Use a hexagonal wrench (3/16 inch (4mm)) to operate the stop valve rod.
- All refrigerant pipe joints should be tightened with a torque wrench to the specified tightening torque.



- Pressurize the liquid pipe and gas pipe from the service ports of each stop valve to 550psi (3.8MPa) (do not pressurize more than 550psi (3.8MPa)) for 1 hour minimum, 24 hours recommended. If there is a pressure drop, check for leaks, make repairs and perform the pressure test again.
- 2) Connect the gauge manifold's charging hose to the gas stop valve's service port.
- Fully open the gauge manifold's low-pressure valve (Lo) and completely close its high-pressure valve (Hi). (High-pressure valve will require no further operation.)
- 4) Evacuate system using vacuum pump to below 500 microns for 1 hour minimum.
- 5) Close the gauge manifold's low-pressure valve (Lo) and stop vacuum pump. (Maintain this condition for 4-5 minutes to make sure that the compound pressure gauge pointer does not swing back.)*1
- 6) Remove the valve caps from the liquid stop valve and gas stop valve.

7) Turn the liquid stop valve's rod 90° counter-clockwise with a hexagonal wrench to open the valve. Close it after 5 seconds, and check for gas leakage.

Using soapy water, check for gas leakage from the indoor unit's flare and outdoor unit's flare and valve rods. After the check is complete, wipe all soapy water off.

8) Disconnect the charging hose from the gas stop valve's service port, then fully open the liquid and gas stop valves. (Do not attempt to turn the valve rod further than it can go.)

 Tighten the valve caps and service port caps for the liquid and gas stop valves with a torque wrench to the specified torques.

Refer to "4. Refrigerant piping" on page 6 for details.

*1 If the compound pressure gauge pointer swings back, the refrigerant may have water content or there may be a loose pipe joint.

Check all pipe joints and retighten nuts as needed, then repeat steps 3) through 5).

6. Refilling refrigerant

Check the type of refrigerant to be used on the machine nameplate. Precautions when adding R410A

Fill from the liquid pipe in liquid form.

R410A is a mixed refrigerant, so adding it in gas form may cause the refrigerant composition to change, preventing normal operation.

1) Before filling, check whether the cylinder has a siphon attached or not. (It should have something like "liquid filling siphon attached" displayed on it.)

There is a siphon pipe inside, so the cylinder need not be upside-down to fill with liquid.



• Be sure to use the R410A tools to ensure pressure and to prevent foreign objects entering.

7. Refrigerant piping work

7-1. Cautions on pipe handling

- Protect the open end of the pipe from dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.

7-2. Selection of copper and heat insulation materials

When using commercial copper pipes and fittings, observe the following:

Insulation material: Polyethylene foam

Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))

- Be sure to use insulation that is designed for use with HVAC Systems. • ACR Copper only.
- Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness
			0.031 inch (0.8mm)	I.D. 15/32-19/32 inch (12-15mm)	
Gas side	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	(C1220T-O)	D) I.D. 9/16-5/8 inch (14-16mm)	13/32 inch
	O.D. 5/8 inch (15.9mm)	1-15/16 inch (50mm) or more	0.039 inch (1.0mm) (C1220T-O)	I.D. 5/8-13/16 inch (16-20mm)	(10mm) Min.
Liquid side	O.D. 1/4 inch (6.4mm)	1-3/16 inch (30mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 5/16-13/32 inch (8-10mm)	

• Use separate thermal insulation pipes for gas and liquid refrigerant pipes.





Be sure to

Wiring

WARNING

- Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
 Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a circuit breaker.
- Use an all-pole disconnection type circuit breaker with at least 1/8 inch (3mm) between the contact point gaps.
- When carrying out wiring, take care not to pull at the conduit.
- Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.
- Do not turn on the circuit breaker until all work is completed.
 - 1) Strip the insulation from the wire (3/4 inch (20mm)).
 - 2) Connect the inter-unit wires between the indoor and outdoor units so that the terminal numbers match. Tighten the terminal screws securely. It is recommended that a slot-head screwdriver be used to tighten the screws. The screws are packed with the terminal block.



09/12 class

[Method of mounting conduit]

- A protection plate is fixed for protection from the high-voltage section.
- 1) Dismount the stop valve cover by removing the screw.
- 2) Dismount the protection plate by removing the 2 screws.
- 3) Dismount the conduit mounting cover by removing the 2 screws.
- 4) Pass wires through the conduit and secure them with a lock nut.
- 5) After completing the work, reattach the stop valve cover, the conduit mounting cover, and the protection plate to its original position.



15/18/24 class

[Method of mounting conduit]

1) Dismount the service lid by removing the 2 screws.

2) Pass wires through the conduit and secure them with a lock nut.

3) After completing the work, reattach the service lid to its original position.





Improper work may cause heat and fires.



Facility Setting (cooling at low outdoor temperature)

This function is limited only for facilities (the target of air conditioning is equipment (such as computer)). Never use it in a residence or office (the space where there is a human).

- <u>Cutting jumper 6 (J6)</u> on the circuit board will extend the operation range to 14°F (-10°C). Installing an air direction adjustment grille (sold separately) will further extend the operation range to -4°F (-20°C). In these cases, the unit will stop operating if the outdoor temperature falls below -4°F (-20°C), restarting once the temperature rises above this level.
- 1) Remove the top plate of the outdoor unit. (09/12 class: 3 screws, 15/18/24 class: 6 screws)
- 2) Remove the front plate. (09/12 class: 4 screws, 15/18/24 class: 8 screws)
- 3) Cut the jumper (J6) of the PCB inside.

CAUTION -

- If the outdoor unit is installed where the heat exchanger of the unit is exposed to direct wind, provide a windbreak wall.
- Intermittent noises may be produced by the indoor unit due to the outdoor fan turning on and off when using facility settings.
- Do not place humidifiers or other items which might raise the humidity in rooms where facility settings are being used.
- A humidifier might cause dew jumping from the indoor unit outlet vent.
- Cutting jumper 6 (J6) sets the indoor fan tap to the highest position. Notify the user about this.

Pump Down Operation

In order to protect the environment, be sure to pump down when relocating or disposing of the unit.

- 1) Remove the valve cap from the liquid stop valve and gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After 5 to 10 minutes, close the liquid stop valve with a hexagonal wrench.
- 4) After 2 to 3 minutes, close the gas stop valve and stop forced cooling operation.
- 5) Attach the valve cap once procedures are complete.



Forced cooling operation

[For FFQ and FDMQ models]

- ■Using the indoor unit's remote controller
- [For wired remote controller]
- 1) Set to COOL operation using the remote controller.
- 2) Press and hold the Cancel button for 4 seconds or longer. Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press the Menu/OK button. Basic screen returns and "Test Operation" is displayed at the bottom.
- Press the On/Off button within 10 seconds, and the forced cooling operation starts.
 - Forced cooling operation will stop automatically after about 15 minutes. To stop the operation, press the On/Off button.



[For wireless remote controller] 1) Press 🚾 and select the COOL operation.	
2) Press 🎬 Test" is displayed.	
3) Press within 10 seconds, and the forced cooling operation starts.	
Forced cooling operation will stop automatically after about 15 minutes.	
To stop the operation, press in .	
[For FTXR models]	
Using the indoor unit ON/OFF switch	
Press the indoor unit ON/OFF switch for at least 5 seconds. (The operation will start.)	
 Forced cooling operation will stop automatically after about 15 minutes. To stop the operation, press the indoor unit ON/OFF switch. 	
■Using the indoor unit's remote controller	
1) Press Mode and select the COOL operation.	
2) Press $\textcircled{0}^{\text{vor}}$ to turn on the system.	
3) Press 🙀 vert and vert at the same time.	
4) Press (** 7 ⁻ *, and press (Mode) for confirmation.	On/

• Forced cooling operation will stop automatically after about 30 minutes. To stop the operation, press 🙆 .

Trial Operation and Testing

1. Trial operation and testing

Refer to the installation manual for the indoor unit.

2. Test items

Test items	Symptom	Check
Indoor and outdoor units are installed properly on solid bases.	Fall, vibration, noise	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
System is properly grounded.	Electrical leakage	
The specified wires are used for inter-unit wiring.	No operation or burn damage	
adoor or outdoor unit's air inlet or air outlet are unobstructed. Incomplete cooling/heating function		
Stop valves are opened.	Incomplete cooling/heating function	
Check that the connector of the lead wires of the decoration panel is connected securely.	Louvers do not move	
Indoor unit properly receives wireless remote control commands.	No operation	

12

3P500432-2B

12. Operation Manual

Read Before Operation

Safety Considerations

Read these **Safety Considerations for Operations** carefully before operating an air conditioner or heat pump. Make sure that the unit operates properly during the startup operation. Instruct the user on how to operate and maintain the unit.

Inform users that they should store this operation manual with the installation manual for future reference. Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:

Anger	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
MWARNING ·······	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<u>∧</u> NOTE	Indicates situations that may result in equipment or property-damage accidents only.

– 🕂 DANGER ·

- Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.
- Any abnormalities in the operation of the air conditioner or heat pump, such as smoke or fire, could result in severe injury or death. Turn off the power and contact your dealer immediately.
- Refrigerant gas may produce toxic gas if it comes into contact with fire, such as from a fan heater, stove, or cooking device. Exposure to this gas could cause severe injury or death.
- For refrigerant leakage, consult your dealer. Refrigerant gas is heavier than air and replaces oxygen. A massive leak could lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- If equipment utilizing a burner is used in the same room as the air conditioner or heat pump, there is the danger of oxygen deficiency which could lead to an asphyxiation hazard resulting in serious injury or death. Be sure to ventilate the room sufficiently to avoid this hazard.
- Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.
- Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face the danger of death by suffocation.

- Contact your dealer for repair and maintenance. Improper repair and maintenance may result in water leakage, electric shock, and fire. Only use accessories made by Daikin that are specifically designed for use with the equipment and have them installed by a professional.
- Contact your dealer to move and reinstall the air conditioner or heat pump. Incomplete installation may result in water leakage, electric shock, and fire.
- Never let the indoor unit or the remote controller get wet. Water can cause an electric shock or a fire.
- Never use flammable spray such as hair spray, lacquer, or paint near the unit. Flammable spray may cause a fire.
- When a fuse blows out, never replace it with one of incorrect ampere ratings or different wires. Always replace any blown fuse with a fuse of the same specification.
- Never remove the fan guard of the unit. A fan rotating at high speed without the fan guard is very dangerous.
- Never inspect or service the unit by yourself. Contact a qualified service person to perform this work.
- Turn off all electrical power before doing any maintenance to avoid the risk of serious electric shock; never sprinkle or spill water or liquids on the unit.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not put a finger or other objects into the air inlet or air outlet. The fan is rotating at high speed and will cause injury.
- Check the unit foundation for damage on a continuous basis, especially if it has been in use for a long time. If left in a damaged condition the unit may fall and cause injury.
- Placing a flower vase or other containers with water or other liquids on the unit could cause a shock or fire if a spill occurs.
- Do not touch the air outlet or horizontal blades while the swing flap is in operation because fingers could get caught and injured.
- Never touch the internal parts of the controller. Do not remove the front panel because some parts inside are dangerous to touch. To check and adjust internal parts, contact your dealer.

– 🕂 CAUTION -

 Do not use the air conditioner or heat pump for any other purposes other than comfort cooling or heating.
 Do not use the unit for cooling precision instruments, food, plants, animals or works of art.

- Do not place items under the indoor unit as they may be damaged by condensates that may form if the humidity is above 80% or if the drain outlet gets blocked.
- Before cleaning, stop the operation of the unit by turning the power off or by pulling the supply cord out from its receptacle. Otherwise, an electric shock and injury may result.
- Do not wash the air conditioner or heat pump with excessive water. An electric shock or fire may result.
- Avoid placing the controller in a spot splashed with water. Water entering the controller may cause an electric shock or damage the internal electronic parts.
- Do not operate the air conditioner or heat pump when using a room-fumigation type of insecticide.
 Failure to observe this could cause the chemicals to be deposited in the unit and can endanger the health of those who are hypersensitive to chemicals.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- The appliance is not intended for use by young children or infirm persons without supervision.
- The remote controller should be kept away from children so they cannot play with it.
- Consult with the installation contractor for cleaning.
- Incorrect cleaning of the inside of the air conditioner or heat pump could make the plastics parts break and cause water leakage or electric shock.
- Do not touch the air inlet or aluminum fin of the air conditioner or heat pump as they can cut and cause injury.
- Do not place objects in direct proximity of the outdoor unit. Do not let leaves and other debris accumulate around the unit. Leaves are a hotbed for small animals which can enter the unit. Once inside the unit, animals can cause the unit to malfunction, and cause smoke or fire when they make contact with electrical parts.

— 🥂 NOTE –

- Never press the button of the remote controller with a hard, pointed object. The remote controller may be damaged.
- Never pull or twist the electric wire of the remote controller. It may cause the unit to malfunction.
- Do not place appliances that produce open flames in places that are exposed to the airflow of the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not expose the controller to direct sunlight. The LCD display can become discolored and may fail to display the data.

- Do not wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discolored or the coating can peel off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Then wipe it with another dry cloth.
- Dismantling of the unit, disposal of the refrigerant, oil, and additional parts, shall be done in accordance with the relevant local, state, and national regulations.
- Operate the air conditioner or heat pump in a sufficiently ventilated area and not surrounded by obstacles. Do not use the air conditioner or heat pump in the following places.
 a. Places with a mist of mineral oil, such as cutting oil.
 - b. Locations such as coastal areas where there is a lot of salt in the air.
 - c. Locations such as hot springs where there is a lot of sulfur in the air.
 - d. Locations such as factories where the power voltage varies a lot.
 - e. In cars, boats, and other vehicles.
 - f. Locations such as kitchens where oil may splatter or where there is steam in the air.
 - g. Locations where equipment produces electromagnetic waves.
 - h. Places with an acid or alkaline mist.
 - i. Places where fallen leaves can accumulate or where weeds can grow.
- Take snow protection measures. Contact your dealer for the details of snow protection measures, such as the use of a snow protection hood.
- Do not attempt to do electrical work or grounding work unless you are licensed to do so. Consult with your dealer for electrical work and grounding work.
- Pay attention to operating sound. Be sure to use the following places:
 - a. Places that can sufficiently withstand the weight of the air conditioner or heat pump yet can suppress the operating sound and vibration.
 - b. Places where warm air from the air outlet of the outdoor unit or the operating sound of the outdoor unit does not annoy neighbors.
- Make sure that there are no obstacles close to the outdoor unit. Obstacles close to the outdoor unit may drop the performance of the outdoor unit or increase the operating sound of the outdoor unit.
- Consult your dealer if the air conditioner or heat pump in operation generates unusual noise.
- Make sure that the drainpipe is installed properly to drain water. If no water is discharged from the drainpipe while the air conditioner or heat pump is in the cooling mode, the drainpipe may be clogged with dust or dirt and water leakage from the indoor unit may occur. Stop operating the air conditioner or heat pump and contact your dealer.

Names of Parts





Names of Parts

Remote Controller





Preparation Before Operation

 \sum

Grip both

sides of the

Incorrect handling of batteries can result in injury from battery leakage, rupturing or heating, or lead to equipment failure. Please observe the following precautions and use safely.

- If the alkaline solution from the batteries should get in the eyes, do not rub the eyes. Instead, immediately flush the eyes with tap water and seek the attention of a medical professional.
- Keep batteries out of reach of children. In the event that batteries are swallowed, seek the immediate attention of a medical professional.
- Do not expose batteries to heat or fire. Do not disassemble or modify batteries. The insulation or gas release vent inside the battery may be damaged, resulting in battery leakage, rupturing, or heating.
- Do not damage or peel off labels on the batteries.

Position ⊕ and ⊖ correctly!

To insert the batteries

- **7.** Slide the front cover to take it off.
- **2.** Insert 2 dry batteries AAA.LR03 (alkaline).
- **3.** Replace the front cover.



2. Attach the holder to a wall, a pillar, or similar location with the screws supplied with the holder.

1. Choose a place where the signals reach the unit.

To attach the remote controller holder to a wall

3. Place the remote controller in the remote controller holder.

Fahrenheit/Celsius display switch





- The temperature will be displayed in Celsius when it is presently displayed in Fahrenheit, and vice versa.
- The switch operation is only possible when the temperature is being displayed.

.....

NOTE

Remote ______ controller holder

Notes on batteries

- To avoid possible injury or damage from battery leakage or rupturing, remove the batteries when not using the product for long periods of time.
 The standard replacement time is about 1 year. Both batteries should be replaced at the same time. Be sure to replace them with new size AAA. LR03 (alkaline) batteries.
- However, if the remote controller display begins to fade and the possible transmission range becomes shorter within a year, replace both batteries as specified above.
- The batteries supplied with the remote controller are for initial operation. The batteries may run out in less than 1 year.

Note on remote controller

• Do not drop the remote controller. Do not get it wet.



Basic Operation







Useful Functions

COMFORT AIRFLOW / INTELLIGENT EYE Operation

COMFORT AIRFLOW operation: The airflow direction is upward while in COOL operation, and downward while in HEAT operation. This function prevents cold or warm air from blowing directly on the occupants in the room.

INTELLIGENT EYE operation: The INTELLIGENT EYE sensor detects human movement and adjusts the right and left airflow direction to avoid blowing air directly on the person. If no one is in the room for more than 20 minutes, the operation automatically changes to energy saving operation. The INTELLIGENT EYE sensor works differently depending on the situation.



Useful Functions

P

@1 m

COMFORT AIRFLOW / P **A**3) **INTELLIGENT EYE Operation**

CAUTION

- Do not place large objects near the INTELLIGENT EYE sensor. Also keep heating units and humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

To start operation

Comfort / Sensor Press (@) and select the desired mode.

- Each time () is pressed, a different setting option is displayed on the LCD.
- When INTELLIGENT EYE is selected, the INTELLIGENT EYE lamp lights green.



• By selecting " (a) and " from the following icons, the air conditioner will switch to COMFORT AIRFLOW operation combined with INTELLIGENT EYE operation.

→ 🕿 —	→ ♣ –	→ 🛣 👫 —	blank
COMFORT AIRFLOW	INTELLIGENT EYE	Combination	No Setting

- When the flaps (horizontal blades) are swinging, selecting any of the modes above will cause the flaps (horizontal blades) to stop.
- The lamp lights when human movement is detected.

COMFORT AIRFLOW / INTELLIGEN	T EYE operation settings
------------------------------	--------------------------

Display	Operation mode	Explanation
A	COMFORT AIRFLOW	The flaps adjust the airflow direction upward while cooling, downward while heating. Page 14
£ ®	INTELLIGENT EYE	The sensor detects the movement of people in the sensing areas and the louvers adjust the airflow direction to an area where people are not present. When there are no people in the sensing areas, the air conditioner switches to the energy saving mode. Page 14
* **	COMFORT AIRFLOW and INTELLIGENT EYE	The air conditioner will be in COMFORT AIRFLOW operation combined with INTELLIGENT EYE operation. Page 14
Blank	No function	-

To cancel operation



• If the INTELLIGENT EYE operation was being used, the INTELLIGENT EYE lamp goes off.

Useful Functions

NOTE

Notes on COMFORT AIRFLOW operation

- The position of the flaps will change, preventing air from blowing directly on the occupants of the room.
- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time.
 Priority is given to the function of whichever button is pressed last.
- The airflow rate will be set to AUTO. If the up and down airflow direction is selected, COMFORT AIRFLOW operation will be canceled.

Notes on INTELLIGENT EYE operation

Application range is as follows.



• While the air conditioner is in INTELLIGENT EYE operation, the louvers adjust the airflow direction if there are people in the sensing areas of the INTELLIGENT EYE so that the leftward or rightward airflow will not be directed to the people.

If no people are detected in either area 1 or 2 for 20 minutes, the air conditioner switches to the energy saving mode with the set temperature shifted by $3.6^{\circ}F$ ($2^{\circ}C$).

The air conditioner may switch to the energy saving operation even if there are people in the areas.

This may occur depending on the clothes the people are wearing, if there is no movement of the people in the areas.

- The airflow direction from the louvers will be leftward if there are people in both areas 1 and 2. The air will also flow left if there is a person right in front of the sensor as the sensor judges that there are people in both areas.
- Due to the position of the sensor, people might be exposed to the airflow of the indoor unit if they are close to the front side of the indoor unit. If there are people close to the front side of the indoor unit or in both areas, it is recommended to use the COMFORT AIRFLOW and INTELLIGENT EYE operations simultaneously. Using both modes together, the air conditioner will not direct the airflow towards the people.
- The sensor may not detect moving objects further than 23ft (7m) away. (Please see the application range.)
- · Sensor detection sensitivity changes according to the indoor unit location, the speed of passers-by, temperature range, etc.
- The sensor could also mistakenly detect pets, sunlight, fluttering curtains and light reflected off of mirrors as passers-by.
- INTELLIGENT EYE operation will not switch on during POWERFUL operation.
- NIGHT SET mode Page 20 will not switch on during use of INTELLIGENT EYE operation.

■ Notes on combining COMFORT AIRFLOW operation and INTELLIGENT EYE operation

- The airflow rate will be set to AUTO. If the up and down airflow direction is selected, COMFORT AIRFLOW operation will be canceled.
 Priority is given to the function of whichever button is pressed last.
- When the INTELLIGENT EYE sensor detects the movement of people, it adjusts the airflow direction upward (while in COOL operation) and downward (while in HEAT operation), by adjusting the flaps. When the sensor detects people, the louvers will direct the airflow in such a way that it will not be blown directly on them. If there are no people, the air conditioner will switch to energy saving operation after 20 minutes.
Useful Functions

POWERFUL Operation



POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. In this mode, the air conditioner operates at maximum capacity.

To start POWERFUL operation



- " 🛟 " is displayed on the LCD.
- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.

To cancel POWERFUL operation

Press 🔐 again.

• " 🛟 " disappears from the LCD.

NOTE

Notes on POWERFUL operation	
• Pressing 🔞 causes the settings to be canceled, and " 🍄 " disappears	from the LCD.
 POWERFUL operation will not increase the capacity of the air conditione demonstrated. 	r if the air conditioner is already in operation with its maximum capacity
 In COOL, HEAT and AUTO operation To maximize the cooling (heating) effect, the capacity of outdoor unit in The temperature and airflow settings cannot be changed. 	creases and the airflow rate becomes fixed at the maximum setting.
 In DRY operation The temperature setting is lowered by 4.5°F (2.5°C) and the airflow rat 	e is slightly increased.
 In FAN operation The airflow rate is fixed at the maximum setting. 	
Regarding the combination of POWERFUL and other operation	ons
POWERFUL + COMFORT AIRFLOW POWERFUL + ECONO Not available*	
POWERFUL + OUTDOOR UNIT QUIET	*Priority is given to the function of whichever button is pressed last.
17	

Useful Functions

ECONO / OUTDOOR UNIT QUIET ECONO Operation 10

ഹിയ∠ IS:30 ന്ത്രി (

ECONO operation enables efficient operation by limiting the maximum power consumption.

This function is useful to prevent the circuit breaker from tripping when the unit operates alongside other appliances on the same circuit.

OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed of the outdoor unit. This function is convenient during the night-time operation.

🕨 blank 🛛

No Setting



To cancel operation



NOTE

Notes on ECONO operation

- Pressing (d) causes the settings to be canceled, and " Ts " disappears from the LCD.
- If the power consumption level is already low, switching to ECONO operation will not reduce the power consumption.

Notes on OUTDOOR UNIT QUIET operation

- Even if the operation is stopped by using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, " 1 will remain displayed on the remote controller.
- OUTDOOR UNIT QUIET operation will not reduce the frequency nor fan speed if they already are operating at reduced levels.
- This operation is performed with lower power and therefore may not provide a sufficient cooling (heating) effect.

Possible combinations of ECONO / OUTDOOR UNIT QUIET operation and basic operations

	Operation mode				
	AUTO	DRY	COOL	HEAT	FAN
ECONO	✓	✓	✓	✓	—
OUTDOOR UNIT QUIET	✓	-	✓	✓	-

ON ON/OFF TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use the ON TIMER and OFF TIMER together.

To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time. Page 10
- **1.** Press _____



οή: **δ:22**

" 6:00 " is displayed on the LCD.
" ON " blinks.

• " • " and day of the week disappear from the LCD.

2. Press until the time setting reaches the point

you like.

• Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3. Press again.

- The multi-monitor lamp blinks twice.
- " ON " and setting time are displayed on the LCD.
- The TIMER lamp periodically lights orange. Page 5



Display

To cancel ON TIMER operation

- " ON " and setting time disappear from the LCD.
- " () and day of the week are displayed on the LCD.

NOTE

Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- When using the ON/OFF TIMER to start/stop operation, the actual operation start/stop time may differ from the time set. (Maximum of about 10 minutes)

In the following cases, set the timer again.

- · After the circuit breaker has turned off.
- After a power failure.
- After replacing the batteries in the remote controller.





To use OFF TIMER operation

- Check that the clock is correct. If not, set the clock to the present time. >Page 10
- **1.** Press —



- " 🕘 " and day of the week disappear from the LCD.
- **2.** Press until the time setting reaches the point

you like.

• Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the time setting rapidly.

3. Press [™] again.

- The multi-monitor lamp blinks twice.
- " OFF " and setting time are displayed on the LCD.
- The TIMER lamp periodically lights orange. Page 5



To cancel OFF TIMER operation



- " OFF " and setting time disappear from the LCD.
- " ${\boldsymbol \Theta}$ " and day of the week are displayed on the LCD.

To combine ON TIMER and OFF TIMER operation

.....

• A sample setting for combining the 2 timers is shown below.



NOTE

NIGHT SET mode

• When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.9°F (0.5°C) up in COOL, 3.6°F (2.0°C) down in HEAT) to prevent excessive cooling (heating) during sleeping hours.

WEEKLY TIMER Operation

Up to 4 timer settings can be saved for each day of the week. This is convenient to adapt the WEEKLY TIMER to your family's life style.

Setting example of the WEEKLY TIMER

The same timer settings are used from Monday through Friday, while different timer settings are used for the weekend.



• Up to 4 reservations per day and 28 reservations per week can be set using the WEEKLY TIMER. The effective use of the copy mode simplifies timer programing.

 The use of ON-ON-ON settings, for example, makes it possible to schedule operating mode and set temperature changes. Furthermore, by using OFF-OFF-OFF settings, only the turn off time of each day can be set. This will turn off the air conditioner automatically if you forget to turn it off.













Care

Care and Cleaning

• Before cleaning, be sure to stop the operation and turn off the circuit breaker.

• Do not touch the aluminum fins of the indoor unit. If you touch those parts, this may cause an injury.

Quick reference



Care





3. Reattach the filters and close the upper front panel.

1) Return the panel support plate to its previous position and close the upper front panel slowly.



2) Do not push on the panel to close it.



3) Turn on the unit using the remote controller. Wait till the upper and lower front panels are completely open. Then, turn off the unit using the remote controller again.



4) Once the both panels close completely, gently push the upper front panel to hook it into position.



- · Operation with dirty filters:
 - cannot deodorize the air,

 - results in poor heating or cooling,
- Dispose of old filters as non-flammable waste.
- To order a titanium apatite deodorizing filter, contact the dealer where you bought the air conditioner.

Item	Titanium apatite deodorizing filter (set of 2)
Part No.	KAF970A46 (without frame)

Split Type Air Conditioners FTXR-T Series

Care Prior to a long period of non-use **1.** Operate the FAN mode for several hours to dry out the inside. 1) Press Mode and select " 💀 " . 2) Press 🕐 and start the operation. **2.** After operation stops, turn off the circuit breaker for the room air conditioner. **3.** Clean the air filters and reattach them. **4.** To prevent battery leakage, take out the batteries from the remote controller. We recommend periodical maintenance • In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a qualified contractor in addition to regular cleaning by the user. · For qualified contractor maintenance, please contact the dealer where you bought the air conditioner.



Before making an inquiry or a reques If the problem persists, consult your d	t for repair, please check the following. lealer.		
Not a problem This case is not a problem			
The air conditioner does n	not operate		
Case	Description / what to check		
Multi-monitor lamp is off.	 Has the circuit breaker been tripped or the fuse blown? Is there a power failure? Are batteries set in the remote controller? Is the timer setting correct? 		
Multi-monitor lamp is blinking.	• Turn off the power with the circuit breaker and restart operation with the remote controller. If the multi-monitor lamp is still blinking, check the error code and consult your dealer.		
The air conditioner sudde	nly stops operating		
The air conditioner sudde Case	Description / what to check		
Case			
Case Multi-monitor lamp is on.	Description / what to check • To protect the system, the air conditioner may stop operating after sudden large voltage		
Case Multi-monitor lamp is on. Multi-monitor lamp is blinking. Fhe air conditioner does n	Description / what to check To protect the system, the air conditioner may stop operating after sudden large voltage fluctuations. It automatically resumes operation in about 3 minutes. Are the air filters dirty? Clean the air filters. Is there anything blocking the air inlet or air outlet of the indoor unit or outdoor unit? Stop operation and after turning off the circuit breaker, remove the obstruction. Then restard operation with the remote controller. If the multi-monitor lamp is still blinking, check the error code and consult your dealer. Is top operating 		
The air conditioner sudder Case Multi-monitor lamp is on. Multi-monitor lamp is blinking. The air conditioner does n Case	Description / what to check ✓ • To protect the system, the air conditioner may stop operating after sudden large voltage fluctuations. It automatically resumes operation in about 3 minutes. ✓ • Are the air filters dirty? Clean the air filters. • Is there anything blocking the air inlet or air outlet of the indoor unit or outdoor unit? Stop operation and after turning off the circuit breaker, remove the obstruction. Then restart operation with the remote controller. If the multi-monitor lamp is still blinking, check the error code and consult your dealer. ▶Page 33		

The room does not cool down / warm up

Case	Description / what to check
Air does not come out.	 In HEAT operation The air conditioner is warming up. Wait for about 1 to 4 minutes. During defrosting operation, hot air does not flow out of the indoor unit. When the air conditioner operates immediately after the circuit breaker is turned on The air conditioner is preparing to operate. Wait for about 3 to 20 minutes.

Troubleshooting

The room does not cool down / warm up

Case	Description / what to check		
Air does not come out / Air comes out.	 Is the airflow rate setting appropriate? Is the airflow rate setting low, such as "Indoor unit quiet" or "Airflow rate 1"? Increase the airflow rate setting. Is the set temperature appropriate? Is the adjustment of the airflow direction appropriate? 		
Air comes out.	 Is there any furniture directly under or beside the indoor unit? Is the air conditioner in ECONO operation or OUTDOOR UNIT QUIET operation? Page 18 Is the air filter dirty? Is there anything blocking the air inlet or air outlet of the indoor unit or outdoor unit? Is a window or door open? Is an exhaust fan turning? 		

Mist comes out

Case	Description / what to check		
Mist comes out of the indoor unit.	• This happens when the air in the room is cooled into mist by the cold airflow during COOL or other operation.		

Remote controller

Case	Description / what to check	
The unit does not receive signals from the remote controller or has a limited operating range.	 The batteries may be exhausted. Replace both batteries with new dry batteries AAA.LR03 (alkaline). For details, refer to "Preparation Before Operation". Page 9 Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult your dealer if that is the case. The remote controller may not function correctly if the transmitter is exposed to direct sunlight. 	
LCD is faint, is not working, or the display is erratic.	The batteries may be exhausted. Replace both batteries with new dry batteries AAA.LR03 (alkaline). For details, refer to "Preparation Before Operation". Prage 9	
Other electric devices start operating.	• If the remote controller activates other electric devices, move them away or consult your dealer.	

Air has an odor

Case	Description / what to check		
The air conditioner gives off an odor.	The room odor absorbed in the unit is discharged with the airflow. We recommend you to have the indoor unit cleaned. Please consult your dealer.		

Upper and lower front panels

Case	Description / what to check
Upper and lower front panels do not open. (Multi-monitor lamp is blinking.)	 Is there something caught in the upper and lower front panels? Remove the object and attempt operation again using the remote controller. If the upper and lower front panels still do not open and the multi-monitor lamp is still blinking, consult your dealer where you bought the air conditioner.
Upper front panel does not close completely.	• Are the upper front panel locks set appropriately?
If the upper and lower front panels are closed while the air conditioner is in operation, the air conditioner will stop operating and the multi-monitor lamp will blink.	• Restart the air conditioner after stopping the operation of the air conditioner with the remote controller.

Others Case Description / what to check The air conditioner suddenly • The air conditioner may malfunction due to lightning or radio. ? If the air conditioner malfunctions, turn off the power with the circuit breaker and restart the starts behaving strangely during operation with the remote controller. operation. • Check that the jumper (J8) has not been cut. If it ? HEAT operation cannot be has been cut, contact your dealer. Jumper (J8) selected, even though the unit is hUn heat pump model. The ON/OFF TIMER does not · Check if the ON/OFF TIMER and the WEEKLY TIMER are set to the same time. \checkmark Change or deactivate the settings in the WEEKLY TIMER. Page 21 operate according to the settings.

Notes on the operating conditions

- If operation continues under any conditions other than those listed in the table,
- A safety device may activate to stop the operation.
 (With a multi connection in COOL operation, the safety device may work to stop the operation of the outdoor unit only.)
- Dew may form on the indoor unit and drip from it when COOL or DRY operation is selected.

Mode	Operating conditions
	Outdoor temperature: [MXS models]: 14-115°F (-10-46°C) [MXL models]: 14-115°F (-10-46°C)
COOL / DRY	[RX models]: 50-115°F (10-46°C)
	Indoor temperature: 64-90°F (18-32°C)
	Indoor humidity: 80% max.
	Outdoor temperature: [MXS models]: 5-75°F (-15-24°C)
HEAT	[MXL models]: -13-75°F (-25-24°C)
HEAL	[RX models]: 5-75°F (–15-24°C)
	Indoor temperature: 50-86°F (10-30°C)

Troubleshooting

Call your dealer immediately

\Lambda WARNING

- When an abnormality (such as a burning smell) occurs, stop operation and turn off the circuit breaker.
- Continued operation in an abnormal condition may result in problems, electric shock or fire.
- Consult the dealer where you bought the air conditioner
- Do not attempt to repair or modify the air conditioner by yourself.
- Incorrect work may result in electric shock or fire.
- Consult the dealer where you bought the air conditioner.

If one of the following symptoms takes place, call your dealer immediately.

- The power cord is abnormally hot or damaged.
- An abnormal sound is heard during operation.
- The circuit breaker cuts off the operation frequently.
- A switch or a button often fails to work properly.
- There is a burning smell.
- Water leaks from the indoor unit.

After a power failure

• The air conditioner automatically resumes operation in about 3 minutes. Please wait for a while.

Lightning

• If there is a risk lightning could strike in the neighborhood, stop operation and turn off the circuit breaker to protect the system.

Turn off the circuit breaker and call your dealer.

Disposal requirements

• Dismantling of the unit, handling of the refrigerant, oil and other parts, should be done in accordance with the relevant local and national regulations.



	CODE	MEANING
	00	NORMAL
SYSTEM	U0	REFRIGERANT SHORTAGE
STSTEIM	U2	OVER-VOLTAGE DETECTION
	U4	SIGNAL TRANSMISSION ERROR (BETWEEN INDOOR AND OUTDOOR UNIT)
	A1	INDOOR UNIT PCB ABNORMALITY
	A5	FREEZE-UP PROTECTION OR HEATING PEAK-CUT CONTROL
INDOOR	A6	FAN MOTOR (DC MOTOR) ABNORMALITY
UNIT	C4	INDOOR HEAT EXCHANGER THERMISTOR ABNORMALITY
	C7	FRONT PANEL OPEN /CLOSE FAULT
	C9	ROOM TEMPERATURE THERMISTOR ABNORMALITY
	EA	FOUR WAY VALVE ABNORMALITY
	E1	OUTDOOR UNIT PCB ABNORMALITY
	E5	OL ACTIVATION (COMPRESSOR OVERLOAD)
	E6	COMPRESSOR LOCK
	E7	DC FAN LOCK
	F3	DISCHARGE PIPE TEMPERATURE CONTROL
OUTDOOR	H0	COMPRESSOR SYSTEM SENSOR ABNORMALITY
UNIT	H6	POSITION SENSOR ABNORMALITY
UNIT	H8	DC VOLTAGE / CURRENT SENSOR ABNORMALITY
	H9	OUTDOOR TEMPERATURE THERMISTOR ABNORMALITY
	J3	DISCHARGE PIPE THERMISTOR ABNORMALITY
	J6	OUTDOOR HEAT EXCHANGER THERMISTOR ABNORMALITY
	L4	RADIATION FIN TEMPERATURE RISE
	L5	OUTPUT OVERCURRENT DETECTION
	P4	RADIATION FIN THERMISTOR ABNORMALITY

NOTE

• A short beep and 2 consecutive beeps indicate non-corresponding codes.

• To cancel the code display, hold down for about 5 seconds. The code display also clears if no button is pressed for 1 minute.

Quick Reference



3P436086-1C

13. Optional Accessories

13.1 Option List

13.1.1 Indoor Unit

	Option Name		Model Name	
1	Wired remote controller +1		BRC944B2	
2	Wired remote controller cord (shielded wire)	Length 9.8 ft (3 m)	BRCW901A03	
2		Length 26.3 ft (8 m)	BRCW901A08	
3	Wireless LAN connection adaptor		BRP072A43	
4	Wiring adaptor for timer clock / remote controller ±2 (normal open pulse contact / normal open contact)		KRP413AB1S	
5	Central remote controller ★3		DCS302C71	
6	Unified ON/OFF controller *3	DCS301C71		
7	Schedule timer controller ★3		DST301BA61	
8	Interface adaptor for DIII-NET (residential air conditioner)		KRP928BB2S	
9	Titanium apatite deodorizing fil	KAF970A46		
10	Remote controller loss prevention with chain		KKF910A4	

Notes:

★1 3 m (BRCW901A03) or 8 m (BRCW901A08) length wired remote controller cord is necessary.

- $\star 2$ Timer clock and other devices ; obtained locally.
- \star 3 An interface adaptor (KRP928BB2S) is also required for each indoor unit.
- ★4 Standard accessory

13.1.2 Outdoor Unit

	Option Name	09/12 Class	18 Class
1	Air direction adjustment grille	KPW937E4	KPW063A4
2	Back protection wire net	KKG067A41	KKG063A42
3	Drain plug ★	KKP937A4	
4	Drain pan heater	FTDBHMS, KEH067A41E	FTDBHML, KEH063A4E
5	Snow hood (intake side plate)	KPS067A41	KPS063A41
6	Snow hood (intake rear plate)	KPS067A42	KPS063A44
7	Snow hood (outlet)	KPS067A44	KPS063A47

Note: ★ Standard accessory

13.2 <BRC944B2> Wired Remote Controller

13.2.1 Installation Manual

- 1. No switch box or staple is supplied. Prepare them locally.
- 2. No remote controller cord is supplied. Prepare the optional remote controller cord 4 wire.
- 3. Be sure to turn off the power to any apparatus connected prior to mounting.
- 4. Prior to mounting equipment, touch something metallic such as a doorknob to remove static electricity from your body. Never touch the remote controller board or the adapter board.
- 5. Keep the wiring away from any other power source lines to avoid electric noise (external noise).
- 6. Select a flat surface, wherever possible, to mount the remote controller. To prevent deformation of the cases, do not overtighten the mounting screws.

1. Securing the remote controller lower case

Insert a bladed screwdriver into the concave (凹) in the remote controller lower case to remove the upper case assembly (two locations).

The remote controller board is located on the upper case. Take care not to scratch the board with the screwdriver.



 Exposed mounting Secure the remote controller lower case with the two supplied wood screws.

Wood screws (¢3.5mm x 16mm) (

(2) Embedded mounting

Secure the remote controller lower case with the two supplied machine screws.





Catch the lower hook first. During mounting of controller cord, be or otherwise dama

During mounting of the remote controller cord, be careful not to pinch or otherwise damage the wires. (Remote controller cord 4 wire)

5. Temperature indication change

To change from Celsius temperature indication to Fahrenheit one



 \leftarrow See Operation Manual

3P202923-2B

13.2.2 Operation Manual

Controller Commands and their Corresponding Functions





Preparation before Operation

Setting Temperature Indication change

Temperature indication can be changed between Celsius and Fahrenheit before use.





To change from Fahrenheit temperature indication to Celsius one

Press and hold down TEMP at the same time for 5 seconds while the Fahrenheit temperature is indicated.



Automatic.DRY.Cooling.Heating Operation

Select your desired operation mode.

Once preset, the system can get restarted in the same operation mode.



■ To stop the operation:

Press ON/OFF again.

The run indicator lamp goes out.

Automatic operation

 In Automatic, the temperature setting and operation mode (DRY, Cooling or Heating) are automatically selected according to the room temperature and outdoor temperature at the time of starting operation.

(DRY operation)

• In this mode, humidity is removed from the air.



Operation Setting mode to be adjusted	Automatic	Cooling	Heating	DRY
© TEMP (Temperature)	Cooling : 26°C-28°C (79°F~82°F) Heating : 20°C-22°C (68°F~72°F)			Temperature cannot be adjusted.
<pre>�FAN from " </pre>		s of airflow rate setting " to " 👼 " plus " 🔝 " are available.		Airflow rate cannot be adjusted.

■ To adjust the temperature and airflow rate:

• When the unit runs in the cooling or heating mode at a low airflow rate, the cooling or heating effect may be insufficient.

■ To adjust the airflow direction:

(🖙 page 9)

(Heating operation)

- Since the heating operation is performed by taking the heat from outdoor into the room, the heating capacity decreases as the outdoor temperature lowers. If the room is not heated sufficiently, it is recommended to use other heating appliance at the same time.
- Since the air conditioner heats the whole room by circulating hot air, it takes some time to heat the entire room completely.
- If the outdoor unit gets frosted during heating operation, the heating capacity is decreased. In this case, the unit starts defrosting operation.
- No hot air comes out of the indoor unit during defrosting operation.

Adjusting Airflow Direction

Adjust the airflow direction for maximum comfort.

To adjust the Airflow Direction

Press during operation.

• Each time the button is pressed, the airflow direction louvers change their movement.



■ Wall Mounted Types (without horizontal swing function)



Adjustment of horizontal airflow direction

 The automatic moving range of the horizontal airflow direction louvers varies depending on the operation mode.



- In fixing the horizontal airflow direction, keep the horizontal airflow direction louvers tilted downward in the heating mode, and keep them nearly horizontal level in the cooling or DRY mode. This will enhance the cooling and heating effect.
- On the air conditioners with vertical and horizontal swing function, be sure to adjust the airflow directions using the remote controller. Do not forcibly adjust louvers by hand or a malfunction may occur.

■ Wall Mounted Type (with horizontal swing function)



• The vertical and horizontal louvers cannot move at the same time.

Duct Connected Type (without swing function)

This function cannot be used.



Timer Operation

The Timer Operation feature automatically turns off operation when you go to sleep and turns it back on when you wake up.

Use the DAILY Timer mode on weekdays, and the ONE TIME timer mode on weekends.

To select the ONE TIME timer mode:



- Before starting the timer operation, make sure the current time is correct. If not, set the clock correctly. (r page 5)
- In making time settings, --:-- is displayed to make it easy to disable the timer too.
- If one minute has passed before making any timer setting, the previous timer settings are reintroduced and the timer is on standby.

In this case, use the \bigcirc (time setting) button and make your desired timer settings.

• When the ON timer is programmed, the

- system starts one hour (maximum) earlier so that the temperature set by the remote controller is reached just in time.
- When the ONE TIME timer is programmed, the current time is no longer displayed.

ONE TIME timer

Once the timer has been activated and then deactivated, it is in the OFF mode. The ON or OFF timers can be programmed.









■ DAILY timer After programming, the system starts and stops each day at the preset times. Two pairs of time settings can be programmed. (Example: 8:00 ~ 10:00, and 18:00 ~ 23:00)

ONE TIME /DAILY Press () to select the DAILY timer.



2 Make the ON and OFF time settings. • Take the steps from ① to ⑧. Program example: 8:00 ~ 10:00, and 18:00 ~ 23:00

Setti	Procedure	Press SET	Press UP DOWN timer setting.
	 ON time setting When the timer 1 is not used, save the setting as ⊕ - 		
	OFF time setting		
	ON time setting ● When the timer 2 is not used, save the setting as ⊕ - !		6 → DALYTIMERÒŻ -1. → → → → → → → → → → → → → → → → → → →
	OFF time setting		

3 Press . The DAILY

. The DAILY timer is now programmed.



Cleaning

Cleaning the remote controller

• Wipe it clean with soft, dry cloth.

Do not use any water hotter than 40°C (104°F), or volatile liquids such as benzine, gasoline and thinner, polishing powder, or anything hard such as a scrub brush.




13.3 <BRCW901A03/08> Wired Remote Controller Cord

Safety Precautions

- Turn OFF the controlled equipment when connecting the equipment.
- Hold the plug of the connector when connecting or disconnecting the connector.

Precautions for Use

- This remote controller cable is of thin-profile BRC944-series remote controller units.
- Be sure to ground both ends of the shield wire.
- Install the controlled equipment after reading through the installation manual of the equipment.



3P201487-1

13.4 <BRP072A43> Wireless LAN Connection Adaptor











[MODE] button

[WPS] butto

The customer is responsible for providing the followin • Smartphone or tablet PC (Supported OS: Android 4.0.3 or later; iOS 7.0 of • Internet line and communicating device (Modem/router or a similar device) • Wireless LAN access point (The corresponding channel for the wireless LA • [DAIKIN Mobile Controller] (No Cost) Installation method of online controller	or later.)
For Android Phones/Tablets	For iPhones/iPads
 (1) Open the [Google Play]. (2) Search for [Daikin Comfort Control]. (3) Follow the directions on the screen to install. 	 (1) Open the [App Store]. (2) Search for [Daikin Comfort Control]. (3) Follow the directions on the screen to install.
Configuring C	Connection Settings (1) (All types
VPS is supported \Rightarrow Proceed to Simple setup If V	WPS is not supported ⇒ Proceed to Advanced setup

 Press the [WPS] button on the router (wireless LAN access point).
 Operation procedures for the [WPS] button vary by router (wireless LAN access point). For details, refer to the instruction manual for the router.



If a connection fails to establish, repeat procedures from step 1 of "Simple setup". If a connection still cannot be established, follow the procedures in "Advanced setup". (In some cases, a connection cannot be established using the steps in "Simple setup" owing to compatibility issues.)

4. Connect the smartphone (tablet PC) and the router (wireless LAN access point).

• A connection can be established by opening the smartphone's Wi-Fi network list, selecting the [SSID] for the router and entering its password.

- 5. Tap the installed app [Daikin Comfort Control] to start it.
 - If the connected air conditioner is listed in the units overview screen, setup is complete.
 If it is not listed, tap C (refresh) in the top right corner of the units overview screen.

Note

about 30 seconds.)

• If an upgrade is available for your adapter, the notification icon "O" will be displayed on the units overview screen. Tap it to upgrade your firmware.



he following table provides brief connection settings. Check our w	descriptions of how to handle problems or uncertainties when you install the product or make ebsite for details.
URL http://daikincomfort.com/Ductless	• FAQ can be viewed via smartphone (tablet PC). To access, please scan the 2D barcode.
When this happens	Explanation and where to check
[RUN] lamp does not light up (continuously).	The [RUN] lamp blinks. → Perform Simple setup or Advanced setup again. → Check that the [SSID] and password for the adapter are entered correctly. → Move the router (wireless LAN access point) closer to the adapter. → The smartphone or router (wireless LAN access point) in use may not be supported.

After-sale Service

For inquiries concerning after-sale service, contact your dealer and advise them of the following details:

Model name

Date of installation

- Conditions at the time of failure (as precisely as possible)
- Your address, name, and telephone number

This telecommunication equipment is in compliance with FCC/IC requirements.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This device complies with Part 15 of FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 8 inches (20cm) or more away from person's body.

Contains FCC ID:VPYLBYD Contains IC: 772C-LBYD

3P427537-1A

13.5 <KRP413AB1S> Wiring Adaptor for Timer Clock / Remote Controller

- Read these safety precautions carefully before installing the unit, and be sure to install the unit properly.
- This manual classifies precautions to the user into the following two categories. These warnings and cautions are for your safety. Follow them.

Faulty installation can result in death or serious injury.
Faulty installation can result in serious injury, damage to property, or other serious consequences.

• After installation is complete, test the unit to confirm that it is working properly, and instruct the owner its proper use.

Ľ	Ŋ	w	٩RI	NING	

- Installation should be left to the dealer from whom you purchased the unit, or another qualified professionals.
- Install the unit securely according to the installation manual. Faulty installation may lead to electric shock or fire.
- Be sure to use the supplied or specified parts. Using other parts may lead to electric shock or fire.
- Install the unit securely in a location that will support its weight. If installed in a
 poor location or improperly installed, the unit may not work as intended.
- For electrical work, follow local electric standards and the installation manual.
 Faulty installation may lead to fire or electric shock.
- Do not bundle the power cord, or attempt to extend it by splicing it with another cord or by using an extension cord. Do not place any other load on the power circuit used for the unit. Improper wiring may lead to electric shock, heat generation or fire.
- Use dedicated wiring for all electrical connections, and be sure to arrange the wiring so that force applied to the wiring will not damage the terminals. Poor wiring or installation may cause electric shock, heat generation or fire.

- Before installation, unplug the air conditioner to ensure safety. Failure to do so may cause electric shock.
- Static electricity may damage electric components. Before connecting cables and communication lines, and operating the switches, be sure to discharge any electrical charge from your body (by, for example, touching the earth line)
- Do not install the unit in a location where it may be exposed to flammable gases. If gas leaks and build up around the unit, it may catch fire.
- Do not place the wiring close to the power cord, inter-unit cable, or pipes which generate noise. Treat the wiring with care.

1. Functions and Features

- On/Off setting
- Switching between Instantaneous Contact/Normal Contact
- Connection with five-room central controller (KRC72 for oversea model)
- Connection with fan coil remote controller
- Automatic reset after power failure
- Output of normal operation signals/malfunction signals

2. Field Wiring

For interconnecting wiring, use Daikin KDC100A12 cable (not supplied) or other similar cable. Use a vinyl-covered wire or cable with four conductors each with a thickness of 0.2 to 1.25 mm².

Optional cable KDC100A12 (without connectors)

Specifications: $0.2 \text{ mm}^2 \times 4 \text{ core (sheathed)}$

Outer diameter:	ф5.З
Length:	100 m
Colour:	Grey

Note : Keep any wiring for the control unit away from the power cord to prevent electrical noise.









13.6 <DCS302C71> Central Remote Controller

13.6.1 Installation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public". Meaning of warning, caution and note symbols. A WARNING Indication a potentially hazardous situation which, if not avoided, could result in death or serious injury. ▲ NOTE Indication situation that may result in equipment or property-damage-only accidents Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself, Improper installation may result in water leakage, electric shocks or fire. Perform installation work in accordance with this installation manual. Improper installation may result in water leakage, electric shocks or fire. Be sure to use only the specified accessories and parts for installation work. Failure to use the specified parts may result in water leakage, electric shocks, fire or the unit falling. Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes, Improper installation work may result in the equipment failing and causing accidents. Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual. An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire. Make sure that all wiring is secured, the specified wires and used, and no external forces act on the terminal connections or wires. connections or installation may result in fire When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened. Improper positioning of the electric parts box lid may result in electric shocks, fire or the terminals overheating. Before touching electrical parts, turn off the unit. Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incomplete grounding may result in electric shocks When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air. Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may result. Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock Install an leak circuit breaker, as required. If an leak circuit breaker is not installed, electric shock may result. Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage. (b) where corrosive gas, such as sulfurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage. (c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment. (d) where flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire. Be very careful about product transportation. Safely dispose of the packing materials. Packing materials, such as nais and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. Do not turn off the power immediately after stopping operation. Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur. Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft, may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps.(inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

COMPONENTS



OSYSTEM CONFIGURATION

With the central remote controller, unified operation/stop is possible with up to a maximum 64 groups of indoor units. When using 2 central remote controllers, unified operation is possible with up to a maximum 128 groups. With this optional accessory, setting of control modes including operation, stop, operation controlled by timer, and ON/OFF control possible/impossible by remote controller can be set individually by zones while it enables to control and display the operation state such as set temperature. It can be connected with the external key system, host computer monitor panel, etc., through forced OFF input (no-voltage normally open contactor). A zone is a one or more groups together. In general, the same settings are used throughout a zone. Outdoor unit Forced OFF • When using 1 central input remote controller Group No.1-00 Group No.1-15 Group No.2-00 Group No.4-15 Central remote Host computer Max. of 64 groups monitor panel controller Outdoor unit When using 2 central Central remote controller Host computer remote Outdoor unit Group No.1-00 Group No.1-15 Group No.2-00 Group No.4-15 monitor panel controller Group No.5-00 Group No.8-15 Forced ON/OFF command Group No.5-15 Group No.6-00 should be connected to Max, of 128 groups one of the two units. Forced OFF input The central remote controller and the separately sold remote control adapter circuit board or group remote control adapter cannot be used together. See the D-BACS design guide for details.

OINSTALLATION



 When using a 	setting master cont nly 1 central remote	controller, o	do not disconnect	t the connector		aster controller. (Us
 When using n 	the connector in the nultiple central remo rollers for centralize	te controller	s, or using the ce	ntral remote co		junction with the
	of optional controllers for ce			ng master controller		
Central remote controller	Unified ON/OFF controller	Schedule timer	Central remote control	lier Unitied UN/UFF	controller Schedule	e timer
1 to 4	1 to 16	1	Set one to "Used" and the rest to "Not used"	all Set all to "Not	used" "Not u	
using the unit toge unit, or the paralle (2) Address settin	g	^{>} controller,	the master station	n II, the DMS in	and the scheo terface, the pa	dule timer when ayment managemer
128 groups of in	ote controllers can be u door units. In this case,	group addres	s must be set. This is	s done with the sv), to control any vitch for setting e	where up to a max. each address (SS3).
SS3 setting				Indoor unit address		
SETTING EACH ADDRE 5-00 15-00 ~ 8-15	SS To control indoor u from group Nos. 1⊣ through 4-15	00 5	-00 1 99 f	To control indoor unit from group Nos, 5-00 through 8-15	-	
			SUD Changeover	switch.		
Central remote	Group No.1-00	• Group No.1-1			🔟 Central re	
controller (1)	Group No.1-00	· Group No.1-1 Max	5 Group No.2-00 . c. 64 groups	Group No.4-15	Central re controller	. (2)
controller (1) One of the two (4) Setting of the The central re units on in 2-s	central remote cont sequential operatior mote controller is ec econd intervals dur ration ON or OFF, s	Group No.1-1 Max rollers (1) . (n function juipped with ing unified c et as follows While holdin.	5 Group No.2-00 5 Groups 2) is set to "MAIN" a sequential oper peration. (Sequents) g down the unifie	While the other	Central re controller er is set to "SU that sequenti	· (2) IB". ally turns indoor
controller (1) One of the two (4) Setting of the The central re units on in 2-s sequential ope	central remote cont sequential operation mote controller is ec econd intervals dur ration ON or OFF, s	Group No.1-1 Max rollers (1) . (n function juipped with ing unified o et as follows	5 Group No.2-00 5 Groups 2) is set to "MAIN" a sequential oper peration. (Sequents) g down the unifie	While the other	Central re controller er is set to "SU that sequentia s factory set to Sequential	• (2) IB". ally turns indoor o "ON.") To switch operation
controller (1) One of the two (4) Setting of the The central re units on in 2-s sequential ope	central remote cont sequential operatior mote controller is ec econd intervals dur ration ON or OFF, s	Group No.1-1 Max rollers (1) . (In function juipped with ing unified o et as follows While holdin perform force While holdin	5 Group No.2-00 5 Groups 2) is set to "MAIN" a sequential oper peration. (Sequents) g down the unifie	" while the othe ration function ntial operation is d stop button, ed operation	Central re controller er is set to "SU that sequenti s factory set to	• (2) IB". ally turns indoor o "ON.") To switch operation
controller (1) One of the two (4) Setting of the The central re units on in 2-s sequential ope Sequential ope Sequential ope	central remote cont sequential operation mote controller is ec econd intervals dur ration ON or OFF, s ential operation "ON"	Group No.1-1 Max rollers (1) . (in function juipped with ing unified o et as follows While holdin perform for While holdin button, per stion is desig prs will not b	5 Group No.2-00 5 Group No.2-00 5 64 groups 2) is set to "MAIN" a sequential oper peration. (Sequer 5. g down the unifie perd reset. A g down the unifie form forced reset ned to reduce the e started simultar	" while the other ation function ation function atial operation is ad stop button, ed operation be load on the pre- neously. You ca ker selection.	Central recontroller er is set to "SU that sequentia factory set to Sequential OF	· (2) IB". ally turns indoor o "ON.") To switch operation F" quipment, but does e count on a

5 ELECTRIC WIRING





(The operation manual lists all error codes, so refer to it.)

For test operation, refer to the installation manual of the outdoor unit.
After turning the power supply ON, if the unit does not accept operation for two minutes or more with the display of "88", check the following points.

- Check that setting of the connector for setting master controller is correct.
 - Check that the group No. for centralized control has been set.

1P124687-1A

13.6.2 Operation Manual

BEFORE USE

■ GENERAL DESCRIPTION OF SYSTEM

This central remote controller can monitor and control up to 64 indoor unit groups. Using two central remote controllers allows monitoring and controlling of up to 128 indoor unit groups.

Main Functions

- 1. Batch starting and stopping of indoor units connected to the central remote controller.
- 2. Handling of operation settings such as start/stop, timer operation, remote controller prohibition/permission, etc., and operation status settings such as temperature.
- 3. Operation status monitoring of operation mode, set temperature, etc.
- 4. Can be connected to an external central monitor panel and key system using the forced stop input (non-voltage a connector).
- · When using 1 central remote controller



(The central remote controller and the separately sold remote control adapter circuit board or group remote control adapter cannot be used together.)

* GROUP OF INDOOR UNIT refers to the below.

- 1. A single indoor unit without remote controller
 - 1. A single indoor unit without remote controller

2. A single indoor unit controlled by one or two remote controllers





Remote Two remote controller



3. Maximum of 16 indoor units, group-controlled by one or two remote controllers



1

* Zone control from the central remote controller

Zone control is available from the central remote controller. With it, it is possible to make unified settings for multiple groups, so setting operations are greatly simplified.



- Any setting you make within a given zone will apply to all groups in the said zone.
- A maximum of 64 zones can be set from a single central remote controller.
- (Each zone contains a maximum of 64 groups.)
- Zones can be set randomly from the central remote controller.

SAFETY CONSIDERATIONS

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly.

After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public".

Meaning of danger, warning, caution and note symbols.

- **DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
- WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
- NOTE.....Indicates situation that may result in equipment or property-damageonly accidents.

Keep these warning sheets handy so that you can refer to them if needed.

Also, if this equipment is transferred to a new user, make sure to hand over this operation manual to the new user.

- Any abnormalities in the operation of the air conditioner such as smoke or fire could result in severe injury or death. Turn off the power and contact your dealer immediately for instructions.
- Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.
- Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face the danger of death due to suffocation.

WARNING -

- Ask your dealer for installation of the air conditioner. Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.
- Ask your dealer for improvement, repair, and maintenance. Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.
- Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for use with the equipment and have them installed by a professional.
- Ask your dealer to move and reinstall the air conditioner or the remote controller.
 Incomplete installation may result in a water leakage, electric shock, and fire.
- Never let the indoor unit or the remote controller get wet. It may cause an electric shock or a fire.



Fig. 2



3



Fig. 5



Fig. 6



Fig. 7



Fig. 8

4

- Never use flammable spray such as hair spray, lacquer or paint near the unit.
 It may cause a fire.
- Do not allow children to play on or around the unit as they could be injured.
- Never replace a fuse with that of wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.
- Never inspect or service the unit by yourself. Ask a qualified service person to perform this work.
- Cut off all electric waves before maintenance.
- Do not wash the air conditioner or the remote controller with excessive water. Electric shock or fire may result.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Never touch the internal parts of the controller. Do not remove the front panel because some parts inside are dangerous to touch. In addition, some parts may be damaged by touching. For checking and adjusting internal parts, contact your dealer.
- Check the unit stand for damage on a continuous basis, especially if it had been in use for a long time. If left in a damaged condition the unit may fall and cause injury.
- Placing a flower vase or other containers with water or other liquids on the unit could result in a shock hazard or fire if a spill occurs.

-A CAUTION -

 Avoid placing the controller in a spot splashed with water.

Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.

- Do not operate the air conditioner when using a room fumigation - type insecticide.
 Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.
- Do not turn off the power immediately after stopping operation.
 Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.
- The appliance is not intended for use by young children or infirm persons without supervision.
- The remote controller should be installed in such a way that children cannot play with it.

- Never press the button of the remote controller with a hard, pointed object.
- The remote controller may be damaged.
 Never pull or twist the electric wire of the remote

controller. It may cause the unit to malfunction.

- The LCD display may get discolored, failing to display the data.
- Do not wipe the controller operation panel with benzine, thinner, chemical dustcloth, etc. The panel may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. And wipe it with another dry cloth.
- Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

CONTENTS

BEFORE USE 1 GENERAL DESCRIPTION OF SYSTEM 1	
SAFETY CONSIDERATIONS	
FEATURES AND FUNCTIONS 6	
NAMES AND FUNCTIONS OF THE	
OPERATING SECTION 7	
OPERATION	
Individual screen, all screen, zone screen	
Batch operation and stop method9	
Group operation and stop method9	
Registering zones9	
Zone operation and stop method 10	
Changing the fan direction and fan strength 11	
Changing the ventilation mode and	
ventilation strength 11	
Timer Number Setting 11	
Setting the Operation Code 12	

OPERATION MODE	13
Setting operation mode	16
Group monitoring	
Error diagnosing function	17
Setting master remote controller	20
Display of time to clean	21
INSTALLATION TABLE	22
OPTIONAL ACCESSORIES	23
DOUBLE CENTRAL REMOTE	
CONTROLLERS	23
SPECIFICATIONS	
Specifications	
Outline drawings	
Fig. 1, 2, 3, 4	
Fig. 5, 6, 7, 8	
Fig. 9, 10, 11, 12	25
Fig. 13, 14, 15, 16	26

FEATURES AND FUNCTIONS



 Room air conditioners and multi-purpose air conditioners may also be connected by using separately-sold adapter boards.

This may limit functionality, so consult the manuals that come with each adapter board.

NAMES AND FUNCTIONS OF THE OPERATING SECTION (Fig. 1, 2)

_			
1	UNIFIED OPERATION BUTTON		"
•	Press to operate all indoor units.	40	S
2	UNIFIED STOP BUTTON	13	Fo
2	Press to stop all indoor units.		th
	OPERATION LAMP (RED)		se
3	Lit white any of the indoor units under control is		"
	in operation.		C T
	" CIRCUIT " DISPLAY (REFRIGERANT	14	W
4	SYSTEM DISPLAY)		m
	This indication in the square is lit while the		m cc
	refrigerant system is being displayed.		"
5	" ^{ZONE} " DISPLAY (ZONE SETTING)	15	(F
	The lamp is lit while setting zones.		Di
	"MONITOR " DISPLAY (OPERATION		"
6	MONITOR)		C
	The lamp is lit while operation is being monitored.	16	T۲
	" ALL " " ZONE " " INDIVIDUALLY " DISPLAY		w l
7	The status displays indicates either batch		In CC
	functions or which zone or individual unit (or group) are being used.		"
	OPERATION MONITOR	47	()
8	Each square displays the state corresponding to	17	lf
	each group.		ev is
	" ()" " 🗞 " " ()" ()" ()" ()" ()" ()" ()" ()" ()" ()"		
9	DISPLAY (OPERATION MODE)		" ' / F
	Displays operating state.	18	(F
	"≞ு" " ॐ " " ℃ " "< ₽ " DISPLAY		Tł or
40	(VENTILATION CLEANING DISPLAY)		
10	This is displayed when a Ventiair total enthalpy		"
	heat exchanger unit or other such unit is connected.	19	D
	"爸们EST" DISPLAY (INSPECTION/TEST)		S D
11	Pressing the maintenance/test run button		Tł
••	(for service) displays this. This button should not		
	normally be used.	20	"
	" 🖉 ∕ ẩో" DISPLAY (TIME TO CLEAN)		Di co
12	It lights up when any individual unit (group) has reached the time for the filter or element to be cleaned.		



7

	" UNIT NO. 18" DISPLAY (OPERATION CODE AND UNIT NUMBER DIS- PLAY)
21	The method of operation (remote controller prohibited, central operation priority after-press operation priority, etc.) is displayed by the corresponding code. This displays the numbers of any indoor units which have stopped due to an error.
22	" 🖉 " " 💒 Ö" DISPLAY (TIME TO CLEAN AIR CLEANER ELEMENT/ TIME TO CLEAN AIR FILTER)
	Displayed to notify the user it is time to clean the air filter or air cleaner element of the group displayed.
	VENTILATION MODE BUTTON
23	This is pressed to switch the ventilation mode of the total enthalpy heat exchanger.
	ALL/INDIVIDUAL BUTTON
24	Pressing this button scrolls through the "all screen", "zone screen", and "individual screen".
	ARROW KEY BUTTON
25	This button is pressed when calling an individual indoor unit or a zone.
	ON/OFF BUTTON
26	Starts and stops ALL, ZONE, and INDIVIDUAL units.
	TEMPERATURE ADJUSTMENT BUTTON (ZONE NUMBER BUTTON)
27	This button is pressed when setting the temperature. Select the zone number if any zones have been registered.
	FAN DIRECTION ADJUSTMENT BUTTON
28	This button is pressed when setting the fan direction to "fixed" or "swing".
29	OPERATION MODE SELECTOR BUTTON
20	This sets the operation mode. The dry setting cannot be done.
• •	TIME NO. BUTTON
30	Selects time No. (Use in conjunction with the schedule timer only).
31	CONTROL MODE BUTTON
••	Selects control mode.
~~	FILTER SIGN RESET BUTTON
32	This button is pressed to erase the "clean filter" display after cleaning or replacement.

33	SET BUTTON				
55	Sets control mode and time No.				
34	FAN STRENGTH ADJUSTMENT BUTTON				
0-1	Pressing this button scrolls through "weak", "strong", and "fast".				
	ZONE SETTING BUTTON				
35 Zone registration mode can be turned on ar by pressing the start and stop buttons simu neously for at least four seconds.					
	INSPECTION/TEST RUN BUTTON (FOR SERVICE)				
36	Pressing this button scrolls through "inspection", "test run", and "system display". This button is not normally used.				
	VENTILATION STRENGTH ADJUSTMENT BUTTON				
37	This button is pressed to switch the ventilation strength ("fresh up") of the total enthalpy heat exchanger.				
2.	tes) Please note that all the displays in the figure appear for explanation purposes or when the cover is open. If the unit is used in conjunction with other optional central controllers, the OPERATION LAMP of the unit that is not under operation control may light up and go out a few minutes behind schedule.				

OPERATION

Individual screen, all screen, zone screen (Fig. 3)

This controller can perform operations in the individual screen, all screen, or zone screen.

- Individual screen The individual screen is used when performing group operations.
 The individual screen is used when performing the screen is use
- All screen The all screen is used when performing operations for all units at once.
 Zono screen The zono screen is used when
- Zone screen The zone screen is used when performing zone operations.
- 1. ^(f) Select the screen by pressing the "ALL/INDIVIDUAL" button.

CD Every time the "ALL/INDIVIDUAL" button is pressed, the selection scrolls through INDIVIDUAL \rightarrow ALL \rightarrow ZONE.

If nothing is done in the all or zone screens for one minute, it automatically goes to the individual screen.

If the zone number in the zone screen is displayed as "---," this indicates that no units are registered in a zone.
 Please perform zone registration before pro-

ceeding in the zone screen. (See page 9)

Batch operation and stop method (Fig. 4)

This is for operating or stopping all connected units at once.

A. What to do when operating or stopping all connected units at once.

1. Press either 🐨 " ALL 1" or

2 "ALL O".

- Operation can be performed from the individual screen, the all screen, or the zone screen.
- The "TEMPERATURE ADJUSTMENT" and "OPERATION MODE SELECTOR" buttons cannot be used. To set the temperature and operation mode,

Is set the temperature and operation mode, use B. batch operation.

B. Batch Operation

1. ⁽³⁾ Press the "ALL/INDIVIDUAL button" to enter the all screen.

The " 🔄 " display lights up on all registered units.

2. ⁽⁴⁾ Press the "SELECT" button.

The " I display lights up on all connected units.

⁽⁵⁾ Press the "RESET" button.

The " **I** " display goes off on all connected units. Operation and stop in the batch screen are done the same as with the batch operation and batch stop buttons.

Image: Second state of the Image and the Imag

The temperature rises 1° every time

the (\blacktriangle) button is pressed.

The temperature drops 1° every time

the ($\mathbf{\nabla}$) button is pressed.

Set to " -- " when you do not wish to use batch setting for the temperature setting. Setting to 1° above or below the temperature setting range displays " -- ".

Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

Set to " -- " when you do not wish to use batch setting for the operation setting.

Group operation and stop method (Fig. 5)

This is for operating or stopping connected units in groups.

[Group operation]

1. Press the Tr "ALL/INDIVIDUAL button"

to enter the *raindividual screen.* The unit will enter the individual screen automatically if nothing is done for one minute.

2. **I**Using the arrow keys, **I** move the

" T * to select the units to operate or stop. Keeping the button pressed down will move it rapidly.

The " 📃 " in this screen has selected unit 1-04.

3. ⁽⁵⁾ Press the "SELECT" button.

The " 🔳 " display lights up in the group.

⁽⁶⁾ Press the "RESET" button.

The " 🔳 " display goes off in the group.

4. ⁽⁾ Press the "TEMPERATURE ADJUST-MENT" button.

The temperature rises 1° every time the

(▲) button is pressed.

The temperature drops 1° every time the

(▼) button is pressed.

Temperature adjustment cannot be done if the selected group's air conditioners are in fan mode.

5. Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

Registering zones (Fig. 6)

It is possible to set multiple groups as one zone and control each zone separately.

No zones are registered when the unit is shipped from the factory.

Zone registration can be done in the individual screen, all screen, or zone screen.

[Registration]

1. Tressing the "ALL/INDIVIDUAL" button for four seconds. To Displays ZONE SET.

Zone Number 1 will be displayed, and if there are any groups already registered in the displayed

zone, a " 🔳 " will light up on the operation monitor.

- 2. ⁽³⁾ Select the Zone Number to be registered using the "ZONE NUMBER" button. Keeping the button pressed down will move it rapidly.
- Image: "Image: Second se
- 4. ^(C) Press the "SELECT" button to register that group to the zone.

The " **n** " display lights up on all the selected units.

There are the second terms of terms o

" 🔳 " goes off.

Repeat steps 3 and 4 until all the units you wish to register to the zone have been added.

2	Z ZONE SET					ZONE					1					
	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
1-																
2-																
3																
4																

In this example, a screen is shown with units 1-00, 1-02, 1-03, and 2-00 registered to Zone Number 1.

- 5. Repeat steps 2 to 4 to register to the next zone.
- Once zone registration is complete,
 press the "ALL/INDIVIDUAL" button to turn off "ZONE SET" display and return to the individual screen.

The display returns to the normal screen if nothing is done for one minute when in zone registration mode.

(NOTE)

• It is impossible to register one group to several different zones.

If this is done, the last zone registered to will be valid.

[Batch deletion of zone registration]

- Pressing the "ALL O" for at least four seconds while pressing the "FIL-TER SIGN RESET" button when "ZONE SET" is displayed will delete all zone registrations. The zone registrations for all units will be lost.
- Zone operation and stop method (Fig. 7)

This is for operating or stopping connected units in zones.

[Zone operation]

- 1. IP Press the "ALL/INDIVIDUAL button" to enter the zone screen.
- 2. ⁽³⁾Using the arrow keys, select the zone number to operate or stop.

Pressing - and + reduces the zone number

while \rightarrow and \uparrow raise the number. Keeping the button pressed down will move it rapidly.

• If the zone number is displayed as "---," this indicates that no units are registered in a zone. Please perform zone registration before using a zone. (See page 9)

3. ^(J) Press the "SELECT" button.

The " 🔳 " display lights up in the group.

Press the "RESET" button.

The " I display goes off in the group.

4. In Press the "TEMPERATURE ADJUST-MENT" button.

The temperature rises 1° every time the (\blacktriangle) button is pressed.

The temperature drops 1° every time the ($\mathbf{\nabla}$) button is pressed.

Set to "--" when you do not wish to use zone setting for the temperature setting. Setting to 1° above or below the temperature setting range displays "--".

 IP Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

Set to " -- " when you do not wish to use zone setting for the operation mode.

Changing the fan direction and fan strength (Fig. 8)

This changes the fan direction and strength settings in the air conditioner.

Changing the fan direction and strength is done in the individual screen.

[Registration]

1. IP Press the "ALL/INDIVIDUAL button"

to enter the (37⁻ individual screen. The unit will enter the individual screen automatically if nothing is done for one minute.

- 2. ③ Using the arrow keys, ④ move the
 - " " to select the units to fan direction adjustment or fan strength adjustment. Keeping the button pressed down will move it rapidly.
- Image: Second State of Second S

This sets "fixed" or "swing" for the fan direction.

Press the "FAN STRENGTH ADJUST-MENT" button.

Pressing this button scrolls through " ${}^{a}_{L}$ ", " ${}^{a}_{H}$ ", and " ${}^{a}_{H}$ ".

Depending on the indoor unit, only " $\frac{2}{L}$ " and " $\frac{2}{H}$ "

may be available.

The functions included in the indoor units may vary. Pressing a button for a function which is not available will cause "NOT AVAILABLE" to be displayed.

Changing the ventilation mode and ventilation strength (Fig. 9)

This changes the ventilation mode and strength settings in the total enthalpy heat exchanger. Changing the ventilation mode and strength is done in the individual screen.

[Registration]

1. IP Press the "ALL/INDIVIDUAL button" to

enter the $\operatorname{\widehat{ur}}$ individual screen.

The unit will enter the individual screen automatically if nothing is done for one minute.

2. In Using the arrow keys, I move the

" To select the units to ventilation mode or ventilation strength adjustment. Keeping the button pressed down will move it rapidly. 3. IP Press the "VENTILATION MODE" button.

It will scroll through " $(\underline{\mathbb{A}}_{\mathbb{D}})^{*} \rightarrow (\underline{\mathbb{A}}_{\mathbb{D}})^{*} \rightarrow (\underline{\mathbb{A}}_{\mathbb{D}})^{*}$ "

→ "௴௺". [©] Press the "VENTILATION STRENGTH ADJUSTMENT" button.

It will scroll through " ${}^{\bullet}_{L}$ " \rightarrow " ${}^{\bullet}_{H}$ " \rightarrow " ${}^{\bullet}_{L}$ " \rightarrow " ${}^{\bullet}_{FRESH UP}$ " \rightarrow

 $\begin{array}{c} \checkmark \\ H \\ FRESH UP \end{array}^{"} \rightarrow \begin{array}{c} \ast \\ L \end{array}^{"}$

The fresh up function may not be available depending on the connected unit model. The functions included in the indoor units may vary. Pressing a button for a function which is not available will cause "NOT AVAILABLE" to be displayed.

Ventilation Mode and Amount

If these are changed using the remote controller depending on the unit model, they cannot be displayed on the central remote controller. To monitor the ventilation mode and amount, check the values on the remote controller.

Timer Number Setting (Fig. 10)

(Only when used with the schedule timer) Using this together with the schedule timer makes it possible to set on and off times four times a day.

[Registration]

 TPressing the "TIMER NO." button causes the number set for timer number 1 to blink.

If no timer setting has been made

" - " will be displayed. Select the desired timer number by pressing the (1) "TIMER NO." button.



2. In Once the desired timer number is displayed, press the "SET" button.

Press the $(27)^{-}$ "SET" button within 10 seconds after the timer number is displayed. The display will return to how it was after 10 seconds.



The display for timer number 1

will stop blinking and then timer number 2 will start blinking.

3. (P Select the desired timer number by pressing the "TIMER NO." button.

Once the desired timer number is displayed, ⁽²⁾ press the "SET" button. The display for timer number 2



The " $\bigoplus_{No.}$ " display will disappear after 3 seconds.

will stop blinking.

Select " - " in the timer number when you do not wish to set a timer number.

It is possible to set only one timer number. (The times for turning the unit(s) on and off twice a day can be set with a single timer number.)

Timer Number Setting

- Group control: select the unit in the individual screen and set the timer number.
- Batch control: set the timer numbers for all connected units.
- Zone control: set the timer numbers for all zone-registered units. Call up the zones which you wish to set in the zone screen and set the timer numbers.
- · Since the timer number will be set to afterpress priority, the timer number in the last screen set will be valid for the connected units.

Example 1

Setting timer number 1 for unit 1-00 to "1" and timer number 2 to "2" in the individual screen and then setting timer number 1 to "3" and timer number 2 to "4" in the batch screen causes the timer numbers for all units to be set, so timer number 1 for unit 1-00 will be "3" and timer number 2 will be "4".

Example 2

To prevent leaving units on, timer number 1 is set to "5" in the batch screen.

Setting timer number 1 in zone number 1 to " - " in the zone screen after that will change the timer number for zone number 1, so the setting to prevent leaving the units on will be lost for zone number 1 only.

If a timer number is set incorrectly by accident, redo the setting in the desired screen.

What happens when the timer number on time and off time are set to the same time

When the on time and off time are set to the same time for the same timer number, operation does not change.

When the on time and off time are set to the same time for different timer numbers, the off time is given priority.

When using timer operation, make sure the times do not overlap when setting the program of the schedule timer.

■ Setting the Operation Code (Fig. 11)

[Registration]

1. ⁽¹⁾ Pressing the "CONTROL MODE" button causes the currently set operation code to blink.

Call up the desired code number by pressing the "CONTROL MODE" button. Scroll through the code numbers.

2. In Once the code number is displayed, press the "SET" button.

The display will stop blinking. The operation code display will disappear after 3 seconds.

[The Operation Code Setting]

Group control:	select the unit in the individual screen
	and set the operation code.

- Batch control: set the operation code for all connected units.
- Zone control: set the operation code for all zone-registered units. Call up the zones which you wish to set in the zone screen and set the operation code.

Since the operation code will be set for after-press priority, setting the operation code in the zone and individual screens after setting the operation code in the batch screen, will cause the operation codes set afterwards to be valid.

OPERATION MODE

The following five operation control modes can be selected along with the temperature setting and operation mode by remote controller, for a total of twenty different modes. These twenty modes are set and displayed with control modes of 0 to 19. (For further details, see **EXAMPLE OF OPERATION SCHEDULE** on the next page.)

ON/OFF control impossible by remote controller	Use this mode when operating and stopping from the central remote controller only. (ON/OFF control by the remote controller is disabled.)
Only OFF control possible by remote controller	Use this mode when executing the operation only by the central remote controller, and executing only the stop by remote controller.
Centralized	Use this mode when executing the operation only by the central remote controller, and executing start/stop freely by remote controller during the preset hours.
Individual	Use this mode when executing start/stop both by central remote controller and remote controller.
Timer operation possible by remote controller	Use this mode when executing start/stop by remote con- troller during the preset hours, and not starting operation by the central remote controller at the programmed time of system start.

[HOW TO SELECT THE CONTROL MODE]

 Select whether to accept or to reject the operation from the remote controller regarding the operation, stop, temperature setting and operation mode setting, respectively, and determine the particular control mode from the rightmost column of the table below.

Example



		Control by remote	controller			
Operation mode	Operat Unified operation, individ- ual operation by central remote controller, or opera- tion controlled by timer	ion Unified stop, individual stop by central remote controller, or timer stop	Stop	Tempera- ture control	Operation mode setting	Control mode
					Acceptance	0
ON/OFF control			Deiestien	Rejection	Rejection	10
impossible by remote controller			Rejection (Example)	Acceptance	Acceptance (Example)	1 (Example
	Rejection			(Example)	Rejection	11
	(Example)			Rejection	Acceptance	2
Only OFF control possible by		Rejection (Example)		Rejection	Rejection	12
remote controller		(Example)		Acceptance	Acceptance	3
					Rejection	13
				Rejection	Acceptance	4
Centralized					Rejection	14
Centralized				Acceptance	Acceptance	5
	Acceptance		Acceptance	Acceptance	Rejection	15
	Acceptance		Acceptance	Rejection	Acceptance	6
Individual		Acceptance		Rejection	Rejection	16
Individual		Acceptance		Accentance	Acceptance	7
				Acceptance	Rejection	17
				Bojection	Acceptance	8
Timer operation	Acceptance	Rejection		Rejection	Rejection	18
possible by remote controller	(During timer at ON position only)	(During timer at OFF position)		Accontance	Acceptance	9
				Acceptance	Rejection	19

Note) Do not select the timer operation possible without the remote controller. In this case, timer operation is disabled.



EXAMPLE OF OPERATION SCHEDULE

Operation schedule is possible only in conjunction with the schedule timer (optional accessory). Liquid crystal display of schedule timer

ON/OFF control impossible by remote controller





Only OFF control possible by remote controller



■ Setting operation mode (Fig. 12)

[Registration]

- 1. IP Press the OPERATION MODE SELEC-TOR BUTTON. Each time you press this button, the display rotates as shown on the below list.
- List of operations which can be set In the below list, " \bigcirc " refers to the acceptable setting, while " × " refers to the not acceptable setting.

\square	A: Zones and groups with no "⊵, " display.			
Display	Setting	Contents of setting		
	×			
**	0	Can be set in individual zones or groups		
	0 * 1	Can be set in individual zones or groups		
*	0	Can be set in individual zones or groups		
*	0	Can be set in individual zones or groups		
da or Stor ℃	0 * 1	Can be set in individual zones or groups * 3		
	0 * 1	Can be set in individual zones or groups		
	0	Select this display if you don't wish to set by zone.		

	B: Zones and groups with a "" display.			
Display	Setting	Contents of setting		
	0	To be set by zone * 2		
+ &-	0	Can be set in individual zones or groups		
★	×			
*	×	The displays are shown by group * 4		
*	×	The displays are shown by group * 4		
⊈#∞ or \$\$\$ 2 or * 2	O * 1	Can be set in individual zones or groups * 3		
	0 * 1	Can be set in individual zones or groups		
	0	Select this display if you don't wish to set by zone.		

- *1: Setting may not be acceptable depending on the type of indoor unit with which this unit is connected.
- *2: In zone control, the units run in temperature adjustment mode (heating or cooling) for the outdoor system for the groups registered to those zones. Heating or cooling selection is not available.
- *4: In group control, the units run in temperature adjustment mode (heating or cooling) for the group outdoor system. Heating or cooling selection is not available.
- The Zone consists of the following two cases.

A. Zone without display" 🔄 🙏

The group with master remote controller setting exists in this zone.

Setting the master remote controller enables cool/ heat selection.

Operations other than cool/heat operations can also be set for some operations. For further details, see the list on the left.

B. Zone with display" [下太 "

No group with master remote controller setting exists in this zone. The cool/heat selection is not available because the master remote controller has not been set. Some operations other than cool/heat operations can be set. For further details, see the list in the left.

See page 20 if the display" See page 20 if the display " is flashing.

- Fan operation can be performed for each zone using the central remote controller even if there is no cooling/heating selection right during cooling or heating. Also, if a Ventiair is connected in the zone, ventilation and ventilation cleaning operation is possible. See the included operating manuals for details.
- When the indoor unit is in heat operation, change the setting to FAN operation through the central remote controller; then, you can switch the fan speed to the extremely low fan speed. Warm air may blow if any other indoor unit belonging to the same system is in heat operation.
- The indoor fan stops during defrost/hot start.
- DRY cannot be set from the central remote controller.

■ Group monitoring (Fig. 13)

Utilize the group monitor function in each of the following cases:

- 1. Check the malfunction code. (See the next page.)
- 2. Check the group that requires cleaning of the air filter and air cleaner element. (See page 21.)
- 3. Change the setting of the master remote controller. (See page 20.)
- Check the group(s) sharing the same outdoor unit. Or, check the particular group(s) with the master remote controller setting. (See page 20.)
- 5. Check the conditions of other individual groups.

When in zone screen

The zone screen will revert to the individual screen automatically if nothing is done in it for one minute.

[Registration]

- 1. TPress the "ALL/INDIVIDUAL" button to switch to the T "INDIVIDUAL" screen.
- 2. I Using the arrow key, move the

" []" to select the unit to be monitored. Keeping the button pressed down will move it rapidly.

 \bigcirc The " \square " lights up and the status of that unit is displayed in the LCD. The cursor in the screen Fig. 13 has selected unit 2-06.

Error diagnosing function (Fig. 14)

This central remote controller is provided with a diagnosing function, for when an indoor unit stops due to malfunction. In case of actuation of a safety device, disconnection in transmission wiring for control or failure of some parts, the operation lamp, inspection display and unit No. start to flash; then, the malfunction code is displayed. Check the contents of the display, and contact your DAIKIN dealer because the above signs can give you the idea on the trouble area.



The display " — " flashes under the group No. where the indoor unit that has stopped due to malfunction.

[Registration]

1. IP Press the ARROW KEY BUTTON to call up the group that has stopped due to malfunction.

(2) The unit No. (3) the malfunction code is flashing because of an error failure.



Operation lamp	Maintenance display	Unit No.	Malfunction code	Error content
÷.	•	⇒	64	Indoor air thermistor error
\$	•	⋪	65	Outdoor air thermistor error
¢.	•	⋪	68	HVU error (Ventiair dust-collecting unit)
¢	•	⋪	6A	Dumper system error
৵	⇒	⋪	6A	Dumper system error + Thermistor error
¢.	•	⋪	6F	Simple remote controller error
÷¢-	•	\$	6H	Door switch (Ventiair dust-collecting unit), relay harness fault (Ventiair dust-collecting/humidifier unit)
*	×,	৵	94	Ventiair internal transmission error (between total enthalpy – fan unit)
÷ þ	÷Þ	⇒	A0	Indoor unit · external safety device error
*	⇒	\$	A1	Indoor unit · BEV unit (Sky-Air connection unit) PC board assembly fault
÷¢	•	\$	A1	Indoor unit · PC board assembly fault
÷	\$	⇒	A3	Indoor unit · Drain level error (33H)
৵	⇒	⋪	A6	Indoor unit · Fan motor (51F) lock, overload
¢.	•	⋪	Α7	Indoor unit \cdot Fan direction adjustment motor (MA) error
\$	৵	A	A9	Indoor unit \cdot BEV unit, electric expansion valve motor (20E) error
¢.	•	\$	AF	Indoor unit · Malfunctioning drain
¢.	•	⋪	АН	Indoor unit · Dust-collector error
\$	⇒	\	AJ	Indoor unit \cdot Insufficient capacity setting, address setting fault

			1	Indeen with Linuid minima the mainten (ThO) Emer (foulty, compare	
¢.	\	\$	C4	Indoor unit · Liquid piping thermistor (Th2) Error (faulty connec- tion, cut wire, short circuit, fault)	
⇒	.⊅	∻	C5	Indoor unit · BEV unit, gas piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)	
÷)		A	C9	Indoor unit · Intake air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)	
৵	⋪		СА	Indoor unit · Outlet air thermistor (Th4) Error (faulty connection, cut wire, short circuit, fault)	
	٠	¢	CJ	Indoor unit remote controller sensor error	
⇒	⊅	¢.	E0	Outdoor unit · Safety device operation	
∻	∻	\$	E1	Outdoor unit · PC board assembly fault	
¢	٠	\$	E1	Outdoor unit · PC board assembly fault	
÷Þ	⊅	\$	E3	Outdoor unit · High-pressure switch fault	
⊅	⋪	\$	E4	Outdoor unit · Low-pressure switch fault	
⇒	÷ þ	\$	E9	Outdoor unit · Electric expansion valve motor (20E) error	
¢	•	Þ	EC	Heat source unit · Intake water temperature inter-lock operation (fan operation)	
∻	⋪	\$	EF	Outdoor unit · Ice thermal storage unit error	
₽	₽	⋪	F3	Outdoor unit · Discharge piping temperature error	
¢	٠	\$	H3	Outdoor unit · High-pressure switch operation	
.≯	÷ þ	\$	H4	Outdoor unit · Low-pressure switch operation	
⇒	⇒	⋪	H9	Outdoor unit · Outdoor air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)	
¢.	•	Þ	H9	Outdoor unit · Outdoor air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)	
☆	٠	⋪	нс	Outdoor unit · Water temperature sensor system error	
¢.	•	Þ	HF	Ice thermal storage unit error, ice thermal storage controller error error in outdoor unit during ice thermal storage operation	
⇒	¢.	\$	HJ	Outdoor unit · water system fault	
৵	∻	⋪	J1	Outdoor unit · pressure sensor error	
÷≯	⋪	⋪	J3	Outdoor unit · Discharge piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)	
¢	•	\$	J3	Outdoor unit · Discharge piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)	
- ' Þ	⋪	৵	J5	Outdoor unit Intake piping thermistor (Th4) Error (faulty connection, cut wire, short circuit, fault)	
- ' Þ	4	\$	J6	Outdoor unit · Heat exchange thermistor (Th2) error	
÷.	•		J6	Outdoor unit · Heat exchange thermistor (Th2) error Error (faulty connection, cut wire, short circuit, fault)	
৵	¢	\$	J7	Outdoor unit · Header thermistor (Th6) error	
÷Þ	₽	\$	JA	Outdoor unit · Discharge piping pressure sensor error	
⊅	⋪	⋪	JC	Outdoor unit · Intake piping pressure sensor error	
∻	¢	4	JF Outdoor unit · Oil temperature sensor (Th5) system err		
¢	٠	\$	JH Outdoor unit · Oil temperature sensor (Th5) system error		
÷ þ	₽	*	LO	Outdoor unit · Inverter system fault	
⇒			L4	Outdoor unit · Inverter cooler fault	
৵	4	¢	L5	Outdoor unit · Ground circuit for compressor motor, short circuit or power unit short circuit	
Г

৵	-Þ	⇒	L6	Outdoor unit · Ground circuit for compressor motor, short circuit
¢	4	÷ Þ	L8	Outdoor unit · Compressor overload, compressor motor wire disconnection
⇒	÷\$	÷	L9	Outdoor unit · Compressor lock
÷	÷\$	÷	LA	Outdoor unit · Power unit error
*	-Þ	÷\$	LC	Outdoor unit · Transmission error between inverter and outdoor control unit
⇔ or ●	.	÷\$	M1	Central controller: PC board fault
⇔ or ●	\$	÷	M8	Transmission error between central controllers
⇔ or ●	⇒	⇒	MA	Central controller: Incorrect combination
⇔ or ●	÷\$	- Þ	МС	Central controller: Address setting fault
÷ þ	•	⇒	P0	Insufficient gas (thermal storage)
\$	÷\$	÷\$	P1	Outdoor unit · Power voltage imbalance, phase loss
÷Þ	->	÷	P4	Outdoor unit · Power unit temperature sensor error
¢	•	*	U0	Pressure drop due to insufficient refrigerant, electric expansion valve fault, etc.
⇒	->	->	U1	Reversed or lost phase
\$	\$	⇒	U2	Power voltage error, momentary electrical stoppage
≉	¢	¢.	U4	Transmission error between indoor unit/BEV unit and outdoor/BS unit, Transmission error between outdoor unit and BS unit
÷	->	->	U5	Transmission error between remote controller and indoor control unit
•	☆	•	U5	Remote controller board fault or remote controller setting fault
⇒	÷\$	÷\$	U6	Transmission error between indoor units
৵	Þ	৵	U7	Transmission error between outdoor units Transmission error between outdoor unit and ice thermal storage unit
¢	•	*	U7	Transmission error between outdoor units (cooling/heating batch, low-noise operation)
*	->¢	•	U8	Transmission error between master remote controller and slave remote controller (slave remote controller error) Incorrect combination of indoor unit and remote controller within a single system (model)
*	Þ	Þ	U9	Transmission error between indoor unit/BEV unit and outdoor unit within a single system Transmission error between BS unit and indoor unit/BEV unit and outdoor unit within a single system
*	Þ	Þ	UA	Incorrect combination of indoor, BS, and outdoor units within a single system (model, number of units, etc.) Incorrect combination of indoor unit and remote controller (remote controller in question) BS unit connection position fault
\$	•	\¢	UC	Central control group numbers overlap
*)	- Þ	÷Þ	UE	Transmission error between indoor unit and central controller
≯	4-	*	UF	Unset system, incorrect settings between BEV unit and indoor unit
÷	÷	⇒	UH	System fault

- error codes (in outline font) do not display "maintenance" and the system will run, but please check the content of the display and contact your dealer.

Setting master remote controller (Fig. 15)

You must set the master remote controller of the operation mode for one of the indoor units, if two or more such indoor units with the remote controller are connected with the outdoor unit where the operation modes such as cool/heat operation and FAN operation can be set by remote controller and central remote controller.

1. Preparations

When you want to fix settings

- Check the particular group with the master remote controller setting for the refrigerant system you wish to reset. (See the below.)
- · Call up the group without the display

" 💽 🙏 " (See page 16.)

CT→ Hold the OPERATION MODE SELECTOR BUTTON down for about four seconds while the above group is being called up.

The display " [], " flashes on the liquid crystal display of the remote controller for all the groups sharing the same outdoor unit or BS unit.

When you turn on the power switch for the first

time, the display" [] time, the display. " flashes.



2. Setting selection right

Pall up the desired group to set the master remote controller, and repress the OPERA-TION MODE SELECTOR BUTTON. The master remote controller is set for this group, and the

display " 💽 🧶 " goes out. The display

"
 "
 "
 "
 appears for the other groups.
 Setting is finished now.

When switching operation

• In case of operation switch Call up the zone including the group with the setting of master remote controller.

(Zone without the display " []太 ")

The Press the OPERATION MODE SELECTOR BUTTON several times, and switch to the desired operation mode.

NOTE

 However, the displays " (A)" " (B)" and "VENTI-LATION MODE" may apper in some zones, depending on the type on indoor unit with which they are connected. (VENTILATION MODE)

📇 or 🕱 or 🏏

[System Display]

- 1. Test run mode is necessary to display the system display.
- 2. In order to turn on test run mode, select the appropriate air conditioner on the individual screen with the cursor and then set its operation mode to either cooling or heating. (It makes no difference if the air conditioner is running or not running while this operator is being performed.)
- 3. Press the "inspection/test run" button twice to put it into test run mode.
- Pressing the "inspection/test run" button for four or more seconds in test run mode will display IP the "REF CIRCUIT."



Call the unit whose system you wish to look up using the arrow keys.

The " **I** " on all groups in the same system as the displayed group will light up.

Of those, the " **[**" display in all groups which have cooling/heating selection privilege will blink.



In this example, individual units 1-00, 1-03, 1-05, 1-06, 1-07, 2-02, and 2-03 are in the same system, and 1-05 has the cooling/heating selection privilege.

To look up other systems, call up all the units you wish to look up using the arrow keys.

Pressing the inspection/test run button one more time gets rid of the system display and ends it.

The unit will enter the individual screen automatically if nothing is done for one minute in the system display screen.

This function may not be available for all connected outdoor units, in which case "REF CIRCUIT" will blink. It will also not be correctly displayed if DIII-NET extension ADP is used.

■ Display of time to clean (Fig. 16)

This central remote controller displays the time to clean the air filter or air cleaner element for each group or any given group by utilizing two types of signs. The display " 같이, 플라" tells the time to clean the air filter or the air

cleaner element of some group.

If a cleaning sign is displayed

A filter or element in some group is ready to be cleaned.

1. ①[¬] Press the ARROW KEY BUTTON, and search the groups displaying " →→→" or

" ﷺ" (The group may be plural.)

Clean or change the air filter or air cleaner element.

For further details, see the operation manual attached to each indoor unit. (Clean or change the air filter or air cleaner element of all the groups dis-

playing " 🔬 " or " 🖉 ".)

2. ② Press the FILTER SIGN RESET BUT-TON, and the display " → " disappears. (Including all the groups where the air filter has been cleaned.)

NOTE

Be sure to check the display I " J has disappeared at this point. The appearance of the above display is a sign that the air filter or air cleaner element of some group still needs cleaning.

INSTALLATION TABLE

When installing the equipment, mark the zone No. of each group and installation location in the below table.

Setting group No.

(Setting is not possible unless power is activated to both the central remote controller and indoor unit.)

Operated by remote controller

- 1. Activate power to both the central remote controller and indoor unit.
- 2. While in the normal mode, hold down the " 圕" button for a minimum of 4 seconds. The unified ON/ OFF controller will enter the FIELD SET MODE.
- 3. Select the MODE No. " 🛺 " with the " 🗐 " button.
- Use the " " button to select the group No. for each group. (Group No. increases in the order of 1-00, 1-01 ... 1-15, 2-00, ... 8-15.)
- 6. Press "🖑 " to return to the NORMAL MODE.



Operated by simplified remote controller

- 1. Activate power to both the central remote controller and indoor unit.
- 2. Remove the upper part of the remote controller.
- 3. Press the **BS6** BUTTON (field set) on the PC board. The controller will enter the FIELD SET MODE.
- 4. Select the MODE No. " 10" with the BS2 BUT-

TON and BS3 BUTTON (temperature setting).

- 5. Use the BS9 BUTTON (set A) and BS10 BUTTON (set B) to select the group No. for each group. (Group No. increases in the order of 1-00, 1-01 ... 1-15, 2-00, ... 8-15.)
- 6. Press BS7 BUTTON (set/cancel) to set the selected group No.
- 7. Press BS6 BUTTON (field set) to return to the NORMAL MODE.



Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																
Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																

22

Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																
Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																

OPTIONAL ACCESSORIES



You can perform the normal operation, take off the malfunction contact point and unified start/stop by contact point, all by connecting this unit with the unification adaptor for computerized control. For further details, ask your DAIKIN dealer.

(a) Unification adaptor for computerized control (b) Central remote controller

DOUBLE CENTRAL REMOTE CONTROLLERS



With two central remote controllers, centralized control (indoor units) is possible from different locations.

(a) Central remote controller
(b) Group No. 1 – 00
(c) Group No. 1 – 15
(d) Group No. 2 – 00
(e) Group No. 4 – 15
(f) A maximum of 64 groups

Note)

• For control alignment and settings for double central remote controllers, contact your dealer.

SPECIFICATIONS

Specifications

Power supply	1 ~ 50/60Hz, 100V – 240V
Power consumption	Max. 8W
Forced ON/OFF input	Continuous "a" contact Contact current: approximately 10mA
Size	180 (W) × 120 (H) × 64.5 (D)
Weight	420g

■ Outline drawings



When using this unit an electric parts box of KJB311A is required. For installation, a steel electric parts box to be embedded is mandatory.



Fig. 9



Fig. 10



Fig. 11



25



Fig. 13



Fig. 14



Fig. 15

Fig. 16



26

3P124623-1E

13.7 <DCS301C71> Unified ON/OFF Controller

13.7.1 Installation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public".
Meaning of warning, caution and note symbols. ▲ WARNING Indication a potentially hazardous situation which, if not avoided, could result in death or serious injury. ▲ CAUTIONIndication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. ▲ CAUTIONIndication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be sued to alert against unsafe practices. ▲ NOTE
Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself. Improper installation may result in water leakage, electric shocks or fire.
Perform installation work in accordance with this installation manual. Improper installation may result in water leakage, electric shocks or fire.
Be sure to use only the specified accessories and parts for installation work. Failure to use the specified parts may result in water leakage, electric shocks, fire or the unit falling.
Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes. Improper installation work may result in the equipment falling and causing accidents.
Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual. An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire.
Make sure that all wiring is secured, the specified wires and used, and no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened. Improper positioning of the electric parts box lid may result in electric shocks, fire or the terminals overheating.
Before touching electrical parts, turn off the unit.
Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incomplete grounding may result in electric shocks.
When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.
Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may result.
Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
Install an leak circuit breaker, as required. If an leak circuit breaker is not installed, electric shock may result.
 Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage. (b) where corrosive gas, such as sulfurous acid gas, is produced (c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment. (d) where fammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire.
Be very careful about product transportation. Safely dispose of the packing materials.
Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation.
Do not turn off the power immediately after stopping operation. Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.
Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.)
Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible.
This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.



which it • When u	was delivere sing multiple	d.)	lers, or using the unified	0	master controller. (Use th		
Patterr Unified ON/OF		n of optional controllers for Central remote control		Unified	Connector for setting ma ON/OFF controller	ster controller (X1A) Set Central remote control	
	-	1 to 4			and all the rest to "Not used". Ill to "Not used".	(Note)	
1 to	16	1 to 4	1		and all the rest to "Not used". Ill to "Not used".	(Note)	"Not used "Not used
centra 2 Switch for These sw	l remote con r setting each itches are us	troller. a address (DS1) ed to set group control a	address.		tral remote controller, see s shipped from the factor		al provided with t
Each Address 1-00	0 ~ 1-15 2-00 ~ 1	2-15 3-00 - 3-15 4-00 - 4-1 DS1 (State of the state of		7-00 ~ 7-15 8-00 ~ 7 DS1	B-15 NOTE) ■ indicates the position of switches. Connector fr	or setting master cont Forced reset sy	roller
3 MAIN/SU With two ur	B changeove	(Example) In the case of 1-00 to er switch setting controllers, centralized contr	own in the diagram belo 1-15, attach 1. ol (indoor units) is possible f ne MAIN/SUB changeover su	rom different		Ch for setting each add Control mode sel MAIN/SUB cha MAIN/SUB cha Group No. 1-00	ector
4 Setting of The unifier sequential indoor uni operation.	the sequentia d ON/OFF co operation fu ts on in 2-sec (Sequential o	WOFF controllers (1)·(2) is al operation function ntroller is equipped with a nction that sequentially tu ond intervals during unifi operation is factory set to eration ON or OFF, set as	rns ed Sequential operat "ON.")	ion While	Unified ON/OFF controller (1) holding down the unified stop but	,	Unified ON controller Sequential op "OFF"
started		usly. You cannot therefor			bly equipment, but does n power supply equipment		pressors will not
		erns of control mode ca	n be set.				
Control mode		Individual	Centralized		Timer operation possible remote controller		control impossible mote controller
Content	unified ON/C remote contr		After operated by unified Of controller, operation/stop is controlled by remote contro stopped by unified ON/OFF	freely op ller until cor	en used in conjunction with schedu eration/stop is controlled freely by n ntroller during the set time but opera available when schedule timer is C	emote ON/OFF contro ation is (This unit can n	ot be operated/stopp
DS2 setting	(Factory s	ONTROL MODE	~ ~		ON SCONTROL MODE		
				I			
• Se • Wi 6 Forced res	et control mo hen used in c set switch (S	,	mote controller, the control		entral remote controller has	s the priority.	<pre></pre>





Before starting test operation, supply power to the indoor units, outdoor units, and unified ON/OFF controller and press the ON/OFF BUTTON. If the operation lamp flashes, it indicates a malfunction in the indoor unit of the applicable group. If the display of " _____ " flashes, it indicates a malfunction in the optional controllers for centralized control. Check for such malfunctions.

NOTES • For test operation of indoor and outdoor units, refer to the installation manual attached with the outdoor unit.

After turning the power supply ON, if the unit does not accept operation for two minutes or more with the display of "______" flashing, check the following points.
 Check that setting of the connector for setting master controller is correct.

Check that the group No. for centralized control has been set.

1P126474-1B

13.7.2 Operation Manual

Please read these "SAFET	Y CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit
operates properly during th	ne start-up operation.
	er on how to operate the unit and keep it maintained. t they should store this installation manual along with the operation manual for future reference.
	under the term "appliances not accessible to the general public"
Meaning of warning, cautio	in and note symbols
•	dication a potentially hazardous situation which, if not avoided, could result in death or serious injury.
-	dication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be sued to alert against unsafe practices.
▲ NOTE In	dication situation that may result in equipment or property-damage-only accidents.
	ets handy so that you can refer to them if needed.
Also, if this equipment is tra	ansferred to a new user, make sure to hand over this operation manual to the new user.
In order to avoid electric	shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off power and call your dealer for instructions.
	lation of the air conditioner.
	formed by yourself may result in a water leakage, electric shock, and fire.
	ovement, repair, and maintenance. repair, and maintenance may result in a water leakage, electric shock, and fire.
	attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment.
-	ssories made by Daikin which are specifically designed for use with the equipment and have them installed by a professional.
	and reinstall the air conditioner or the remote controller. y result in a water leakage, electric shock, and fire.
Never let the indoor unit	or the remote controller get wet.
It may cause an electric sh Never use flammable spi	ray such as hair spray, lacquer or paint near the unit.
It may cause a fire.	
	h that of wrong ampere ratings or other wires when a fuse blows out. • may cause the unit to break down or cause a fire.
Never inspect or service Ask a qualified service per	
Cut off all electric waves	
Do not wash the air cond Electric shock or fire may r	litioner or the remote controller with excessive water.
Do not install the air con	ditioner or the remote controller at any place where flammable gas may leak out.
T the gas leaks out and stand	ays around the air conditioner, a fire may break out.
	ingers can cause electric shock.
After a long use, check ti	he unit stand and fitting for damage.
If they are left in a damage	ed condition, the unit may fall and result in injury.
Do not allow a child to m Falling or tumbling may res	oount on the unit or avoid placing any object on it. sult in injury
Do not let children play o	
-	essly, it may result in injury.
	se and anything containing water. causing an electric shock or fire.
Never touch the internal	parts of the controller. anel. Some parts inside are dangerous to touch, and a machine trouble may happen.
For checking and adjusting	g the internal parts, contact your dealer.
	iller in a spot splashed with water. nachine may cause an electric leak or may damage the internal electronic parts.
Do not operate the air co	onditioner when using a room fumigation - type insecticide.
Failure to observe could ca Safely dispose of the page	ause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.
Packing materials, such as	s nails and other metal or wooden parts, may cause stabs or other injuries.
	/ plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. r immediately after stopping operation.
	inutes before turning off the power. Otherwise, water leakage and trouble may occur.
	nded for use by young children or infirm persons without supervision.
The remote controller sh	nould be installed in such away that children cannot play with it.
	of the remote controller with a hard, pointed object.
The remote controller may	of the remote controller with a hard, pointed object.
The remote controller may Never pull or twist the ele It may cause the unit to ma	of the remote controller with a hard, pointed object. be damaged. sectric wire of the remote controller. alfunction.
The remote controller may Never pull or twist the ele It may cause the unit to ma Do not place the controlle	of the remote controller with a hard, pointed object. be damaged. sectric wire of the remote controller.
The remote controller may Never pull or twist the ele It may cause the unit to ma Do not place the controll The LCD display may get o Do not wipe the controlle	of the remote controller with a hard, pointed object. be damaged. ectric wire of the remote controller. alfunction. er exposed to direct sunlight. discolored, failing to display the data. er operation panel with benzine, thinner, chemical dustcloth, etc.
The remote controller may Never pull or twist the ele It may cause the unit to ma Do not place the controll The LCD display may get c Do not wipe the controlle The panel may get discolor cloth.	by the damaged. exctric wire of the remote controller. alfunction. er exposed to direct sunlight. discolored, failing to display the data.



The following four	patterns of control mode can be set.			
Control mode	Individual	Centralized	Timer operation possible by remote controller	ON/OFF control impossible by remote controller
Content	Operation/stop is controlled by both unified ON/OFF controller and remote controller.	After operated by unified ON/OFF controller,operation/stop is freely controlled by remote controller until stopped by unified ON/OFF controller.	When used in conjunction with schedule timer, operation/stop is controlled freely by remote controller during the set time but operation is not available when schedule timer is ON.	Operation/stop is controlled by unified ON/OFF controller only. Indoor units can not be operated/ stopped by remote controller.
	AODE Set)	NODE	WODE	WODE

NOTE: indicates the position of switches.

Set control modes before turning power supply on.
 When used in conjunction with central remote controller, the control modes of the central remote controller has the priority.

DISPLAY OF MALFUNCTION

Flashing of lamps indicates malfunctions. Contact your Daikin dealer. When turning power supply on, all lamps may light and UNDER HOST COMPUTER INTEGRATED CONTROL lamp may flash and not accept the operation for about on minute. These conditions are not malfunctions States of lamps Contents of malfunctions

-

1			1 1
	Flashing of operation lamp	Indicates malfunctions in the indoor unit in the group where the operation lamp is flashing.	
	Flashing of UNDER HOST COMPUTER INTEGRATED CONTROL lamp	Indicates malfunctions in optional controllers for centralized control.	
$\overline{\ }$			

2P126475-1

N Ś

DS2 setting

13.8 <DST301BA61> Schedule Timer Controller

Enables you to connect and control weekly schedule for up to 128 indoor units all together.



- Simultaneous control of up to 128 indoor units is managed by a week schedule.
- The start and stop time for twice a day can be set for the week in increments of 1 minute.
- By combining with a central remote controller and schedule timer, you can construct a system that matches the size and use of the building.
- If used together with a central remote controller, you can set up to 8 schedule patterns which can be distributed among zones as desired using the central remote controller.
- Is equipped with a compensation function for power failure up to 48 hours.
- Features thin design of a mere 16 mm in thickness. (Uses JIS recessed box for 2.)
- Wiring can be up to 1 km in length. Applicable wiring methods include bus and star in addition to crossover type.
- Can be used in combination with other D-BACS equipment.

13.8.1 Specifications / Dimensions SPECIFICATIONS

Specifications

Display of time	12-hour digital display
Clock cycle type	Quartz clock type
Clock accuracy	Within ±30 sec./month (environmental temperature from 15°C to 35°C)
Timer programming	Two pairs of programmed time for both system start and system off can be set in units of minute for each day of the week
Power failure compensation time	Approximately 48 hours for a single occurrence of power failure (clock with No. of programmed time)
Size	120 (W) × 120 (H) × 53 (D) mm (Width/Height/Depth)
Weight	Approximately 210g

Outline drawings





Specifications and appearance subject to change without notice.

13.8.2 Installation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public".
Meaning of warning, caution and note symbols.
▲ WARNINGIndication a potentially hazardous situation which, if not avoided, could result in death or serious injury. ▲ CAUTIONIndication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
▲ NOTE
⚠ WARNING
Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself. Improper installation may result in water leakage, electric shocks or fire.
Perform installation work in accordance with this installation manual.
Improper installation may result in water leakage, electric shocks or fire. Be sure to use only the specified accessories and parts for installation work.
Failure to use the specified parts may result in water leakage, electric shocks, fire or the unit falling.
Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes. Improper installation work may result in the equipment falling and causing accidents.
Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual. An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire.
Make sure that all wiring is secured, the specified wires and used, and no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened. Improper positioning of the electric parts box lid may result in electric shocks, fire or the terminals overheating.
Before touching electrical parts, turn off the unit.
Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incomplete grounding may result in electric shocks.
When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.
Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may result.
Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
Install an earth leak circuit breaker, as required. If an earth leak circuit breaker is not installed, electric shock may result.
 Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage. (b) where corrosive gas, such as sulfurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage. (c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment.
 (d) where flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire.
CISPR 22 Class A Warning. This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Be very careful about	product transportation.
Tear apart and throw aw	packing materials. as nails and other metal or wooden parts, may cause stabs or other injuries. <i>y</i> ay plastic packaging bags so that children will not play with them. If children play with a plastic bag t, they face the risk of suffocation.
	wer immediately after stopping operation. minutes before turning off the power. Otherwise, water leakage and trouble may occur.
radios in order to prev	outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or rent image interference or noise. o waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.)
fluorescent lamps. (inv	eless kit) transmitting distance can result shorter than expected in rooms with electronic verter or rapid start types) far away from fluorescent lamps as possible.
motali tric macor anit ao	product.







Refer to the installation manual attached to the outdoor unit.

In case the schedule timer is used individually and the wiring is changed after the system has been operated, reset the power after energizing for more than five minutes. It may not be possible to control the unit from the schedule timer.

3P162015-1A

13.8.3 Operation Manual



1



[1]



SAFETY CONSIDER-ATIONS

Please read these "SAFETY CONSIDER-ATIONS " carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.

Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference.

This air conditioner comes under the term " appliances not accessible to the general public ".

Meaning of warning, caution and note symbols.

- WARNING......Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE Indicates situation that may result in equipment or property-damage-only accidents.

Keep these warning sheets handy so that you can refer to them if needed.

Also, if this equipment is transferred to a new user, make sure to hand over this operation manual to the new user.

— 🥂 WARNING -

In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off power and call your dealer for instructions.

Ask your dealer for installation of the air conditioner.

Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.

Ask your dealer for improvement, repair, and maintenance.

Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for use with the equipment and have them installed by a professional.

Ask your dealer to move and reinstall the air conditioner or the remote controller. Incomplete installation may result in a water leakage, electric shock, and fire.

Never let the indoor unit or the remote controller get wet.

It may cause an electric shock or a fire.

Never use flammable spray such as hair spray, lacquer or paint near the unit. It may cause a fire.

Never replace a fuse with that of wrong ampere ratings or other wires when a fuse blows out.

Use of wire or copper wire may cause the unit to break down or cause a fire.

Never inspect or service the unit by yourself.

Ask a qualified service person to perform this work.

Cut off all electric waves before maintenance.

Do not wash the air conditioner or the remote controller with excessive water. Electric shock or fire may result.

Do not install the air conditioner or the remote controller at any place where flammable gas may leak out.

If the gas leaks out and stays around the air conditioner, a fire may break out.

Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.

CISPR 22 Class A Warning:

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

After a long use, check the unit stand and fitting for damage.

If they are left in a damaged condition, the unit may fall and result in injury.

Do not allow a child to mount on the unit or avoid placing any object on it.

Falling or tumbling may result in injury.

Do not let children play on and around the unit.

If they touch the unit carelessly, it may result in injury.

Do not place a flower vase and anything containing water.

Water may enter the unit, causing an electric shock or fire.

Never touch the internal parts of the controller.

Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.

For checking and adjusting the internal parts, contact your dealer.

Avoid placing the controller in a spot splashed with water.

Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.

Do not operate the air conditioner when using a room fumigation - type insecticide.

Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.

Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or

other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation.

Do not turn off the power immediately after stopping operation.

Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.

The appliance is not intended for use by young children or infirm persons without supervision.

The remote controller should be installed in such away that children cannot play with it.

Never press the button of the remote controller with a hard, pointed object. The remote controller may be damaged.

Never pull or twist the electric wire of the remote controller.

It may cause the unit to malfunction.

Do not place the controller exposed to direct sunlight.

The LCD display may get discolored, failing to display the data.

Do not wipe the controller operation panel with benzine, thinner, chemical dustcloth, etc.

The panel may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. And wipe it with another dry cloth.

Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

CONTENTS

SAFETY CONSIDERATIONS	1
FEATURES AND FUNCTIONS	3
NAMES AND FUNCTIONS OF	
OPERATING SECTION	4
OPERATION	ō
Setting present time	5
Setting no. of programmed time	3

Change and cancellation of no. of	
programmed time	7
Manual operation	9
Operation control code	9
Error diagnosing function	
QUESTION AND ANSWER	
SPECIFICATIONS	12
Specifications	12
Outline drawings	12

FEATURES AND FUNCTIONS



• When used in conjunction with central remote controller (Optional Accessory) The operation controlled by programmed time can be set for up to eight different patterns (timer No. 1 - 8). Each schedule pattern can be also selected.

3

NAMES AND FUNCTIONS OF OPERATING SECTION (Fig. 1, 2)

	UNIFIED OPERATION BUT-	
1	TON " "	
•	Press this button to perform the unified operation regardless of the No. of pro- grammed time.	
	UNIFIED STOP BUTTON	
2	" ALL O "	1
L	Press this button to perform the unified stop regardless of the No. of pro- grammed time.	
	OPERATION LAMP (RED)	1
3	The light turns on during the operation of the indoor unit.	
	DISPLAY " 🖱 🖁 " (TIME NO.)	┢
4	Displays the time No. only when used in conjunction with the central remote controller.	1
	controller.	1
	DISPLAY	
5		1
5	DISPLAY "PROGRAM ↓START."	1
	DISPLAY "PROGRAM → START." (PROGRAMMING START) The light turns on when the timer is	
5	DISPLAY "PROGRAM J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY	1
	DISPLAY "PROGRAM J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by	
	DISPLAY "PROGRAM J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by timer is not available on that day. DISPLAY " — " (SETTING	
	DISPLAY "PROGRAM → START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by timer is not available on that day. DISPLAY " — " (SETTING OF DAYS OF A WEEK) Flashes below the day of the week pro-	1





OPERATION

■ Setting present time (Fig. 3)

(Example) In case of setting Friday, 5:30 p.m.

Image: Optimized and the second second

(NOTE)

• The present time needs adjusting in case of turning power supply on for the first time or the occurrence of power failure over the period of 48 hours or more.

мо́м-сlock ам

2. ⁽²⁾ Press the BUTTON FOR SELECTING DAYS OF A WEEK. Each time the button is pressed, the day display shifts to the right. (NOTE)

The display " MON " follows the display " SUN."

	-)約11/1
CLOCK	^ ₩ ₽₽:00 K

Set the day to Friday.

3. ^(J) Set the time with the HOUR/ MINUTE BUTTON. Each time the HOUR/MINUTE BUTTON is pressed, the display is put forward minute by minute and hour by hour. When the button is kept pressed, the display is put forward continuously.

(NOTES)

- After becoming " AM 11:00 ", when the button is pressed, the display becomes " PM 0:00 ".
- After becoming " 59 " (minute), when the button is pressed, the display becomes " 00 " (minute).



Set the time to 5:30 p.m.

4. ^(J) Press the TIMER ON BUTTON the moment the time signal of TV, radio, telephone, etc. is heard. The mark ":" flashes, and the clock starts.

	FŘI .
CLOCK	рм 930

Press the TIMER ON BUTTON in tune with the time signal at 5:30 p.m.

(NOTES)

- The clock used is of 12-hour type.
- When you turn power supply on, the system may display " *BB* " for about one minute and not start to operate after all the liquid crystal displays appear at a time.
- If the CLOCK ADJUSTING BUTTON is pressed by mistake, press it again to return to the original state. As the clock does not stop, the time indicated by the clock is kept correct. In case of power failure within 48 hours, the clock keeps operating by utilizing the built-in battery.

Setting no. of programmed time (Fig. 4)

(Example) Time No. 5 (to be programmed only when used in conjunction with the central remote controller)

> Monday to Friday: Operating from 8:45 a.m. till 5:00 p.m. Operating from 5:15 p.m. till 11:00 p.m.

- Saturday and Sunday: Setting the whole day stop operation (application for holidays) controlled by programmed time.
- I. IP Press the PROGRAMMING START BUTTON. Programming is available. The display "PROGRAM J START" appears, and the display of days of a week flashes.

PROGRAM J START

2. Press the TIME No. BUTTON, and select the desired number. (NOTE)

Unless used in conjunction with the central remote controller, The TIME No. is not displayed and can not be selected.

Select the TIME No. 5.



3. ^(J) Press the BUTTON FOR SELECTING DAYS OF A WEEK, and set the proper day of the week. Each time you press it, the flashing display of days of a week shifts to the right.

ſ	Ð NO.	5 NON T		J START	A/A	LON - 🗲	0 OFF -:
l		GLO	^{оск} РІ	[≜] 5:30	/ ^{SET2}	ΓOΝ - ►	O ^{off} -:

Set to Monday.

- (1) Setting programmed time
- 4. Set the programmed time of system start 1 by using the HOUR/ MINUTE BUTTON. Each time the HOUR/MINUTE BUTTON is pressed, the display is put forward minute by minute and hour by hour. When the button is kept pressed, the display is put forward continuously.

Ð NO.		START SET LON OFF
	CLOCK PN	råi SET2 ON O OFF S:30 -: ► -:)

Set the "PROGRAMMED TIME OF SYSTEM START 1" at 8:45 a.m.

 (5) Press the TIMER ON BUTTON, and set the programmed time of system start 1. Each time you press it, the next area to be set flashes.

(NOTE)

Set the other programmed time in the same procedure.



- (2) Set the next day of the week. Set the day of the week to Tuesday, and copy the program of the previous day (Monday). In the same procedure, set the day of the week to Wednesday through Friday in sequence.
- 6. ^(J) Press the BUTTON FOR SELECTING DAYS OF A WEEK and set the following day. Press the BUTTON FOR COPYING PRO-GRAM OF PREVIOUS DAY. The same program as that of the immediately preceding day of the week is set.

(NOTE)

Repeat each procedure 3 - 5 in the above when not copying the contents of the previous day.

(3) Holiday setting

 C Press the BUTTON FOR SELECTING DAYS OF A WEEK and set one or more days of the week as holiday. Press the HOLI-DAY SETTING BUTTON, and the display " OFF " is displayed at the top of the day of the week. If you press it again, the display returns to the original state.

Ð NO.		J START	SET I ION	0 off -:
	CLOCK	рм 5:30	SET2 ON -: ►	O ^{off} -:

Set Saturday and Sunday as holidays.

8. IPress the PROGRAMMING START BUTTON, and finish the program setting.

(NOTES)

- Unless the button is pressed within 20 minutes, the display will automatically revert back to the original state. In this case, setting contents up to the point where the TIMER ON BUTTON (or HOL-IDAY SETTING BUTTON or BUTTON FOR COPYING PROGRAM OF PREVI-OUS DAY) is pressed will only take effect.
- The display "PROGRAM J START " and the display of days of a week "—" disappears.

- The flashing display goes off, and the No. of programmed time of the present day is displayed. Then the operation controlled by timer starts.
- The operation controlled by timer is executed even while the program is being set.

Ð NO.		J START OFF OFF AM THU FRI SAT SUN 8:45 ► 5:00
	CLOCK	PM 5:30 SET2 ON O OFF PM 5:30 S: 15 ► 1 1:00

This is the end of the setting example.

Change and cancellation of no. of programmed time (Fig. 5)

(Example) Time No. 3 (to be set only when used in conjunction with the central remote controller)



- 1. ⁽J[¬]) Press the PROGRAMMING START BUTTON. The program setting is ready. The display " PROGRAM ↓ START " appears, and the display of days of a week flashes.
- 2. In Press the TIME No. BUTTON, and select the desired No.

⊕ №.		OFF OFF THU FRI SAT SUN B:45 ► 5:00
	CLOCK	^{sh} _{FRI} SET2 ^{ON} O ^{OFF} PM 5:00 S: 15 ► 1 1:00

Select the time No. 3.

3. ^(J) Press the BUTTON FOR SELECTING DAYS OF A WEEK, and set the day of the week to be changed. The set No. of programmed time of the day of the week is displayed.

	OFF OFF SET1 ION O OFF THU FRI SAT SUN B: 45 5:00
сьоск	FRI SET2 ON OOFF PM 5:00 S: IS ► I I:00

Set the day to Wednesday.

- A. Change/cancel partially
- 4. (4) Press the TIMER ON BUTTON and change, and the display of programmed time flashes. Each time you press it, the next area to be set flashes.

() NO.	J MÔN TỦI	ะ พร้อ านั้น คลั้	OFF OFF 8 7 I SAT SUN	SET1 ON M 8:45 ►	Q IF. S:00
	CLO	[™] PM	's:00	SET2 ON PM S: /S ►	0 ## :00

Shift to the display "PROGRAMMED TIME OF SYSTEM OFF 1".

5. ⁽³⁾ Press the HOUR/MINUTE BUTTON and change the programmed time. Press the TIMER ON BUTTON, and finalize the setting of change.

() NO.	Mon Tue <u>w</u> êg	OFF OFF	SET1 ON #M 8:45 ►	0 ¶. 1:00
	СГОСК	рм 6:00	SET2 ON PM 5: /5 ►	0 °FF 1:00

Change the "PROGRAMMED TIME OF SYSTEM OFF 1" to 7:00 p.m.

6. ^(C) Press the PROGRAM CAN-CELING BUTTON, and cancel the programmed time. If you press it again, display returns to the original state. Press the TIMER ON BUTTON to finalize the cancellation.

	OFF OFF AM AM FRI SAT SUN 8:45 ► 7:00
сгоск	FÅI PM 5:00 5:15€ 11:00

Shift to the "PROGRAMMED TIME OF SYSTEM START 2".

OFF OFF STI ON OF AM NON TŮE WÊD THU FRI SÂT SUN B:45 ► 7: NO	D D D D
	DFF PM UU

Set the "PROGRAMMED TIME OF SYSTEM START 2" to program cancellation.

In the same procedure, cancel the programmed time of system off 2.

B. Cancel the whole

7. The Press the BUTTON FOR SELECTING DAYS OF A WEEK, and shift to the day of the week to be canceled. Then, press the HOL-IDAY SETTING BUTTON, the display "OFF" appears at the top of the particular day of the week. The programmed time is canceled. If you press the button again, the display returns to the original state.

⊕ №.	OFF OFF
	гла слоск рм 5:00 SET2 ОN О ОFF

Shift the day of the week to Thursday to set as a holiday.

8. ^(I) Press the PROGRAMMING START BUTTON. The program setting is now finished.

(NOTES)

- Unless the button is pressed within 20 minutes, the display will automatically revert back to the original state. In this case, setting contents to the point where the TIMER ON BUTTON (or HOLIDAY SETTING BUTTON or BUTTON FOR COPYING PROGRAM OF PREVIOUS DAY) is pressed will only take effect.
- To continue the change/cancellation, do not press the PROGRAMMING START BUTTON until all change/cancellation are completed.
- The operation controlled by timer is executed even while the program is being set.

■ Manual operation (Fig. 6)

This schedule timer enables the operation/stop by pressing the UNIFIED OPERATION/STOP BUTTON in addition to the operation controlled by timer (operation/stop according to the programmed time) at any time.

- 1. CP Press the UNIFIED OPERA-TION BUTTON, and the OPERA-TION LAMP turns on.
- 2. Press the UNIFIED STOP BUT-TON, and the OPERATION LAMP is turned off.

(NOTES)

- The operation automatically stops according to the programmed time of system off even during the manual operation. In the meantime, the operation starts automatically according to the programmed time of system start even during the stop of operation.
- If the unit is used in conjunction with other optional controllers for centralized control, the OPERATION LAMP of the unit that is not under operation control may be turned on or off a few minutes behind schedule. This shows that the signal is being exchanged, and does not indicate any failure.

Operation lamp

 Turn on: The light turns on when any of the indoor units is in operation whether the operation is controlled by timer or by hand.
 Turn off: The light turns off when all the

indoor units stop.

■ Operation control code

Two different types of operation control codes can be selected when this kit is used independently (when not used in conjunction with the central remote controller, unified ON/OFF controller, etc.).

Individual

In case where the operation/stop is controlled by both schedule timer and remote controller.

Centralized

The operation is controlled by the schedule timer alone, and the operation/stop is controlled freely with the remote controller during the programmed time.

(NOTES)

- For current settings, contact your DAIKIN dealer.
- To change settings, contact your DAIKIN dealer.

Do not change settings yourself.

Error diagnosing function (Fig. 7)

This schedule timer is provided with the malfunction diagnosing function. The malfunction code flashes if there occurs any malfunction in communication, etc. between and among the optional controllers for centralized control. In addition, the operation lamp also flashes if there occurs any malfunction in communication with the indoor unit. Check the contents of the display and contact your DAIKIN dealer because the signals give you the idea of the trouble area.

9

Opera- tion lamp	Malfunc- tion code	Contents of mal- function
Turn off	M1	Failure of PC board of schedule timer. Fixes The following causes are possi- ble. Check each one. 1. PC board prob- lems
Turn on or off	M8	Malfunction of transmission between each optional controllers for centralized con- trol. Fixes Check all central devices which are connected (e.g., power supply, transmission wiring, etc.).
Turn on or off	MA	Improper combina- tion of optional controllers for cen- tralized control. Fixes The following causes are possi- ble. Check each one. 1. Are all central devices com- bined correctly? 2. Is the master central connec- tor attached to two or more cen- tral devices? 3. Are there 128 or more indoor units con- nected?

		1
Turn on or off	МС	 Address failure of schedule timer. Fixes The following causes are possible. Check each one. 1. Do the control range addresses in the central remote controller overlap? 2. Do the control range addresses in the on/off controller overlap? 3. Are there 2 or more schedule timers connected?
Flash	UE	Malfunction of transmission between indoor unit and optional controllers for cen- tralized control. Fixes Inspect all indoor units which are dis- playing an error (e.g., power supply, transmission wiring, etc.).
Flash	_	Malfunction in indoor unit (Refer to the malfunction codes of the indoor remote controller, while also read the " CAUTION FOR SERVICING " attached to the indoor unit.)

QUESTION AND ANSWER

Question	Answer
It is possible to make settings twice a day, but is it possible to make only the " off " setting? (To avoid forget- ting to turn the unit off.)	Yes. Press the PRO- GRAM CANCELING BUTTON in the "ﷺ ^{1™} " section in order to set it to " oFF".

Is it possible to set times which straddle days?	Yes, it is possible. Example: Start operation at 5:00 a.m. on Sunday Stop operation at 6:00 p.m. on Monday	The TIME NO. is not displayed.	 The following causes are possible. 1. The TIME NO. is not displayed when using the schedule timer alone. (It can be set if using the central remote controller at the same time.)
The unit does not turn on even though the set " on " time has come. (When using the schedule timer alone)	The following causes The following causes The following causes The following causes The following causes The following causes The following causes	The display remains " [stri] ou O or <u>bstri] ou O or</u> <u>stri] ou O or</u> (stri] ou O or <u>bstri] ou O or</u> (stri] ou O or <u>bstri] ou O or</u> (stri] ou O or (stri] (stri] (stri] ou O or (stri] (stri] (The following causes are possible. 1. Is the day set to a holiday?
The unit does not turn on even though the set " on " time has come. (When using the unit with a central remote controller)	 The following causes are possible. Check each one. 1. Was the timer number set with the central remote controller? Was an incorrect timer number set? 2. Is another timer no. set with the central remote controller set for " off " at the same time? 3. Is the operation code set to " remote control permission timer " using the central remote controller or the on/off controller? 	I cannot set " central manage- ment priority " or " after-push prior- ity " with the schedule timer.	The following causes are possible. 1. Is a central remote controller or on/off controller also installed? * The priority order of the operation codes depends on the central devices which are installed. The below operation codes are set. • Schedule timer Central remote controller is used as well Operation code of the central remote controller • Schedule timer
The unit oper- ates even though that day is set as a holiday. (When using the unit with a central remote controller)	The following causes are possible. 1. Is another timer num- ber set with the cen- tral remote controller set for " on " at the same time? (If two timer numbers are set, make sure that the settings for holidays and working days do not overlap between the different timer numbers.)		 Schedule timer On/off controller is used as well Operation code of the on/off control- ler Schedule timer Central remote controller On/off controller is used as well Operation code of the central remote controller

11

3P124623-5C

<KRP928BB2S> Interface Adaptor for DIII-NET (Residential Air Conditioner) 13.9

Safety Precautions	1.Overview, Features and Compatible Models						
Read these Safety Precautions carefully to ensure correct installation.	This kit is the interface required when connecting the central controller and a Room Air Conditioner. Use of the central controller makes it						
This manual classifies precautions into WARNING and CAUTION.	possible to perform the following monitoring and operations. It is						
WARNING : Failure to follow WARNING is very likely to result in such	compatible with room air con						
grave consequences as death or serious injury.	 Run / stop for the central control selection, and temperature can 		mote controller, operating	I mode			
CAUTION : Failure to follow CAUTION may result in serious injury or property damage, and in certain circumstances, may result in	2.The operating status, any errors		nt of those errors can be n	nonitored			
a grave consequence.	from the central controller and 3.Run / stop for the central control			ing mod			
Be sure to follow all the precautions below ; they are all important for	selection, and the temperature						
ensuring safety.	4.Zone control can be performed 5.The unit can remember the oper			nowor			
<u> </u>	outage and then start operating	in the same stat	us when the power comes				
	 Card keys, operating control pa connection-compatible equipment 						
Installation should be left to the dealer or another qualified professional.	7. The Operating / error signals ca	n be read.					
Improper installation by yourself may cause malfunction, electrical shock, or fire. Install the set according to the instructions given in this manual.	8.The indoor temperature can be	monitored from	the Intelligent Touch Cont	roller.			
Incomplete or improper installation may cause malfunction, electrical shock, or fire.	Precaution 1. When reading the Operating /	arror eignalo	onarato ovtornol novier a	ourco			
Be sure to use the standard attachments or the genuine parts.	(12 V DC) is needed.						
Use of other parts may cause malfunction, electrical shock, or fire.	A separate timer power source timer independently, and not in						
Disconnect power to the connected equipment before starting installation. Failure to do so may cause malfunction, electrical shock, or fire.	 The range of temperatures tha 32°C in cooling and 14°C to 28 	t can be set fror					
A ground fault circuit interrupter / an earth leakage circuit breaker should	Fan operation cannot be selected	from the central c	ontroller or wired remote co	ntroller.			
be installed. If the breaker is not installed, electrical shock may occur,	Group control (i.e., control of mu not available.	Itiple indoor unit	s with a single remote cont	roller) is			
ו זויפ טופמגפו זא זוטן ווואנמופט, פופעורכמו אוסטג זוומץ טכנטו.	Monitoring is not available of the indoor fan operating status, ele						
	Forced thermo off, filter sign di	splay and reset,	fan direction and speed s	settings,			
Do not install the set in a location where there is danger of exposure to	air conditioning fee manageme instructions, and demand instru			•			
inflammable gas.	2.00	omponent	Parta				
Gas accumulated around the unit at the worst may cause fire. To prevent damage due to electrostatic discharge, touch your hand to a							
nearby metal object (doorknob, aluminum sash, etc.) to discharge static	This kit includes the following these are missing.	components.	Check to ensure that	none oi			
electricity from your body before touching this kit.	Parts	Q'ty	Parts	Q'ty			
Static electricity can damage this kit.	Kit assy		Connection harness (about 1.6m)	1			
Lay this cable separately from other power cables to avoid external							
 Lay this cable separately from other power cables to avoid external electrical noises. 	PCB is in the housing.	1	Mounting screws	3			
		1	Mounting screws Binding band	3 6			
electrical noises.		1	· ·				
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user.	PCB is in the housing.	1	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a	PCB is in the housing.	1	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a	PCB is in the housing.	1	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. S.Names of Parts a Wiring procedure> Reading the Connecting a Momentary / constant Co	PCB is in the housing.	t a central	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Connecting a Momentary / constant Constan	PCB is in the housing.		Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating / error Display Connecting a Momentary / constant Contact Input Equipment Contact Input Equipment Contact Input Equipment Contact Input Equipment	PCB is in the housing. and Electric Wiring Donnecting a Wired temote Controller	It a central	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating / error Display Operating monitoring equipment Card key (field supply) Free B	PCB is in the housing. and Electric Wiring In case the connecting a Wired temote Controller incle controller BRC844 Series	t a central connected ler ies	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. S.Names of Parts a Wiring procedure> Reading the Operating / error Display Operating monitoring Connecting a Momentary / constant Contact Input Equipment Constant Input Equipment Reading the Operating monitoring Connecting a Momentary / constant Contact Input Equipment Reading the Operating monitoring Connecting a Momentary / constant Contact Input Equipment Reading the Operating monitoring Connecting a Momentary / constant Contact Input Equipment Reading the Operating monitoring Connecting a Momentary / constant Contact Input Equipment Reading the Operating monitoring Contact Input Equipment Reading the Operating monitoring Contact Input Equipment Contact Inpu	PCB is in the housing. and Electric Wiring In case the connecting a Wired temote Controller NRC844 Series Central contro • DCS302 Se • DCS303 Se • DCS303 Se	t a central connected ler ies ies	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure>	PCB is in the housing.	t a central connected ler ies ies ies ies	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating monitoring equipment (field supply) Operating control panel (field supply) The add	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating monitoring equipment (field supply) Operating control panel (field supply) The add	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating monitoring equipment (field supply) Operating control panel (field supply) The add	PCB is in the housing. and Electric Wiring and Electric Wiring In case the controller and controller Central control PCS301 Se DCS301 Se DCS301 Se DCS301 Se DCS301 Se DCS301 Se RC651 Se DCS301 Se DCS301 Se CS101 Se Series cannol	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating orror Display (field supply) (field supply)	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure> Reading the Operating monitoring equipment (field supply) Operating control panel (field supply) The add	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure>	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band	6			
electrical noises. After installation is complete, test the operation of the PCB set to check for problems, and explain how to use the set to the end-user. 3.Names of Parts a Wiring procedure>	PCB is in the housing.	t a central connected ler ies ies ies ies iea d KDC101B	Binding band Installation manual	6			

Upper group number switch (SW2-5 to 7)

₽₽

Lower group number switch (SW1)

Supplied connection harne

Power supply terminal (S8)

Connect an external 12 V DC power supply only when reading the Operating / error display.

615

Service monitor (LED1: green) When the CPU is working properly, the LED flashes.

 $\otimes \otimes \otimes \otimes \otimes \otimes \otimes \otimes$

Operation when recovering from a power outage mode switch (SW2-R)

Remote control all prohibition/permission setting switch (SW3-1)

Momentary contact / constant contact Selection switch (SW3-2)

Japanese unit / Overseas unit Setting switch (SW3-3)

Cable available field supply (See the installation manual of the central controller)

air conditioner indoor uni

To HA connector (S21)

		4	.Swi	itch Settings					5.	Cont	rol C	00
NOTE				er all the switches ha the power is on are in			When using operation fro continuously	m wireless when the w	remote co /ireless rer	ntrollers	. Three	bee
				thes on the circuit boa	ard.		 : permitte 	a; × : proni	Dited		Ope	erati
Room ai	rseas / Japa r conditione	anese u ers, diffe	rent m	ting (SW3-3) nethods are used for s	etting the temperatu	ure in					"Run" c central	
automati	c mode, so	this swi	itch ne	eds to be set.			S1	Control	mada	Control	<u> </u>	cont Q
Destination	SW3-3 se	etting		What Ha			operating mode	Control	mode	code	5	Sto
Japan	OFF (Factory set	ettina)	Wher	matic" operation is not ava n using "automatic" operational of the controller	on using the wireless remo displays automatic cooling	ote					Bun	
	(rabiory of	, ang,	(heat returr	ing) and 25°C. Even if the t n to 25°C after a while.	emperature is changed, it	will		ON / OFF is rejecte		0,1,3		× ×
Overseas	ON		 "Auto 	omatic" operation is availa	ble from the central cont	troller.		Only OFF is accepted	control	2 12–19	×	0
2) Group n	umber setti	ngs (SV	V1 and	SW2-5 to SW2-7)			Instantaneo	IS Central p		4		0
than one	e unit to the	same r	numbe	controller. (Set to the r. recovering from a po		more	contact mod	Last comm Timer op	and priority eration	5 6,7 8	0	0 0 0*
		s do not	need	to be made when us	ng the schedule time	er		is accepte remote co	ed by ontroller	9	0*	0*
ndependen The setting		ed wher	n used	in conjunction with a	nother DCS Series					2,10-19		
central cont	roller.)			an auto address after th		o new	Constant			0,1,3,5-7 4	×	×
roup numbe	rs are autom	atically s	et. Sett	ings made using the sw	tches will be overwritte	n.	contact mod	ы	ļ	8		
Group NO. Se	ttings table (E	nlarged se	ection S	W1 and SW2 in "3. Names	of Parts and Electrical W	/iring")	All remote			9		_
Group NO. Up	•			Group NO. Lower			controller action	ns d			×	×
1— Ø	5- 80	0	0					*Only during				
			43	21 4321	4 3 2 1 4 3 2			ntroller permis d; ×:prohi		ition setti	ngs usini	j trie
2— KOD	6- A	0	1 д									_
3— 🛛	7—	0	2	06 10			S1 pin	-	gent Touch C	ontroller	settings	
. 2 0	, 877	5	4 3		4321 432		operating mod	Start / stop	Change	Ch	ange se	t
	, ⁸ — 8,	5	3	2 1 07 4 3 2 1 1	4 3 2 1 4 3 2		Instantaneous contact mode	ON / OFF	operating mo permitte		npëratur Ited/prohil	
:Use with	power failure	ecovery s	ettings	Set to the 🔳 side 🕴	:ON û Seff		Contact mode	control is rejected	prohibite	-		
							contact mode	rejected	<u> </u>		tted/prohi ermitted	
NOTE also schedule ti	that a sep mer indepe	arate tin	ner po	wer source is needed	when using the		Instantaneous contact mode	Only OFF	permitte	p p	rohibited	ł
				%, -15%, 200mA.			Constant	- control is accepted	prohibite permittee	, p	tted/prohi ermitted	1
				oower outage (SW2-F			contact mode	lassopted	prohibite	p p	rohibitec tted/prohi	
power ou	itage occuri	ed durir	ng ope	ration when the powe ration. This setting is g	iven priority in cases	3	Instantaneous		permitte	d permi	tted/prohi	bited
where the	e indoor un	t has an	auto	start ON / OFF jumpe off, the operating mod	. Note also that regar	rdless	Contact mode Constant	Last command priority	permitte	d permi	tted/prohi tted/prohi	bited
fan direct	tion and spe	ed setti	ngs, a	nd remote control pro	nibitio n status are sto	ored.	Contact mode All remote		prohibite	d permi	tted/prohi	oitec
SW2-F	R setting			What Hap	oens		controller action are prohibited	is D	oes not aff	ect settin	igs	
	tory setting) Sto	ps afte	er recovering from a p	ower outage				-			
C	N	Stops	s if the ur	nit was stopped before the pow	er outage and runs if it was ru	unning.		6.Read	Opera	ting	/ Err	br
NOTE) The	-	~		to the models below.			The Operat		gnals can	be read	d from t	he
		de befo power o		COOLING	HEATING		Output spec	:s ∕IR 1 ON wł	on the oil	oonditi	onor lo	FUE
Room air c	_			OODEING	TIEATING			/IR 2 when a				
	ith humid h		and		HUMID HEATI	NG		ie air conditi				i the
denu	midifying fu Models wit			DRY COOLING			MH 2 KRP928BB	is not turne	d ON duri	ng a wa	irning.	
dehu	midifying fu				HEATING							
				W3-1 to SW3-2)			S8		Хр	ower sup	ply for r	elay
				noose one of the follo	ving functions.		Θ		8			
S1 operating r		1 SW3-2 g setting		What Happens	Control mode			(+)	Operatir	ig contro	l panel i	Fiel
Instantaneous c			The ope	erating status of the air conditioner			MC		м	B1		
input (factory se	tting)	OFF	DEE lis reviewed by an instantaneous input of 1 act command priority							rating Displ	ay	
Constant contac	t innut	ON	Close to	- Open to close: air condition runs. o open: air conditioner is stopped	ON / OFF control is rejecte (operate / stop / timer prof	ed	M2	(-) MR	< II -		ormality disp	lay -
			(NOTE :	1).	(NOTE 2).							_
Remote control prohibition/pern		Invalid	air cor	ct - Open to close: ndition stops. Close to open: ange in operating status.	All remote controller ac are prohibited when the contact is closed. (NOT	e			7.Con			<u> </u>
input	ce central -			ange in operating status. s last command priori			The central	controller c	an be con	nbined	with the	e fo
				onditioner might not n		anu				oller	oller	
Ēxa				the central controller whil the contact will be open						ontr	ontre	
	erating mod	te and f	an dire	ection and speed sett	ings can be changed	1. Č				ote C	ON / OFF controlle	
NOTE3: If th	ne contact i	s closec	l while	the ON timer is set, operation starts at t	as the power ON tim	er the				Jemc	10	
tim	er. To preve	ent opera	ation o	of the power ON time	, use of the					Central Remote Controller	No	
				trol PC-board set is re n tandem with the ce		ver,				Cen	[
				to an air conditioner r		Hor	Control Bor	note Controlle		0	0	-

note that it cannot be used in tandem with the central controller. If this product is connected to an air conditioner manufactured in or after 2011, when the contact is closed, the power ON timer may be cancelled depending on the combination with the model.



Contact specs No-voltage minute electric current contact (Minimum applicable load 12 V DC, 1mA or lower)

Total wire length max: 100m

des

ng codes can be used to limit eeps for signal reception will be heard operated while in central control.

			Operations from the remote controller								j ti
S1 operating mode		Control code	"Run" control from the central controller				"Stop" control from the central controller				s from central and contact input
	Control mode		Run / timer	Stop	Operating mode temperature	Fan direction and fan speed	Run / timer	Stop	Operating mode temperaturet	Fan direction and fan speed	Operations from controller and controller
	ON / OFF control	0,1,3	×	×	0		×	×	0		
	is rejected	10,11	×	×	×		X	×	×	0	
	Only OFF control is accepted	2 12–19	×	0	×		×	0	×		
Instantaneous	Central priority	4	0	0	0		×	0	×		
contact mode	Central phonty	5	0	0	0		×	×	0		
	Last command priority	6,7	0	0	0		0	0	0		
	Timer operation	8	O*	0*	O*	0	×	0	×		
	is accepted by remote controller	9	O*	0*	O*		×	×	0		0
		2,10-19			×				×		
0		0,1,3,5-7			0				0		
Constant contact mode		4	×	×	0		×	×	×		
contact mode		8			0*				×	1	
		9			O [®]				0	1	
All remote controller actions are prohibited			×	×	×	×	×	×	×	×	

he Intelligent Touch Controller are as follows.

S1 pin operating mode	Intellige	ent Touch Cor		Operations from central controller and contact input						
	Start / stop	Change operating mode	Change Change set operating mode temperature		Stop	Operating mode temperature	Fan direction and fan speed	Operation		
Instantaneous contact mode	ON / OFF	permitted	permitted/prohibited	×	×	0				
Constant contact mode	rejected	prohibited	permitted/prohibited	×	×	×				
Instantaneous	Only OFF control is accepted		permitted x x	0						
contact mode			prohibited	×	0	×				
contact mode		prohibited	permitted/prohibited	1 ^		· ^				
Constant				permitted	permitted	×	×	0		
contact mode		permited	prohibited		× ×			0		
contact mode		prohibited	permitted/prohibited	1 × 1		×				
Instantaneous		permitted	permitted/prohibited	0	0	0]			
contact mode	Last command	prohibited	permitted/prohibited	×	0	×				
Constant	priority	permitted	permitted/prohibited	×	×	0				
contact mode		prohibited	permitted/prohibited	×	×	×				
All remote controller actions are prohibited	De	Does not affect settings				×	×			

r Display Signal

contact output (S5).

unning. occurred between the KRP928BB2S he unit has stopped after an error.

with 2 to not turned on during a warning.									
(RP928BB2S									
S8	•	Rower supply for relay (Supply 12	Power supply for relay (Supply 12 V DC externally.)						
	θ —								
Operating control panel (Field supply)									
S5	MC (+) M1 (-) M2 (-)	MR1 MR2 MR2 C Operating Display MR2 C Operating Display MR2 C Operating Display MR2	Relay specs (MR1 and MR2) Coil voltage: 12 V DC Coil resistance: 160Ω 10% Wiring length Max: 100m						

uipment

The central controller can be combined with the following devices.									
	Central Remote Controller	ON / OFF controller	Schedule timer	D-BIPS	Contact input	Wired Remote Controller	Wireless Remote Controller		
Central Remote Controller	0	0	0	0	0	0	0		
ON / OFF controller	0	0	0	0	0	0	0		
Schedule timer	0	0	×	×	0	0	0		
D-BIPS	0	0	×	×	0	0	0		
Contact input	0	0	0	0	×	0	0		
Wired Remote Controller	0	0	0	0	0	×	×		
Wireless Remote Controller	0	0	0	0	0	×	0		

3P248024-1E


3P248024-3D

13.10 <KPW937E4> Air Direction Adjustment Grille

Name	① Air direction	② Screw	③ Installation manual
Name	adjustment grille		
Shape		C. David and a second second	
Q'ty	1 pc.	4 pcs.	1 sheet(this sheet)
followin 1. When i 2. When c garden autions for ● Be sure directio 1. Be sur 2. Avoid 3. When u Do not of the 4. Be car instal	g conditions. nstalling the outdoor unit hanging the airflow direction plants. usage to perform the following as adjustment grille. to stop the operation bef short-circuits during instand using the unit in areas with install the grille to create outdoor unit as this may do reful of foreign substances ling the grille to create a	fore installation. Illation. I snow, install the grille to c Ite an upward airflow to preve lamage the unit. Such as dead leaves, which may In upward airflow.	
Pitch of and hori	zontal directions. ation can be performed in 4		t grille(①)is 434mm in the vertica
 Temporar angle, ar 	ily secure the air direction ad then tighten the screws. wire outlet grill	on adjustment grille(①) using	4 screws(2), check the installation



3P397163-1

13.11 <KPW063A4> Air Direction Adjustment Grille



2 Installation of air direction adjustment grille)



3P398171-1

13.12 <KKG067A41> Back Protection Wire Net



13.13 <KKG063A42> Back Protection Wire Net



2P403095-1

13.14 <FTDBHMS, FTDBHML, KEH067A41E, KEH063A4E> Drain Pan Heater

ead these Safety Co perates properly duri		ully before installing the drain pan he ation.	ater. After completing	g the installation, check if the uni	
eaning of DANGER,		•	1	Indicatos a potentially hazarda	
A DANGER		Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.		Indicates a potentially hazardo situation which, if not avoided, may result in minor or moderat	
		ally hazardous situation which, if not ult in death or serious injury.		injury. It may also be used to alert against unsafe practices.	
After completing the All phases of the fiel manufacturer's instru- This product is a heaunit from freezing.	installation, make s d-installation, incluc uctions and must co ater designed to me	installation manual for future reference ure that the unit operates properly du ling, but not limited to, electrical, pipir mply with national, state, provincial, a It snow that is blown into the product od on a high stand if this product is u	uring the startup open ng, and safety, must th and local codes. from the outside to p	be done in accordance with prevent the drain pan of the outdo	
		nout wearing gloves.			
		me high when the heater is turned on. Il result in burns or injury.			
	IING				
 Request the deal 	ler or an authori	zed technician to install the pro	oduct.		
Improper installation	of the product could re	sult in water leakage, an electric shock, o	r fire.		
The product mu	- Aller - Standard Handler				
		cording to the instructions give			
The Incomplete insta	llation of the product c	ould result in water leakage, an electric sh			
The Incomplete insta	llation of the product c d or specified ins	ould result in water leakage, an electric sh stallation parts.	nock, or fire.		
The Incomplete insta • Use the supplie Use of other parts co	llation of the product c d or specified ins uld result in the unit be	ould result in water leakage, an electric sh stallation parts. ecoming loose and falling, water leakage,	nock, or fire.		
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow	llation of the product c d or specified ins uld result in the unit be rer supply at the	ould result in water leakage, an electric sh stallation parts. ecoming loose and falling, water leakage, time of installation.	nock, or fire. electric shock, or fire.		
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric	llation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p	ould result in water leakage, an electric sh stallation parts. ecoming loose and falling, water leakage,	nock, or fire. electric shock, or fire. ctric shock.		
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified with	llation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and	ould result in water leakage, an electric sh stallation parts. ecoming loose and falling, water leakage, time of installation. power supply turned on could result in elec	nock, or fire. electric shock, or fire. ctric shock.		
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified win Wires connected or fi • When wiring an	llation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and xed improperly could in d connecting the	ould result in water leakage, an electric sh stallation parts. acoming loose and falling, water leakage, i time of installation. hower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire.	force on the terminal junctio	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified win Wires connected or fi • When wiring an put improper for	llation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and xed improperly could in d connecting the rce on the struct	ould result in water leakage, an electric sh stallation parts. acoming loose and falling, water leakage, time of installation. hower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care ures.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the	force on the terminal junctio wiring so that they will not	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified win Wires connected or fi • When wiring an put improper for	llation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and xed improperly could in d connecting the rce on the struct	ould result in water leakage, an electric sh stallation parts. acoming loose and falling, water leakage, i time of installation. hower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the	force on the terminal junctio wiring so that they will not	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified win Wires connected or fi • When wiring an put improper for	llation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and the xed improperly could in d connecting the rce on the struct be wires. Incomplete com	ould result in water leakage, an electric sh stallation parts. acoming loose and falling, water leakage, time of installation. hower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care ures.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the	force on the terminal junctio wiring so that they will not	
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT	llation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and txed improperly could r d connecting the rce on the struct e wires. Incomplete cou	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, in time of installation. sower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s in indoor and outdoor units, care ures. ver installation could result in terminal ove	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the	force on the terminal junctio wiring so that they will not	
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT • Wear protective	Ilation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and ta xed improperly could r d connecting the rce on the struct e wires. Incomplete could ION gloves at the tim	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, in time of installation. sower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s in indoor and outdoor units, care ures. ver installation could result in terminal ove	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the	force on the terminal junctio wiring so that they will not	
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT • Wear protective Touching the suction	Ilation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and take at connecting the rece on the struct wires. Incomplete con ION gloves at the tim mouth or aluminum fir	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, time of installation. oower supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal ove	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. ef ully arrange the rheating, an electric sho	force on the terminal junctio wiring so that they will not ock, or fire.	
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT Wear protective Touching the suction Do not install th If the gas leaks and th	Ilation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and ta xed improperly could r d connecting the rce on the structure wires. Incomplete cour- lion gloves at the tim mouth or aluminum fir e product in plac wilds up around the ur	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, time of installation. power supply turned on could result in elect fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal ove he of installation. of the outdoor unit may result in injury. ces where there is danger of explicit.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. ef ully arrange the rheating, an electric sho rheating, an electric sho	force on the terminal junctio wiring so that they will not ock, or fire.	
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT Wear protective Touching the suction Do not install the If the gas leaks and the	Ilation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and ta xed improperly could r d connecting the rce on the structure wires. Incomplete cour- lion gloves at the tim mouth or aluminum fir e product in plac wilds up around the ur	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, time of installation. ower supply turned on could result in electric fix the wires so that the wires will result in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal ove he of installation. of the outdoor unit may result in injury. ces where there is danger of exp it, it may catch fire.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. ef ully arrange the rheating, an electric sho rheating, an electric sho	force on the terminal junctio wiring so that they will not ock, or fire.	
The Incomplete insta Use the supplie Use of other parts co Turn off the powr Touching any electric Use specified wind Wires connected or fi When wiring any put improper for Install covers over the CAUT Wear protective Touching the suction Do not install the If the gas leaks and the The sharp edge of the Do not install the The sharp edge of the	Ilation of the product c d or specified ins uld result in the unit be ver supply at the al parts may with the p res. Connect and ta xed improperly could in d connecting the rce on the structure wires. Incomplete cou- lion gloves at the tim mouth or aluminum fir e product in plac uilds up around the ur top plate of the e top plate may cause e outdoor unit in de and touch the interr	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, time of installation. ower supply turned on could result in electric fix the wires so that the wires will result in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal ove he of installation. of the outdoor unit may result in injury. ces where there is danger of exp it, it may catch fire.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the rheating, an electric sho posure to inflamn emoving the top p lay nest in the out	force on the terminal junctio wiring so that they will not ock, or fire. nable gas leakage. late.	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wil Wires connected of fi • When wiring an put improper for Install covers over the CAUT • Wear protective Touching the suction • Do not install the If the gas leaks and the The sharp edge of th • Do not install the If small animals intrue Advise the user to ke • Do not touch the	Ilation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and tad improperly could in d connecting the ree on the struct e wires. Incomplete could wires. Incomplete could be units. Incomplete could be units. Incomplete could be units up around the unit top plate of the de top plate may cause e outdoor unit in fe and touch the interre of the place clean.	ould result in water leakage, an electric sh stallation parts. coming loose and falling, water leakage, time of installation. ower supply turned on could result in electric fix the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal over he of installation. I of the outdoor unit may result in injury. ces where there is danger of explicit, it may catch fire. Dutdoor unit carelessly when re- injury. I places where small animals m hal parts of the outdoor unit, the outdoor u bare hands.	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the rheating, an electric sho posure to inflamn emoving the top p lay nest in the out	force on the terminal junctio wiring so that they will not ock, or fire. nable gas leakage. late.	
The Incomplete instal Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified win Wires connected or fi When wiring an put improper for Install covers over the CAUT Wear protective Touching the suction Do not install the If the gas leaks and the The sharp edge of the The sharp edge of the Son ot install the If small animals intruc Advise the user to ke Do not touch the The temperature of the The temperature of the	Ilation of the product c d or specified ins uld result in the unit be rer supply at the al parts may with the p res. Connect and the xed improperly could in d connecting the rec on the structure wires. Incomplete cou- loon gloves at the tim mouth or aluminum fin e product in place uilds up around the ur top plate of the c top plate may cause e outdoor unit in de and touch the interre ep the place clean.	ould result in water leakage, an electric sh stallation parts. ecoming loose and falling, water leakage, time of installation. bower supply turned on could result in elect fix the wires so that the wires will result in terminal overheating, an electric s indoor and outdoor units, care ures. ver installation could result in terminal ove the of installation. to of the outdoor unit may result in injury. ces where there is danger of exp it, it may catch fire. Dutdoor unit carelessly when re- injury. places where small animals m al parts of the outdoor unit, the outdoor u	nock, or fire. electric shock, or fire. ctric shock. I not put improper shock, or fire. efully arrange the rheating, an electric sho posure to inflamn emoving the top p lay nest in the out	force on the terminal junction wiring so that they will not ock, or fire. nable gas leakage. plate.	

		Acces	sories							
	KEH067A418 FTDBHMS	E KEH063A4E FTDBHML		KEH067A41E FTDBHMS	KEH063A4E FTDBHML					
A Drain pan heater	1	1	E Installation manual (multi-language)] 1	1					
B M4 piercing screw	3	6	Electric wiring diagram label	1	1					
© Binding band	× 1	1	G Information label] 1	1					
Sealing material	1	2	Appearance of the (A) drain pan models.	heater may diffe	_ II					
Tools Required for Installation										
• Electric drill • \phi1/8 inch (\phi3.2mm)		8.2mm) drill	Phillips screwdriver Nippers							
A	Instal	lation I	Procedure (1)							
WARNING Be sure to check that	t the power supply of t	he product is tur	ned off.							
Some stages in the installa model of outdoor unit. Refe relevant model.		~,	pe A models	Top plate						
Type A models : RX09/1	2, RXN09/12, RXL09	9/12	© Electric wiring							
Type B models : RX15/1	8/24, RXN18/24, RX	L15	diagram label 🖌 🚺	1999 S						

Type C models : 2/3/4MXS, 2/3MXL, RX30/36

1. Remove each component of the outdoor unit.

- 1) Remove the top plate.
- 2) Affix the (F) electric wiring diagram label where there is enough space available on the back of the top plate.
- Remove the screws from the protective wire mesh if one is fitted. (2 screws) (For type B and C models only)
- 4) Remove the front plate.
- 5) Remove the anti-drip cover. (For type B and C models only)
- 6) Affix the G information label near the manufacture's label.
- The appearance of the outdoor unit and the number of screws may differ from some models.
- Screw types for each component are indicated as below.

No icon: Hexagon tapping screw \triangle : Truss head tapping screw











3P421082-1C

13.15 <KPS067A41> Snow Hood (Intake Side Plate)





2 Appearance of the snow hood (intake side plate) following installation



3P436077-1

13.16 <KPS067A42> Snow Hood (Intake Rear Plate)





3P436078-1

13.17 <KPS067A44> Snow Hood (Outlet)



Installing the snow hood (outlet)





3P436079-1

13.18 <KPS063A41> Snow Hood (Intake Side Plate)







3P436071-1

13.19 <KPS063A44> Snow Hood (Intake Rear Plate)





2 Appearance of the snow hood (intake rear plate) after installation)



3P436072-1

13.20 <KPS063A47> Snow Hood (Outlet)







- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
 - Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
 - Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced. 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.