EDUS091617A





# **Engineering Data**

# **Split Type Air Conditioners**

# - Heat Pump -

# **FFQ-Q** Series





# Split Type Air Conditioners FFQ-Q Series

	FFQ09Q2VJU	RX09QMVJU
Heat Dump	FFQ12Q2VJU	RX12QMVJU
Heat Pump	FFQ15Q2VJU	RX15QMVJU
	FFQ18Q2VJU	RX18QMVJU

1.	Pow	er Supply	3
2.	Fund	tions	4
3.	Spec	cifications	5
4.	Dime	ensions	7
	4.1	Indoor Unit	7
	4.2	Outdoor Unit	10
5.	Wirir	ng Diagrams	11
	5.1	Indoor Unit	
	5.2	Outdoor Unit	12
6.	Pipir	g Diagrams	
	6.1	Indoor Unit	
	6.2	Outdoor Unit	
7.		acity Tables	15
	7.1	Capacity Correction Factor by the Length of Refrigerant Piping	
	_	(Reference)	
	•	ration Limit	28
9.	Sour		
		nd Level	
	9.1	Measuring Location	29
	9.1 9.2	Measuring Location Indoor Unit	29 30
	9.1 9.2 9.3	Measuring Location Indoor Unit Outdoor Unit	29 30 31
	9.1 9.2 9.3 Elect	Measuring Location Indoor Unit Outdoor Unit tric Characteristics	
	9.1 9.2 9.3 Elect	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual	
	9.1 9.2 9.3 Elect Insta 11.1	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual Indoor Unit	
	9.1 9.2 9.3 Elect Insta 11.1 11.2	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual Indoor Unit <byfq60b3w1> Decoration Panel</byfq60b3w1>	
	9.1 9.2 9.3 Elect Insta 11.1 11.2 11.3	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual Indoor Unit <byfq60b3w1> Decoration Panel <byfq60c2w1w(s)> Decoration Panel</byfq60c2w1w(s)></byfq60b3w1>	29 
	9.1 9.2 9.3 Elect Insta 11.1 11.2 11.3 11.4	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual Indoor Unit <byfq60b3w1> Decoration Panel <byfq60c2w1w(s)> Decoration Panel <brc1e73> Wired Remote Controller.</brc1e73></byfq60c2w1w(s)></byfq60b3w1>	
	9.1 9.2 9.3 Elect 11.1 11.2 11.3 11.4 11.5	Measuring Location Indoor Unit Outdoor Unit tric Characteristics Ilation Manual Indoor Unit <byfq60b3w1> Decoration Panel <byfq60c2w1w(s)> Decoration Panel</byfq60c2w1w(s)></byfq60b3w1>	

12.Operation Manual	
12.1 With <brc1e73> Wired Remote Controller</brc1e73>	106
12.2 With <brc082a41w, brc082a42w(s)=""></brc082a41w,>	
Wireless Remote Controller	156
13.Option List	165
13.1 Indoor Unit	
13.2 Outdoor Unit	165
13.3 <bryq60a2w(s)> Sensor Kit</bryq60a2w(s)>	166
13.4 <kdbq44ba60a> Panel Spacer</kdbq44ba60a>	168
13.5 <kddq44xa60> Fresh Air Intake Kit</kddq44xa60>	170
13.6 <dcs302c71> Central Remote Controller</dcs302c71>	172
13.7 <dcs301c71> Unified ON/OFF Controller</dcs301c71>	203
13.8 <dst301ba61> Schedule Timer Controller</dst301ba61>	210
13.9 <krp1c75> Adaptor for Wiring</krp1c75>	229
13.10 <krp4a74> Wiring Adaptor for Electrical Appendices</krp4a74>	230
13.11 <krp1ba101> Installation Box for Adaptor PCB</krp1ba101>	234
13.12 <krcs01-4b> Remote Sensor</krcs01-4b>	236
13.13 <kpw937e4> Air Direction Adjustment Grille</kpw937e4>	239
13.14 <kpw063a4> Air Direction Adjustment Grille</kpw063a4>	
13.15 <kkg067a41> Back Protection Wire Net</kkg067a41>	243
13.16 <kkg063a42> Back Protection Wire Net</kkg063a42>	244
13.17 <ftdbhms, ftdbhml,="" keh063a4e="" keh067a41e,=""></ftdbhms,>	
Drain Pan Heater	
13.18 <kps067a41> Snow Hood (Intake Side Plate)</kps067a41>	251
13.19 <kps067a42> Snow Hood (Intake Rear Plate)</kps067a42>	253
13.20 <kps067a44> Snow Hood (Outlet)</kps067a44>	255
13.21 <kps063a41> Snow Hood (Intake Side Plate)</kps063a41>	257
13.22 <kps063a44> Snow Hood (Intake Rear Plate)</kps063a44>	259
13.23 <kps063a47> Snow Hood (Outlet)</kps063a47>	261



Cautions
 1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided and choose an outdoor unit with anti-corrosion treatment.

## 1. Power Supply

Indoor Unit	Outdoor Unit	Power Supply
FFQ09Q2VJU	RX09QMVJU	1 phase, 208 - 230 V, 60 Hz
FFQ12Q2VJU	RX12QMVJU	
FFQ15Q2VJU	RX15QMVJU	
FFQ18Q2VJU	RX18QMVJU	

Note: Power Supply Intake; Outdoor Unit

## 2. Functions

Category	Functions	FFQ09/12/15/18Q2VJU RX09/12/15/18QMVJU with BYFQ60B3W1	FFQ09/12/15/18Q2VJU RX09/12/15/18QMVJU with BYFQ60C2W1W(S)	Category	Functions	FFQ09/12/15/18Q2VJU RX09/12/15/18QMVJU with BYFQ60B3W1	FFQ09/12/15/18Q2VJU RX09/12/15/18QMVJU with BYFQ60C2W1W(S)
Basic	Inverter (with inverter power control)	•	•	Health &	Auto cleaning filter	—	—
Functions	Operation limit for cooling	Defert		Cleanliness	Air-purifying filter	_	—
	Operation limit for heating	Refer t	io P. 28		Titanium apatite deodorizing filter	_	—
	PAM control	—	—		Longlife filter	٠	•
	Standby electricity saving	—	_		Air filter	•	•
Compressor	Oval scroll compressor	—	_		Filter cleaning indicator	•	•
	Swing compressor	•	•		Wipe-clean flat panel	—	—
	Rotary compressor	—	_		Washable grille	•	•
	Reluctance DC motor		•		MOLD PROOF operation	—	—
Comfortable	Power-airflow flap (horizontal blade)	—	_		Good-sleep cooling operation	_	—
Airflow	Power-airflow dual flaps			Timer	Schedule TIMER operation	● <b>★</b> 1	● <b>★</b> 1
	(horizontal blade)		_		72-hour ON/OFF TIMER	● <b>★</b> 2	<b>●★</b> 2
	Power-airflow diffuser	—	_		NIGHT SET mode	_	—
	Wide-angle louvers (vertical blades)	—	_		Off Timer (power off forget prevention)	● <b>★</b> 1	● <b>★</b> 1
	Auto-swing (up and down)		•	Worry Free	Auto-restart (after power failure)	•	•
	Auto-swing (right and left) Individual flap control		_	(Reliability & Durability)	Self-diagnosis (R/C, LED)	•	•
			● <b>★</b> 1	, , , , , , , , , , , , , , , , , , ,	Wiring error check function	—	—
	3-D airflow	—	_		Anti-corrosion treatment of outdoor heat exchanger	_	_
Comfort	COMFORT AIRFLOW operation		-	Flovibility			
Comfort Control	Auto fan speed Indoor unit quiet operation	●★1 ●	●★1 ●	Flexibility	Multi-split/split type compatible indoor unit	•	•
	NIGHT QUIET mode (automatic)	•	•		H/P, C/O compatible indoor unit		
	OUTDOOR UNIT QUIET operation				Flexible power supply correspondence		
	(manual)	-	_		Chargeless	32.8 ft	 32.8 ft
	Presence and floor sensor (option)	—	● <b>★</b> 1		<u> </u>	(10 m)	(10 m)
	Hot-start function	•	•		Either side drain (right or left)	—	
	Draft prevention	•	•		Power selection	—	
	Automatic defrosting	•	•		Low outdoor temperature cooling	● <b>★</b> 3	● <b>★</b> 3
Operation	Automatic operation	•	•		operation (-20°C) (-4°F)		
	Program dry function	•	•		°F/°C changeover R/C temperature display (factory setting: °F)	● <b>★</b> 1	<b>●</b> ★1
	Fan only	•	•	-	display (lactory setting. F)		
	Setback function	● <b>★</b> 1	● <b>★</b> 1	Remote Control	Remote control adaptor (normal open pulse contact) (option)	_	_
Lifestyle Convenience	POWERFUL operation (non-inverter)				(normal open pulse contact) (option)		
	POWERFUL operation (inverter)	-	_		Remote control adaptor (normal open contact) (option)	—	_
	Priority-room setting	_	_		, ,		
	COOL/HEAT mode lock			Domoto	DIII-NET compatible (adaptor) (option)	-	
	HOME LEAVE operation			Remote Controller	Wireless (option)	•	•
	ECONO operation Indoor unit <b>ON/OFF</b> button	-			Wired (option)	•	•
		-					
	Signal receiving sign	●★2 ★4	●★2 ★4	<u> </u>			
	R/C with back light	● <b>★</b> 1	● <b>★</b> 1		★1: With wired remote controller		

Note: • : Available

- : Not available

 $\star$ 1: With wired remote controller

★2: With wireless remote controller
★3: With air direction adjustment grille (option)

★4: Receiving sound only

## 3. Specifications

60 Hz,	208 -	230	۷
--------	-------	-----	---

	Indoor Unit		FFQ09		FFQ12Q2VJU				
Model	Outdoor Unit		RX09C Cooling	MVJU Heating	RX120 Cooling	QMVJU Heating			
Capacity		Dt. /h	0	ů – Č	J	<u> </u>			
Capacity Rated (Min. ~ Max.) Running Current (Rated)		Btu/h	9,100 (4,600 ~ 11,000)	10,000 (4,600 ~ 14,000)	10,800 (4,600 ~ 13,300)	13,500 (4,600 ~ 16,800)			
Power Consumption	ed)	A	3.64 - 3.29	3.43 - 3.10	4.61 - 4.17	4.96 - 4.49			
Rated (Min. ~ Max.)		W	700 (280 ~ 1,050)	641 (250 ~ 1,150)	864 (280 ~ 1,410)	985 (250 ~ 1,450)			
Power Factor (Rated)		%	92.5 - 92.5	89.8 - 89.9	90.1 - 90.1	95.5 - 95.4			
SEER / HSPF			20.90	11.70	20.20	11.20			
COP (Rated)		W/W	-	4.58		4.02			
EER (Rated)	Liquid	Btu/W·h in. (mm)	13.00		12.50	(\$ 6.4)			
Piping Connections	Gas	in. (mm)	φ 3/8 (	,		(¢ 9.5)			
1 3 1 1 1	Drain	in. (mm)	VP20 (O.D. ¢	,		1-1/32 (\$ 26))			
Heat Insulation			Both Liquid a	nd Gas Pipes		nd Gas Pipes			
Max. Interunit Piping L		ft (m)	65-5/8	· · ·		8 (20)			
Max. Interunit Height [	Difference	ft (m)	49-1/4			4 (15)			
Chargeless Amount of Additional (	Charge of	ft (m) oz/ft	32-13/*			16 (10)			
Refrigerant	Sharge of	(g/m)	0.21	(20)	0.21	(20)			
Indoor Unit	1		FFQ09			Q2VJU			
	Model		BYFQ6			60B3W1			
Decoration	Color Dimensions		Wh 2-3/16 × 27-9/16 × 27-			nite -9/16 (55 × 700 × 700)			
Panel (1)	$(H \times W \times D)$	in. (mm)	2-0/10 X 2/-0/10 X 2/-	0/10 (00 × 700 × 700)	2-0/10 X 27-0/10 X 27	0,10 (00 × 100 × 100)			
	Weight (Mass)	Lbs (kg)	6 (2	,		2.7)			
	Model		BYFQ60C2W1W			/ BYFQ60C2W1S			
Decoration	Color Dimensions		/ White 1-13/16 × 24-7/16 × 24			/ Silver 1-7/16 (46 × 620 × 620)			
Panel (2)	$(H \times W \times D)$	in. (mm)	1-10/10 × 2+-1/10 × 24	-1/10 (40 × 020 × 020)	1-13/10 × 2+-1/10 × 2-	-1/10 (40 × 020 × 020)			
	Weight (Mass)	Lbs (kg)	6.2 (			(2.8)			
	Н	cfm	378 (10.7)	399 (11.3)	406 (11.5)	427 (12.1)			
Airflow Rate	M	(m³/min)	339 (9.6) 268 (7.6)	357 (10.1) 282 (8.0)	353 (10.0)	371 (10.5)			
	Type		Turbo Fan		268 (7.6) 282 (8.0) Turbo Fan				
Fan	Speed	Steps	3 St		3 Steps				
Running Current (Rate	ed)	A	0.23 - 0.21	0.23 - 0.21	0.27 - 0.24	0.27 - 0.24			
Power Consumption (F	Rated)	W	23	23	27	27			
Power Factor (Rated)		%	48.1 - 47.6	48.1 - 47.6	48.1 - 48.9	48.1 - 48.9			
Temperature Control Dimensions (H × W ×	D)	in. (mm)	Microcompu 10-1/4 × 22-5/8 × 22-5			uter Control $5/8(260 \times 575 \times 575)$			
Packaged Dimensions		in. (mm)	11 × 27 × 23-1/2 (		10-1/4 × 22-5/8 × 22-5/8 (260 × 575 × 575) 11 × 27 × 23-1/2 (280 × 686 × 597)				
Weight (Mass)	(	Lbs (kg)	36 (16)		36 (16)				
Gross Weight (Gross N	Mass)	Lbs (kg)	40 (	18)	40 (18)				
Sound Pressure Level	H/M/L	dB(A)	38 / 35 / 29	38 / 35 / 29	39 / 36 / 30	39 / 36 / 30			
Outdoor Unit			RX09C			QMVJU			
Casing Color	Туре		lvory V Hermetically Sea			White aled Swing Type			
Compressor	Model		1YC23	6 11		BAUXD			
e empresses.	Motor Output	W	79			90			
Refrigerant Oil	Туре		FVC	50K	FVC50K				
	Charge	oz (L)	12.68 (		12.68 (0.375)				
Refrigerant	Туре		R-4			10A			
5	Charge	Lbs (kg) cfm	2.09 (			(0.95)			
Airflow Rate	н	(m³/min)	985 (27.9)	992 (28.1)	1,104 (31.27)	992 (28.1)			
Fan	Туре		Prop			beller			
Running Current (Rate	,	A W	3.41 - 3.08	3.20 - 2.89	4.34 - 3.93	4.69 - 4.25			
Power Consumption (F Power Factor (Rated)	Hated)	۷۷ %	677 95.4 - 95.6	618 92.8 - 93.0	837 92.7 - 92.6	958 98.2 - 98.0			
Starting Current		A	95.4 - 95.0 7.			.5			
Dimensions (H × W ×	D)	in. (mm)	21-5/8 × 26-9/16 × 11-3			3/16 (550 × 675 × 284)			
Packaged Dimensions	$(H \times W \times D)$	in. (mm)	24-3/4 × 32-11/16 × <sup>-</sup>	1		16 (629 × 830 × 407)			
Weight (Mass)		Lbs (kg)	60 (			(27)			
Gross Weight (Gross N Sound Pressure Level		Lbs (kg)	71 ( 	<u>32)</u> 50	49	(32) 51			
Drawing No.	Lu –	dB(A)	46 3D106			51			
0	otes: 1. SL	· The Quiet	fan level of the airflow rate sett		3010	,			
			based on the conditions shown i	0		Conversion Formulae			
		Cooling	Indoor ; 80.0°FDB (26.7°CDI		]	$kcal/h = kW \times 860$			
		-	Outdoor ; 95.0°FDB (35°CDE Indoor ; 70.0°FDB (21.1°CDE		4	Btu/h = kW $\times$ 3412 cfm = m <sup>3</sup> /min $\times$ 35.3			
		Heating	Outdoor ; 70.0°FDB (21.1°CDF Outdoor ; 47°FDB (8.33°CDF			CITT = TT?/TTITT X 33.3			
	Pip	ing Length	25 ft (7.5 m)		]				
	· · · ·				_				

#### 60 Hz, 208 - 230V

	Indoor Unit		FFQ15	Q2VJU	FFQ18	Q2VJU			
Model				2MVJU	RX18QMVJU				
	Outdoor Unit	÷	Cooling	Heating	Cooling	Heating			
Capacity Rated (Min. ~ Max.)		Btu/h	14,400 (5,100 ~ 16,200)	16,200 (5,200 ~ 16,300)	17,400 (5,100 ~ 18,800)	21,600 (5,400 ~ 21,800)			
Running Current (Rate	ed)	А	5.83 - 5.27	6.23 - 5.63	7.12 - 6.44	9.51- 8.6			
Power Consumption Rated (Min. ~ Max.)		w	1,152 (310 ~ 1,640)	1,235 (330 ~ 1,300)	1,392 - 1,392 (340 ~ 1,650)	1,875 - 1,875 (370 ~ 1,920)			
Power Factor (Rated)		%	95.0 - 95.0	95.3 - 95.4	94 - 94	94.8 - 94.8			
SEER / HSPF			20.70	11.00	19.30	10.10			
COP (Rated)		W/W	—	3.86	—	3.36			
EER (Rated)	_	Btu/W⋅h	12.50	_	12.50				
	Liquid	in. (mm)		(\$ 6.4)		(\$ 6.4)			
Piping Connections	Gas	in. (mm)		φ 12.7)		φ 12.7)			
	Drain	in. (mm)		1-1/32 (\oplus 26))	VP20 (O.D ¢	1-1/32 (\(\phi\) 26))			
Heat Insulation		ft ()		nd Gas Pipes		Ind Gas Pipes			
Max. Interunit Piping L Max. Interunit Height I	<u> </u>	ft (m) ft (m)		16 (30) 8 (20)		16 (30) 8 (20)			
Chargeless	Jillerence	ft (m)		8 (20) 16 (10)		(16 (10)			
Amount of Additional (	Charge of	oz/ft				× /			
Refrigerant		(g/m)		(20)		(20)			
Indoor Unit	Model			Q2VJU					
	Model			60B3W1		60B3W1			
Decoration	Color Dimensions	, I		nite		hite			
Panel (1)	$(H \times W \times D)$	in. (mm)		-9/16 (55 × 700 × 700)		-9/16 (55 × 700 × 700)			
	Weight (Mass)	Lbs (kg)	,	2.7)	1	2.7)			
	Model			/ BYFQ60C2W1S		/ BYFQ60C2W1S			
Decoration	Color	-	White	/ Silver	White	/ Silver			
Panel (2)	Dimensions $(H \times W \times D)$	in. (mm)	1-13/16 × 24-7/16 × 24	I-7/16 (46 × 620 × 620)	1-13/16 × 24-7/16 × 24	4-7/16 (46 × 620 × 620)			
	Weight (Mass)	Lbs (kg)	6.2	(2.8)	6.2 (2.8)				
	H		420 (11.9)	441 (12.5)	448 (12.7)	498 (14.1)			
Airflow Rate	М	cfm (m <sup>3</sup> /min)	367 (10.4)	385 (10.9)	378 (10.7)	420 (11.9)			
	L	(111 / 1111)	293 (8.3) 307 (8.7)		275 (7.8)	307 (8.7)			
Fan	Туре		Turbo Fan		Turb	o Fan			
	Speed	Steps		teps	3 Steps				
Running Current (Rate		A	0.29 - 0.26	0.29 - 0.26	0.52 - 0.47	0.52 - 0.47			
Power Consumption (	Rated)	W	28	28	51 - 51	51 - 51			
Power Factor (Rated)		%	46.4 - 46.8	46.4 - 46.8	47.2 - 47.2	47.2 - 47.2			
Temperature Control Dimensions (H × W ×	D)	in (mm)		uter Control 5/8 (260 × 575 × 575)	Microcomputer Control 10-1/4 × 22-5/8 × 22-5/8 (260 × 575 × 575)				
Packaged Dimensions	,	in. (mm) in. (mm)		(280 × 686 × 597)	11 × 27 × 23-1/2 (280 × 686 × 597)				
Weight (Mass)		Lbs (kg)		(16)		(17.5)			
Gross Weight (Gross	Mass)	Lbs (kg)		(18)	42.0 (19.0)				
Sound Pressure Level		dB(A)	40 / 37 / 31	40/37/31	44/40/32	44 / 40 / 32			
Outdoor Unit	1 · · ·			ULVMQ	RX180	QMVJU			
Casing Color			Ivory	White	Ivory	White			
	Туре		Hermetically Se	aled Swing Type	Hermetically Se	aled Swing Type			
Compressor	Model		2YC3	6PXD	2YC3	6PXD			
	Motor Output	W		100		100			
Refrigerant Oil	Туре			50K	FVC50K				
rionigorani on	Charge	oz (L)		(0.65)		(0.650)			
Refrigerant	Туре			10A		10A			
0	Charge	Lbs (kg)	2.49	(1.13)	2.49	(1.13)			
Airflow Rate	Н	cfm (m <sup>3</sup> /min)	2,314 (65.53)	1,896 (53.7)	2,461 (69.7)	2,295 (65)			
Fan	Туре			peller		peller			
Running Current (Rated)		A W	5.54 - 5.01	5.94 - 5.37	6.60 - 5.97	8.99 - 8.13			
Power Consumption (Rated)		W %	1,124	1,207 97.7 - 97.7	1,341 - 1,341	1,824 - 1,824			
Power Factor (Rated) Starting Current		% A	97.5 - 97.5	.0	97.7 - 97.7	97.5 - 97.5 51			
Dimensions (H × W ×	ח	in. (mm)		.0 2-5/8 (735 × 870 × 320)		2-5/8 (735 × 870 × 320)			
Packaged Dimensions	,	in. (mm)		-5/8 (755 × 870 × 320) 1/4 (810 × 1,056 × 464)		2-5/8 (755 × 870 × 320) 1/4 (810 × 1,056 × 464)			
Weight (Mass)		Lbs (kg)		(44)		(44)			
	Mass)	Lbs (kg)		(52)		(52)			
Gross Weight (Gross Mass)									
Gross Weight (Gross Sound Pressure Level	,	dB(A)	50	51	54	55			

Notes:

 SL: The Quiet fan level of the airflow rate setting.
 The data are based on the conditions shown in the table below. 2.

<u> </u>	The data are based on the conditions shown in the table below.						
		Indoor ; 80.0°FDB (26.7°CDB) / 67.0°FWB (19.4°CWB) Outdoor ; 95.0°FDB (35°CDB) / 75°FWB (23.9°CWB)					
	Heating	Indoor ; 70.0°FDB (21.1°CDB) / 60.0°FWB (15.6°CWB) Outdoor ; 47°FDB (8.33°CDB) / 43.0°FWB (6.11°CWB)					
	Piping Length	25 ft (7.5 m)					

Conversion Formulae

 $\label{eq:kcal/h} \begin{array}{l} kcal/h = kW \times 860 \\ Btu/h = kW \times 3412 \\ cfm = m^3/min \times 35.3 \end{array}$ 

## 4. Dimensions

#### 4.1 Indoor Unit

#### FFQ09/12/15/18Q2VJU with BYFQ60B3W1 (Decoration Panel)



FFQ09/12/15/18Q2VJU with BYFQ60C2W1W(S) (Decoration Panel)



#### BRC1E73 — Wired Remote Controller (Option) —



#### BRC082A41W — Wireless Remote Controller (Option) —





#### BRC082A42W(S) — Wireless Remote Controller (Option) —

#### • REMOTE CONTROLLER DIMENSIONS







RECEIVER INSTALLATION PROCEDURE





3D082024

#### 4.2 Outdoor Unit

#### RX09/12QMVJU



#### RX15/18QMVJU



#### 5. Wiring Diagrams

#### 5.1 **Indoor Unit**

FFQ09/12/15/18Q2VJU



3D106024

#### 5.2 Outdoor Unit

#### RX09/12QMVJU



#### RX15/18QMVJU



## 6. Piping Diagrams

#### 6.1 Indoor Unit

#### FFQ09/12/15/18Q2VJU



MODEL	A	в
FFQ09Q2VJU	1/4(6.4)	3/8(9.5)
FFQ12Q2VJU		
FFQ15Q2VJU		1/2(12.7)
FFQ18Q2VJU		

4D106033

#### 6.2 Outdoor Unit

#### RX09/12QMVJU



3D092207A

#### RX15/18QMVJU



## 7. Capacity Tables

#### FFQ09Q2VJU + RX09QMVJU

#### 60 Hz, 208 V

Cooling							
AFR	10.7						
BF	0.18						

#### Temp: Celsius

TC, SHC, PI: kW

INDO	INDOOR		OUTDOOR TEMPERATURE (°CDB)																
EWB	EDB	10 20			20		30			35			40						
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.98	2.35	0.43	2.74	2.23	0.54	2.49	2.12	0.64	2.36	2.06	0.69	2.24	2.00	0.74	2.09	1.94	0.81
16.0	22.0	3.11	2.31	0.44	2.86	2.20	0.54	2.61	2.09	0.64	2.49	2.03	0.70	2.36	1.98	0.75	2.21	1.92	0.81
18.0	25.0	3.23	2.43	0.44	2.98	2.33	0.54	2.73	2.23	0.65	2.61	2.18	0.70	2.48	2.13	0.75	2.33	2.07	0.81
19.4	26.7	3.29	2.59	0.44	3.04	2.49	0.54	2.79	2.39	0.65	2.67	2.34	0.70	2.55	2.29	0.75	2.40	2.24	0.81
22.0	30.0	3.48	2.50	0.45	3.23	2.41	0.55	2.98	2.32	0.65	2.85	2.28	0.70	2.73	2.24	0.76	2.58	2.19	0.82
24.0	32.0	3.60	2.43	0.50	3.35	2.35	0.55	3.10	2.28	0.66	2.98	2.24	0.71	2.85	2.20	0.76	2.70	2.15	0.82

#### Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

#### F1. KVV

INDO	DOR							0	UTDOO	r temp	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.18	8.03	0.43	9.33	7.62	0.54	8.48	7.23	0.64	8.06	7.03	0.69	7.64	6.84	0.74	7.13	6.61	0.81
60.8	71.6	10.60	7.88	0.44	9.75	7.50	0.54	8.90	7.13	0.64	8.48	6.94	0.70	8.06	6.76	0.75	7.55	6.55	0.81
64.4	77.0	11.02	8.31	0.44	10.17	7.95	0.54	9.32	7.61	0.65	8.90	7.44	0.70	8.48	7.27	0.75	7.97	7.07	0.81
67.0	80.0	11.23	8.82	0.44	10.38	8.48	0.54	9.53	8.15	0.65	9.10	7.99	0.70	8.69	7.82	0.75	8.18	7.63	0.81
71.6	86.0	11.86	8.51	0.45	11.01	8.22	0.55	10.16	7.92	0.65	9.74	7.78	0.70	9.32	7.63	0.76	8.81	7.47	0.82
75.2	89.6	12.28	8.30	0.50	11.43	8.03	0.55	10.58	7.76	0.66	10.16	7.63	0.71	9.74	7.50	0.76	9.23	7.35	0.82

#### Heating

AFR 11.3

#### Temp: Celsius

TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUR	RE (°CW	B)				
EDB		15	-1	10	-	5	(	2	6	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.40	0.41	1.68	0.43	1.96	0.45	2.25	0.48	3.04	0.63	3.31	0.65	3.84	0.69
21.1	1.31	0.42	1.60	0.45	1.88	0.47	2.16	0.49	2.94	0.64	3.21	0.66	3.74	0.70
22.0	1.28	0.43	1.56	0.45	1.84	0.47	2.13	0.49	2.90	0.65	3.16	0.67	3.70	0.71
24.0	1.24	0.43	1.53	0.45	1.81	0.48	2.09	0.50	2.86	0.65	3.12	0.67	3.66	0.72
25.0	1.23	0.44	1.51	0.46	1.79	0.48	2.07	0.50	2.84	0.66	3.10	0.68	3.64	0.72
27.0	1.19	0.44	1.48	0.46	1.76	0.48	2.04	0.50	2.80	0.66	3.06	0.68	3.59	0.72

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.41	5.74	0.43	6.70	0.45	7.67	0.48	10.38	0.63	11.28	0.65	13.10	0.69
70.0	4.48	0.42	5.45	0.45	6.41	0.47	7.37	0.49	10.00	0.64	10.94	0.66	12.75	0.70
71.6	4.37	0.43	5.33	0.45	6.29	0.47	7.25	0.49	9.89	0.65	10.80	0.67	12.61	0.71
75.2	4.25	0.43	5.21	0.45	6.17	0.48	7.14	0.50	9.75	0.65	10.66	0.67	12.47	0.72
77.0	4.19	0.44	5.15	0.46	6.11	0.48	7.08	0.50	9.69	0.66	10.59	0.68	12.40	0.72
80.6	4.07	0.44	5.03	0.46	6.00	0.48	6.96	0.50	9.55	0.66	10.45	0.68	12.27	0.72

#### 60 Hz, 230 V

Cooling	
AFR	10.7
BF	0.18

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC         PI         TC           2.23         0.54         2.49			SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	2.98	2.35	0.43	2.74	2.23	0.54	2.49	2.12	0.64	2.36	2.06	0.69	2.24	2.00	0.74	2.09	1.94	0.81
16.0	22.0	3.11	2.31	0.44	2.86	2.20	0.54	2.61	2.09	0.64	2.49	2.03	0.70	2.36	1.98	0.75	2.21	1.92	0.81
18.0	25.0	3.23	2.43	0.44	2.98	2.33	0.54	2.73	2.23	0.65	2.61	2.18	0.70	2.48	2.13	0.75	2.33	2.07	0.81
19.4	26.7	3.29	2.59	0.44	3.04	2.49	0.54	2.79	2.39	0.65	2.67	2.34	0.70	2.55	2.29	0.75	2.40	2.24	0.81
22.0	30.0	3.48	2.50	0.45	3.23	2.41	0.55	2.98	2.32	0.65	2.85	2.28	0.70	2.73	2.24	0.76	2.58	2.19	0.82
24.0	32.0	3.60	2.43	0.50	3.35	2.35	0.55	3.10	2.28	0.66	2.98	2.24	0.71	2.85	2.20	0.76	2.70	2.15	0.82

## Temp: Fahrenheit TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC					PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	10.18	8.03	0.43	9.33	7.62	0.54	8.48	7.23	0.64	8.06	7.03	0.69	7.64	6.84	0.74	7.13	6.61	0.81
60.8	71.6	10.60	7.88	0.44	9.75	7.50	0.54	8.90	7.13	0.64	8.48	6.94	0.70	8.06	6.76	0.75	7.55	6.55	0.81
64.4	77.0	11.02	8.31	0.44	10.17	7.95	0.54	9.32	7.61	0.65	8.90	7.44	0.70	8.48	7.27	0.75	7.97	7.07	0.81
67.0	80.0	11.23	8.82	0.44	10.38	8.48	0.54	9.53	8.15	0.65	9.10	7.99	0.70	8.69	7.82	0.75	8.18	7.63	0.81
71.6	86.0	11.86	8.51	0.45	11.01	8.22	0.55	10.16	7.92	0.65	9.74	7.78	0.70	9.32	7.63	0.76	8.81	7.47	0.82
75.2	89.6	12.28	8.30	0.50	11.43	8.03	0.55	10.58	7.76	0.66	10.16	7.63	0.71	9.74	7.50	0.76	9.23	7.35	0.82

#### Heating AFR

11.3

Temp: Celsius TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUF	RE (°CW	B)				
EDB	-	15	-1	10	-	5	(	)	e	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.40	0.41	1.68	0.43	1.96	0.45	2.25	0.48	3.04	0.63	3.31	0.65	3.84	0.69
21.1	1.31	0.42	1.60	0.45	1.88	0.47	2.16	0.49	2.94	0.64	3.21	0.66	3.74	0.70
22.0	1.28	0.43	1.56	0.45	1.84	0.47	2.13	0.49	2.90	0.65	3.16	0.67	3.70	0.71
24.0	1.24	0.43	1.53	0.45	1.81	0.48	2.09	0.50	2.86	0.65	3.12	0.67	3.66	0.72
25.0	1.23	0.44	1.51	0.46	1.79	0.48	2.07	0.50	2.84	0.66	3.10	0.68	3.64	0.72
27.0	1.19	0.44	1.48	0.46	1.76	0.48	2.04	0.50	2.80	0.66	3.06	0.68	3.59	0.72

## Temp: Fahrenheit TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	4.78	0.41	5.74	0.43	6.70	0.45	7.67	0.48	10.38	0.63	11.28	0.65	13.10	0.69
70.0	4.48	0.42	5.45	0.45	6.41	0.47	7.37	0.49	10.00	0.64	10.94	0.66	12.75	0.70
71.6	4.37	0.43	5.33	0.45	6.29	0.47	7.25	0.49	9.89	0.65	10.80	0.67	12.61	0.71
75.2	4.25	0.43	5.21	0.45	6.17	0.48	7.14	0.50	9.75	0.65	10.66	0.67	12.47	0.72
77.0	4.19	0.44	5.15	0.46	6.11	0.48	7.08	0.50	9.69	0.66	10.59	0.68	12.40	0.72
80.6	4.07	0.44	5.03	0.46	6.00	0.48	6.96	0.50	9.55	0.66	10.45	0.68	12.27	0.72

#### Symbols:

AFR	: Airflow rate	(m³/min.)
BF	: Bypass factor	
EWB	: Entering wet bulb temp.	(°C) / (°F)
EDB	: Entering dry bulb temp.	(°C) / (°F)
тс	: Total capacity	(kW) / (kBtu/h)
SHC	: Sensible heat capacity	(kW) / (kBtu/h)
ΡI	: Power input	(kW)

#### Notes:

- shows nominal (rated) capacities and power input.
   TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
   Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
   Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106252A

#### FFQ12Q2VJU + RX12QMVJU

#### 60 Hz, 208 V

Cooling	
AFR	11.5
BF	0.28

#### Temp: Celsius

TC, SHC, PI: kW

INDO	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.55	2.59	0.54	3.26	2.44	0.66	2.96	2.29	0.79	2.81	2.22	0.85	2.67	2.15	0.92	2.49	2.06	0.99
16.0	22.0	3.70	2.54	0.54	3.40	2.40	0.67	3.11	2.26	0.79	2.96	2.19	0.86	2.81	2.12	0.92	2.63	2.05	1.00
18.0	25.0	3.85	2.64	0.54	3.55	2.51	0.67	3.25	2.39	0.80	3.11	2.32	0.86	2.96	2.26	0.93	2.78	2.19	1.00
19.4	26.7	3.92	2.78	0.54	3.62	2.65	0.67	3.33	2.53	0.80	3.18	2.47	0.86	3.03	2.41	0.93	2.85	2.34	1.00
22.0	30.0	4.14	2.67	0.55	3.84	2.56	0.68	3.55	2.45	0.81	3.40	2.40	0.87	3.25	2.34	0.93	3.07	2.28	1.01
24.0	32.0	4.29	2.60	0.55	3.99	2.49	0.68	3.69	2.39	0.81	3.55	2.35	0.87	3.40	2.30	0.94	3.22	2.24	1.01

#### Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

INDO	DOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	12.13	8.83	0.54	11.12	8.32	0.66	10.11	7.82	0.79	9.60	7.57	0.85	9.10	7.33	0.92	8.49	7.04	0.99
60.8	71.6	12.63	8.66	0.54	11.62	8.17	0.67	10.61	7.71	0.79	10.10	7.48	0.86	9.60	7.25	0.92	8.99	6.98	1.00
64.4	77.0	13.13	9.02	0.54	12.12	8.57	0.67	11.11	8.14	0.80	10.60	7.92	0.86	10.10	7.71	0.93	9.49	7.46	1.00
67.0	80.0	13.38	9.48	0.54	12.37	9.05	0.67	11.36	8.63	0.80	10.80	8.43	0.86	10.34	8.22	0.93	9.74	7.98	1.00
71.6	86.0	14.13	9.11	0.55	13.12	8.73	0.68	12.11	8.36	0.81	11.60	8.18	0.87	11.09	8.00	0.93	10.49	7.79	1.01
75.2	89.6	14.63	8.85	0.55	13.62	8.51	0.68	12.61	8.17	0.81	12.10	8.00	0.87	11.59	7.84	0.94	10.99	7.64	1.01

#### Heating

AFR 12.1

#### Temp: Celsius

TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUR	RE (°CW	B)				
EDB		15	-1	10	-	5	(	C	6	3	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.63	2.27	0.67	2.65	0.70	3.03	0.73	4.10	0.96	4.45	1.00	5.17	1.06
21.1	1.77	0.65	2.15	0.68	2.53	0.72	2.91	0.75	3.96	0.99	4.32	1.02	5.03	1.08
22.0	1.72	0.66	2.10	0.69	2.48	0.72	2.86	0.76	3.91	0.99	4.26	1.03	4.98	1.09
24.0	1.68	0.67	2.06	0.70	2.44	0.73	2.82	0.76	3.85	1.00	4.21	1.04	4.92	1.10
25.0	1.65	0.67	2.03	0.70	2.41	0.73	2.79	0.77	3.82	1.01	4.18	1.04	4.90	1.10
27.0	1.61	0.68	1.99	0.71	2.37	0.74	2.75	0.77	3.77	1.02	4.13	1.05	4.84	1.11

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.63	7.73	0.67	9.03	0.70	10.33	0.73	13.98	0.96	15.20	1.00	17.64	1.06
70.0	6.04	0.65	7.33	0.68	8.63	0.72	9.93	0.75	13.50	0.99	14.73	1.02	17.17	1.08
71.6	5.88	0.66	7.18	0.69	8.47	0.72	9.77	0.76	13.32	0.99	14.55	1.03	16.99	1.09
75.2	5.72	0.67	7.02	0.70	8.31	0.73	9.61	0.76	13.14	1.00	14.36	1.04	16.80	1.10
77.0	5.64	0.67	6.94	0.70	8.24	0.73	9.53	0.77	13.05	1.01	14.27	1.04	16.71	1.10
80.6	5.48	0.68	6.78	0.71	8.08	0.74	9.37	0.77	12.86	1.02	14.08	1.05	16.52	1.11

#### 60 Hz, 230 V

Cooling	
AFR	11.5
BF	0.28

Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.55	2.59	0.54	3.26	2.44	0.66	2.96	2.29	0.79	2.81	2.22	0.85	2.67	2.15	0.92	2.49	2.06	0.99
16.0	22.0	3.70	2.54	0.54	3.40	2.40	0.67	3.11	2.26	0.79	2.96	2.19	0.86	2.81	2.12	0.92	2.63	2.05	1.00
18.0	25.0	3.85	2.64	0.54	3.55	2.51	0.67	3.25	2.39	0.80	3.11	2.32	0.86	2.96	2.26	0.93	2.78	2.19	1.00
19.4	26.7	3.92	2.78	0.54	3.62	2.65	0.67	3.33	2.53	0.80	3.18	2.47	0.86	3.03	2.41	0.93	2.85	2.34	1.00
22.0	30.0	4.14	2.67	0.55	3.84	2.56	0.68	3.55	2.45	0.81	3.40	2.40	0.87	3.25	2.34	0.93	3.07	2.28	1.01
24.0	32.0	4.29	2.60	0.55	3.99	2.49	0.68	3.69	2.39	0.81	3.55	2.35	0.87	3.40	2.30	0.94	3.22	2.24	1.01

#### Temp: Fahrenheit

. TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	12.13	8.83	0.54	11.12	8.32	0.66	10.11	7.82	0.79	9.60	7.57	0.85	9.10	7.33	0.92	8.49	7.04	0.99
60.8	71.6	11.62	8.66	0.54	11.62	8.17	0.67	10.61	7.71	0.79	10.10	7.48	0.86	9.60	7.25	0.92	8.99	6.98	1.00
64.4	77.0	12.12	9.02	0.54	12.12	8.57	0.67	11.11	8.14	0.80	10.60	7.92	0.86	10.10	7.71	0.93	9.49	7.46	1.00
67.0	80.0	12.37	9.48	0.54	12.37	9.05	0.67	11.36	8.63	0.80	10.80	8.43	0.86	10.34	8.22	0.93	9.74	7.98	1.00
71.6	86.0	13.12	9.11	0.55	13.12	8.73	0.68	12.11	8.36	0.81	11.60	8.18	0.87	11.09	8.00	0.93	10.49	7.79	1.01
75.2	89.6	13.62	8.85	0.55	13.62	8.51	0.68	12.61	8.17	0.81	12.10	8.00	0.87	11.59	7.84	0.94	10.99	7.64	1.01

#### Heating

AFR 12.1

Temp: Celsius

TC, PI: kW

INDOOR					0	UTDOOI	R TEMP	ERATUF	RE (°CW	B)				
EDB		15	-1	10	-	5	(	C	6	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	1.89	0.63	2.27	0.67	2.65	0.70	3.03	0.73	4.10	0.96	4.45	1.00	5.17	1.06
21.1	1.77	0.65	2.15	0.68	2.53	0.72	2.91	0.75	3.96	0.99	4.32	1.02	5.03	1.08
22.0	1.72	0.66	2.10	0.69	2.48	0.72	2.86	0.76	3.91	0.99	4.26	1.03	4.98	1.09
24.0	1.68	0.67	2.06	0.70	2.44	0.73	2.82	0.76	3.85	1.00	4.21	1.04	4.92	1.10
25.0	1.65	0.67	2.03	0.70	2.41	0.73	2.79	0.77	3.82	1.01	4.18	1.04	4.90	1.10
27.0	1.61	0.68	1.99	0.71	2.37	0.74	2.75	0.77	3.77	1.02	4.13	1.05	4.84	1.11

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	6.43	0.63	7.73	0.67	9.03	0.70	10.33	0.73	13.98	0.96	15.20	1.00	17.64	1.06
70.0	6.04	0.65	7.33	0.68	8.63	0.72	9.93	0.75	13.50	0.99	14.73	1.02	17.17	1.08
71.6	5.88	0.66	7.18	0.69	8.47	0.72	9.77	0.76	13.32	0.99	14.55	1.03	16.99	1.09
75.2	5.72	0.67	7.02	0.70	8.31	0.73	9.61	0.76	13.14	1.00	14.36	1.04	16.80	1.10
77.0	5.64	0.67	6.94	0.70	8.24	0.73	9.53	0.77	13.05	1.01	14.27	1.04	16.71	1.10
80.6	5.48	0.68	6.78	0.71	8.08	0.74	9.37	0.77	12.86	1.02	14.08	1.05	16.52	1.11

#### Symbols:

: Airflow rate	(m³/min.)
: Bypass factor	
: Entering wet bulb temp.	(°C) / (°F)
: Entering dry bulb temp.	(°C) / (°F)
: Total capacity	(kW) / (kBtu/h)
: Sensible heat capacity	(kW) / (kBtu/h)
: Power input	(kW)
	<ul> <li>Bypass factor</li> <li>Entering wet bulb temp.</li> <li>Entering dry bulb temp.</li> <li>Total capacity</li> <li>Sensible heat capacity</li> </ul>

#### Notes:

- shows nominal (rated) capacities and power input.
   TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
   Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
   Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106253

#### FFQ15Q2VJU + RX15QMVJU

#### 60 Hz, 208 V

Cooling	
AFR	11.9
BF	0.32

#### Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.94	2.77	0.66	3.94	2.77	0.86	3.91	2.76	1.05	3.72	2.66	1.14	3.52	2.55	1.22	3.29	2.43	1.33
16.0	22.0	4.84	3.10	0.72	4.50	2.92	0.89	4.11	2.72	1.06	3.91	2.62	1.14	3.71	2.53	1.23	3.48	2.41	1.33
18.0	25.0	5.08	3.21	0.72	4.69	3.02	0.89	4.30	2.83	1.06	4.10	2.74	1.15	3.91	2.65	1.23	3.67	2.55	1.34
19.4	26.7	5.18	3.33	0.73	4.79	3.15	0.90	4.40	2.97	1.07	4.20	2.88	1.15	4.00	2.79	1.24	3.77	2.69	1.34
22.0	30.0	5.47	3.19	0.73	5.08	3.02	0.90	4.69	2.86	1.07	4.49	2.78	1.16	4.29	2.71	1.24	4.06	2.62	1.35
24.0	32.0	5.66	3.08	0.74	5.27	2.93	0.91	4.88	2.78	1.08	4.68	2.71	1.16	4.49	2.64	1.25	4.25	2.56	1.35

#### Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	ΡI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	13.44	9.47	0.66	13.44	9.47	0.86	13.35	9.42	1.05	12.68	9.06	1.14	12.01	8.72	1.22	11.21	8.31	1.33
60.8	71.6	16.51	10.58	0.72	15.34	9.96	0.89	14.01	9.28	1.06	13.34	8.95	1.14	12.67	8.62	1.23	11.87	8.23	1.33
64.4	77.0	17.34	10.96	0.72	16.00	10.30	0.89	14.67	9.66	1.06	14.00	9.35	1.15	13.33	9.05	1.23	12.53	8.69	1.34
67.0	80.0	17.67	11.37	0.73	16.33	10.74	0.90	15.00	10.12	1.07	14.40	9.82	1.15	13.66	9.53	1.24	12.86	9.18	1.34
71.6	86.0	18.66	10.87	0.73	17.32	10.31	0.90	15.99	9.76	1.07	15.32	9.50	1.16	14.65	9.23	1.24	13.85	8.93	1.35
75.2	89.6	19.32	10.51	0.74	17.98	10.00	0.91	16.65	9.50	1.08	15.98	9.25	1.16	15.31	9.01	1.25	14.51	8.73	1.35

#### Heating

AFR 12.5

#### Temp: Celsius

#### TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUR	RE (°CW	'В)				
EDB		15		10	-	5	(	C	(	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.26	0.79	2.71	0.84	3.17	0.88	3.62	0.92	4.90	1.21	5.33	1.25	6.19	1.33
21.1	2.12	0.82	2.57	0.86	3.03	0.90	3.48	0.94	4.74	1.24	5.17	1.28	6.02	1.36
22.0	2.06	0.83	2.52	0.87	2.97	0.91	3.43	0.95	4.67	1.25	5.10	1.29	5.96	1.37
24.0	2.01	0.83	2.46	0.88	2.92	0.92	3.37	0.96	4.61	1.26	5.04	1.30	5.89	1.38
25.0	1.98	0.84	2.43	0.88	2.89	0.92	3.34	0.96	4.58	1.26	5.00	1.30	5.86	1.38
27.0	1.92	0.85	2.38	0.89	2.83	0.93	3.29	0.97	4.51	1.27	4.94	1.31	5.80	1.40

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	7.70	0.79	9.25	0.84	10.81	0.88	12.36	0.92	16.73	1.21	18.19	1.25	21.11	1.33
70.0	7.23	0.82	8.78	0.86	10.33	0.90	11.88	0.94	16.20	1.24	17.63	1.28	20.56	1.36
71.6	7.04	0.83	8.59	0.87	10.14	0.91	11.69	0.95	15.95	1.25	17.41	1.29	20.33	1.37
75.2	6.85	0.83	8.40	0.88	9.95	0.92	11.50	0.96	15.73	1.26	17.19	1.30	20.11	1.38
77.0	6.75	0.84	8.31	0.88	9.86	0.92	11.41	0.96	15.61	1.26	17.08	1.30	20.00	1.38
80.6	6.56	0.85	8.12	0.89	9.67	0.93	11.22	0.97	15.39	1.27	16.85	1.31	19.77	1.40

#### 60 Hz, 230 V

Cooling	
AFR	11.9
BF	0.32

#### Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC				SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	3.94	2.77	0.66	3.94	2.77	0.86	3.91	2.76	1.05	3.72	2.66	1.14	3.52	2.55	1.22	3.29	2.43	1.33
16.0	22.0	4.84	3.10	0.72	4.50	2.92	0.89	4.11	2.72	1.06	3.91	2.62	1.14	3.71	2.53	1.23	3.48	2.41	1.33
18.0	25.0	5.08	3.21	0.72	4.69	3.02	0.89	4.30	2.83	1.06	4.10	2.74	1.15	3.91	2.65	1.23	3.67	2.55	1.34
19.4	26.7	5.18	3.33	0.73	4.79	3.15	0.90	4.40	2.97	1.07	4.20	2.88	1.15	4.00	2.79	1.24	3.77	2.69	1.34
22.0	30.0	5.47	3.19	0.73	5.08	3.02	0.90	4.69	2.86	1.07	4.49	2.78	1.16	4.29	2.71	1.24	4.06	2.62	1.35
24.0	32.0	5.66	3.08	0.74	5.27	2.93	0.91	4.88	2.78	1.08	4.68	2.71	1.16	4.49	2.64	1.25	4.25	2.56	1.35

#### Temp: Fahrenheit

. TC, SHC: kBtu/h

#### PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	B)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	13.44	9.47	0.66	13.44	9.47	0.86	13.35	9.42	1.05	12.68	9.06	1.14	12.01	8.72	1.22	11.21	8.31	1.33
60.8	71.6	15.34	10.58	0.72	15.34	9.96	0.89	14.01	9.28	1.06	13.34	8.95	1.14	12.67	8.62	1.23	11.87	8.23	1.33
64.4	77.0	16.00	10.96	0.72	16.00	10.30	0.89	14.67	9.66	1.06	14.00	9.35	1.15	13.33	9.05	1.23	12.53	8.69	1.34
67.0	80.0	16.33	11.37	0.73	16.33	10.74	0.90	15.00	10.12	1.07	14.40	9.82	1.15	13.66	9.53	1.24	12.86	9.18	1.34
71.6	86.0	17.32	10.87	0.73	17.32	10.31	0.90	15.99	9.76	1.07	15.32	9.50	1.16	14.65	9.23	1.24	13.85	8.93	1.35
75.2	89.6	17.98	10.51	0.74	17.98	10.00	0.91	16.65	9.50	1.08	15.98	9.25	1.16	15.31	9.01	1.25	14.51	8.73	1.35

#### Heating

AFR 12.5

Temp: Celsius

#### TC, PI: kW

INDOOR					0	UTDOOI	R TEMP	ERATUF	RE (°CW	'В)				
EDB		15		10	-	5	(	C	6	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	2.26	0.79	2.71	0.84	3.17	0.88	3.62	0.92	4.90	1.21	5.33	1.25	6.19	1.33
21.1	2.12	0.82	2.57	0.86	3.03	0.90	3.48	0.94	4.74	1.24	5.17	1.28	6.02	1.36
22.0	2.06	0.83	2.52	0.87	2.97	0.91	3.43	0.95	4.67	1.25	5.10	1.29	5.96	1.37
24.0	2.01	0.83	2.46	0.88	2.92	0.92	3.37	0.96	4.61	1.26	5.04	1.30	5.89	1.38
25.0	1.98	0.84	2.43	0.88	2.89	0.92	3.34	0.96	4.58	1.26	5.00	1.30	5.86	1.38
27.0	1.92	0.85	2.38	0.89	2.83	0.93	3.29	0.97	4.51	1.27	4.94	1.31	5.80	1.40

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	7.70	0.79	9.25	0.84	10.81	0.88	12.36	0.92	16.73	1.21	18.19	1.25	21.11	1.33
70.0	7.23	0.82	8.78	0.86	10.33	0.90	11.88	0.94	16.20	1.24	17.63	1.28	20.56	1.36
71.6	7.04	0.83	8.59	0.87	10.14	0.91	11.69	0.95	15.95	1.25	17.41	1.29	20.33	1.37
75.2	6.85	0.83	8.40	0.88	9.95	0.92	11.50	0.96	15.73	1.26	17.19	1.30	20.11	1.38
77.0	6.75	0.84	8.31	0.88	9.86	0.92	11.41	0.96	15.61	1.26	17.08	1.30	20.00	1.38
80.6	6.56	0.85	8.12	0.89	9.67	0.93	11.22	0.97	15.39	1.27	16.85	1.31	19.77	1.40

#### Symbols:

AFR	: Airflow rate	(m³/min.)
BF	: Bypass factor	
EWB	: Entering wet bulb temp.	(°C) / (°F)
EDB	: Entering dry bulb temp.	(°C) / (°F)
тс	: Total capacity	(kW) / (kBtu/h)
SHC	: Sensible heat capacity	(kW) / (kBtu/h)
ΡI	: Power input	(kW)

#### Notes:

- shows nominal (rated) capacities and power input.
   TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
   Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
   Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106254A

#### FFQ18Q2VJU + RX18QMVJU

#### 60 Hz, 208 V

Cooling	
AFR	12.7
BF	0.08

#### Temp: Celsius

TC, SHC, PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°CD	B)						
EWB	EDB		10			20			30			35			40			46	
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	5.69	4.01	0.85	5.29	3.79	1.07	4.81	3.55	1.27	4.57	3.43	1.38	4.33	3.31	1.48	3.23	2.78	1.37
16.0	22.0	6.00	3.97	0.87	5.52	3.73	1.07	5.04	3.49	1.28	4.80	3.38	1.38	4.56	3.27	1.49	3.45	2.77	1.37
18.0	25.0	6.24	4.11	0.87	5.76	3.88	1.08	5.28	3.67	1.29	5.04	3.56	1.39	4.80	3.45	1.49	3.67	2.98	1.37
19.4	26.7	6.36	4.29	0.88	5.88	4.07	1.08	5.40	3.87	1.29	5.16	3.76	1.39	4.92	3.66	1.49	3.77	3.20	1.37
22.0	30.0	6.72	4.11	0.89	6.24	3.92	1.09	5.76	3.74	1.30	5.52	3.65	1.40	5.28	3.56	1.50	4.10	3.14	1.37
24.0	32.0	6.96	3.99	0.89	6.48	3.81	1.10	5.99	3.64	1.30	5.75	3.56	1.41	5.51	3.48	1.51	4.32	3.09	1.37

#### Temp: Fahrenheit

TC, SHC: kBtu/h

PI: kW

IND	OOR							0	UTDOO	R TEMP	ERATU	RE (°FDI	3)						
EWB	EDB		50			68			86			95			104			115	
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	19.41	13.67	0.85	18.04	12.94	1.07	16.40	12.10	1.27	15.58	11.69	1.38	14.76	11.28	1.48	11.03	9.50	1.37
60.8	71.6	20.49	13.53	0.87	18.85	12.71	1.07	17.21	11.92	1.28	16.39	11.53	1.38	15.57	11.15	1.49	11.77	9.45	1.37
64.4	77.0	21.30	14.01	0.87	19.66	13.25	1.08	18.02	12.51	1.29	17.20	12.14	1.39	16.38	11.79	1.49	12.51	10.17	1.37
67.0	80.0	21.70	14.64	0.88	20.07	13.90	1.08	18.43	13.19	1.29	17.40	12.84	1.39	16.79	12.50	1.49	12.88	10.92	1.37
71.6	86.0	22.92	14.03	0.89	21.28	13.38	1.09	19.64	12.75	1.30	18.82	12.44	1.40	18.00	12.14	1.50	13.99	10.70	1.37
75.2	89.6	23.73	13.60	0.89	22.09	13.01	1.10	20.45	12.43	1.30	19.63	12.15	1.41	18.81	11.87	1.51	14.73	10.54	1.37

#### Heating

AFR 14.1

#### Temp: Celsius

#### TC, PI: kW

INDOOR					0	UTDOO	R TEMP	ERATUF	RE (°CW	'В)				
EDB		15	-1	10	-	5	(	)	(	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	3.00	1.21	3.60	1.27	4.21	1.33	4.81	1.39	6.52	1.83	7.09	1.89	8.06	1.96
21.1	2.82	1.24	3.42	1.30	4.02	1.36	4.63	1.43	6.30	1.88	6.87	1.94	7.74	1.96
22.0	2.74	1.25	3.35	1.32	3.95	1.38	4.56	1.44	6.21	1.89	6.78	1.95	7.62	1.96
24.0	2.67	1.27	3.27	1.33	3.88	1.39	4.48	1.45	6.13	1.91	6.70	1.97	7.50	1.96
25.0	2.63	1.27	3.24	1.34	3.84	1.40	4.44	1.46	6.08	1.92	6.65	1.98	7.44	1.96
27.0	2.56	1.29	3.16	1.35	3.77	1.41	4.37	1.47	6.00	1.93	6.56	2.00	7.32	1.96

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR					0	UTDOO	R TEMP	ERATU	RE (°FW	B)				
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	10.24	1.21	12.30	1.27	14.36	1.33	16.43	1.39	22.24	1.83	24.18	1.89	27.49	1.96
70.0	9.61	1.24	11.67	1.30	13.73	1.36	15.80	1.43	21.60	1.88	23.44	1.94	26.41	1.96
71.6	9.35	1.25	11.42	1.32	13.48	1.38	15.54	1.44	21.20	1.89	23.14	1.95	25.99	1.96
75.2	9.10	1.27	11.16	1.33	13.23	1.39	15.29	1.45	20.90	1.91	22.84	1.97	25.57	1.96
77.0	8.98	1.27	11.04	1.34	13.10	1.40	15.16	1.46	20.75	1.92	22.70	1.98	25.37	1.96
80.6	8.72	1.29	10.79	1.35	12.85	1.41	14.91	1.47	20.46	1.93	22.40	2.00	24.97	1.96

#### 60 Hz, 230 V

Cooling								
AFR	12.7							
BF	0.08							

Temp: Celsius

TC, SHC, PI: kW

IND	OOR		OUTDOOR TEMPERATURE (°CDB)																
EWB	EDB		10			20			30		35		40						
°C	°C	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
14.0	20.0	5.69	4.01	0.85	5.29	3.79	1.07	4.81	3.55	1.27	4.57	3.43	1.38	4.33	3.31	1.48	3.73	3.02	1.51
16.0	22.0	6.00	3.97	0.87	5.52	3.73	1.07	5.04	3.49	1.28	4.80	3.38	1.38	4.56	3.27	1.49	3.95	2.99	1.51
18.0	25.0	6.24	4.11	0.87	5.76	3.88	1.08	5.28	3.67	1.29	5.04	3.56	1.39	4.80	3.45	1.49	4.16	3.18	1.51
19.4	26.7	6.36	4.29	0.88	5.88	4.07	1.08	5.40	3.87	1.29	5.16	3.76	1.39	4.92	3.66	1.49	4.27	3.40	1.51
22.0	30.0	6.72	4.11	0.89	6.24	3.92	1.09	5.76	3.74	1.30	5.52	3.65	1.40	5.28	3.56	1.50	4.60	3.31	1.51
24.0	32.0	6.96	3.99	0.89	6.48	3.81	1.10	5.99	3.64	1.30	5.75	3.56	1.41	5.51	3.48	1.51	4.81	3.25	1.51

#### Temp: Fahrenheit

. TC, SHC: kBtu/h

PI: kW

IND	OOR		OUTDOOR TEMPERATURE (°FDB)																
EWB	EDB		50			68			86		95			104					
°F	°F	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI	TC	SHC	PI
57.2	68.0	19.41	13.67	0.85	18.04	12.94	1.07	16.40	12.10	1.27	15.58	11.69	1.38	14.76	11.28	1.48	12.73	10.29	1.51
60.8	71.6	20.49	13.53	0.87	18.85	12.71	1.07	17.21	11.92	1.28	16.39	11.53	1.38	15.57	11.15	1.49	13.46	10.20	1.51
64.4	77.0	21.30	14.01	0.87	19.66	13.25	1.08	18.02	12.51	1.29	17.20	12.14	1.39	16.38	11.79	1.49	14.20	10.86	1.51
67.0	80.0	21.70	14.64	0.88	20.07	13.90	1.08	18.43	13.19	1.29	17.40	12.84	1.39	16.79	12.50	1.49	14.57	11.59	1.51
71.6	86.0	22.92	14.03	0.89	21.28	13.38	1.09	19.64	12.75	1.30	18.82	12.44	1.40	18.00	12.14	1.50	15.68	11.30	1.51
75.2	89.6	23.73	13.60	0.89	22.09	13.01	1.10	20.45	12.43	1.30	19.63	12.15	1.41	18.81	11.87	1.51	16.42	11.08	1.51

#### Heating

AFR 14.1

Temp: Celsius

TC, PI: kW

INDOOR		OUTDOOR TEMPERATURE (°CWB)												
EDB		15	-1	10	-	5	(	)	(	6	1	0	1	8
°C	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
15.0	3.00	1.21	3.60	1.27	4.21	1.33	4.81	1.39	6.52	1.83	7.09	1.89	8.22	2.02
21.1	2.82	1.24	3.42	1.30	4.02	1.36	4.63	1.43	6.30	1.88	6.87	1.94	8.01	2.06
22.0	2.74	1.25	3.35	1.32	3.95	1.38	4.56	1.44	6.21	1.89	6.78	1.95	7.92	2.08
24.0	2.67	1.27	3.27	1.33	3.88	1.39	4.48	1.45	6.13	1.91	6.70	1.97	7.83	2.09
25.0	2.63	1.27	3.24	1.34	3.84	1.40	4.44	1.46	6.08	1.92	6.65	1.98	7.79	2.10
27.0	2.56	1.29	3.16	1.35	3.77	1.41	4.37	1.47	6.00	1.93	6.56	2.00	7.54	2.09

#### Temp: Fahrenheit

TC: kBtu/h

INDOOR		OUTDOOR TEMPERATURE (°FWB)												
EDB	Ę	5	1	4	2	3	3	2	4	3	5	0	6	4
°F	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
59.0	10.24	1.21	12.30	1.27	14.36	1.33	16.43	1.39	22.24	1.83	24.18	1.89	28.06	2.02
70.0	9.61	1.24	11.67	1.30	13.73	1.36	15.80	1.43	21.60	1.88	23.44	1.94	27.32	2.06
71.6	9.35	1.25	11.42	1.32	13.48	1.38	15.54	1.44	21.20	1.89	23.14	1.95	27.02	2.08
75.2	9.10	1.27	11.16	1.33	13.23	1.39	15.29	1.45	20.90	1.91	22.84	1.97	26.73	2.09
77.0	8.98	1.27	11.04	1.34	13.10	1.40	15.16	1.46	20.75	1.92	22.70	1.98	26.58	2.10
80.6	8.72	1.29	10.79	1.35	12.85	1.41	14.91	1.47	20.46	1.93	22.40	2.00	25.71	2.09

#### Symbols:

AFR	: Airflow rate	(m³/min.)
BF	: Bypass factor	
EWB	: Entering wet bulb temp.	(°C) / (°F)
EDB	: Entering dry bulb temp.	(°C) / (°F)
тс	: Total capacity	(kW) / (kBtu/h)
SHC	: Sensible heat capacity	(kW) / (kBtu/h)
ΡI	: Power input	(kW)

#### Notes:

- shows nominal (rated) capacities and power input.
   TC, PI and SHC must be calculated by interpolation using the figures in the above tables. (Figures out of the tables should not be used for calculation.)
   Capacities are based on the following conditions. Corresponding refrigerant piping length : 25 ft (7.5 m) Level difference : 0 ft (0 m)
   Airflow rate (AFR) and Bypass factor (BF) are tabulated above table.

C: 3D106255

#### 7.1 Capacity Correction Factor by the Length of Refrigerant Piping (Reference)

The cooling capacity and the heating capacity of the unit have to be corrected in accordance with the length of refrigerant piping — the distance between the indoor unit and the outdoor unit.

<--- line : cooling capacity> <--- line : heating capacity>

#### 7.1.1 09/12 Class



7.1.2 15/18 Class



Note: The graphs show the factor when additional refrigerant of the proper quantity is charged.

#### **Operation Limit** 8.

#### RX09/12/15/18QMVJU



- Cutting jumper 6 (J6) on the circuit board
   Cutting jumper 6 (J6) on the circuit board
   installing an air direction adjustment grille (wind baffle) (sold separately)
   : extend the operation range to 14°F (-20°C).

, 3D092209B

## 9. Sound Level

### 9.1 Measuring Location





2. The operation sound measuring method is based on JIS standard.

#### 9.2 Indoor Unit



OCTAVE BAND CENTER FREQUENCY (Hz)

#### 9.3 Outdoor Unit



## **10. Electric Characteristics**

Unit Con	nbination		Power Supply	Compressor	OFM		IFM			
Indoor Unit	Outdoor Unit	Hz - Volts	Voltage Range	MCA	MFA	RLA	W	FLA	W	FLA
FFQ09Q2VJU	RX09QMVJU	60 - 208	Max. 253 V	8.6	15	7.5	18	0.15	50	0.28
FFQ09Q2VJ0		60 - 230	Min. 187 V	0.0		7.5	10	0.15	50	0.20
FFQ12Q2VJU	Q2VJU RX12QMVJU	60 - 208	Max. 253 V	8.6	15	7.5	18	0.15	50	0.28
11 Q12Q2 V30		60 - 230	Min. 187 V							0.20
FFQ15Q2VJU	RX15QMVJU	60 - 208	Max. 253 V	9.1	15	8.0	59	0.39	50	0.28
1101302030	HX 15QIVIVJU	60 - 230	Min. 187 V	9.1	15			0.39	50	0.20
FFQ18Q2VJU	18Q2VJU RX18QMVJU		Max. 253 V	12.0	15	10.75	<u> </u>	0.46	50	0.28
11 @10@2730		60 - 230	Min. 187 V	12.0	15	10.75	69	0.46	50	0.20

#### Symbols:

MCA : Min. circuit amps (A)

MFA : Max. fuse amps (A)

RLA : Rated load amps (A)

- OFM : Outdoor fan motor
- IFM : Indoor fan motor
- W : Fan motor rated output (W)
- FLA : Full load amps (A)

#### Notes:

- 1. RLA is the max current that comes in cooling operation and heating operation.
- Maximum allowable voltage variation between phases is 2%.
   Select wire size based on the larger value of MCA.
- 4. Be sure to install a ground leak detector.

(This unit uses an inverter, which means that a ground leak detector capable of handling high harmonics must be used in order to prevent malfunctioning of the ground leak detector.)

3D106058A

## **11.Installation Manual**

## 11.1 Indoor Unit Contents

Safety Considerations	1						
Before Installation							
Accessories							
Choosing an Installation Site	4						
Indoor Unit Installation	6						
1. Relation of ceiling opening to unit and suspension bolt position	6						
2. Make the ceiling opening needed for installation where applicable (For existing ceilings)	7						
3. Installing the suspension bolts	7						
4. Installing the indoor unit	7						
5. Drain piping work	8						
6. Wiring	11						

Refrigerant Piping Work 14	
1. Flaring the pipe end14	
2. Refrigerant piping14	
Installation of the Decoration Panel16	
Field Settings16	
1. Setting air outlet direction16	
2. Setting for options16	
3. Setting air filter sign 16	
4. When implementing group control17	
5. 2 remote controllers (controlling 1 indoor unit	
by 2 remote controllers)17	
Trial Operation and Testing17	
1. Trial operation and testing17	
2. Test items	
3. How to diagnose for malfunction20	

## **Safety Considerations**

Read these **Safety Considerations for Installation** carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:

A DANGER ·······	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<u>∧</u> NOTE	Indicates situations that may result in equipment or property-damage accidents only.

#### A DANGER -

- Refrigerant gas is heavier than air and replaces oxygen. A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

#### 🕂 WARNING -

- Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

#### A CAUTION -

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. Your hands may suffer burns or frostbite if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to proper drainage. Improper drain piping may result in water leakage and property damage.
- Insulate piping to prevent condensation.
- · Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
- (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight -- R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter *Refrigerant Piping Work* and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors. This unit is for indoor use.
- Do not install the air conditioner or heat pump in the following locations:
- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen.
   Plastic parts may deteriorate and fall off or result in water leakage.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in

corroding copper pipes or soldered parts may result in refrigerant leakage.

- (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
- (d) Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

#### 

- The indoor unit should be positioned where the unit and inter-unit wires (outdoor to indoor) are at least 3.3ft (1m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 3.3ft (1m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.
# **Before Installation**

- Leave the unit inside its packaging until you reach the installation site. Where unpacking is unavoidable, use a sling of soft
  material or protective plates together with a rope when lifting, this to avoid damage or scratches to the unit.
   When unpacking the unit or when moving the unit after unpacking, be sure to lift the unit by holding on to the hanger bracket
  without exerting any pressure on other parts, especially on refrigerant piping, drain piping and other resin parts.
- Refer to the installation manual of the outdoor unit for items not described in this manual.
- Caution concerning refrigerant series R410A:
- The connectable outdoor units must be designed exclusively for R410A.

#### Precautions

- Do not install or operate the unit in places mentioned below.
- Places with mineral oil, or filled with oil vapor or spray like in kitchens. (Plastic parts may deteriorate.)
- Where corrosive gas like sulphurous gas exists. (Copper tubing and brazed spots may corrode.)
- Where volatile flammable gas like thinner or gasoline is used.
- Where machines generating electromagnetic waves exist. (Control system may malfunction.)
- Where the air contains high levels of salt such as near the ocean and where voltage fluctuates a lot (e.g. in factories). Also inside vehicles or vessels.
- When selecting the installation site, use the supplied template for installation.
- Do not install accessories on the casing directly. Drilling holes in the casing may damage electrical wires and consequently cause fire.

# Accessories

A Drain hose	1	B Clamp metal	1	© Washer for hanger bracket	8	D Clamp	7
E Template (cut out from upper part of packing)	1	(F) Screws (M5) (for template)	4	G Fitting insulation (for gas pipe)	1	(H) Fitting insulation (for liquid pipe)	1
③ Sealing pad (large)	1	(K) Sealing pad (medium A)	1	L Sealing pad (medium B)	1	M Sealing pad (small)	1
N Washer for conduit	1	P Operation manual	1	(a) Installation manual	1	(R) Warranty	1

#### **Optional Accessories**

• The optional decoration panel and remote controller are required for this indoor unit.

Table 1

Optional decoration panel					
Туре А	BYFQ60B3W1	Color: White			
Туре В	BYFQ60C2W1W	Color: White			
Туре В	BYFQ60C2W1S	Color: Silver			

• There are 2 types of remote controllers: wired and wireless. Select a remote controller from Table 2 according to customer request and install in an appropriate place.

#### Table 2

Remote controller type	Heat Pump type
Wired type	BRC1E73
Wireless type	BRC082A41W / BRC082A42W / BRC082A42S

• If you wish to use a remote controller that is not listed in Table 2, select a suitable remote controller after consulting catalogs and technical materials.

# **Choosing an Installation Site**

Hold the unit by the 4 hanger brackets when opening the box and moving it, and do not exert pressure on to any other part, piping (refrigerant, drain, etc.), or plastic parts.

If the temperature or humidity inside the ceiling might rise above 86°F (30°C) or RH 80%, respectively, add extra insulation to the unit.

Use polyethylene foam as insulation and make sure it is at least 3/8 inch (10mm) thick and fits inside the ceiling opening.

#### Select the air flow directions best suited to the room and point of installation.

For air discharge in 3 directions, it is necessary to make field settings by means of the remote controller and to close the air outlet (s).

#### Refer to the installation manual of the blocking pad kit (sold separately) and to "Field Settings" on page 16.

- · Before choosing the installation site, obtain user approval.
  - The indoor unit should be positioned in a place where:
  - 1) both the air inlet and air outlet are unobstructed,
  - 2) the unit is not exposed to direct sunlight,
  - 3) the unit is away from the source of heat or steam,
  - 4) there is no source of machine oil vapor (this may shorten the indoor unit service life),
  - 5) cool/warm air is circulated throughout the room,
  - 6) the unit is away from electronic ignition type fluorescent lamps (inverter or rapid start type) as they may affect the remote controller range,
  - 7) no laundry equipment is nearby,
  - 8) drainage can be performed without any problem,
  - 9) the weight of the indoor unit can be adequately supported,
- 10) the wall is not significantly tilted,
- 11) room can be left for installation and service work,
- 12) there is no risk of flammable gas leaking,
- 13) the required length of indoor-outdoor piping would not exceed the specified maximum length (see the installation manual that came with the outdoor unit for details).

# **Choosing an Installation Site**



unit:inch (mm)

• Leave 8 inch (200mm) or more space where marked with the \*, on sides where the air outlet is closed.

### Air flow direction

- The air direction shown is an example.
- Select the appropriate number of directions according to the shape of the room and the location of the unit. (Field settings have to be made using the remote controller and the outlet vents have to be shut off if 2 or 3 directions are selected. See the blocking pad kit (sold separately) installation manual for details.)



Use suspension bolts for installation. Check whether the ceiling is strong enough to support the weight of the unit or not. If there is a risk, reinforce the ceiling before installing the unit. (Installation pitch is marked on the template. Refer to it to check for points requiring reinforcing.)

# **Indoor Unit Installation**

## 1. Relation of ceiling opening to unit and suspension bolt position



## NOTE

- \*If the panel does not extend over the ceiling by this amount, supplement with extra ceiling material or restore the ceiling.
- Install the inspection opening on the electrical wiring box side where maintenance and inspection of the electrical wiring box and drain pump are easy.



# **Indoor Unit Installation**

# 2. Make the ceiling opening needed for installation where applicable (For existing ceilings)

- Refer to the (E) template for ceiling opening dimensions.
- Create the ceiling opening required for installation. From the side of the opening to the casing outlet, implement the
  refrigerant and drain piping and wiring for remote controller (unnecessary for wireless type) and wiring between units.
  Refer to each Drain piping work or Wiring section.
- After making an opening in the ceiling, it may be necessary to reinforce ceiling beams to keep the ceiling level and to prevent it from vibrating. Consult the builder for details.

# 3. Installing the suspension bolts

(Use either a M8-M10 size bolt or the equivalent) Use a hole-in anchor for existing ceilings, and a sunken insert, sunken anchor or other field supplied parts for new ceilings to reinforce the ceiling to bear the weight of the unit. Adjust clearance (2-4 inch (50-100mm)) from the ceiling before proceeding further.

· All the above parts are field supplied.

# 4. Installing the indoor unit

When installing optional accessories (except for the decoration panel), read also the installation manual of the optional accessories. Depending on the field conditions, it may be easier to install optional accessories before the indoor unit is installed. However, for existing ceilings, always install fresh air intake kit before installing the unit. As for the parts to be used for installation work, be sure to use the provided accessories and specified parts designated by Daikin.

### For new ceilings

1) Install the indoor unit temporarily.

• Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and (C) washer from the upper and lower sides of the hanger bracket.



- The center of the ceiling opening is indicated on the
   (E) template. This indication also indicates the center of the
   unit.
- The (E) template can be rotated by 90° to be able to indicate the correct dimensions on all 4 sides.
- After cutting the template from the packaging, attach the E template to the unit with F screws (×4) as shown in figure.
- Ceiling height is shown on the side of the (E) template. Adjust the height of the unit according to this indication.

#### **Ceiling work**

- 3) Adjust the unit to the right position for installation.
  - (Refer to 1. Relation of ceiling opening to unit and suspension bolt position.)



Installation Example

2-4 (50-100) Ceiling slab

unit:inch (mm)

Long nut or turn-buckle

Suspension bolt

False ceiling

Anchor





## 

If the unit is tilted against condensate flow, the float switch may malfunction and cause water to drip.

- 4) Check the unit is horizontally level.
- The indoor unit is equipped with a built-in drain pump and float switch. Verify that it is level by using a water level or a water-filled vinyl tube.
- 5) Remove the (E) template.



### For existing ceilings

- 1) Install the indoor unit temporarily.
- Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and (C) washer from the upper and lower sides of hanger bracket.

Securing the hanger bracket



2) Adjust the height and position of the unit.

(Refer to 1. Relation of ceiling opening to unit and suspension bolt position.)

3) Perform steps 4) in For new ceilings

# 5. Drain piping work

## CAUTION -

- Water pooling in the drainage piping can cause the drain to clog.
- Do not connect the drain piping directly to sewage pipes that smell of ammonia. The ammonia in the sewage might enter the indoor unit through the drain pipes and corrode the heat exchanger.
- · Keep in mind that the drain pipe becomes blocked if water collects on it.

#### 1. Install of drain piping

- Install the drain piping as shown in the figure and take measures against condensation. Improperly rigged piping could lead to leaks and eventually wet furniture and belongings.
- Keep piping as short as possible and slope it downwards at a gradient of at least 1/100 so that air may not remain trapped inside the pipe.
- Keep pipe size equal to or greater than that of the connecting pipe (vinyl pipe of nominal diameter 13/16 inch (20mm) and outer diameter 1 inch (26mm)).
- Push the supplied drain hose as far as possible over the drain socket.
- If the drain hose cannot be sufficiently set on a slope, refer to "Precautions for drain raising piping".
- To keep the drain hose from sagging, space hanger bracket every 40-60 inch (1000-1500mm).



# **Indoor Unit Installation**

- Tighten the (B) clamp metal as indicated in the illustration.
- After the testing of drain piping is finished, attach the drain (J) sealing pad (large) supplied with the unit over the uncovered part of the drain socket (= between drain hose and unit body).
- Wrap the supplied large sealing pad over the (B) clamp metal and (A) drain hose to insulate and fix it with clamps.
- Insulate the complete drain piping inside the building (field supply).
- If the drain hose cannot be sufficiently set on a slope, fit the hose with drain raising piping (field supply).

#### Precautions for drain raising piping

• Install the drain raising pipes at a height of less than H2.



• Install the drain raising pipes at a right angle to the indoor unit and no more than 11-3/4 inch (300mm) from the unit.

Drain socket



- To ensure no excessive pressure is applied to the included (A) drain hose, do not bend or twist the hose when installing as it could cause leakage.
- If converging multiple drain pipes, install according to the procedure shown below.



Select converging drain pipes with gauges is suitable for the operating capacity of the unit.



### 2. After piping work is finished, check if drainage flows smoothly

• Add approximately 1/4 gal of water slowly from the air outlet and check drainage flow.

### When electric wiring work is finished

• Check drainage flow during COOL operation, explained in "Trial operation and testing" on page 17.

When electric wiring work is not finished

### 

Electrical wiring work should be done by a certified electrician.

- If someone who does not have the proper qualifications performs the work, perform the following actions after the trial
  operation is complete.
- Remove the electrical wiring box cover (2 screws). Connect the single phase power supply (SINGLE PHASE 60 Hz 208/230V) to connections No.1 and No.2 on the terminal block for power supply. Do not connect to No.3 of the terminal block for power supply or the drain pump will not operate.
  - When carrying out wiring work around the electrical wiring box, make sure none of the connectors come undone. Be sure to attach the electrical wiring box cover before turning on the power.
- 2) After confirming drainage, turn off the power supply and remove the power supply wiring.
- 3) Attach the electrical wiring box cover as before.





# **Indoor Unit Installation**

# **6.** Wiring

Refer also to the installation manual for the outdoor unit.

### MARNING -

- Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
- Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.

## 

When connecting the connection wire to the terminal block using a single core wire, be sure to perform curling.
 Problems with the installation may cause heat and fires.



- When clamping wiring, use the included clamping material to prevent outside pressure being exerted on the wiring connections and clamp firmly. When doing the wiring, make sure the wiring is neat and does not cause the electrical wiring box cover to stick up, then close the cover firmly.
- Outside the unit, separate the low voltage wiring (remote controller wiring) and high voltage wiring (wiring between units, ground, and other power wiring) at least 2 in. so that they do not pass through the same place together. Proximity may cause electrical interference, malfunctions, and breakage.

### Tightening torque for the terminal blocks

- Use the correct screwdriver for tightening the terminal screws. If the blade of screwdriver is too small, the head of the screw might be damaged, and the screw will not be properly tightened.
- If the terminal screws are tightened too hard, screws might be damaged.
- Refer to the table below for the tightening torque of the terminal screws.

unit:	lbf •	• ft	(N	•	m)
-------	-------	------	----	---	----

	Tightening torque
Terminal block for remote controller (6P)	0.58 - 0.72 (0.79 - 0.98)
Terminal block for power supply (4P)	0.87 - 1.06 (1.18 - 1.44)

#### Precautions for power supply wiring

Use a round crimp-style terminal for connection to the terminal block for power supply. If it cannot be used due to unavoidable reasons, be sure to observe the following instructions:

• In wiring, make certain that prescribed wires are used, carry out complete connections, and fix the wires so that external forces are not applied to the terminals.



- Use copper wire only.
- For electric wiring work, refer also to "Wiring diagram label" attached to the electrical wiring box cover.
- For remote controller wiring details, refer to the installation manual attached to the remote controller.
- A circuit breaker capable of shutting down power supply to the entire system must be installed.
- · Specifications for field wire

The remote controller wiring should be procured locally.

## Table 3

	Wire	Size	Length (ft.)
Wiring between units	Wire size and length must comply with local codes.	-	-
Remote controller wiring	Sheathed (2 wire)	AWG 18 - 16	Max.1640*
Wiring to ground terminal	Wire size and length must comply with local codes.	_	_

\* This will be the total extended length in the system when doing group control.

### **CAUTION** -

- Arrange the wires and fix a cover firmly so that the cover does not float during wiring work.
- Do not clamp remote controller wiring together with wiring between units. Doing so may cause malfunction.
- Remote controller wiring and wiring between units should be located at least 2 inch (50mm) from other electric wires. Not following this guideline may result in malfunction due to electrical noise.

# **Indoor Unit Installation**

#### Connection of wiring between units, ground wire and remote controller wiring

Wiring between units and ground wire

1) Remove the electrical wiring box cover (2 screws)



2) Insert the wires including the ground wire into the conduit, and secure the conduit to the hole in the electrical wiring box using a lock nut and the (N) washer for conduit, as shown in the illustration.



- 3) Connect the ground wire to the corresponding terminals.
- 4) Match wire colors with terminal numbers on the terminal block for power supply of indoor and outdoor unit and firmly secure the wires in the corresponding terminals with screws.
- 5) In doing this, pull the wires inside through the hole and fix the wires securely with the included (D) clamp.
- 6) Give enough slack to the wires between the (D) clamp and terminal block for power supply.
- 7) Pull the wires inside through the hole and connect them to the terminal block for remote controller (no polarity). Securely fix the remote controller wiring with the included (D) clamp.
- 8) Give enough slack to the wires between the (D) clamp and the terminal block for remote controller.
- 9) Attach the electrical wiring box cover as before.
- 10) After all wiring connections are done, fill in any gaps in the casing wiring holes with putty or (M) sealing pad (small) thus to prevent small animals or dirt from entering the unit from outside and causing short circuits in the electrical wiring box.



# **Refrigerant Piping Work**

Refer also to the installation manual for the outdoor unit.

### WARNING .

- · Do not apply mineral oil on flared part.
- Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- Never use piping which has been used for previous installations. Only use parts which are delivered with the unit.
- Never install a dryer to this R410A unit in order to guarantee its service life.
- The drying material may dissolve and damage the system.
- Incomplete flaring may result in refrigerant gas leakage

Execute thermal insulation work completely on both sides of the gas and the liquid piping. Otherwise, a water leakage can result sometimes.

Be sure to use insulation designed for use with HVAC systems.

Also, in cases where the temperature and humidity of the refrigerant piping sections might exceed 86°F (30°C) or RH80%, reinforce the refrigerant insulation. (13/16 inch (20mm) or thicker) Condensation may form on the surface of the insulating material.

Before refrigerant piping work, check which type of refrigerant is used. Proper operation is not possible if the types of refrigerant are not the same.

## **1.** Flaring the pipe end

- 1) Cut the pipe end with a pipe cutter.
- 2) Remove burrs with the cut surface facing downward
- so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.







# 2. Refrigerant piping

## 

Liquid side

O.D. 1/4 inch (6.4mm)

- Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
- Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a torque wrench.

10-1/2-12-3/4lbf • ft (14.2-17.2N • m)



Split Type Air Conditioners FFQ-Q Series

# **Refrigerant Piping Work**

### Cautions on piping handling

- Protect the open end of the pipe from dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.



#### Selection of copper and heat insulation materials

When using commercial copper pipes and fittings, observe the following:

- Insulation material: Polyethylene foam Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))
- Be sure to use insulation that is designed for use with HVAC Systems.
- ACR Copper pipe only.



• Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness
Casaida	O.D. 3/8 inch (9.5mm)	1-3/16 inch (30mm) or more		I.D. 15/32-19/32 inch (12-15mm)	
Gas side	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 9/16-5/8 inch (14-16mm)	13/32 inch (10mm) Min.
Liquid side	O.D. 1/4 inch (6.4mm)	1-3/16 inch (30mm) or more		I.D. 5/16-13/32 inch (8-10mm)	

· Use separate thermal insulation pipes for gas and liquid refrigerant pipes.

• Make absolutely sure to execute thermal insulation works on the pipe-connecting section, after checking for gas leakage, by thoroughly studying the following figures and using the included thermal insulating materials (G) fitting insulation and (H) fitting insulation. Fasten both ends with the (D) clamps.

#### Piping insulation procedure



## 

Be sure to insulate any field piping all the way to the piping connection inside the unit. Any exposed piping may cause condensation or burns if touched.

# **Installation of the Decoration Panel**

With the wireless remote controller, field setting and trial operation cannot be performed without attaching the decoration panel.

Read "**Trial Operation and Testing**" before making a trial operation without attaching the decoration panel. Refer to the installation manual attached to the decoration panel.

After installing the decoration panel, ensure that there is no space between the unit body and decoration panel.

# **Field Settings**

## 

When performing field setting or trial operation without attaching the decoration panel, do not touch the drain pump. This may cause electric shock.

Field Settings

Unit No

0-01

Mod 20

2-02

6

14

3-01

**4\$** 

15-

1-01

• Make sure the electrical wiring box cover is closed on the indoor and outdoor units.

- Field settings must be made from the remote controller and in accordance with installation conditions.
- Setting can be made by changing the "Mode No.", "FIRST CODE NO." and "SECOND CODE NO.".
- The "Field Settings" included with the remote control lists the order of the settings and method of operation.

# **1.** Setting air outlet direction

• For changing air outlet direction (2 or 3 directions), refer to the installation manual attached to the blocking pad kit (sold separately) or the service manual.

(SECOND CODE NO. is factory set to "01" for air outlet in 4 directions.)

## **2.** Setting for options

• For settings for options, see the installation manual provided with the option.

## **3.** Setting air filter sign

- · Remote controllers are equipped with liquid crystal display air filter signs to display the time to clean air filters.
- Change the SECOND CODE NO. depending on the amount of dirt or dust in the room. (SECOND CODE NO. is factory set to "01" for air filter contamination-light.)

JE NO. IS I	actory set to	UT for al	r niter contai	nination-light.)	

Setting	Time until AIR FILTER CLEANING TIME INDICATOR lamp lights up (Long life type)	Mode No.	FIRST CODE NO.	SECOND CODE NO.
Air filter contamination-light	Approx. 2500 hrs		0	01
Air filter contamination-heavy	Approx. 1250 hrs	10 (20)	0	02
Display on		10 (20)	2	01
Display off	_		3	02

#### When using wireless remote controllers

• When using the wireless remote controllers, wireless remote controller address setting is necessary. Refer to the installation manual attached to the wireless remote controller.

1	n
	0

# **Field Settings**

## 4. When implementing group control

- When using as a pair unit, you may control up to 16 units with the remote controller.
- In this case, all the indoor units in the group will operate in accordance with the group control remote controller.
- Select a remote controller which matches as many of the functions (swing flap, etc.) in the group as possible.

#### Wiring Method (Refer to "6. Wiring" on page 11.)

1) Remove the electrical wiring box cover.



 Cross-wire the terminal block for remote controller (P1, P2) inside the electrical wiring box. (There is no polarity.) (Refer to Table 3 in "6. Wiring" on page 12)

## 5. 2 remote controllers (controlling 1 indoor unit by 2 remote controllers)

- When using 2 remote controllers, one must be set to "MAIN" and the other to "SUB".
- Wiring Method (Refer to "6. Wiring" on page11.)
- 1) Remove the electrical wiring box cover.
- 2) Add remote controller 2 to the terminal block for remote controller (P1, P2) in the electrical wiring box. (There is no polarity.) (Refer to Table 3 in "6. Wiring" on page 12)

# **Trial Operation and Testing**

## 

When performing field settings or trial operation without attaching the decoration panel, do not touch the drain pump. This may cause electric shock.

• After finishing the construction of refrigerant piping, drain piping, and electric wiring, conduct trial operation accordingly to protect the unit.

# **1.** Trial operation and testing

Make sure to install the decoration panel before carrying out trial operation if the wireless remote controller is used.

- Trial operation should be carried out in either COOL or HEAT operation.
- 1-1. Measure the supply voltage and make sure that it is within the specified range.
- 1-2. In COOL operation, select the lowest programmable temperature; in HEAT operation, select the highest programmable temperature.
- 1-3. Carry out the trial operation following the instructions in the operation manual to ensure that all functions and parts, such as the movement of the louvers, are working properly.

• To protect the air conditioner, restart operation is disabled for 3 minutes after the system has been turned off.

- 1-4. After trial operation is complete, set the temperature to a normal level (78°F to 82°F (26°C to 28°C) in COOL operation, 68°F to 75°F (20°C to 24°C) in HEAT operation).
- When operating the air conditioner in COOL operation in winter, or HEAT operation in summer, set it to the trial operation mode using the following method.

Refer to **For wired remote controller** on page 18.

Refer to For wireless remote controller on page 19.



## For wired remote controller

- 1) Set to COOL or HEAT operation using the remote controller.
- 2) Press and hold Cancel button for 4 seconds or longer. Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and "Test Operation" is displayed at the bottom.
- Press On/Off button within 10 seconds, and the test operation starts.

Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool/heat regardless of the temperature setpoint and room temperature.

- In the case of above-mentioned procedures 3) and 4) in reverse order, test operation can start as well.
- 5) Press Menu/OK button in the basic screen. Main menu is displayed.
- 6) Select Air Flow Direction in the main menu and check that air flow direction is actuated according to the setting. For operation of air flow direction setting, see the operation manual.
- 7) After the operation of air flow direction is confirmed, press Menu/OK button. Basic screen returns.
- 8) Press and hold Cancel button for 4 seconds or longer in the basic screen.

Service settings menu is displayed.

- 9) Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and normal operation is conducted.
- Test operation will stop automatically after 15-30 minutes. To stop the operation, press On/Off button.
- 10) If the decoration panel has not been installed, turn off the power after the test operation.



# **Trial Operation and Testing**

### For wireless remote controller

1) Press and select the COOL or HEAT operation.

Press twice. "Test" is displayed.

UON∕OFF

3) Press (iii) within 10 seconds, and the test operation starts.

Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool/heat regardless of the temperature setpoint and room temperature.

- In the case of above-mentioned procedures 1) and 2) in reverse order, test operation can start as well.
- Test operation will stop automatically after 15 30 minutes. To stop the operation, press
- Some of the functions cannot be used in the test operation mode.

### Precautions

1) Refer to "3. How to diagnose for malfunction" if the unit does not operate properly.

## **2.** Test items

Test items	Symptom	Check
Indoor and outdoor units are installed securely.	Fall, vibration, noise	
Is the outdoor unit fully installed?	No operation or burn damage	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
Does the power supply voltage correspond to that shown on the name plate?	No operation or burn damage	
Only specified wires are used for all wiring, and all wires are connected correctly.	No operation or burn damage	
System is properly grounded.	Electrical leakage	
Is wiring size according to specifications?	No operation or burn damage	
Is something blocking the air outlet or inlet of either the indoor or outdoor units?	Incomplete cooling/heating function	
Are refrigerant piping length and additional refrigerant charge noted down?	The refrigerant charge in the system is not clear	
Pipes and wires are connected to the corresponding connection ports / terminal blocks for the connected unit.	No cooling/heating	
Stop valves are opened.	Incomplete cooling/heating function	
Check that the connector of the lead wires of the decoration panel is connected securely.	Louvers do not move	
Indoor unit properly receives wireless remote control commands.	No operation	

#### Items to be checked at time of delivery

Also review the "Precautions" on page 3

Test items	
Are the electrical wiring box cover, air filter, suction grille attached?	
Did you explain about operations while showing the operation manual to your customer?	
Did you hand the operation manual over to your customer?	

### Points for explanation about operations

The items with  $\Delta$  WARNING and  $\Delta$  CAUTION marks in the operation manual are the items pertaining to possibilities for bodily injury and material damage in addition to the general usage of the product. Accordingly, it is necessary that you make a full explanation about the described contents and also ask your customers to read the operation manual.

#### Note to the installer

Be sure to instruct customers how to properly operate the unit (especially cleaning the filter, operating different functions, and adjusting the temperature) by having them carry out operations while looking at the manual.

## **3.** How to diagnose for malfunction

• If the air conditioner does not operate normally after installing the air conditioner, a malfunction shown in the table below may happen.

Wired remote controller display	Description	
	Power outage, power voltage error or open-phase	
No display	Incorrect wiring (between indoor and outdoor units)	
	Indoor PC-board assembly failure	
	Remote controller wiring not connected	
	Remote controller failure	
	Open fuse or tripped circuit breaker (outdoor unit)	
"Checking the connection. Please	e Indoor PC-board assembly failure	
stand by." *	Wrong wiring (between indoor and outdoor units)	

\* "Checking the connection. Please stand by" will be displayed for up to 90 seconds following the application of power to the indoor unit. This is normal and does not indicate a malfunction.

Diagnose with the display on the liquid crystal display remote controller.

#### With the wired remote controller

When the operation stops due to a malfunction, operation lamp blinks, and the malfunction code is indicated on the liquid crystal display. In such a case, diagnose the fault contents by referring to **Error History** in the service settings menu. In the case of group control, the unit No. is displayed so that the indoor unit with the trouble can be identified.

#### With the wireless remote controller

(Refer also to the operation manual attached to the wireless remote controller)

When the operation stops due to a malfunction the display on the indoor unit blinks. In such a case, diagnose the fault contents with the error code which can be found by following procedures.

1) Press the INSPECTION/TEST OPERATION button, " binks." is displayed and " 0 " blinks.

2) Press the TEMPERATURE SETTING button and find the unit No. which stopped due to trouble.
---

Number of beeps	3 short beeps	Perform all the following operations
	1 short beep	Perform (3) and (6)
	1 long beep	No trouble

3) Press the OPERATION MODE SELECTOR button and upper figure of the error code blinks.

4) Continue pressing the TEMPERATURE SETTING button until it makes 2 short beeps and find the upper code.

5) Press the OPERATION MODE SELECTOR button and lower figure of the error code blinks.

6) Continue pressing the TEMPERATURE SETTING button until it makes a long beep and find the lower code.

•A long beep indicate the error code.

# 11.2 <BYFQ60B3W1> Decoration Panel





The English text is the original instruction. Other languages are translations of the original instructions.

Read this manual attentively before installation. Do not throw it away. Keep it in your files for future reference.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin that are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information.

### **Before installation**

Leave the unit inside its packaging until you reach the installation site.



Cut off the main power before opening the grille.

Refer to the installation manual of the indoor unit for items not described in this manual.

NOTE To the installer Be sure to instruct t

Be sure to instruct the customer how to properly operate the system showing him or her the operation manual of the indoor unit.

#### Accessories

Installation manual		Wire harness	
Screws (4x)	ALL A	Temporary latch	$\square$
Fibre glass tube		Tie wrap (7x)	

### Preparation before installation

For this unit, you are able to select air flow directions. To discharge air in 2 or 3 directions, it is necessary to purchase the optional blocking pad kit for sealing air discharge outlets.

#### Handling of the decoration panel

To prevent any damage to the decoration panel, take care of the following:

- Never place the decoration panel facing down.
- Never let the decoration panel lean against a wall.
- Never place the decoration panel on a sharp or projecting object.
- Never touch or put pressure on the swing flap in order to prevent malfunction of the swing flap.

#### Preparing the decoration panel for installation

- 1 Remove the suction grille from the decoration panel.
  - 1 Decoration panel
  - 2 Suction grille
  - 3 Lever
  - Push the suction grille lever (3) inward and open the suction grille (2). (See figure 1)
  - Detach the suction grille from the decoration panel by lifting the suction grille up approximately 45 degrees (A) until the position is reached on which removal of the suction grille is possible (B). (See figure 2)

# Installation of the decoration panel to the indoor unit

Refer to the installation manual of the indoor unit for details on installing the indoor unit.

Installation and wiring of the decoration panel.



For installation and wiring of the decoration panel see figure 6.

	1	Screws
Α	1	Tie wrap
	2	Latch
		Socket X36
		Socket X80
в	1	Tie wrap
D	2	Latch
С	1	Tie wrap
U	2	Tie wrap
	3	Fibre glass tube
	4	Tie wrap

- 1 Attach wire harness from panel accessory set to unit and to other wire harness by two tie wraps (1). (See figure 6-C)
- 2 Lead the wire harness through unit's groove and attach it by tie wrap (1) to the rest of wire harnesses. (See figure 6-B)
- 3 Open two latches (2) and insert the wire harness so it is in the same condition as other wire harnesses. (See figure 6-A and 6-B)
- 4 Insert wire harness into switch box using lower hole, insert two connectors into proper sockets (X36, X80) and secure the wire harness by tie wrap (1). (See figure 6-A)
- 5 Provisionally tighten the 2 supplied screws (1) approximately 5 mm (0.2 in) into the indoor unit as marked in figure. (See figure 6)

- 6 Attach latch (2) from panel accessory set to unit according to figure 3. Then turn this latch up. (See figure 3)
- 7 Slide the panel over the provisionally tightened screws matching the 2 attachment holes (  $\bigcap$  ).
- 8 Turn decoration panel lever (1) 90 degrees and then turn temporary latch (2) down to secure panel in temporary position. (See figure 3)
- 9 Attach remaining screws and tighten all 4 screws until the thickness of the sealing material between the decoration panel and the indoor unit reduces to 6-8 mm. (See figure 4)
  - 1 Indoor unit
  - 2 Ceiling
  - 3 Sealing material
  - 4 Decoration panel
  - 5 Air outlet
- 10 Pull the fibre glass tube (3) over decoration panel wire harness. Then connect both wire harnesses together and move the fibre glass tube over this connection. Secure the fiber glass tube by two tie wraps (2) according to figure 6-C. Then attach decoration panel wire harness to unit by tie wrap (4). (See figure 6-C)



Make sure that the swing flap motor lead wire is not caught between the indoor unit and the decoration panel and inbetween the electric component box lid.

Precautions

- Improper tightening of the screws (See figure 5) may cause air to leak into the unit and between the ceiling and the decoration panel (1), resulting in formation of contamination (2) and dew (3).
- If there is a gap remaining between the ceiling and the decoration panel after tightening the screws, re-adjust the indoor unit body height. The indoor unit must be kept leveled and the drain piping kept unaffected.

### Installation of the suction grille

Install the suction grille by reversing the procedure shown in "Preparing the decoration panel for installation" on page 1.

- The suction grille may be installed in 4 directions by simply turning it 90 degrees.
- Change the direction when adjusting the direction of the suction grille of multiple units or to comply with the demands of the customer.

NOTE Be careful not to get the swing flap motor lead wire get caught when installing the suction grille.

# 11.3 <BYFQ60C2W1W(S)> Decoration Panel



A

The English text is the original instruction. Other languages are translations of the original instructions.

Read this manual attentively before installation. Do not throw it away. Keep it in your files for future reference.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin that are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information.

### **Before installation**

Leave the unit inside its packaging until you reach the installation site.



Cut off the main power before opening the grille.

 Refer to the installation manual of the indoor unit for items not described in this manual.

NOTE To the installer

Be sure to instruct the customer how to properly operate the system showing him or her the operation manual of the indoor unit.

#### Accessories

e e

Installation manual	
Screws (4x)	ALL
Grille hinge (2x)	(T)

### Preparation before installation

For this unit, you are able to select air flow directions. To discharge air in 2 or 3 directions, it is necessary to purchase the optional blocking pad kit for sealing air discharge outlets.

#### Handling of the decoration panel

To prevent any damage to the decoration panel, take care of the following:

- Never place the decoration panel facing down.
- Never let the decoration panel lean against a wall.
- Never place the decoration panel on a sharp or projecting object.
- Never touch or put pressure on the swing flap in order to prevent malfunction of the swing flap.

#### Preparing the decoration panel for installation

- 1 Remove the suction grille from the decoration panel.
  - 1 Decoration panel
  - 2 Suction grille
  - 3 Lever
  - Remove the transporting tape from the decoration panel suction grille and flaps.
  - Push the suction grille lever (3) inward and open the suction grille (2). (See figure 1)
  - Detach the suction grille from the decoration panel by lifting the suction grille up approximately 90 degrees (A) until the position is reached on which removal of the suction grille is possible (B). (See figure 2)

# Installation of the decoration panel to the indoor unit

Refer to the installation manual of the indoor unit for details on installing the indoor unit.

Install the decoration panel (See figure 3)

1 Temporary latch

- 2 Hook
- 3 Swing flap motor lead wire
- 4 Piping area
- 5 Piping side mark
- 6 Drain area
- 7 Drain side mark
- 1 Hold the decoration panel against the indoor unit by matching the piping side and drain side marks on the decoration panel with the position of the piping area and drain area of the indoor unit.
- 2 Turn 2 panel temporary latches up into the hooks of the indoor unit so the decoration panel is temporarily fixed to the indoor unit. (See figure 3)
- 3 Make sure that the swing flap motor lead wire isn't caught between the decoration panel and the indoor unit.
- 4 Attach 4 supplied screws and check whether the decoration panel is properly aligned with the indoor unit and ceiling.
- 5 Tighten all 4 screws until the thickness between of the sealing material between the decoration panel and the indoor unit reduces to 4-8 mm. (See figure 4)
  - 1 Indoor unit
  - 2 Ceiling
  - 3 Sealing material
  - 4 Decoration panel
  - 5 Air outlet

#### Precautions

- Improper tightening of the screws (See figure 5) may cause air to leak into the unit and between the ceiling and the decoration panel (1), resulting in formation of contamination (2) and dew (3).
- If there is a gap remaining between the ceiling and the decoration panel after tightening the screws, re-adjust the indoor unit body height. The indoor unit must be kept leveled and the drain piping kept unaffected.
- 2 Wiring of the decoration panel (See figure 6)



Make sure to turn off the power supply before wiring!

- 1 Screws (2)
- 2 Switch box
- 3 Swing flap motor lead wire
- 4 Swing flap motor lead wire fixed by tie wrap to the rest of the wires (See detail in figure 6)
- 5 Connector of the indoor unit PCB (X36A)
- 6 Tie wrap
- Remove the electric components box lid. Loosen 2 screws and slide the electric components box lid in the direction of the arrows.
- 2 Securely connect the connector of swing flap motor lead wire installed on the decoration panel. Attach the swing flap motor lead wire to the rest of the wires firmly by tie wrap (from indoor unit accessory set). (See figure 6)
- 3 Replace the electric components box lid reversing the procedure to remove it.



Make sure that the swing flap motor lead wire is not caught between the indoor unit and the decoration panel and inbetween the electric component box lid.

# Installation of the suction grille to decoration panel

Install the suction grille (See figure 7)

- 1 Decoration panel
- 2 Suction grille
- 3 Suction grille hinge (attached to decoration panel)
- 1 Remove the transportation tape which is securing 2 suction grille hinges in place.
- 2 Attach the suction grille to hinges by pressing the hinge and inserting both ends of hinge to holes on the suction grille. (See figure 7)
- 3 Make sure that the suction grille is attached to the decoration panel properly by 2 hinges.
- 4 Close the suction grille by reversing the procedure shown in "Preparing the decoration panel for installation" on page 1.
- The suction grille may be installed in 4 directions by simply turning it 90 degrees.
- Change the direction when adjusting the direction of the suction grille of multiple units or to comply with the demands of the customer.

4P340850-1B

# 11.4 <BRC1E73> Wired Remote Controller

# 1. Safety Considerations

The original instructions are written in English. All other languages are translations of the original instructions.

All phases of the field-installation, including, but not limited to, electrical, piping, safety, etc. must be in accordance with manufacturer's instructions and must comply with national, state, provincial and local codes.

Read these SAFETY CONSIDERATIONS carefully before installing the remote controller.

After completing the installation, ensure that the remote controller operates properly during the startup operation.

Train the customer to operate and maintain the remote controller. Inform customers that they should store this Installation Manual with the Operation Manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in electrical shock, fire, or explosion.

Meanings of WARNING, CAUTION, and NOTE Symbols.

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
Indicates situations that may result in equipment or property-damage accidents only.

# 

Only qualified personnel must carry out the installation work.

Consult your Daikin dealer regarding relocation and reinstallation of the remote controller. Improper installation work may result in electric shocks or fire.

Electrical work must be performed in accordance with relevant local and national regulations and with instructions in this installation manual.

Improper installation may cause electrical shocks or fire.

Use only specified accessories and parts for installation work.

Failure to use specified parts may result in electric shocks, fire, or the unit falling.

Do not disassemble, reconstruct, or repair.

Electric shock or fire may occur.

Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires.

Improper connections or installation may result in fire.

Before touching electrical parts, confirm the power-off to the unit.

Keep water out of the remote controller.
To avoid electric shock due to entry of water or insects, fill the wiring through-hole with putty.
Do not wash the remote controller with water as it may result in electrical shocks or fire.
Do not touch the remote controller buttons with wet fingers.
Touching the buttons with wet fingers can cause an electric shock.
Do not install the remote controller in the following locations:
(a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen.
Plastic parts may deteriorate.
(b) Where corrosive gas, such as sulfurous acid gas, is produced.
(c) Near machinery emitting electromagnetic waves.
Electromagnetic waves may disturb the operation of the control system and cause the unit to
malfunction.
(d) Where flammable gas may leak, where there is carbon fiber or ignitable dust suspensions in the
air, or where volatile flammables such as thinner or gasoline are handled.
Operating the unit in such conditions can cause a fire.
(e) High temperature area or direct flame.
Overheating and/or fire can occur.
(f) Moist area, where there is exposure to water. If water enters the inside of the remote controller, it may cause electric shock and electrical components may fail.
Å NOTE
Install the control wires for the indoor and the remote controller at least 3.5 feet (1 meter) away from
televisions or radios to prevent image interference or noise. Depending on the radio waves, a
distance of 3.5 feet (1 meter) may not be sufficient to eliminate the noise.
When remote controller's temperature sensor is used, select the installation location as per the
following:
• A place where average temperature in the room can be detected

- A place where average temperature in the room can be detected.
- A place where it is not exposed to direct sunlight.
- A place where it is far away from any heat source.
- A place where it is not affected directly by outside air.

# 2. Accessories

The following accessories are included.

Drywall screw	Drywall anchor	Wire tie	Operation manual	Installation manual	Wiring retainer
O.	ALL COLOR	A A A A A A A A A A A A A A A A A A A			
(2 pcs.)	(2 pcs.)	(1 pc.)	(1 pc.)	(1 pc.)	(1 pc.)

# 3. Remote Controller Installation Procedure

3-1 Determine where to install the remote controller.

Make sure to follow the Safety Considerations when determining the location.

3-2 If the control wire for the remote controller is to be routed from the rear, consider the location of the access hole in the lower case for making a hole in the wall.



## 3-3 Remove upper case.

Insert a screwdriver in the recess of lower case to remove the upper case (2 points).



- 3-4 Determine the location where the wiring will enter the remote controller (back, left side, top left, top center).
  - 3-4-1 Back outlet



Cut off resin area (notched area).

## 3-4-3 Top left outlet



Cut the plastic at the notched area and remove any remaining burrs.

3-4-2 Left outlet



Cut the plastic at the notched area and remove any remaining burrs.

## **3-4-4 Top center outlet**



Cut the plastic at the notched area and remove any remaining burrs.

## 3-5 Install wiring.

# - 🗥 NOTE -

- 1. Switch box and control wiring are filed supplied.
- 2. Do not touch the remote controller printed-circuit board.

### Wiring Specifications

Wiring Type	Non-shielded, 2-conductor, stranded copper wire
Wiring Size	AWG-18
Wiring Length	Maximum 1640 feet (500 m)



Prepare the wiring for connection to the remote controller following these instructions:

Length of jacket to be removed:

- Approx. 6 inch (150 mm) for top left outlet
- Approx. 8 inch (200 mm) for top center outlet

Connect the terminals (P/P1, N/P2) of the remote controller to the terminals (P1, P2) of the indoor unit. (P1 and P2 are not polarity sensitive.)

### 3-5-1 Back outlet



## 3-5-2 Left outlet



## 3-5-3 Top left outlet



## 3-5-4 Top center outlet



## — 🗥 NOTE -

• To prevent electrical noise and possible communication errors, avoid installing the remote controller wiring parallel to or in the vicinity of line voltage circuits.

## 3-6 Installation procedure for the lower case.

When wiring the remote controller through the top center or rear access points, attachment of the wire to the lower case is required before it is wall mounted. Closely follow the wiring procedures.

### 3-6-1 Wall installation

Secure by using furnished drywall anchors and screws (2 pcs.).



## 3-6-2 Switch box installation

Secure by using field supplied machine screws (2 pcs.).







# 3-7 Install the upper case.

- Align the upper case with tabs of the lower case (6 points), insert and install the upper case.
- Install the wiring with care to prevent pinching.
- Peel off the protective membrane which overlays the upper case.



# 4. Functions and Menu Items of Remote Controller Buttons

## 4-1 Functions and menu items



Language

\*Depending on connected model

### (7) Left button ◀

- Used to highlight items to the left of the currently selected item.
- Display contents are changed to previous screen per page.

#### (8) On/Off button

Press once to operate, and press once again to stop.

### (9) Operation lamp

Green lamp lights up during operation. The lamp will flash if a malfunction occurs.

#### (10) Cancel button

- Used to return to the previous screen.
- Press and hold this button for 4 seconds or longer to display service settings menu.

### (11) LCD (with backlight)

The backlight will illuminate for approximately 30 seconds by pressing any operation button.

#### Service Settings menu

- Test Operation Maintenance Contact Field Settings \*Energy Saving Options Prohibit Function Min Setpoints Differential \*Outdoor unit AirNet Address Error History \*Indoor Unit Status \*Outdoor Unit Status Forced Fan ON Switch Main Sub Controller Filter Indicator \*Brush/Filter Ind.
- \*Disable Filter Auto Clean

\*Depending on connected model

## 

- Operate the button while the backlight is illuminated.
- When one indoor unit is controlled by two remote controllers (main / sub) only the first controller to be accessed by the user will illuminate it's backlight.

## 4-2 Button menu display descriptions

### <Service settings menu screen>



# 5. Power-on

- Check for completion of indoor/outdoor unit wiring.
- Ensure that covers have been replaced on electrical component boxes for both indoor and outdoor units prior to restoring power.



NOTE
 When selecting a different language, refer to Chapter 12. Language.
 (See page 21.)

# 6. Field Settings

- 6-1 Press and hold Cancel button for 4 seconds or longer. Service settings menu is displayed.
- **6-2** Select **Field Settings** in the Service Settings menu, and press **Menu/OK** button. Field settings screen is displayed.
- **6-3** Highlight the mode, and select desired "Mode No." by using ▲▼ (Up/Down) button.
- 6-4 In the case of setting per indoor unit during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select "Indoor unit No." to be set by using ▲▼ (Up/Down) button. (In the case of group setting, this operation is not needed.)

In the case of individual setting per indoor unit, current settings are displayed. And, SECOND CODE NO. " - " means no function.

6-3

6-4

6-5

6-5 Highlight SECOND CODE NO. of the FIRST CODE NO. to be changed, and select desired "SECOND CODE NO." by using ▲▼ (Up/Down) button. Multiple identical mode number settings are available.

In the case of setting for all indoor units in the remote control group, available SECOND CODE NO. is displayed as " \* " which means it can be changed. When SECOND CODE NO. is displayed as " - ", there is no function.


- **6-6** Press Menu/OK button. Setting confirmation screen is displayed.
- **6-7** Select Yes and press Menu/OK button. Setting details are determined and field settings screen returns.
- 6-8 In the case of multiple setting changes, repeat "6-3" to "6-7".
- **6-9** After all setting changes are completed, press **Cancel** button twice.
- 6-10 Backlight goes out, and [Checking the connection. Please stand by.] is displayed for initialization. After the initialization, the basic screen returns.



- Installation of optional accessories on the indoor unit may require changes to field settings. See the manual of the optional accessory.
- For field setting details related to the indoor unit, see installation manual shipped with the indoor unit.

Mode No.	First Code	Description	Second Code No. (Note 2) (Items in bold are factory default settings)						
(Note 1)			01	01 02		04			
10 (20)	2	Priority of thermistor sensors for space temperature control	The return air thermistor is primary and the remote controller thermistor is secondary.	The remote controller thermistor is not utilized. Only the return air thermistor will be utilized.	Only the remote controller thermistor will be utilized.				
	5	Room temperature value reported to multizone controllers	Return air thermistor	Thermistor designated by 10-2 above (Note 3)					
12 (22)	2	Thermo-on/off deadband (Note 4)	2F (1C)	1F (0.5C)					
1c	1	Thermistor sensor for auto changeover and setback control by the remote controller	Utilize the return air thermistor	Utilize the remote controller thermistor					
	3	Access permission level setting	Level 2	Level 3					
1e	2	Setback availability	N/A	Heat only	Cool only	Cool/Heat			

- Notes) 1. Field settings are normally applied to the entire remote control group, however if individual indoor units in the remote control group require specific settings or for confirmation that settings have been established, utilize the mode number in parenthesis.
  - 2. Any features not supported by the connected indoor unit will not be displayed.
  - 3. When mode 10-2-01 is selected, only the return air temperature value is reported to the multizone controller.
  - 4. The actual default deadband value will depend upon the indoor unit model.

## 7. Test Operation

## Also see installation manuals furnished with the indoor unit and the outdoor unit.

- Verify that the wiring of the indoor unit and the outdoor unit is completed.
- Ensure that covers have been replaced on electrical component boxes for both indoor and outdoor units prior to restoring power.
- After refrigerant piping, drain piping and electric wiring are completed, clean inside of the indoor unit and decorative panel.
- Perform the test operation according to following procedure.
- To protect the compressor, apply power to the outdoor unit at least 6 hours prior to test operation.
- Set the remote controller display mode to standard or detailed display mode. Refer to Operation Manual for the setting method.

### Notes for backlight -

- The backlight will be ON for 30 seconds by pressing any button.
- The initial push of the button will only turn on the backlight. While the backlight is turned on, the buttons assigned functionality will be available.
- **7-1** Set the operation mode to cooling by using the remote controller.
- **7-2** Press and hold **Cancel** button for 4 seconds or longer. Service settings menu is displayed.
- **7-3** Select **Test Operation** in the service settings menu, and press **Menu/OK** button. Basic screen returns and message "Test Operation" is displayed at the bottom.







- **7-4** Press **On/Off** button within 10 seconds, and the test operation starts. Monitor the operation of the indoor unit for a minimum of 10 minutes. During test operation, the indoor unit will continue to cool regardless of the temperature setpoint and room temperature.
  - \* Note) In the case of above-men-

tioned procedures **7-3** and **7-4** in reverse order, test operation can start as well.

- **7-5** Press Menu/OK button in the basic screen. Main menu is displayed.
- 7-6 In the case of a model having airflow direction function, select
   <u>Airflow Direction</u> in the main menu and check that airflow direction is actuated according to the setting. For operation of airflow direction setting, see the operation manual.
- **7-7** After the operation of airflow direction is confirmed, press **Menu/OK** button. Basic screen returns.
- 7-8 Press and hold Cancel button for 4 seconds or longer in the basic screen.
   Service settings menu is displayed.
- 7-9 Select Test Operation in the service settings menu, and press Menu/OK button. Basic screen returns and normal operation is conducted. \* Note) The test operation will automat-

ically finish in 30 minutes.

- **7-10** Check the functions according to the operation manual.
- **7-11** When the decorative panel is not installed, shut off the power supply after the test operation finishes.
- If construction activities are planned within the space following the test operation procedure, recommend to the customer that the indoor unit is not operated to prevent contamination from paints, drywall dust and other airborne materials.



<Basic screen>

### 

- If operation is not possible due to a malfunction, refer to following Failure diagnosis method
   After the test operation finishes, check whether the error code history is displayed on the
- maintenance information screen of the main menu according to the following procedure.
- 7-12 Press Menu/OK button in the basic screen. Main menu screen is displayed.
- **7-13** Select Maintenance Information in the main menu, and press Menu/OK button.
- **7-14** Maintenance information screen is displayed. Check whether the error code history is displayed on the screen.
  - \* If no error code history is displayed following this procedure the system has normally completed the test operation mode.
- 7-15 If the error code history is displayed, conduct the failure diagnosis referring to <Error code list> in the installation manual of the indoor unit.
  After the failure diagnosis finishes, press and hold On/Off button for 4 seconds or longer in the maintenance information screen to erase the error code history.

### Failure diagnosis method

- Whenever the remote controller display is blank or displays [Checking the connection. Please stand by.], troubleshoot the system with the items in the Description column of the following table.
- If an error occurs, CODE is displayed on the LCD as shown to the right. Conduct the failure analysis referring to <Error code list> in the installation manual of the indoor unit. When the unit No. which detected the error during group control is confirmed,

refer to Chapter 8: Procedure for Checking Error History.





Remote controller display	Description
No display	<ul> <li>Power outage, power voltage error or open-phase</li> <li>Incorrect wiring (between indoor and outdoor units)</li> <li>Indoor printed-circuit board assembly failure</li> <li>Remote controller wiring not connected</li> <li>Remote controller failure</li> <li>Open fuse or tripped circuit breaker (outdoor unit)</li> </ul>
Checking the connection. Please stand by. *	<ul> <li>Indoor printed-circuit board assembly failure</li> <li>Wrong wiring (between indoor and outdoor units)</li> </ul>

\* [Checking the connection. Please stand by.] will be displayed for up to 90 seconds following the application of power to the indoor unit. This is normal and does not indicate a malfunction.

## 8. Procedure for Checking Error History

- **8-1** Press and hold **Cancel** button for 4 seconds or longer in the basic screen. Service settings menu is displayed.
- **8-2** Select Error History in the service settings menu, and press Menu/OK button. The error history menu screen is displayed.
- 8-3 Select RC Error History in the error history menu, and press Menu/OK button.
   Error codes and unit No. can be confirmed in the RC error history screen.
- **8-4** In the error history, the 10 most recent items are displayed in order of occurrence.
- **8-5** Press Cancel button in the RC error history screen 3 times. The basic screen returns.



## 9. Adding Maintenance Contact Information

- Registration of the maintenance contact.
- 9-1 Press and hold Cancel button for 4 seconds or longer in the basic screen.
   Service settings menu is displayed.
- 9-2 Select Maintenance Contact in the service settings menu, and press
   Menu/OK button. Maintenance contact menu screen is displayed.
- 9-3 Select Maintenance Contact , and press Menu/OK button.
- 9-4 Enter the telephone number.
  Scroll through the numbers by using
  ▲▼ (Up/Down) buttons. Start from the left side. Blank digits should remain as " ".
- **9-5** Press **Menu/OK** button. Setting confirmation screen is displayed.
- **9-6** Select Yes and press Menu/OK button. Setting details are saved and service settings menu screen returns.
- **9-7** Press Cancel button once. The basic screen returns.



## **10. Confirming Registered Details**

10-1 Press Menu/OK button in the basic

Main menu is displayed.

10

Select Maintenance Information in the main menu, and press Menu/OK button.

**10-2** Press **Cancel** button twice. The basic screen returns.

screen.



## 11. Clock & Calendar



11-3 Select year, month, day and time by using ▲► (Left/Right) button and set by using ▲▼ (Up/Down) button in the date & time screen. Press and hold the button for continuous change of the numeric value.

\* Day of the week is set automatically.

- **11-4** Press **Menu/OK** button. Setting confirmation screen is displayed.
- **11-5** Select Yes and press Menu/OK button. Setting details are saved and basic screen returns.
- \* If power outage exceeds 48 hours, reset is needed.



## 12. Language

12-1 Press Menu/OK button in the basic <Basic screen> screen.  $\nabla$ Main menu is displayed. Select Language in the main menu, <Main menu screen> press Menu/OK button. 12-1 Main Menu Language 12-2 Press ▲▼ (Up/Down) buttons to select Language on the language screen. English/Français/Español Press Menu/OK button. Press Menu/OK button.  $\overline{\mathbf{v}}$ 12-2 Language English

Setting



3P243521-7L

## 11.5 <BRC082A41W, BRC082A42W(S)> Wireless Remote Controller



Figure 1



Figure 2



### Contents

Safety considerations	1
Before installation	1
Accessories	1
Note to the installer	1
Remote controller installation	2
Installing the wireless remote controller	2
Determination of address and	
MAIN/SUB remote controller	2
Setting procedure	2
Installation of the transmitter board	3
Installation of the decoration panel	3
Installation of the receiver in case of BRC082A41W	4
Installation of the receiver in case of BRC082A42W/S	2
Field setting	Ę

READ THIS MANUAL ATTENTIVELY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE. IMPROPER INSTALLATION OR ATTACHMENT

OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORTCIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

The English text is the original instruction. Other languages are translations of the original instructions.

## Safety considerations

Please read this "Safety considerations" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure at start up operation that the unit operates properly. Please instruct the customer how to operate the unit and how to perform maintenance.

#### Meaning of caution symbols

Fail resu

Failure to observe these instructions properly may result in property damage or personal injury.

Information classified as **NOTE** contains instructions to ensure proper use of the equipment.



Refer also to the installation manual supplied with the indoor unit and the installation manual supplied with the decoration panel.

- There is only 1 possible installation position of this kit into the decoration panel. It is therefore recommended that installation orientation of the decoration panel is confirmed prior to installation of this kit.
  - Ensure that nothing interrupts operation of the wireless remote controller.
- Ensure that the signal from the remote controller can easily be transmitted.
- Ensure that the operation display lamp and other indicator lamps can easily be seen.
- Ensure that there is neither a source of light nor a fluorescent lamp near the receiver.
- Ensure that the receiver is not exposed to direct sunlight.

## **Before installation**

### Accessories

See figure 1. Check if the following accessories are included with your kit.

- 1 Receiver
- 2 Transmitter board
- 3 Wireless remote controller
- 4 Remote controller holder
- 5 Alkaline battery of type AAA.LR03
- 6 Unit number label
- 7 Screw for installing remote controller holder
- 8 Installation manual
- 9 Operation manual
- 10 Clamp
- 11 Plastic spacer
- 12 Plastic band
- 13 Sealing

#### Note to the installer

Be sure to instruct the customer how to properly operate the system showing him/her the supplied operation manual.

### **Remote controller installation**

#### Installing the wireless remote controller

- Do not throw the remote controller or subject it to powerful shocks and do not store the remote controller where it may be exposed to moisture or direct sunlight.
- When operating, point the transmitting part of the remote controller in the direction of the receiver.
- The direct transmitting distance of the remote controller is approximately 23ft (7m).
- The signal cannot be transmitted if something such as curtains blocks the receiver and the remote controller.

Installing to a wall or a pillar

- 1 Turn on all the fluorescent lamps in the room, if any, and find a location where the remote controller signals are properly received by the indoor unit (within 23ft (7m)).
- 2 Fix the remote controller holder with the supplied screws.
- 3 Mount the remote controller on to the hook of the remote controller holder and then push it toward the wall.



How to insert the batteries

1 Slide the back cover to take it off.



2 Insert 2 dry batteries AAA. LR03 (alkaline).



3 Replace the back cover.

## Determination of address and MAIN/SUB remote controller

- If setting multiple wireless remote controllers to operate in one room, perform address setting for the receiver and the wireless remote controller.
- If using both a wired remote controller and a wireless remote controller with one indoor unit, change the MAIN/ SUB switch of the transmitter board.

#### Setting procedure

#### Setting the transmitter board

Set the wireless address switch (SS2) on the transmitter board according to the table below.

	Unit No.				
	1	2	3		
Wireless address switch (SS2)	1 2 3	1 2 3	123		

When using both a wired and a wireless remote controller for 1 indoor unit, the wired controller should be set to MAIN. Therefore, set the MAIN/SUB switch (SS1) of the transmitter board to SUB.



Setting the address of the wireless remote controller

(See figure 3)

- A Field Set mode
- **B** Address (is factory set to " *l* ")
- C Display setting

Setting from the remote controller

- 1 Hold down the ⊞ button and the ☆/TEST button for at least 4 seconds to enter the Field Set mode. (Indicated in the display area in the figure.)
- 2 Press the & FAN button and select an appropriate display setting (*R/b*). Each time the button is pressed the display switches between "*R* " and " b ". Refer to "Display setting *R/b*" on page 3 for full comprehension of this feature.
- **3** Press the  $\bigoplus$  button and  $\bigcup$  button to set the address.



Address can be set from 1 to 6, but set it to 1-3 and to same address as the receiver. (The receiver does not work with address 4-6.)

- 4 Press the RESERVE button to confirm the setting.
- 5 Press the ₩/TEST button to quit the Field Set mode and to return to normal display again.

#### Display setting 8/b

The wireless remote controller has 2 possible display settings.

The standard setting R permanently indicates all operational items whereas the multi system display setting b indicates operations for a limited period of time after execution of settings only.

In case the target indoor unit is simultaneously being controlled;

- by another unit in group control,
- by a wired remote controller,
- by a centralized remote controller.

the indoor unit sometimes does not respond to ON/OFF and temperature setting commands from the wireless remote controller.

In order not to confuse the customer with possible discrepancies between the wireless remote controller display and the actual operation state of the indoor unit, it is recommended to set the display on the wireless remote controller to b in such a control configuration. Check what setting the customer prefers and adjust the

display setting accordingly.

Display setting	Remote controller display	Result of the display setting in case the target indoor unit is simultaneously being controlled by more than 1 device
8: standard	All operational items are permanently displayed.	In the operation mode changeover, temperature setting or the like are carried out from the wireless remote controller, the indoor unit rejects the instruction. (Signal receiving sound, 1 long beep or 3 short beeps) As a result, a display discrepancy between the operation state of the indoor unit and the indication on the wireless remote controller display occurs.
ኔ: multi system	Operations only remain displayed for a short time after execution of the commands.	Since the indications on the wireless remote controller are turned off, a discrepancy such as described above no longer occurs.

#### Affix the unit number label

Affix corresponding unit number labels onto both air outlet of the decoration panel and onto back of the wireless remote controller.



NOTE Set the Unit No. of the receiver and the wireless remote controller to be equal. If the settings differ, the signal from the remote controller cannot be transmitted.

#### Installation of the transmitter board

(See figure 2)

- 1 Electrical wiring box cover
- 2 Transmitter board
- 3 Shorter wire harness
- 4 Longer wire harness
- 5 Clamp
- 6 Electrical wiring box
- 7 Plastic spacer
- 1 Cut off the power supply.
- 2 Remove the electrical wiring box cover as described in the installation manual supplied with the indoor unit.
- **3** Attach four plastic spacers (7) to the transmitter board (2) and install it in the electrical wiring box (6).
- 4 Connect the shorter wire harness from the X2A connector on transmitter board (2) to X24A connector on the printed circuit board in the electrical wiring box of indoor unit. Lay down the shorter wire harness as shown in the figure 2.
- 5 When the receiver is installed bring the longer wire harness to the electrical wiring box of indoor unit and connect it to X1A connector on the transmitter board.
- 6 Clamp the wire harness by the clamp (5) as shown in the figure 2.

#### Installation of the decoration panel

Install the decoration panel as described in the installation manual supplied with the decoration panel.

NOTE Make sure that the wire harness (longer one) from the transmitter board is not caught between the indoor unit and the decoration panel, and between the ceiling and the decoration panel. The installation process of the receiver depends on used decoration panel.

## Installation of the receiver in case of BRC082A41W

- 1 Remove the suction grille as described in the installation manual supplied with the decoration panel.
- 2 Detach the brand name plate part of the decoration panel piece, before attaching the decoration panel. This part is not needed hereafter.
- 3 Remove the electrical wiring box cover as described in the installation manual supplied with the indoor unit. (Be sure to turn off power, before removing the electrical wiring box cover.)



4 Pass the wire harness from the receiver through the wiring hole of the decoration panel. Then attach the receiver to the decoration panel. Lead the wire harness to the electrical wiring box on the indoor unit and connect it to X1A connector on the transmitter board.





input the plastic band. Then screw it back. The wire harness goes through the plastic band. Clamp the wire harness from the receiver to other cables with the clamp.

## Installation of the receiver in case of BRC082A42W/S

- 1 Remove the suction grille as described in the installation manual supplied with the decoration panel.
- 2 The receiver (1) should be installed in the corner that is surrounded by 2 square marks on one side and 1 square mark on the other, as shown in the illustration. Then remove the plastic corner cover.



3 Break off the plastic cover from back side of the panel.



4 Pass the wire harness through the hole and insert the cover into its position and screw it.



## **Field setting**

If optional accessories are mounted on the indoor unit, the indoor unit setting may have to be changed. Refer to the instruction manual (option handbook) for each optional accessory.

(See figure 4)

- A Mode No.B Field Set mode
- **C** First code No.
- D Second code No.

#### Procedure

- 1 When in normal mode, hold down the ₩/TEST button for at least 4 seconds to enter the Field Set mode.
- 2 Select the desired Mode No. with the MODE button.
- **3** Press the  $\bigoplus_{uv}$  button and select the First code No.
- 4 Press the  $\sum_{n \in \mathbb{N}}$  button and select the Second code No.
- 5 Press the RESERVE button to confirm the settings.
- 6 Press the ₩/TEST button to quit the Field Set mode and to return to normal display again.

#### Example

If the time to clean air filter is set to "Filter Contamination-Heavy", set Mode No. to """, First code No. to """, and Second code No. to """.

Mode	First code	Description of setting			Second code No.				
No.	No.	Description of setting	Description of setting				8	03	
10	0	Sets operation time until AIR FILTER CLEANING TIME INDICATOR lamp ghts up. (When dirt and dust levels tre high, change the setting to "Filter Contamination-Heavy".)		Light	±2,500 hrs.	Heavy	±1,250 hrs.	_	
	3	Changes AIR FILTER CLEANING TIME INDICATOR lamp on/off settings.		C	Dn	Off		_	
	8	Setting air outlet velocity. This setting is to be changed in function height (H).	of ceiling		7/8ft .7m)		≨9-13/16ft ≤3.0m)	9-13/16 <h≤11-1 2ft<br="">(3.0<h≤3.5m)< td=""></h≤3.5m)<></h≤11-1>	
13	1	Selection of air flow direction. This setting is to be changed when blocking pad optional kit is used.		4-way flow 3-way flow		y flow	2-way flow		
	ч	Airflow direction range setting. This setting is to be changed when rang flap movement needs to be changed.	e of swing	Up	per	Mec	lium	Lower	

#### NOTE

Factory settings of the Second code No. are marked in grey backgrounds.

Do not use any settings not listed in the table.

For group control with a wireless remote controller, initial settings for all the indoor units of the group are equal.

(For group control, refer to the installation manual supplied with the indoor unit for group control.)

### 11.6 Outdoor Unit

## Contents

Safety Considerations	1
Accessories	3
Precautions for Selecting a Location	3
Precautions on Installation	4
Outdoor Unit Installation Diagram	4
Installation Space Requirements	5
Outdoor Unit Installation	5
1. Installing the outdoor unit	5
2. Drain work	6
3. Flaring the pipe end	6

4. Refrigerant piping	6
5. Pressure test and evacuating system	7
6. Refilling refrigerant	8
7. Refrigerant piping work	8
Wiring	9
Facility Setting (cooling at low outdoor temperature) 1	1
Pump Down Operation1	1
Trial Operation and Testing1	2
1. Trial operation and testing1	2
2. Test items 1	2

# **Safety Considerations**

Read these **Safety Considerations for Installation** carefully before installing an air conditioner or heat pump. After completing the installation, make sure that the unit operates properly during the startup operation.

Instruct the user on how to operate and maintain the unit. Inform users that they should store this installation manual with the operation manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electric shock, fire, or explosion.

Meanings of  $\ensuremath{\textbf{DANGER}}$  ,  $\ensuremath{\textbf{WARNING}}$  ,  $\ensuremath{\textbf{CAUTION}}$  , and  $\ensuremath{\textbf{NOTE}}$  . Symbols:

A DANGER ·······	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
MWARNING ·······	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<u>∧</u> NOTE	Indicates situations that may result in equipment or property-damage accidents only.
•	

#### 🕂 DANGER

- Refrigerant gas is heavier than air and replaces oxygen. A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not ground units to water pipes, gas pipes, telephone wires, or lightning rods as incomplete grounding can cause a severe shock hazard resulting in severe injury or death.
   Additionally, grounding to gas pipes could cause a gas leak and potential explosion causing severe injury or death.

- If refrigerant gas leaks during installation, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with fire. Exposure to this gas could cause severe injury or death.
- After completing the installation work, check that the refrigerant gas does not leak throughout the system.
- Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.
- Safely dispose all packing and transportation materials in accordance with federal/state/local laws or ordinances. Packing materials such as nails and other metal or wood parts, including plastic packing materials used for transportation may cause injuries or death by suffocation.

### A WARNING -

- Only qualified personnel must carry out the installation work. Installation must be done in accordance with this installation manual. Improper installation may result in water leakage, electric shock, or fire.
- When installing the unit in a small room, take measures to keep the refrigerant concentration from exceeding allowable safety limits. Excessive refrigerant leaks, in the event of an accident in a closed ambient space, can lead to oxygen deficiency.
- Use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shock, fire, or the unit falling.
- Install the air conditioner or heat pump on a foundation strong enough that it can withstand the weight of the unit. A foundation of insufficient strength may result in the unit falling and causing injuries.
- Take into account strong winds, typhoons, or earthquakes when installing. Improper installation may result in the unit falling and causing accidents.

- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local, state, and national regulations. An insufficient power supply capacity or improper electrical construction may lead to electric shock or fire.
- Make sure that all wiring is secured, that specified wires are used, and that no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
- When wiring, position the wires so that the electrical wiring box cover can be securely fastened. Improper positioning of the electrical wiring box cover may result in electric shock, fire, or the terminals overheating.
- · Before touching electrical parts, turn off the unit.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- Securely fasten the outdoor unit terminal cover (panel). If the terminal cover/panel is not installed properly, dust or water may enter the outdoor unit causing fire or electric shock.
- When installing or relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- Do not change the setting of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may occur.

### A CAUTION -

- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not touch the refrigerant pipes during and immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor, and other refrigerant cycle parts. Your hands may suffer burns or frostbite if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature or, if you must touch them, be sure to wear proper gloves.
- Install drain piping to proper drainage. Improper drain piping may result in water leakage and property damage.
- Insulate piping to prevent condensation.
- Be careful when transporting the product.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- Do not use a charging cylinder. Using a charging cylinder may cause the refrigerant to deteriorate.
- Refrigerant R410A in the system must be kept clean, dry, and tight.
- (a) Clean and Dry -- Foreign materials (including mineral oils such as SUNISO oil or moisture) should be prevented from getting into the system.

- (b) Tight -- R410A does not contain any chlorine, does not destroy the ozone layer, and does not reduce the earth's protection again harmful ultraviolet radiation. R410A can contribute to the greenhouse effect if it is released. Therefore take proper measures to check for the tightness of the refrigerant piping installation. Read the chapter *Refrigerant Piping Work* and follow the procedures.
- Since R410A is a blend, the required additional refrigerant must be charged in its liquid state. If the refrigerant is charged in a state of gas, its composition can change and the system will not work properly.
- The indoor unit is for R410A. See the catalog for indoor models that can be connected. Normal operation is not possible when connected to other units.
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit far away from fluorescent lamps as much as possible.
- Indoor units are for indoor installation only. Outdoor units can be installed either outdoors or indoors. This unit is for indoor use.
- Do not install the air conditioner or heat pump in the following locations:
- (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen. Plastic parts may deteriorate and fall off or result in water leakage.
- (b) Where corrosive gas, such as sulfurous acid gas, is produced. Corroding copper pipes or soldered parts may result in refrigerant leakage.
- (c) Near machinery emitting electromagnetic waves. Electromagnetic waves may disturb the operation of the control system and cause the unit to malfunction.
- (d) Where flammable gas may leak, where there is carbon fiber, or ignitable dust suspension in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions can cause a fire.
- Take adequate measures to prevent the outdoor unit from being used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke, or fire. Instruct the user to keep the area around the unit clean.

- The outdoor unit should be positioned where the unit and power supply wires (breaker panel to outdoor unit) are at least 10ft (3m) away from any televisions or radios. (The unit may cause interference with the picture or sound.) Depending on the radio waves, a distance of 10ft (3m) may not be sufficient to eliminate the noise.
- Dismantling the unit, treatment of the refrigerant, oil and additional parts must be done in accordance with the relevant local, state, and national regulations.
- Do not use the following tools that are used with conventional refrigerants: gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, or refrigerant recovery equipment.
- If the conventional refrigerant and refrigerator oil are mixed in R410A, the refrigerant may deteriorate.
- This air conditioner or heat pump is an appliance that should not be accessible to the general public.
- As design pressure is 604 psi, the wall thickness of fieldinstalled pipes should be selected in accordance with the relevant local, state, and national regulations.

# Accessories

(A) Installation manual			B Drain socket     This is at the bottom	)))) m of the packaging.	1
© Drain cap (1)	09/12 class	4	D Drain cap (2)	09/12 class	2
() 15/18 class			Ĩ	15/18 class	3
© Warranty					

# **Precautions for Selecting a Location**

- 1) Choose a place solid enough to bear the weight and vibration of the unit, where the operating sound will not be amplified.
- 2) Choose a location where the hot air discharged from the unit or the operating sound will not cause a nuisance to the neighbors of the user.
- 3) Avoid locations, such as near bedrooms, where the operating sound may cause disturbance.
- 4) There must be sufficient space to carry the unit into and out of the site.
- 5) There must be sufficient space for air passage and no obstructions around the air inlet and the air outlet.
- 6) The site must not be prone to flammable gas leaks in the surrounding area.
- In coastal areas or other places with a salty atmosphere or one containing sulfate gas, corrosion may shorten the life of the air conditioner.
- Since water will flow from the drain of the outdoor unit, do not place under the unit anything which must be kept away from moisture.

#### NOTE

Cannot be installed suspended from a ceiling or stacked.

### 

When operating the air conditioner in a low outdoor ambient temperature, be sure to follow the instructions described below.

- To prevent exposure to wind, install the outdoor unit with its suction side facing the wall.
- Never install the outdoor unit at a site where the suction side may be exposed directly to wind.
- To prevent exposure to wind, it is recommended to install a baffle plate on the air discharge side of the outdoor unit.
- In heavy snow areas, select an installation site where the snow will not affect the unit.

Construct a large canopy.Construct a pedestal.



Install the unit high enough off the ground to prevent burying in snow.

## **Precautions on Installation**

- Check the strength and level of the installation surface so that the unit does not cause any operating vibrations or noise after installation.
- Fix the unit in place securely using foundation bolts, as in the figure. (Prepare 4 sets of 5/16 inch (M8) or 3/8 inch (M10) foundation bolts, nuts and washers; all separately available.)
- It is best to screw in the foundation bolts until their ends are 3/4 inch (20mm) from the foundation surface.



# **Outdoor Unit Installation Diagram**



89

## **Installation Space Requirements**

- Where a wall or other obstacle is in the path of the outdoor unit's intake or exhaust airflow, follow the installation space requirements below.
- For any of the below installation patterns, the wall height on the outlet side should be 47-1/4 inch (1200mm) or less.



# **Outdoor Unit Installation**

### **1.** Installing the outdoor unit

When installing the outdoor unit, refer to "Precautions for Selecting a Location" and the "Outdoor Unit Installation Diagram".
 If drain work is necessary, follow the procedures on the next page.

### 2. Drain work

- If the drain port is covered by a mounting base or floor surface, place additional foot bases of at least 1-1/4 inch (30mm) in height under the outdoor unit's feet.
- In cold areas, do not use a drain socket, drain caps (1,2) and a drain hose with the outdoor unit. (Drain water may freeze, impairing heating performance.)
- 1) Attach  $\bigcirc$  drain cap (1) and  $\bigcirc$  drain cap (2).
- 2) Attach (B) drain socket.
  - When attaching (B) drain socket to the bottom frame, make sure to connect the drain hose to the drain socket first.



- 1) Cut the pipe end with a pipe cutter.
- Remove burrs with the cut surface facing downward, so that the filings do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring has been done correctly.



0.039-0.059 inch

(1.0-1.5mm)

Clutch-type

0-0.020 inch

(0-0.5mm)

15/18 class

Drain cap (2)

C Drain cap (1)

Clutch-type (Rigid-type) Wing-nut type (Imperial-type

0.059-0.079 inch

(1.5-2.0mm)

### 

- Do not apply mineral oil to the flare.
- · Prevent mineral oil from getting into the system as this would reduce the service life of the units.
- Never use piping which has been used for previous installations. Only use parts which are delivered with this unit.

X

'n

09/12 class

Drain cap (2)

CDrain cap (1)

- Never install a dryer to this R410A unit in order to guarantee its service life.
- The drying material may dissolve and damage the system.
- Incomplete flaring may result in refrigerant gas leakage.

## 4. Refrigerant piping

### 

- Use the flare nut fixed to the main unit. (This is to prevent the flare nut from cracking as a result of deterioration over time.)
- To prevent gas leakage, apply refrigeration oil only to the inner surface of the flare. (Use refrigeration oil for R410A.)
- Use a torque wrench when tightening the flare nuts to prevent damage to the flare nuts and gas leakage.
- Align the centers of both flares and tighten the flare nuts 3 or 4 turns by hand, then tighten them fully with a spanner and a torque wrench.

Flare nut tightening torque								
Gas side Liquid side								
3/8 inch (9.	5mm)		1/2 inch(12.7mm)		1/4 ir	nch (6.4mm)		
24-1/8-29-1/	2lbf • ft	30	6-1/2-44-1/2lbf • 1	ft	10-1/2-12-3/4lbf • ft			
(32.7-39.9N	l∙m)	(49.5-60.3N • m)		(14.2-17.2 N • m)				
Width across flats	11/16 inch(1	7mm)	7mm) 3/4 inch(19mm) 7/8 in		nch(22mm)	1-1/16 inch(27mm)		
			12-5/8-15-3/8lbf • ft (17.1-20.9N • m)			35-3/8-44-1/8lbf • ft (48-59.8N • m)		
Service port cap tightening torque								
8−10-7/8lbf • ft (10.8-14.7N • m)								

Apply oil



# **Outdoor Unit Installation**

### 5. Pressure test and evacuating system

### 

- Make sure that air or any matter other than refrigerant (R410A) does not get into the refrigeration cycle.
- If refrigerant gas leaks should occur, ventilate the room as soon and as much as possible.
- R410A, as well as other refrigerants, should always be recovered and never be released directly into the environment.
- Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
- When piping work is complete, it is necessary to perform a pressure test and evacuate system with a vacuum pump.
- If using additional refrigerant, purge the air from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.
- Use a hexagonal wrench (3/16 inch (4mm)) to operate the stop valve rod.
- All refrigerant pipe joints should be tightened with a torque wrench to the specified tightening torque.



- 1) Pressurize the liquid pipe and gas pipe from the service ports of each stop valve to 550psi (3.8MPa) (do not pressurize more than 550psi (3.8MPa)) for 1 hour minimum, 24 hours recommended. If there is a pressure drop, check for leaks, make repairs and perform the pressure test again.
- 2) Connect the gauge manifold's charging hose to the gas stop valve's service port.
- Fully open the gauge manifold's low-pressure valve (Lo) and completely close its high-pressure valve (Hi). (High-pressure valve will require no further operation.)
- 4) Evacuate system using vacuum pump to below 500 microns for 1 hour minimum.
- 5) Close the gauge manifold's low-pressure valve (Lo) and stop vacuum pump. (Maintain this condition for a few minutes to make sure that the compound pressure gauge pointer does not swing back.)\*1
- 6) Remove the valve caps from the liquid stop valve and gas stop valve.
- 7) Turn the liquid stop valve's rod 90° counter-clockwise with a hexagonal wrench to open the valve. Close it after 5 seconds, and check for gas leakage. Using soapy water, check for gas leakage from the indoor unit's flare and outdoor unit's flare and valve rods. After the check is complete, wipe all soapy water off.
- Disconnect the charging hose from the gas stop valve's service port, then fully open the liquid and gas stop valves. (Do not attempt to turn the valve rod further than it can go.)
- 9) Tighten the valve caps and service port caps for the liquid and gas stop valves with a torque wrench to the specified torques.

Refer to "4. Refrigerant piping" on page 6 for details.

\*1 If the compound pressure gauge pointer swings back, the refrigerant may have water content or there may be a loose pipe joint.

Check all pipe joints and retighten nuts as needed, then repeat steps 3) through 5).

### 6. Refilling refrigerant

Check the type of refrigerant to be used on the machine nameplate. Precautions when adding R410A

#### Fill from the liquid pipe in liquid form.

R410A is a mixed refrigerant, so adding it in gas form may cause the refrigerant composition to change, preventing normal operation.

1) Before filling, check whether the cylinder has a siphon attached or not. (It should have something like "liquid filling siphon attached" displayed on it.)

Filling a cylinder with an attached siphon

Stand the cylinder upright when filling.



There is a siphon pipe inside, so the cylinder need not be upside-down to fill with liquid.

· Be sure to use the R410A tools to ensure pressure and to prevent foreign objects entering.

## 7. Refrigerant piping work

#### 7-1. Cautions on pipe handling

- · Protect the open end of the pipe from dust and moisture.
- · All pipe bends should be as gentle as possible. Use a pipe bender for bending.

### 7-2. Selection of copper and heat insulation materials

When using commercial copper pipes and fittings, observe the following:

- Insulation material: Polyethylene foam Heat transfer rate: 0.041 to 0.052W/mK (0.024 to 0.030Btu/fth°F (0.035 to 0.045kcal/mh°C))
  - Be sure to use insulation that is designed for use with HVAC Systems.
- ACR Copper only.
- · Be sure to insulate both the gas and liquid piping and observe the insulation dimensions as below.

	Piping size	Minimum bend radius	Piping thickness	Thermal insulation size	Thermal insulation thickness	
Gas side	O.D. 3/8 inch (9.5mm) 1-3/16 inch (30mm) or more		0.031 inch (0.8mm)	I.D. 15/32-19/32 inch (12-15mm)		
Gas side	O.D. 1/2 inch (12.7mm)	1-9/16 inch (40mm) or more	(C1220T-O)	I.D. 9/16-5/8 inch (14-16mm)	13/32 inch (10mm) Min.	
Liquid side	O.D. 1/4 inch (6.4mm)	1-3/16 inch (30mm) or more	0.031 inch (0.8mm) (C1220T-O)	I.D. 5/16-13/32 inch (8-10mm)		

· Use separate thermal insulation pipes for gas and liquid refrigerant pipes.



Be sure to place a ca

If no flare cap is available, cover the flare mouth with tape to kee dirt and water ou

# Wiring

### 

- Do not use tapped wires, extension cords, or starburst connections, as they may cause overheating, electric shock, or fire.
- Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- The circuit must be protected with safety devices in accordance with local and national codes, i.e. a fuse, a circuit breaker, a disconnect or a GFCI.
- Use an all-pole disconnection type circuit breaker with at least 1/8 inch (3mm) between the contact point gaps.
- When carrying out wiring, take care not to pull at the conduit.
- Do not connect the power wire to the indoor unit. Doing so may cause electric shock or fire.
- Do not turn on the circuit breaker until all work is completed.
  - 1) Strip the insulation from the wire (3/4 inch (20mm)).
  - 2) Connect the inter-unit wires between the indoor and outdoor units so that the terminal numbers match. Tighten the terminal screws securely. It is recommended that a slot-head screwdriver be used to tighten the screws. The screws are packed with the terminal block.



#### 09/12 class

- [Method of mounting conduit]
- · A protection plate is fixed for protection from the high-voltage section.
- 1) Dismount the stop valve cover by removing the screw.
- 2) Dismount the protection plate by removing the 2 screws.
- 3) Dismount the conduit mounting cover by removing the 2 screws.
- 4) Pass wires through the conduit and secure them with a lock nut.
- 5) After completing the work, reattach the stop valve cover, the conduit mounting cover, and the protection plate to its original position.



#### 15/18 class

[Method of mounting conduit]

1) Dismount the service lid by removing the 2 screws.

2) Pass wires through the conduit and secure them with a lock nut.

3) After completing the work, reattach the service lid to its original position.



### 

- Precautions to be taken for power supply wiring
- Round crimp-style • When using stranded wires, make sure to use the round crimp-style terminal terminal for connection to the power supply terminal block. Stranded wire Flat washer Screw Screw



• When connecting the inter-unit wires to the terminal block using a single core wire, be sure to curl the end of the lead. Improper work may cause heat and fires.



# Facility Setting (cooling at low outdoor temperature)

This function is limited only for facilities (the target of air conditioning is equipment (such as computer)). Never use it in a residence or office (the space where there is a human).

- Cutting jumper 6 (J6) on the circuit board will extend the operation range to 14°F (-10°C). Installing an air direction adjustment grille (sold separately) will further extend the operation range to -4°F (-20°C). In these cases, the unit will stop operating if the outdoor temperature falls below -4°F (-20°C), restarting once the temperature rises above this level.
  - 1) Remove the top plate of the outdoor unit. (09/12 class: 3 screws, 15/18 class: 6 screws)
- 2) Remove the front plate. (09/12 class: 4 screws, 15/18 class: 8 screws)
- 3) Cut the jumper (J6) of the PCB inside.

### 

- If the outdoor unit is installed where the heat exchanger of the unit is exposed to direct wind, provide a windbreak wall.
- Intermittent noises may be produced by the indoor unit due to the outdoor fan turning on and off when using facility settings.
- Do not place humidifiers or other items which might raise the humidity in rooms where facility settings are being used.
   A humidifier might cause dew jumping from the indoor unit outlet vent.
- Cutting jumper 6 (J6) sets the indoor fan tap to the highest position. Notify the user about this.

# **Pump Down Operation**

In order to protect the environment, be sure to pump down when relocating or disposing of the unit.

- 1) Remove the valve cap from the liquid stop valve and gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After 5 to 10 minutes, close the liquid stop valve with a hexagonal wrench.

4) After 2 to 3 minutes, close the gas stop valve and stop forced cooling operation.



#### Forced cooling operation

- ■Using the indoor unit's remote controller
- [For wired remote controller]
- 1) Set to COOL operation using the remote controller.
- 2) Press and hold the Cancel button for 4 seconds or longer. Service settings menu is displayed.
- Select Test Operation in the service settings menu, and press the Menu/OK button. Basic screen returns and "Test Operation" is displayed at the bottom.
- Press the On/Off button within 10 seconds, and the forced cooling operation starts.
  - Forced cooling operation will stop automatically after about 15 minutes. To stop the operation, press the On/Off button.



[For wireless remote controller] 1) Press 📶 and select the COOL operation.
2) Press 🗂 twice. "Test" is displayed.
3) Press within 10 seconds, and the forced cooling operation starts.
<ul> <li>Forced cooling operation will stop automatically after about 15 minutes.</li> </ul>
To stop the operation, press in .



# **Trial Operation and Testing**

## **1.** Trial operation and testing

Refer to the installation manual for the indoor unit.

## 2. Test items

Test items	Symptom	Check
Indoor and outdoor units are installed properly on solid bases.	Fall, vibration, noise	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
System is properly grounded.	Electrical leakage	
The specified wires are used for inter-unit wiring.	No operation or burn damage	
Indoor or outdoor unit's air inlet or air outlet are unobstructed.	Incomplete cooling/heating function	
Stop valves are opened.	Incomplete cooling/heating function	
Check that the connector of the lead wires of the decoration panel is connected securely.	Louvers do not move	
Indoor unit properly receives wireless remote control commands.	No operation	

## 12. Operation Manual

# Contents

### Read Before Operation

Safety Considerations	1
Names of Parts	4

### Care

Care and Cleaning	5
-------------------	---

# **Safety Considerations**

Read these **Safety Considerations for Operations** carefully before operating an air conditioner or heat pump. Make sure that the unit operates properly during the startup

operation. Instruct the user on how to operate and maintain the unit.

Inform users that they should store this operation manual with the installation manual for future reference. Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:

A DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
A WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<u>∧</u> NOTE	Indicates situations that may result in equipment or property-damage accidents only.

### - 🕂 DANGER ·

- Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.
- Any abnormalities in the operation of the air conditioner or heat pump, such as smoke or fire, could result in severe injury or death. Turn off the power and contact your dealer immediately.
- Refrigerant gas may produce toxic gas if it comes into contact with fire, such as from a fan heater, stove, or cooking device. Exposure to this gas could cause severe injury or death.
- For refrigerant leakage, consult your dealer. Refrigerant gas is heavier than air and replaces oxygen. A massive leak could lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- If equipment utilizing a burner is used in the same room as the air conditioner or heat pump, there is the danger of oxygen deficiency which could lead to an asphyxiation hazard resulting in serious injury or death. Be sure to ventilate the room sufficiently to avoid this hazard.
- Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.

 Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face the danger of death by suffocation.

### — 🥂 WARNING ·

- Contact your dealer for repair and maintenance. Improper repair and maintenance may result in water leakage, electric shock, and fire. Only use accessories made by Daikin that are specifically designed for use with the equipment and have them installed by a professional.
- Contact your dealer to move and reinstall the air conditioner or heat pump. Incomplete installation may result in water leakage, electric shock, and fire.
- Never let the indoor unit or the remote controller get wet. Water can cause an electric shock or a fire.
- Never use flammable spray such as hair spray, lacquer, or paint near the unit. Flammable spray may cause a fire.
- When a fuse blows out, never replace it with one of incorrect ampere ratings or different wires. Always replace any blown fuse with a fuse of the same specification.
- Never inspect or service the unit by yourself. Contact a qualified service person to perform this work.
- Turn off all electrical power before doing any maintenance to avoid the risk of serious electric shock; never sprinkle or spill water or liquids on the unit.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Do not allow children to play on or around the unit to prevent injury.
- The heat exchanger fins are sharp enough to cut. To avoid injury wear gloves or cover the fins while working around them.
- Do not put a finger or other objects into the air inlet or air outlet. The fan is rotating at high speed and will cause injury.
- Check the unit foundation for damage on a continuous basis, especially if it has been in use for a long time. If left in a damaged condition the unit may fall and cause injury.
- Never touch the internal parts of the controller. To check and adjust internal parts, contact your dealer.
- Be sure to establish a ground.
   Do not ground the unit to a utility pipe, arrester, or telephone ground. Incomplete grounding may cause electrical shock, or fire. A high surge current from lightning or other sources may cause damage to the air conditioner.
- Be sure to install a ground fault circuit interrupter. Failure to install a ground fault circuit interrupter may result in electric shock or fire.

### - A CAUTION -

- Do not use the air conditioner or heat pump for any other purposes other than comfort cooling or heating.
   Do not use the unit for cooling precision instruments, food, plants, animals or works of art.
- Do not place items under the indoor unit as they may be damaged by condensates that may form if the humidity is above 80% or if the drain outlet gets blocked.
- Before cleaning, stop the operation of the unit by turning the power off or by pulling the supply cord out from its receptacle. Otherwise, an electric shock and injury may result.
- Do not wash the air conditioner or heat pump with excessive water. An electric shock or fire may result.
- Avoid placing the controller in a spot splashed with water. Water entering the controller may cause an electric shock or damage the internal electronic parts.
- Do not operate the air conditioner or heat pump when using a room-fumigation type of insecticide.
   Failure to observe this could cause the chemicals to be deposited in the unit and can endanger the health of those who are hypersensitive to chemicals.
- Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, water leakage may occur.
- The appliance is not intended for use by young children or infirm persons without supervision.
- The remote controller should be kept away from children so they cannot play with it.
- · Consult with the installation contractor for cleaning.
- Incorrect cleaning of the inside of the air conditioner or heat pump could make the plastics parts break and cause water leakage or electric shock.
- Do not touch the air inlet or aluminum fin of the air conditioner or heat pump as they can cut and cause injury.
- Do not place objects in direct proximity of the outdoor unit. Do not let leaves and other debris accumulate around the unit. Leaves are a hotbed for small animals which can enter the unit. Once inside the unit, animals can cause the unit to malfunction, and cause smoke or fire when they make contact with electrical parts.
- · For care and cleaning, call service personnel.

# **Safety Considerations**

### — 🥂 NOTE -

- Never press the button of the remote controller with a hard, pointed object. The remote controller may be damaged.
- Never pull or twist the electric wire of the remote controller. It may cause the unit to malfunction.
- Do not place appliances that produce open flames in places that are exposed to the airflow of the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not expose the controller to direct sunlight. The LCD display can become discolored and may fail to display the data.
- Do not wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discolored or the coating can peel off. If it is heavily dirty, soak a cloth in a water-diluted neutral detergent, squeeze it well and wipe the panel clean. Then wipe it with another dry cloth.
- Dismantling of the unit, disposal of the refrigerant, oil, and additional parts, should be done in accordance with the relevant local, state, and national regulations.
- Operate the air conditioner or heat pump in a sufficiently ventilated area and not surrounded by obstacles. Do not use the air conditioner or heat pump in the following places.
  - a. Places with a mist of mineral oil, such as cutting oil.
  - Locations such as coastal areas where there is a lot of salt in the air.
  - c. Locations such as hot springs where there is a lot of sulfur in the air.
  - d. Locations such as factories where the power voltage varies a lot.
  - e. In cars, boats, and other vehicles.
  - f. Locations such as kitchens where oil may splatter or where there is steam in the air.
  - g. Locations where equipment produces electromagnetic waves.
  - h. Places with an acid or alkaline mist.
  - i. Places where fallen leaves can accumulate or where weeds can grow.
- Take snow protection measures. Contact your dealer for the details of snow protection measures, such as the use of a snow protection hood.
- Do not attempt to do electrical work or grounding work unless you are licensed to do so. Consult with your dealer for electrical work and grounding work.

- Pay attention to operating sound. Be sure to use the following places:
  - a. Places that can sufficiently withstand the weight of the air conditioner or heat pump yet can suppress the operating sound and vibration.
  - b. Places where warm air from the air outlet of the outdoor unit or the operating sound of the outdoor unit does not annoy neighbors.
- Make sure that there are no obstacles close to the outdoor unit. Obstacles close to the outdoor unit may drop the performance of the outdoor unit or increase the operating sound of the outdoor unit.
- Consult your dealer if the air conditioner or heat pump in operation generates unusual noise.
- Make sure that the drainpipe is installed properly to drain water. If no water is discharged from the drainpipe while the air conditioner or heat pump is in the cooling mode, the drainpipe may be clogged with dust or dirt and water leakage from the indoor unit may occur. Stop operating the air conditioner or heat pump and contact your dealer.

This is an appliance that is not accessible to the general public.



	are and Cleaning	
<u>/!</u>	WARNING Only a qualified service person is allowed to perform maintenanc	
• 8	Before cleaning, be sure to stop unit operation and turn off the ci	
• 0		s and be sure to use only accessories specified by the manufacturer
	an accessory is attached incorrectly, water leakage, an electric shoc	k, or fire may result.
$\underline{\wedge}$		
	Vhen cleaning, use a sturdy and stable stand and watch your ste /lake sure to firmly support the suction grille with your hand whil	
	nake sure to mining support the suction grine with your hand with	
	Quick reference	
	Nooping parts	
	cleaning parts	
	Outside nenal and flame	
	Outside panel and flaps Nipe the parts with a soft cloth.	
	When it is difficult to remove stains, use water or a neutral detergent.	
	f the flaps are stained severely, contact your dealer and	
'	have the flaps replaced.	
C	li dirty	
	Air filter	
• \	/acuum dust or wash the filter.	
	When the air filter cleaning time indicator lamp on	
	the decoration panel lights up or when "Time to	
	clean filter" displays on the wired remote controller	
C	►Page 6	
	Remote controller	Suction grille
• \	Nipe them with a soft cloth.	• Wipe it with a soft damp cloth.
	If dirty	If dirty Page 7.8
L	If dirty	If dirty Page 7,8
N	lotes on cleaning	
	cleaning, do not use any of the following: ater hotter than 104°F (40°C)	
• Vo	latile liquid such as benzene, gasoline and thinner	
	lishing compounds or liquid insecticide ugh materials such as a scrubbing brush	







#### 3P436084-1

## 12.1 With <BRC1E73> Wired Remote Controller

# Safety Considerations

The original instructions are written in English. All other languages are translation of the original instructions.

Read these SAFETY CONSIDERATIONS carefully before operating the remote controller.

Train the customer to operate and maintain the remote controller.

Inform customers that they should store this Operations Manual with the Installation Manual for future reference.

Meanings of WARNING and CAUTION Symbols:

	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
<b>⚠</b> NOTE	Indicates situations that may result in equipment or property-damage accidents only.

• The following pictograms are used in this manual.



$\bigcirc$	• Do not modify or repair the remote controller. Consult your Daikin dealer for any modification or for repairs.
$\bigcirc$	• Do not relocate or reinstall the remote controller by yourself. Improper installation may result in electric shocks or fire. Consult your Daikin dealer to relocate or for any reinstallation.
$\oslash$	• Do not use flammable materials (e.g., hairspray or insecticide) near the remote controller. Do not clean the product with organic solvents such as paint thinner. The use of organic solvents may cause cracking, damaging the product, causing electric shocks, or fire.
0	<ul> <li>Consult the dealer if the remote controller was submerged under water due to a natural disaster, such as a flood or hurricane.</li> <li>Do not operate the remote controller at this time or a malfunction, electric shock, or fire can occur.</li> </ul>




## **Button Locations and Descriptions**



Functions other than basic operation items (i.e., On/Off, Operation Mode, Fan Speed, and Setpoint) are set from the menu screen.

### NOTE

- Do not install the remote controller in places exposed to direct sunlight, the LCD will be damaged.
- Do not pull or twist the remote controller cord, the remote controller may be damaged.
- Do not use objects with sharp ends to press the buttons on the remote controller, damage may result.

#### 1. Operation mode selector button

 Press this button to select the operation mode of your preference. (See page 10.)
 \*Available modes vary with the indoor unit model.

#### 2. Fan speed control button

 Press this button to select the fan speed of your preference. (See page 11.)
 \* Available fan speeds vary with the indoor unit model.

#### 3. Menu/OK button

- Used to enter the main menu. (See page 20 for the menu items.)
- Used to enter the selected item.

### 4. Up button ▲

- Used to raise the setpoint.
- The item above the current selection will be highlighted.
   (The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

### 5. Down button ▼

- Used to lower the setpoint.
- The item below the current selection will be highlighted.

(The highlighted items will be scrolled continuously when the button is continuously pressed.)

Used to change the selected item.

### 6. Right button ▶

- Used to highlight the next items on the right-hand side.
- Each screen is scrolled in the right-hand direction.

#### 7. Left button ◀

- Used to highlight the next items on the left-hand side.
- Each screen is scrolled in the left-hand direction.

#### 8. On/Off button

- Press this button and system will start.
- Press this button again to stop the system.

#### 9. Operation lamp

- This lamp illuminates solid green during normal operation.
- This lamp flashes if an error occurs.

#### 10.Cancel button

• Used to return to the previous screen.

### 11.LCD (with backlight)

- The backlight will be illuminated for approximately 30 seconds by pressing any button.
- If two remote controllers are used to control a single indoor unit, only the controller accessed first will have backlight functionality.

## Names and Functions

### Liquid Crystal Display

- Three types of display mode (Standard, Detailed and Simple) are available.
- Standard display is set by default.
- Detailed and Simple displays can be selected in the main menu. (See page 40.)

### Standard display



### Detailed display

The airflow direction, clock, and selectable item appear on Detailed display screen in addition to the items appearing on Standard display.



### Simple display



### Note for all display modes

• Depending on the field settings, while the indoor unit is stopped, OFF may be displayed instead of the operation mode and/or the setpoint may not be displayed.

## Names and Functions

### 1. Operation mode

- Used to display the current operation mode: Cool, Heat, Vent, Fan, Dry or Auto.
- In Auto mode, the actual operation mode (Cool or Heat) will be also displayed.
- Operation mode cannot be changed when OFF is displayed.
   Operation mode can be changed after starting operation.

### 2. Fan Speed

- Used to display the fan speed that is set for the indoor unit.
- The fan speed will not be displayed if the connected model does not have fan speed control functionality.

### 3. Setpoint

- Used to display the setpoint for the indoor unit.
- Use the Celsius/Fahrenheit item in the main menu to select the temperature unit (Celsius or Fahrenheit).

### 4. Stand by for Defrost/Hot start

- " [STANDBY] " (See page 12.)
- If ventilation icon is displayed in this field:
- Indicates that an energy recovery ventilator (ERV) is connected.
   For details, refer to the Operation Manual of the ERV.

### 5. Message

### The following messages may be displayed.

"This function is not available"

- Displayed for a few seconds when an Operation button is pressed and the indoor unit does not provide the corresponding function.
- In a remote control group, the message will not appear if at least one of the indoor units provides the corresponding function.

- "Error: Push Menu button"
- "Warning: Push Menu button"
- Displayed if an error or warning is detected (see page 50).
- "Time to clean filter"
- "Time to clean element"
- "Time to clean filter & element"
- Displayed as a reminder when it is time to clean the filter and/or element (see page 48).

#### 6. Ventilation

- Displayed when an energy recovery ventilator is connected.
- Ventilation Mode icon." ERV BYPASS " These icons indicate the current ventilation mode (ERV only) (AUTO, ERV, BYPASS).
- Air Purify ICON " ARRIEV " This icon indicates that the air purifying unit (Optional) is in operation.

#### 7. - Key Lock (See page 19.)

• Displayed when the key lock is set.

### 8. ④ Scheduled (See page 30.)

• Displayed if the Schedule or Off timer is enabled.

#### 9. Under Centralized control " GNTRL "

• Displayed if the system is under the management of a multi-zone controller (Optional) and the operation of the system through the remote controller is limited.

## 10.Changeover controlled by the master indoor unit "

#### (VRV only)

 Displayed when another indoor unit on the system has the authority to change the operation mode between cool and heat.

### 11. Setback " SETBACK " (See page 14.)

• The setback icon flashes when the unit is turned on by the setback control.

#### **12.Airflow Direction ".**,<sup>–</sup>"

- Displayed when the airflow direction and swing are set (see page 23).
- If the connected indoor unit model does not include oscillating louvers this item will not be displayed.

## 13.Current Day/Time (12/24 hour time display)

- Displayed if the clock is set (see page 42).
- If the clock is not set, "--: --" will be displayed.
- 12 hour time format is displayed by default.
- Select 12/24 hour time display option in the main menu under "Clock & Calendar".

#### 14.Selectable Display Item

- Room temperature is selected by default.
- For other choices see page 41.

#### 15. XUnable to schedule

- Displayed when the clock needs to be set.
- The schedule function will not work unless the clock is set.

## **Basic Operation**

### Cool/Heat/Auto/Fan Operation (SkyAir and VRV)



### Preparation

• For mechanical protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.

### Operation





## **Basic Operation**

 Adjust Airflow Direction from the main menu (see page 23).
 \* If the connected indoor unit does not have oscillating louvers, this function will not be available.



 When **On/Off** button is pressed again, the system will stop operating and the Operation lamp will turn off.



\*When the system is stopped while in the heating mode, the fan will continue to operate for approximately one minute to remove residual heat from the indoor unit.

#### Note

• To prevent condensation water damage or system failure, do not shut off the power supply to the indoor unit immediately after operation. Wait at least five minutes for the condensate pump to finish draining residual water from the indoor unit.

### **Characteristics of Heat Mode**

The system automatically controls the following operating modes to prevent the reduction of heating capacity and space comfort.

Defrost operation	<ul> <li>The system will automatically go into defrost operation to prevent frost accumulation at the outdoor unit and subsequent loss of heating capacity.</li> <li>The indoor unit fan will stop, and " <u>STANDBY</u> " will be displayed on the remote controller.</li> <li>The system will finish the Defrost operation and return to normal usually within six to eight minutes. It won't last for more than ten</li> </ul>
Hot start	<ul> <li>When the system starts heating operation, the indoor unit fan will operate with a delay in order to prevent a cold draft.</li> <li>(In that case, " (STANDBY)" will be displayed on the remote controller.)</li> </ul>

Split Type Air Conditioners FFQ-Q Series

### **Dry Mode**

### Preparation

- For equipment protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.
- The dry mode may not be selected if the remote controller is master controlled and the system is not already in the cooling mode of operation. (see page 18 for details)

### Operation



 Press Mode button several times until the Dry mode is selected.



\*The dry mode may not be available depending on the type of indoor unit.



### Press On/Off button. The Operation lamp will illuminate solid green and the system will start operating.



\* In Dry mode, the system maintains automatic temperature and fan speed control. Therefore, temperature setpoint or fan speed settings are not available while the indoor unit is in the Dry mode.

 Adjust Airflow Direction from the main menu (see page 23).

\* If the connected indoor unit does not have oscillating louvers, this function will not be available.

## **Basic Operation**



 When On/Off button is pressed again, the system will stop operating and the Operation lamp will turn off.



#### Note

• To prevent condensation water damage or system failure, do not shut off the power supply to the indoor unit immediately after operation. Wait at least five minutes for the condensate pump to finish draining residual water from the indoor unit.

### Characteristic of Dry mode

The Dry mode dehumidifies the space at reduced cooling capacity to prevent the room temperature from dropping to an uncomfortable level.



### Setback

The Setback function can be used to maintain the space temperature in an assigned range for an unoccupied period.

### Note

- When enabled, the Setback mode becomes active when the indoor unit is turned off by either the user, a schedule event or an off timer.
- This function is not available by default. It can be enabled by the system installer.

### Operation



• The setback icon flashes when the unit is turned on by the setback control.

### Ventilation Mode When the Indoor Unit is Interlocked with Energy Recovery Ventilator

### Preparation

• For equipment protection purposes, apply power to the outdoor units at least six hours before starting the operation of the system.

#### Operation



Split Type Air Conditioners FFQ-Q Series

## **Basic Operation**



 Press On/Off button.
 The Operation lamp will illuminate solid green and the system will start operating.



 When On/Off button is pressed again, the system will stop operating and the Operation lamp will turn off.



### Setting the Cool / Heat Changeover Master

### (VRV only)

Setting Changes See page 18 for an explanation of the cool/heat changeover master indoor unit.



- Press **Mode** button on the remote controller of the changeover master indoor unit for at least four seconds while the backlight is illuminated.
- The "
  "
  "
  icon on each remote controller for the indoor units connected to the same outdoor unit or Branch Selector unit will start flashing.
- \*Vent mode setting changes are possible regardless of the cool/ heat changeover master indoor unit.
- \* If the outdoor unit is configured as cool/heat changeover master, all remote controllers serving the associated indoor units will display its "[\_\_MATELE\_]" icon.
- Set the cool/heat changeover master indoor unit as outlined below.

### Selection Settings The icon " COMMENCED " will flash on all remote controllers when the power is turned ON for the first time.



 Press Mode button on the remote controller of the indoor unit which is to serve as the cool/heat changeover master.
 The remote controller for the changeover master indoor unit is established and the complete icon is no longer displayed.
 Other remote controllers in the system (indoor units served by the same outdoor unit or indoor units served by the same branch selector unit) will now display the complete icon.



• Press **Mode** button on the remote controller of the indoor unit designated as the cool/heat changeover master (the remote controller not displaying the communication) repeatedly until the desired mode is selected. The display will change to **Fan**, **Dry**, **Auto**, **Cool**, **Heat** each time the button is pressed.

• Simultaneously, the other indoor units on the system will follow suit and change modes to reflect the new mode selected at the changeover master remote controller.



## **Basic Operation**

### Cool / Heat Mode Selection Availability

• "Cool", "Heat", and "Auto" are all only available for selection on the cool/heat changeover master indoor unit. The following table indicates the available operating modes of the other indoor units on the system based upon the selected mode of the master indoor unit.

When the master indoor unit is set to	The other indoor units in the system can be set to			
	Cool	Dry	Heat	Fan
Cool mode	1			
Dry mode	1	1		<ul> <li>✓</li> </ul>
Heat mode			1	<ul> <li>✓</li> </ul>
Fan mode				<ul> <li>✓</li> </ul>
Auto mode (Cooling operation)	1	1		<ul> <li>✓</li> </ul>
Auto mode (Heating operation)			1	<ul> <li>✓</li> </ul>

### Precautions for Selecting the Cool / Heat Changeover Master Indoor Unit

• The cool/heat changeover master must be set for a single indoor unit in the following applications



### (3-Pipe Heat Recovery System)



cool/heat changeover master.

18

Split Type Air Conditioners FFQ-Q Series



## Quick Reference

### ■The main menu has the following items.

М	enu item	Description	Reference page
Airflow Direct	ion	Used to configure airflow direction settings. • The airflow direction louver is automatically operated up and down (left and right). • The fixed airflow directions are configurable for five positions. * This function is not available on all indoor unit models.	23
Individual	Louver Setting	Set the airflow direction individually for each of the 4 louvers. • Maximum 16 units (unit 0 till 15).	25
Airflow Direction (depends on	Louver Setting List	Setting table for louver.	26
indoor unit model)	Reset All Louvers Position	Reset all louvers to factory default setting.	27
Ventilation Ventilation operation settings	Ventilation Rate	Used to set "Low" or "High"	28
for energy recovery ventilator	Ventilation Mode	Used to set Auto, ERV, or Bypass.	29
Schedule	Daily Patterns	• Day settings are selected from four patterns, i.e., "7Days", "Weekday/Sat/Sun", "Weekday/Weekend", and "Everyday".	31
	Settings	<ul> <li>Set the startup time and operation stop time. ON: Startup time, cooling and heating temperature setpoints can be configured.</li> <li>OFF: Operation stop time, cooling and heating setback temperature setpoints can be configured. (: Indicates that the setback function is disabled for this time period. )</li> <li>Indicates that the temperature setpoint and setback temperature setpoint for this time period is not specified. The last active setpoint will be utilized.</li> <li>Up to five actions can be set for each day.</li> </ul>	32
Off Timer		<ul> <li>Used to set the run-time for the indoor unit using this controller.</li> <li>Possible to set in 10 minute increments from 30 to 180 minutes.</li> </ul>	35
Celsius / Fahr	enheit	• Used to select whether temperature values will be displayed in Celsius or Fahrenheit.	_

Menu item		Description	Reference page	
Filter Auto Clean		Set the time when the filter needs to be automatically cleaned. For the detailed operation refer to the Operation Manual of the self cleaning decoration panel.		
Maintenance I	nformation	Used to display the maintenance information.	37	
Configuration	Draft Prevention (Only available with Occ. sensor installed indoor unit model)	The draft prevention function can be <b>enabled</b> or <b>disabled</b> . When enabled, the Occ. sensor will adjust the louver's position to prevent air blowing directly on occupant.	38	
	Contrast Adjustment	Used to make LCD contrast adjustment.	39	
	Display	<ul> <li>Used to set the display mode.</li> <li>Display mode Standard, Detailed, or Simple display</li> <li>Detailed and Simple displays provide the selectable display item among Room Temp, System, None or Outside Air Temp.</li> </ul>	40	
Current Settin	gs	• Used to display a list of current settings for available items.	42	
Clock & Calendar	Date & Time	<ul> <li>Used to configure date and time settings and corrections.</li> <li>The default time display is 12H.</li> <li>The clock will maintain accuracy to within ±30 seconds per month.</li> <li>If there is a power failure for a period not exceeding 48 hours, the clock will continue working with the built-in backup power supply.</li> </ul>	42	
	12H/24H Clock	The time can be displayed in either a 12 hour or a 24 hour time format.	45	
Daylight Savir	ng Time	Used to adjust the clock in observance of daylight saving time.	45	
Language		The display language can be selected between <b>English</b> , <b>Francais</b> , or <b>Espanol</b> .	48	

Note: Available setting items vary with the indoor unit model.



### Navigating the Main Menu Screen

### ■Display Method for Main Menu

Operation

1 Cool Set to 74F Basic screen	• Press <b>Menu/OK</b> button.	
Aifflow Direction Individual Aifflow Direction Ventilation Schedule Off Timer	• The main menu screen is displayed.	
Celsius / Fahrenheit	Instructions for navigating the main menu will appear.	
3	<ul> <li>Selecting items from the main menu.</li> <li>1. Press ▼▲ buttons to select the desired item to be set.</li> </ul>	
	<ol><li>Press Menu/OK button to display the details for the selected item.</li></ol>	
4	• To go back to the basic screen from the main menu, press <b>Cancel</b> button.	

### Note

• If a button is not pressed for 5 minutes during configuration, the controller will automatically revert to the basic screen.

## **Airflow Direction**

### ■Configuring Airflow direction

Operation

Main Menu     1/3       Airflow Direction       Individual Airflow Direction       Ventilation       Schedule       Off Timer       Celsius / Fahrenheit       Setting	<ul> <li>Display the main menu screen. (See page 22.)</li> <li>Press ▼▲ buttons to select Airflow Direction and press Menu/OK button.</li> </ul>	
2	<ul> <li>(1) Adjusting method when there is single airflow direction.</li> <li>Select the desired airflow direction from Position 0, Position 1, Position 2, Position 3, Position 4, Swing or Auto using VA buttons.</li> <li>Press Menu/OK button to confirm the settings and to return to the basic screen.</li> </ul>	
Setting (up/down)	$\begin{array}{c} 0\\1\\2\\3\\4\end{array}$ $\begin{array}{c} 0\\1\\2\\3\\4\end{array}$ $\begin{array}{c} 0\\1\\2\\3\end{array}$	: Position 0 : Position 1 : Position 2 : Position 3 : Position 4



Airflow Direction Louver

Position 0

When front/back direction is selected

When left/right direction is selected

Position 0

(2) Adjusting method for selecting dual airflow directions.



● Press ◀▶ buttons, to select front/back or left/right direction setting.

### Notice -

These operation and screen are example of dual airflow directions type indoor unit (Single flow cassette model).



 Select the desired airflow direction from Position 0, Position 1, Position 2 Position 3 , Position 4 , Swing or Auto







- Selecting Swing will cause the airflow direction louver to swing position 0 to 4.
- Setting Auto is not available when left/ right direction is selected.
- Press Menu/OK button to confirm the settings and return to the basic screen.





Airflow Directio

• If dual airflow directions are set, then the dual airflow direction icons are displayed in the basic screen.

### Individual Airflow Direction

### ■Louver Setting

### Operation



	Louver Setting	
4	Outlet Unit 0	Direction No Ind Set
	Outletmark	
	Setti	ing 💠

- Press <> button to select the airflow direction.
   Use
- Use ▼▲ buttons to change the airflow direction to the following:

No Ind Set , Position 0 , Position 1 Position 2 , Position 3 , Position 4 , Swing or Blocked .



Blocked : Individual airflow is blocked.

• Press **Menu/OK** button to confirm the settings and to return to the basic screen.



• If individual airflow direction is set, then the individual airflow direction icon is displayed in the basic screen.

### ■Louver Setting List







2

- A table shows the current settings.
   Press ▼▲ buttons to go to the next unit.
- Press Cancel button to return to the previous menu.



### ■Reset All Louvers Position

Operation



### **Operational Details and Functions**

There are two types of airflow direction settings.



### Movement of airflow direction louver

Under the operating conditions shown next, airflow direction is controlled automatically. Actual operation may be different than what is displayed on the remote controller.

Operating condition	<ul> <li>Room temperature is higher than the remote controller's setpoint (in heating operation).</li> <li>When defrosting (in heating operation). (The airflow discharges horizontally to avoid creating a draft for the room occupants.)</li> <li>Under continuous operation with the airflow discharging horizontally.</li> </ul>
---------------------	--

### Ventilation

### ■Ventilation screen display properties

### Operation



### Changing the ventilation rate

### Operation



• Navigate to the ventilation screen (see above).

 Press VA buttons to select
 Ventilation Rate on the ventilation screen.

Press **Menu/OK** button to display the ventilation rate screen.





### Changing the ventilation mode





• Selecting and confirming the desired ventilation mode will take you back to the basic screen. (Pressing **Cancel** button takes you back to the previous screen without changing the ventilation



Auto mode	Using information from the indoor unit (cool, heat, fan, and setpoint) and the energy recovery ventilator unit (indoor and outdoor temperatures), the ventilation mode is automatically changed between ERV and Bypass.
ERV mode	Outside air is passed through the ERV core and is supplied to the conditioned space.
Bypass mode	Outside air is supplied to the conditioned space without passing through the ERV core.

mode.)

### Schedule

### ■Setting the schedule

Operation The schedule will disappear when a multizone controller is connected, but can be re-enabled by the system installer.



Display the main menu screen. (See page 22.)
Press ▼▲ buttons to select Schedule Press Menu/OK button to display the

schedule screen.





### ■ Daily Patterns

### Operation

• The schedule screen will appear. Schedule nable/Disable ● Press ▼▲ buttons to Daily Patte select Daily Patterns on the schedule screen. The daily patterns screen will appear when Menu/OK button is pressed. Schedule Press ▼▲ buttons to select 7 Days, Weekday/Sat/Sun, 7 Days Weekday/Weekend or Everyday on the daily patterns screen.

The confirmation screen will appear when Menu/OK button is pressed.







Press ◀ ▷ buttons to select Yes on the confirmation screen.
 Pressing Menu/OK button enters the daily patterns in the schedule and takes you back to the main menu screen.



### ■Settings

Operation		
Schedule Enable/Disable Daily Patterns Settings	<ul> <li>The schedule screen will appear.</li> <li>Press ▼▲ buttons to select Settings on the schedule screen. The settings screen will appear when Menu/OK button is pressed.</li> </ul>	
2	<ul> <li>Press ▼▲ buttons to select the day to be set.</li> <li>* It cannot be selected in the case of EVDY.</li> </ul>	
3 Schedule Mon BOOA	<ul> <li>Input the time for the selected day.</li> <li>Press ◄► buttons to move the highlighted item and press ▼▲ buttons to input the desired operation start time. Each press of ▼▲ buttons moves the numbers by 1 hour or 1 minute.</li> </ul>	





#### Operation Display the schedule screen. Schedule Enable/Disable (See page 30.) Daily Patterns Settings ● Press ▼▲ buttons to select Enable / Disable on the schedule Setting screen. Press Menu/OK button to display the enable/disable screen. ● Press ▼▲ buttons to select Enable Schedule Enable/Disable or Disable on the enable/disable Disable screen. Press Menu/OK button after selecting the item. The confirmation screen is displayed. ● Press ◀▶ buttons to select Yes on the Schedule Save the settings? confirmation screen. Yes No Pressing Menu/OK button confirms the enable/disable setting for the schedule Setting and takes you back to the basic screen.

### Off Timer

## ■Configuring and Confirming the Off Timer settings

Operation

1	Main Menu     1/3       Airflow Direction     Individual Airflow Direction       Ventilation     Schedule       Off Timer     Celsius / Fahrenheit       Setting     \$	<ul> <li>Display the main menu screen. (See page 22.)</li> <li>Press ▼▲ buttons to select the Off Timer on the main menu screen. Press Menu/OK button to display the off timer screen.</li> </ul>	
2	Off Timer Enable/Disable Settings	<ul> <li>Press VA buttons to select</li> <li>Settings on the off timer screen.</li> <li>Press Menu/OK button to display the configuration screen.</li> </ul>	
3	Off Timer After you turn on the unit, it will automatically turn off in 60 minutes. Setting	<ul> <li>Use ▼▲ buttons to set the time from operation start until the unit automatically stops. Selections can be made in increments of 10 minutes from 30 to 180 minutes. Holding down the button causes the number to change continuously.</li> <li>Select the desired time and press Menu/OK button. The confirmation screen will appear.</li> </ul>	
4	Off Timer Save the settings? YES NO Setting	<ul> <li>Press &lt;&gt; button to select Yes on the confirmation screen.</li> <li>Pressing Menu/OK button confirms the off timer and takes you back to the basic screen.</li> </ul>	



### Operation



### **Maintenance Information**

# Displaying the service contact and model information

### Operation

1	Main Menu     2/3       Filter Auto Clean     Maintenance Information       Configuration     Current Settings       Clock & Calendar     Daylight Saving Time       Setting     \$	<ul> <li>Display the main menu screen. (See page 22.)</li> <li>Press ▼▲ buttons to select <u>Maintenance Information</u> on the main menu screen and press Menu/OK button.</li> </ul>	
2	Maintenance Information Contact Info 0123-456-7890 Indoor Model/000 Outdoor Model/000	<ul> <li>The phone number for the contact is displayed at the top of the screen. (If it has not yet been entered, it will not be displayed.)</li> <li>The model information of the indoor and outdoor units for your product will be displayed on the bottom of the screen. (For some models the product code may be displayed.)</li> <li>*The model name will not be displayed if the indoor unit PCB has been replaced.</li> </ul>	
		*The error code history may also be displayed. If the Operation lamp is not flashing, the unit is working properly. The error code history is no longer displayed if you press <b>On/Off</b> button for more than 4 seconds.	

Menu Options Configuration		
Operation Main Menu 2/3 Filter Auto Clean Maintenance Information Corrent Settings Clock & Calendar Daylight Saving Time Setting	<ul> <li>Display the main menu screen. (See page 22.)</li> <li>Press ▼▲ buttons to select Configuration and press Menu/OK button.</li> </ul>	
2 Configuration Draft Prevention Contrast Adjustment Display Setting	<ul> <li>Press ▼▲ buttons to select</li> <li>Draft Prevention and press</li> <li>Menu/OK button.</li> </ul>	
3 Draft Prevention Enable/Disable Disable Setting	<ul> <li>Press ▼▲ buttons to select</li> <li>Enable or Disable .</li> <li>The confirmation screen will appear when Menu/OK button is pressed.</li> </ul>	
A Draft Prevention Save the settings? Fes No Setting	<ul> <li>Press ◀▶ buttons to select Yes.</li> <li>Press Menu/OK button to confirm the settings and to return to the basic screen.</li> </ul>	
## ■Contrast Adjustment

### Operation



# Menu Options

## ■Display Display Mode

Operation



## **Display Item**

#### Operation



Navigate to the display screen. (See page 40.)
Press ▼▲ buttons to select
Display Item on the display screen. Press Menu/OK button to display the





\* Some models may not display these items even if they are selected.

• Be sure to read the following notes regarding display of room temperature and outside air temperature.

#### Room Temp

display item screen.

...... The temperature at the remote controller.

The temperature that is detected may be affected by the location of the remote controller.

#### Outside Air Temp

- ....... The temperature at the outdoor unit. The temperature that is detected may be affected by factors such as the location of the unit (for example, if it is in direct sunlight) and unit operation during defrosting.
- After setting, press **Menu/OK** button to confirm settings and return to the basic screen.

# Menu Options

# Current Settings

## ■Confirming the current settings

### Operation



# **Clock & Calendar**

2/3

# ■Date & Time

Main Menu

Configuration

Current Settings Clock & Calendar Daylight Saving Tin

Filter Auto Clean Maintenance Information

### Operation

- Display the main menu screen. (See page 22.)
- Press VA buttons to select
   Clock & Calendar on the main menu screen.

Press **Menu/OK** button to display the clock & calendar screen.



2	Clock & Calendar Date & Time 12H/24H Clock Setting ◆	<ul> <li>Press ▼▲ buttons to select Date &amp; Time on the clock &amp; calendar screen.</li> <li>Press Menu/OK button to display the date &amp; time screen.</li> </ul>	
3	Date & Time Year 2015 Month 1 Day 1 Thursday 12:00A Setting 4€→	<ul> <li>Select Year with ◀▶ buttons. Change the year with ▼▲ buttons. Holding down the button causes the number to change continuously.</li> </ul>	
4	Date & Time       Year     2016       Month     10       Day     1       Saturday     1       12:00A     Setting	<ul> <li>Select Month with ◀▶ buttons. Change the month with ▼▲ buttons. Holding down the button causes the number to change continuously.</li> </ul>	
5	Date & Time Year 2016 Month 10 Day ▼ Friday 12:00A Setting ↔	<ul> <li>Select Day with ◄► buttons. Change the day with ▼▲ buttons. Holding down the button causes the number to change continuously. Days of the week change automatically.</li> </ul>	
6	Date & Time           Year         2016           Month         10           Day         7           Friday         12:00A           Setting         ▲♦▶	<ul> <li>Select Hour with ◄► buttons. Change the hour with ▼▲ buttons. Holding down the button causes the number to change continuously.</li> </ul>	

# Menu Options



# ■12H/24H CLOCK

### Operation

1	Clock & Calendar Date & Time 12H/24H Clock Setting	<ul> <li>Display the clock &amp; calendar screen. (See page 42.)</li> <li>Press V▲ buttons to select 12H/24H Clock on the clock &amp; calendar screen. The 12H/24H clock screen will appear when Menu/OK button is pressed.</li> </ul>	
2	12H/24H Clock 12H Setting	<ul> <li>By default, the time display is set to the 12H format.</li> <li>Press V▲ buttons to select 12H 24H on the 12H/24H clock screen.</li> <li>The confirmation screen will appear when Menu/OK button is pressed.</li> </ul>	
3	Save the settings?	<ul> <li>Press &lt;&gt; buttons to select Yes on the confirmation screen.</li> <li>Pressing Menu/OK button confirms the 12H or 24H and takes you back to the basic screen.</li> </ul>	

# Daylight Saving Time

# ■How to display Daylight Saving Time

#### Operation



# Menu Options

### Enabling or disabling Daylight Saving Time

### Operation

Daylight Saving Time Enable/Disable DST Dates	<ul> <li>Display the daylight saving time screen. (See page 45.)</li> <li>Press ▼▲ buttons to select Enable/Disable on the daylight saving time screen. Press Menu/OK button to display the enable/disable screen.</li> </ul>	
2	<ul> <li>Press VA buttons to select Enable or Disable on the enable/disable screen.</li> <li>Press Menu/OK button to display the setting confirmation screen.</li> </ul>	
3 Daylight Saving Time Save the settings? Fres No Setting	<ul> <li>Press &lt;&gt; buttons to select Yes on the setting confirmation screen.</li> <li>Pressing Menu/OK button confirms the daylight saving time enable/disable setting and takes you back to the basic screen.</li> </ul>	

# Setting the date

### Operation





### When Daylight Saving Time is enabled

When the time in the remote controller reaches 2:00 a.m. on the specified start date, the clock is automatically set forward by one hour. When the time in the remote controller reaches 2:00 a.m. on the end date, the clock is automatically set back by one hour.

# Menu Options

# Language

### ■Selectable Languages

### Operation

1	Main Menu     3/3       Language       Setting	<ul> <li>Display the main menu screen. (See page 22.)</li> <li>Press ▼▲ buttons to select Language on the main menu screen and press Menu/OK button.</li> </ul>	
2	English Setting	<ul> <li>Press ▼▲ buttons to select the preferred language on the language screen.</li> <li>English/Français/Español are available.</li> <li>Press Menu/OK button to confirm the settings and return to the basic screen.</li> </ul>	

# Maintenance

### **Reset Filter Indicator** Operation • When it is time to clean or replace the filter, one of Cool the following messages will be displayed on the Set to 2 74⊧ bottom of the basic screen. Time to clean filter Time to clean filter & element Time to clean element \* This is not displayed when Simple display is set. • Wash, clean, or replace the filter or element. For details, refer to the operation manual supplied with the indoor unit.



# Maintaining the Unit and LCD Display

- Wipe the LCD and surface of the remote controller with a dry cloth when they become dirty.
- If the dirt on the surface cannot be removed, soak the cloth in neutral detergent diluted with water, squeeze the cloth tightly, and clean the surface. Wipe the surface with a dry cloth.

#### Note

• Do not use any paint thinner, organic solvent, or strong acid.

# **Reference Information**

# Error Code Display

## Contact your Daikin dealer in the following cases

### Operation



# After-sale Service



• Do not relocate or reinstall the remote controller by yourself. Improper installation may result in electric shocks or fire. Consult your Daikin dealer.

### ■Advise your Daikin Dealer of the following items

- Model name
- Date of installation
- Failure conditions: As precise as possible.
- Your address, name, and telephone number

## ■ Repairs after Warranty Period

Consult your Daikin dealer.

### ■Inquiry about After-sale Service

Contact your Daikin dealer.

### 12.2 With <BRC082A41W, BRC082A42W(S)> Wireless Remote Controller



### Contents

Safety considerations	1
Names and functions of the operating	
section	2
Handling for wireless remote controller	3
Precautions in handling remote controller	3
Installation site	3
Placing the remote controller in the remote controller	
holder	3
How to put the batteries	3
When to change batteries	З
In case of a centralized control system	З
Operation range	4
Operation procedure	4
COOLING, HEATING, AUTOMATIC, FAN and DRY operation	4
Adjustment	5
Program timer operation	6
Emergency operation	6
Precautions for group control system or two remote control system	6
Troubleshooting	7
Emergency stop	7
In case besides emergency stop	7
When you think there is something wrong	8

Thank you for purchasing this Daikin remote controller. Carefully read this operation manual before using the air conditioner. It will tell you how to use the unit properly and help you if any trouble occurs. After reading the manual, file it away for future reference.

The English text is the original instruction. Other languages are translations of the original instructions.

### Safety considerations

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, we recommend that you read this instruction manual carefully before use. The precautions described herein are classified as WARNING and CAUTION. They both contain important information regarding safety. Be sure to observe all precautions without fail.

#### WARNING

Failure to follow these instructions properly may result in personal injury or loss of life.

Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstances. Information classified as **NOTE** contains instructions to ensure proper use of the equipment. After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the

## 

manual

- Be aware that prolonged, direct exposure to cool or warm air from the air conditioner, or to air that is too cool or too warm can be harmful to your physical condition and health.
- When the air conditioner is malfunctioning (giving off a burning odor, etc.) turn off power to the unit and contact your local dealer. Continued operation under such circumstances may result in a failure, electric shock or fire hazards.
- Do not attempt to install or repair the air conditioner yourself. Improper workmanship may result in water leakage, electric shock or fire hazards. Please contact your local dealer or qualified personnel for installation and maintenance work.
- Ask your dealer to perform servicing or repairs whenever necessary.

Improper servicing or repairs may result in water leaks, electric shock or fire.

- Do not place objects, including rods, your fingers, etc., in the air inlet or outlet. Injury may result due to contact with the air conditioner's highspeed fan blades.
- Consult your local dealer regarding relocation and reinstallation of the air conditioner. Improper installation work may result in leakage, electric shock or fire hazards.

# 

- Do not use the air conditioner for purposes other than those for which it is intended. Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.
- To avoid oxygen depletion, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.
- Do not expose plants or animals directly to air flow from the unit as this may cause adverse effects.
- To avoid electric shock, do not operate with wet hands.
- Do not place burners or heaters in places exposed to the air flow from the unit as this may impair combustion of the burner or heater.
- Do not place flammable sprays or operate spray containers near the unit as this may result in fire.

# Names and functions of the operating section

See figure 1, (figure 1B shows the remote controller with front cover opened)

- 1 DISPLAY "▲" (SIGNAL TRANSMISSION) This lights up when a signal is being transmitted.
- 2 DISPLAY " 🗞 " " 🚺 " " 🛣 " " 🔆 " " 🔅 " (OPERATION MODE)

This display shows the current OPERATION MODE.

- 3 DISPLAY "<sup>H</sup>·<sup>M</sup>·<sup>L</sup><sub>Φ</sub>", " <sup>B</sup><sup>D</sup><sup>P</sup><sub>F</sub>" (SET TEMPERATURE) This display shows the set temperature.
- 4 DISPLAY "hr. ⊕ O hr. ⊕ I " (PROGRAMMED TIME) This display shows PROGRAMMED TIME of the system start or stop.
- 5 DISPLAY " ⊷ (<sup>---</sup> " (SWING FLAP) Refer to "AIR FLOW DIRECTION ADJUST" on page 5.
- 6 DISPLAY " **&** " " **&** " " **&** " (FAN SPEED) The display shows the set fan speed.
- 7 DISPLAY "爸TEST" (INSPECTION/TEST OPERATION) When the INSPECTION/TEST OPERATION BUTTON is pressed, the display shows the system mode is in.
- 8 ON/OFF BUTTON Press the button and the system will start. Press the button again and the system will stop.
- 9 FAN SPEED CONTROL BUTTON Press this button to select the fan speed, LOW, MEDIUM or HIGH, of your choice.
- 10 TEMPERATURE SETTING BUTTON Use this button for SETTING TEMPERATURE.
- 11 TIMER MODE START/STOP BUTTON Refer to "TIMER MODE START/STOP" on page 6.
- 12 TIMER RESERVE/CANCEL BUTTON Refer to "PROGRAMMING TIME" on page 6.
- 13 AIR FLOW DIRECTION ADJUST BUTTON Refer to "AIR FLOW DIRECTION ADJUST" on page 5.
- 14 OPERATION MODE SELECTOR BUTTON Press this button to select OPERATION MODE.
- 15 FILTER SIGN RESET BUTTON Refer to the section of MAINTENANCE in the operation manual attached to the indoor unit.
- 16 INSPECTION/TEST OPERATION BUTTON This button is used only by qualified service persons for maintenance purposes.

See figure 3, (receiver on decoration panel)

- 17 EMERGENCY OPERATION SWITCH This switch is readily used if the remote controller does not work.
- 18 RECEIVER This receives the signals from the remote controller.
- 19 OPERATION LAMP (Red) This lamp stays lit while the air conditioner runs. It blinks when the unit is in trouble.
- 20 TIMER LAMP (Green) This lamp stays lit while the timer is set.
- **21** AIR FILTER CLEANING TIME INDICATOR LAMP (Red) Lights up when it is time to clean the air filter.
- 22 DEFROST LAMP (Orange) Lights up when the defrosting operation has started.

NOTE For the sake of explanation, all indications are shown on the display in figure 1 contrary to actual running situations.

- If the AIR FILTER CLEANING TIME INDICATOR lamp lights up, clean the air filter as explained in the operation manual provided with the indoor unit.
   After cleaning and reattaching the air filter, press the FILTER SIGN RESET button on the remote controller. The AIR FILTER CLEANING TIME INDICATOR lamp on the receiver will go out.
  - The DEFROST lamp will blink when the power is turned on. This is not a malfunction.

# Handling for wireless remote controller

#### Precautions in handling remote controller

- Direct the transmitting part of the remote controller to the receiving part of the air conditioner.
- If something blocks the transmitting and receiving path of the indoor unit and the remote controller such as curtains, it will not operate.



- Transmitting distance is approximately 23ft (7m).
- 2 short beeps from the receiver indicates that the transmission is properly done.
- Do not drop or get it wet. It may get damaged.
- Never press the button of the remote controller with a hard, pointed object.

The remote controller may get damaged.

#### Installation site

- It is possible that signals will not be received in rooms that have electronic fluorescent lighting. Please consult with the salesman before buying new fluorescent lights.
- If the remote controller operated some other electrical apparatus, move that machine away or consult your dealer.

# Placing the remote controller in the remote controller holder

Choose a place where the signals reach the unit. Install the remote controller holder to a wall or a pillar with the attached screw.



#### How to put the batteries

- 1 Slide the back cover to take it off.
- 2 Insert 2 dry batteries AAA. LR03 (alkaline).



3 Replace the back cover.

#### When to change batteries

Under normal use, batteries last about a year. However, if the remote controller display begins to fade and the possible transmission range becomes shorter within a year, replace both batteries as specified above.



Replace the two batteries at the same time, do not use new and old batteries intermixed. In case the remote controller is not used for a long time, take out all batteries in order to prevent liquid leak of the battery.

#### In case of a centralized control system

If the indoor unit is under centralized control, it is necessary to switch the remote controller's setting. In this case, contact your dealer.

### **Operation range**

- Refer to the operation manual provided with the indoor unit or with the outdoor unit.
- If the indoor temperature or humidity is beyond operating conditions as listed in the indoor unit or outdoor unit manuals, it may happen
  - that safety devices work,
- that the air conditioner does not operate,
- that water drips from the indoor unit.
- The setting temperature range of the remote controller is 60°F (16°C) to 90°F (32°C).

### **Operation procedure**

■ If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again

#### COOLING, HEATING, AUTOMATIC, FAN and **DRY** operation

Operate in the following order:

MODE

AUTOMATIC operation can be selected only by heat pump system.

For systems without a cool/heat changeover remote control switch

See figure 1

1

**OPERATION MODE SELECTOR** 

Press the OPERATION MODE SELECTOR button several times and select the OPERATION MODE of your choice as follows:

- COOLING operation
- HEATING operation
- AUTOMATIC operation
- FAN operation
- DRY operation

- This operation is to decrease the humidity in your room with the minimum temperature decrease.
- The set point is the air temperature when starting operation by DRY operation.
- Micro computer automatically determines TEMPERATURE and FAN SPEED.
- DRY operation will not activate when room temperature is 57°F (14°C) or less.

() ON/OF (11) ON/OFF

#### Press ON/OFF button.

The OPERATION lamp lights up or goes off and the system starts or stops operation.



2

Do not turn OFF power immediately after the unit stops. Wait at least 5 minutes. Failure to do so may result in water leakage etc.

Explanation of HEATING operation **DEFROST** operation

- As the frost on the coil of an outdoor unit increase, heating effect decreases and the system goes into DEFROST operation.
- The FAN operation stops and the DEFROST lamp of the indoor unit goes on.

After about 4 to 12 minutes of DEFROST operation, the system returns to HEATING operation.

#### Heating capacity and outdoor air temperature

- Heating capacity drops as outdoor air temperature lowers. If feeling cold, use another heater at the same time with this air conditioner.
- Hot air is circulated to warm the room. It will take some time from when the air conditioner is first started until the entire room becomes warm. The internal fan automatically turns at low speed until the air conditioner reaches a certain temperature on the inside.
- If hot air accumulates on the ceiling and feet are left feeling cold, it is recommended to use a circulator. For details, contact the place of purchase.

#### Adjustment

For programming TEMPERATURE, FAN SPEED and AIR FLOW DIRECTION, follow the procedure shown below.

 $\mathbb{Q}_{\mathbb{Z}}$ TEMPERATURE SETTING

Press TEMPERATURE SETTING button and program the setting temperature.



Each time this button is pressed, setting temperature rises 1°F (0.56°C).

Each time this button is pressed, setting temperature lowers 1°F (0.56°C).

DOWN

#### In case of AUTOMATIC operation



Each time this button is pressed, setting temperature shifts to "H" side.

Each time this button is pressed, setting temperature shifts to "L" side.

DOWN

						°F(°C)
		н	•	М	•	L
	Setting temperature	77 (25)	73 (23)	71.5 (22)	70 (21)	66 (19)
l		(20)	(20)	(22)	(21)	(15

. The setting is impossible for FAN operation

- The setting temperature range of the remote controller is 60°F (16°C) to 90°F (32°C).

#### & FAN

FAN SPEED CONTROL 6

Press FAN SPEED CONTROL button.

- LOW, MEDIUM or HIGH fan speed can be selected.
- The micro computer may sometimes control the fan speed in order to protect the unit.

...

#### AIR FLOW DIRECTION ADJUST

The movable limit of the flap is changeable. Contact your dealer for details.

Up and down adjustment



Press the AIR FLOW DIRECTION ADJUST button to select the air direction as shown below.

Display appears and the air flow direction continuously varies. (Automatic swing setting.)

Press AIR FLOW DIRECTION ADJUST button to select the air direction of your choice. Display vanishes and the air flow direction is

fixed. (Fixed air flow direction setting.)

#### Movement of the swing flap

\_ ef

For the following conditions, the micro computer controls the air flow direction so it may be different from the display.

Operation mode	HEATING		
Operation conditions	<ul> <li>When starting operation.</li> <li>When room temperature is higher than the set temperature.</li> <li>In DEFROST operation. (The flaps turn to the horizontal position to avoid blowing cold air directly on the occupants of the room.)</li> </ul>		
NOTE Operation mode includes AUTOMATIC operation.			

#### **Program timer operation**

Operate in the following order.

- The timer is operated in the following two ways:

  - Programming the start time ( ④ ► |). The system starts operating after the set time has elapsed.
- The timer can be programmed for a maximum of 72 hours.
- The start and the stop time can be simultaneously programmed.

Press the TIMER MODE START/STOP button several

times and select the mode on the display. The display blinks.

- For setting the timer stop .....

- For setting the timer start.....

Press the TEMPERATURE SETTING button and set the time for stopping or starting the system.



1

2

When this button is pressed, the time advances by 1 hour.

When this button is pressed, the time goes backward by 1 hour.

DOWN

3

RESERVE TIMER RESERVE

- Press the TIMER RESERVE button. - The timer setting procedure ends.
- The display changes from blinking light to a constant light.

4 O TIMER CANCEL

Press the TIMER CANCEL button to cancel programming. The display vanishes.

For example. When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and then 1 hour later the system will start.



NOTE After the timer is programmed, the display shows the remaining time.

#### **Emergency operation**

When the remote controller does not work due to battery failure or the absence thereof, use the switch which is located beside the discharge grille on the indoor unit. When the remote controller does not work, contact your dealer.



Press the emergency operation switch.

- The unit runs in the previous mode.
- The system operates with the previously set air flow direction.

#### 2 STOP

Press the emergency operation switch again.



# Precautions for group control system or two remote control system

This system provides two other control systems beside individual control (one remote controller controls one indoor unit) system. Confirm the following if your unit is of the following control system type:

- Group control system
- One remote controller controls up to 16 indoor units. All indoor units are equally set.
- Two remote controller control system
   Two remote controllers control one indoor unit. (In case of group control system, one group of indoor units.)
   The unit follows individual operation.



Cannot have a two remote controller control system with only wireless remote controllers. (It will be a two remote controller control system having one wired remote controller and one wireless remote controller.)

- Under two remote controller control system, wireless remote controller cannot control timer operation.
- Only the OPERATION lamp out of 3 other lamps on the indoor unit display functions.
   Contact your dealer in case of changing the combination or setting of group control and two remote controller control systems.

### Troubleshooting

#### **Emergency stop**

#### (See figure 2)

When the air conditioner stops unexpectedly, the OPERATION lamp on the indoor unit starts blinking. Take the following steps yourself to read the malfunction code that appears on the display. Contact your dealer with this code. It will help pinpoint the cause of the trouble and speeding up the repair.

1 TEST

Press the INSPECTION/TEST button to select the inspection mode.

"UNIT No." lights up and the unit number " [] " blinks.

Press the TEMPERATURE SETTING button and change the unit number.

Hold down the TEMPERATURE SETTING button until the indoor unit emits one of the following beep tones.

#### Number of beeps

- 3 short beeps ..... perform all steps from 3 to 6
- 1 short beep ..... perform steps 3 and 6

- 1 long beep.....No trouble

3 Press the OPERATION MODE SELECTOR button.

MODE

" [] " on the left-hand of the malfunction code blinks.

Press the TEMPERATURE SETTING button and change the malfunction code.

Press until the indoor unit makes 2 short beeps.

5 (MODE

Press the OPERATION MODE SELECTOR button. " " on the right-hand of the malfunction code blinks.

#### 

Press the TEMPERATURE SETTING button and change the malfunction code.

Press until the indoor unit makes a long beep. The malfunction code is fixed when the indoor unit makes a long beep.



MODE Reset of the display.

Press OPERATION MODE SELECTOR button to get the display back to its normal state.

#### In case besides emergency stop

- 1 The unit does not operate at all.
  - Check if the receiver is exposed of sunlight or strong light. Keep receiver away from light.
  - Check if there are batteries in the remote controller. Place the batteries.
  - Check if the indoor unit number and wireless remote controller number are equal. See figure 4.
     Operate the indoor unit with the remote controller of the same number.
     Signals transmitted from a remote controller of a different number cannot be accepted. (If the number is
- not mentioned, it is considered as "1".) 2 The system operates but it does not sufficiently cool or
  - warm.
  - Check if the set temperature is proper.
  - Check if the FAN SPEED is not set to LOW SPEED.
  - Check if the air flow angle is proper.

Contact the place of purchase in the following case.



When you detect a burning odor, shut OFF power immediately and contact the place of purchase. Using the equipment in anything but proper working condition can result in equipment damage, electric shock and/or fire.

#### Trouble

The OPERATION lamp of the indoor unit is blinking and the unit does not work at all. See figure 5.

- 1 Malfunction code
- 2 Unit No. which sensed trouble
- 3 INSPECTION display

#### Remedial action

Check the malfunction code  $(\beta + U^{c})$  on the remote controller. Notify and inform the model name and what the malfunction code indicates to your dealer.

# When you think there is something wrong

The following symptoms do not indicate air conditioner malfunction:

#### Symptom 1: The system does not operate

Example	Reason
The system does not restart immediately after the ON/ OFF button is pressed.	If the OPERATION lamp lights, the system is in normal condition. It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.
If operation stops as a result of changing the temperature setting, there will be a delay before operation restarts if the setting is lowered (in COOLING) or raised (in HEATING) again.	It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.
If the reception beep is rapidly repeated 3 times (It sounds only twice when operating normally.)	Control is set to the optional controller for centralized control.
If the DEFROST lamp on the indoor unit's display is lit when heating is started.	This indication is to warn against cold air being blown from the unit. There is nothing wrong with the equipment.
The outdoor unit stops.	Because the room temperature reaches to the set temperature. The indoor unit goes into FAN operation.

#### Symptom 2: The unit stops once in a while

Example	Reason
The remote controller indicates "IJ" and "IJ5", the unit stops. Within several minutes the unit restarts.	Due to electrical noise other than that from the air conditioner, the communication between the units is cut off and the unit stops. When the noise is gone, the unit automatically restarts.

# Symptom 3: No changeover is available between HEATING and COOLING modes

Example	Reason
The indoor unit makes a	When operation changeover
long beep sound.	is under control, the control
	is set to the mode that
	cannot be carried out.

#### Symptom 4: Air flow rate cannot be obtained as set

Example	Reason
During HEATING operation, even if the FAN SPEED CONTROL button is pressed, the air flow rate does not change.	When the room temperature reaches the indoor unit set temperature, the outdoor unit stops and the air flow rate of indoor unit drops to the minimum. This is to avoid the cold air from getting in contact with the people in the room.

#### Symptom 5: Air discharge direction is not as set

Example	Reason
The remote controller	Because it is controlled by
indication and the air	microcomputer. Refer to
discharge direction is not the	"AIR FLOW DIRECTION
same.	ADJUST" on page 5.
Air discharge direction swing	
is impossible.	

#### Symptom 6: Only a part of indication shows

Example	Reason
Even if the unit is operated, only the operation indication shows, or even if the indication shows, soon after, the indication other than that for operation disappears.	The corresponding indoor unit is that for multi-system and the remote controller is set to the multi-system.

#### Symptom 7: No indication shows or all indication show

Example	Reason
When the remote controller button is pressed.	The battery is dead.

#### Symptom 8: Insufficient cooling

Example	Reason
It is in DRY operation.	The DRY operation is an operation mode trying to keep the room temperature constant as much as possible. Refer to "COOLING, HEATING, AUTOMATIC, FAN and DRY operation" on page 4.

# **13.Option List**

### 13.1 Indoor Unit

	Option Name		Model Name		
		New design (white)	BYFQ60C2W1W		
1	Decoration panel (required)	New design (silver)	BYFQ60C2W1S		
		Current design (white)	BYFQ60B3W1		
		Wired type +1	BRC1E73		
2	2 Remote controller (required)	Wireless type	BRC082A42W ★2 ★6 BRC082A42S ★3 ★6 BRC082A41W ★4 ★6		
3	Sensor kit		BRYQ60A2W ★2 / BRYQ60A2S ★3		
4	Sealing member of air discha	rge outlet	BDBHQ44C60		
5	Panel spacer		KDBQ44BA60A ★4		
6	Fresh air intake kit (direct inst	allation type)	KDDQ44XA60		
7	Longlife filter		KAFQ441BA60		
8	Central remote controller		DCS302C71		
9	Unified ON/OFF controller		DCS301C71		
10	Schedule timer controller		DST301BA61		
11	Adaptor for wiring $\star 5$		KRP1C75		
12	Wiring adaptor for electrical a	ppendices ★5	KRP4A74		
13	Installation box for adaptor PC	СВ	KRP1BA101		
14	Remote sensor		KRCS01-4B		

**Notes:**  $\star 1$  Wiring for wired remote controller should be obtained locally.

- ★2 For BYFQ60C2W1W
- ★3 For BYFQ60C2W1S
- ★4 For BYFQ60B3W1
- ★5 Installation box for adaptor PCB (KRP1BA101) is necessary.
- $\star 6$  Sensing function and individual flap control function are not available.

### 13.2 Outdoor Unit

	Option Name	09/12 Class	15/18 Class
1	Air direction adjustment grille	KPW937E4	KPW063A4
2	Back protection wire net	KKG067A41	KKG063A42
3	Drain plug 🛨	KKPS	37A4
4	Drain pan heater	FTDBHMS, KEH067A41E	FTDBHML, KEH063A4E
5	Snow hood (intake side plate)	KPS067A41	KPS063A41
6	Snow hood (intake rear plate)	KPS067A42	KPS063A44
7	Snow hood (outlet)	KPS067A44	KPS063A47



# 13.3 <BRYQ60A2W(S)> Sensor Kit





4P343368-1A

### 13.4 <KDBQ44BA60A> Panel Spacer





### 13.5 <KDDQ44XA60> Fresh Air Intake Kit



- 1. This kit can be installed to the Ceiling mounted cassette type (Multi-flow).
- 2. When installing this kit, duct (Nominal dia.: \(\phi100)\) is required on site.
  - $\cdot$  In case that metal duct is penetrated through wooden walls, make sure the duct and the wall electrically insulated.
  - $\cdot$  Install the duct inclined downwardly to outdoor so that the rain may not get into the duct. (Inclination 1/100 to 1/50)
  - $\cdot$  To avoid birds, small animals or insects getting inside the duct, make sure to install net where it contacts the outside air.

#### Contents

Prior to installation, make sure you have the complete kit of parts.

Name	① Duct flange	2 Screws	③ Insulation for duct flange	④ Insulation for opening of unit	5 Installation manual
Q'ty	1 piece	4 pieces	1 piece	1 piece	1 piece
Shape		<sup>ستی</sup> M4×12	Ø		Ĥ
Neces	sary tools	L.			
Philips	head screw drive	er, nipper, cutte	er etc.		

Installation procedures of duct flange





2P108307-1B

### 13.6 <DCS302C71> Central Remote Controller

#### 13.6.1 Installation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public". Meaning of warning, caution and note symbols. A WARNING ...... Indication a potentially hazardous situation which, if not avoided, could result in death or serious injury. CAUTION ....... Indication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be sued to alert against unsafe practices. ▲ NOTE Indication situation that may result in equipment or property-damage-only accidents Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself, Improper installation may result in water leakage, electric shocks or fire. Perform installation work in accordance with this installation manual. Improper installation may result in water leakage, electric shocks or fire. Be sure to use only the specified accessories and parts for installation work. Failure to use the specified parts may result in water leakage, electric shocks, fire or the unit falling. Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes, Improper installation work may result in the equipment failing and causing accidents. Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual. An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire. Make sure that all wiring is secured, the specified wires and used, and no external forces act on the terminal connections or wires. connections or installation may result in fire When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened. Improper positioning of the electric parts box lid may result in electric shocks, fire or the terminals overheating. Before touching electrical parts, turn off the unit Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incomplete grounding may result in electric shocks When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air. Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may result. Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock Install an leak circuit breaker, as required. If an leak circuit breaker is not installed, electric shock may result. Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage. (b) where corrosive gas, such as sulfurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage. (c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment. (d) where flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire. Be very careful about product transportation. Safely dispose of the packing materials. Packing materials, such as nais and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. Do not turn off the power immediately after stopping operation. Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur. Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft, may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps.(inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

## **COMPONENTS**



# **OSYSTEM CONFIGURATION**

With the central remote controller, unified operation/stop is possible with up to a maximum 64 groups of indoor units. When using 2 central remote controllers, unified operation is possible with up to a maximum 128 groups. With this optional accessory, setting of control modes including operation, stop, operation controlled by timer, and ON/OFF control possible/impossible by remote controller can be set individually by zones while it enables to control and display the operation state such as set temperature. It can be connected with the external key system, host computer monitor panel, etc., through forced OFF input (no-voltage normally open contactor). A zone is a one or more groups together. In general, the same settings are used throughout a zone. Outdoor unit Forced OFF • When using 1 central input remote controller Group No.1-00 Group No.1-15 Group No.2-00 Group No.4-15 Central remote Host computer Max. of 64 groups monitor panel controller Outdoor unit When using 2 central Central remote controller Host computer remote Outdoor unit Group No.1-00 Group No.1-15 Group No.2-00 Group No.4-15 monitor panel controller Group No.5-00 Group No.8-15 Forced ON/OFF command Group No.5-15 Group No.6-00 should be connected to Max, of 128 groups one of the two units. Forced OFF input The central remote controller and the separately sold remote control adapter circuit board or group remote control adapter cannot be used together. See the D-BACS design guide for details.

# **3** INSTALLATION



<ul> <li>When using a</li> </ul>	nly 1 central remo <sup>.</sup>	te controller, c	(Provided with con to not disconnect tl ich it was delivered	he connector for s		ntroller. (Us
<ul> <li>When using n</li> </ul>	nultiple central rem	ote controller	s, or using the cent akes settings as ind	ral remote controlle		with the
	of optional controllers for c			master controller (X1A) S		
Central remote controller	Unified ON/OFF controlle	er Schedule timer	Central remote controller	Unified ON/OFF controlle	er Schedule timer	
1 to 4	1 to 16	1	Set one to "Used" and all the rest to "Not used"	Set all to "Not used"	"Not used"	
		1	-		"Not used"	
<ul><li>unit, or the paralle</li><li>(2) Address settin</li><li>Two central rem</li></ul>	l interface station.) Ig ote controllers can be	used as shown	the master station I in <b>② SYSTEM CON</b> s must be set, This is de	FIGURATION), to c	control anywhere up	o to a max.
SS3 setting	; Indoor unit add	ress	SS3 setting Inc	oor unit address		
SETTING EACH ADDRE				control indoor units		
5-00 ~ 8-15	from group Nos. 1 through 4-15	-00 5		n group Nos, 5-00 bugh 8-15		
			l control (indoor un SUB changeover sv		n different locatio	ons. In this
		*				
	Group No.1-00	Group No.1-1	5 Group No.2-00	Group No.4-15	Entral remote	
Central remote controller (1)		Max	. 64 groups		ontroller (2)	
One of the two	central remote cor	ntrollers (1) . (	2) is set to "MAIN" v	vhile the other is se	et to "SUB".	
						indoor
units on in 2-s	mote controller is e	iring unified o	peration. (Sequentia			
The central re units on in 2-s	mote controller is e second intervals du	ring unified o set as follows	peration, (Sequentia 3. 3 down the unified	al operation is fact		
The central re units on in 2-s sequential ope	mote controller is e second intervals du ration ON or OFF, ential operation	ring unified o set as follows While holding	peration, (Sequentia 3. 3 down the unified	al operation is fact	ory set to "ON.") <sup>-</sup> quential operatio	To switch
The central re units on in 2-s sequential ope Sequ	mote controller is e econd intervals du ration ON or OFF,	ring unified o set as follows While holding perform forc While holdir	peration, (Sequentia 3. 3 down the unified	al operation is fact	ory set to "ON.") <sup>-</sup>	To switch
The central re units on in 2-s sequential ope Sequ ( NOTE: The seque not guarar	mote controller is e econd intervals du ration ON or OFF, ential operation "ON" Factory set) ential operation fur tee that compress	rring unified o set as follows While holding perform ford While holding While holding button, per action is design sors will not b	peration. (Sequentia g down the unified reset.	al operation is fact stop button, Se l operation bad on the power sously, You cannot	ory set to "ON.") <sup>-</sup> quential operatio "OFF" supply equipmen	To switch m

### **5** ELECTRIC WIRING





• After turning the power supply ON, if the unit does not accept operation for two minutes or more with the • Check that setting of the connector for setting master controller is correct.

• Check that the group No. for centralized control has been set.

• For test operation, refer to the installation manual of the outdoor unit.

Call the group of flashing display, confirm malfunction code, and check the source of malfunction.

If the operation lamp flashes, it indicates a malfunction.

(The operation manual lists all error codes, so refer to it.)

display of "88", check the following points.

1P124687-1A

NOTES

#### 13.6.2 Operation Manual

### **BEFORE USE**

#### ■ GENERAL DESCRIPTION OF SYSTEM

This central remote controller can monitor and control up to 64 indoor unit groups. Using two central remote controllers allows monitoring and controlling of up to 128 indoor unit groups.

Main Functions

- 1. Batch starting and stopping of indoor units connected to the central remote controller.
- 2. Handling of operation settings such as start/stop, timer operation, remote controller prohibition/permission, etc., and operation status settings such as temperature.
- 3. Operation status monitoring of operation mode, set temperature, etc.
- 4. Can be connected to an external central monitor panel and key system using the forced stop input (non-voltage a connector).
- · When using 1 central remote controller



(The central remote controller and the separately sold remote control adapter circuit board or group remote control adapter cannot be used together.)

\* GROUP OF INDOOR UNIT refers to the below.

- 1. A single indoor unit without remote controller
  - 1. A single indoor unit without remote controller

2. A single indoor unit controlled by one or two remote controllers



Remote



3. Maximum of 16 indoor units, group-controlled by one or two remote controllers



controller

\* Zone control from the central remote controller

Zone control is available from the central remote controller. With it, it is possible to make unified settings for multiple groups, so setting operations are greatly simplified.



- Any setting you make within a given zone will apply to all groups in the said zone.
- A maximum of 64 zones can be set from a single central remote controller.
- (Each zone contains a maximum of 64 groups.)
- Zones can be set randomly from the central remote controller.

### SAFETY CONSIDERATIONS

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly.

After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public".

Meaning of danger, warning, caution and note symbols.

- **DANGER** ..... Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
- WARNING .... Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION .... Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
- NOTE.....Indicates situation that may result in equipment or property-damageonly accidents.

# Keep these warning sheets handy so that you can refer to them if needed.

Also, if this equipment is transferred to a new user, make sure to hand over this operation manual to the new user.

### 

- Any abnormalities in the operation of the air conditioner such as smoke or fire could result in severe injury or death. Turn off the power and contact your dealer immediately for instructions.
- Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.
- Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face the danger of death due to suffocation.

### WARNING -

- Ask your dealer for installation of the air conditioner. Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.
- Ask your dealer for improvement, repair, and maintenance. Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.
- Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for use with the equipment and have them installed by a professional.
- Ask your dealer to move and reinstall the air conditioner or the remote controller.
   Incomplete installation may result in a water leakage, electric shock, and fire.
- Never let the indoor unit or the remote controller get wet. It may cause an electric shock or a fire.






Fig. 5



Fig. 6



Fig. 7



#### Fig. 8

- Never use flammable spray such as hair spray, lacquer or paint near the unit.
   It may cause a fire.
- Do not allow children to play on or around the unit as they could be injured.
- Never replace a fuse with that of wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.
- Never inspect or service the unit by yourself. Ask a qualified service person to perform this work.
- Cut off all electric waves before maintenance.
- Do not wash the air conditioner or the remote controller with excessive water. Electric shock or fire may result.
- Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
- Never touch the internal parts of the controller. Do not remove the front panel because some parts inside are dangerous to touch. In addition, some parts may be damaged by touching. For checking and adjusting internal parts, contact your dealer.
- Check the unit stand for damage on a continuous basis, especially if it had been in use for a long time. If left in a damaged condition the unit may fall and cause injury.
- Placing a flower vase or other containers with water or other liquids on the unit could result in a shock hazard or fire if a spill occurs.

#### -A CAUTION -

 Avoid placing the controller in a spot splashed with water.

Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.

- Do not operate the air conditioner when using a room fumigation - type insecticide.
   Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.
- Do not turn off the power immediately after stopping operation.
   Always wait at least five minutes before turning off the
- power. Otherwise, water leakage and trouble may occur. • The appliance is not intended for use by young abildron or infirm persons without supervision
- children or infirm persons without supervision.The remote controller should be installed in such a way that children cannot play with it.

### 

- Never press the button of the remote controller with a hard, pointed object.
- The remote controller may be damaged.
- Never pull or twist the electric wire of the remote controller.

It may cause the unit to malfunction.

- Do not place the controller exposed to direct sunlight. The LCD display may get discolored, failing to display the data.
- Do not wipe the controller operation panel with benzine, thinner, chemical dustcloth, etc.
   The panel may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. And wipe it with another dry cloth.
- Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

## CONTENTS

BEFORE USE1GENERAL DESCRIPTION OF SYSTEM1SAFETY CONSIDERATIONS2FEATURES AND FUNCTIONS6	
NAMES AND FUNCTIONS OF THE	
OPERATING SECTION	
OPERATION 8	
Individual screen, all screen, zone screen	
Batch operation and stop method9	
Group operation and stop method9	
Registering zones9	
Zone operation and stop method 10	
Changing the fan direction and fan strength 11 Changing the ventilation mode and	
ventilation strength 11	
Timer Number Setting 11	
Setting the Operation Code12	

OPERATION MODE	13
Setting operation mode	16
Group monitoring	16
Error diagnosing function	17
Setting master remote controller	20
Display of time to clean	21
INSTALLATION TABLE	22
OPTIONAL ACCESSORIES	23
DOUBLE CENTRAL REMOTE	
CONTROLLERS	23
SPECIFICATIONS	
Specifications	
Outline drawings	
	24
Fig. 1, 2, 3, 4	3
Fig. 5, 6, 7, 8	
Fig. 9, 10, 11, 12	25
Fig. 13, 14, 15, 16	
······································	



 Room air conditioners and multi-purpose air conditioners may also be connected by using separately-sold adapter boards.

This may limit functionality, so consult the manuals that come with each adapter board.

# NAMES AND FUNCTIONS OF THE OPERATING SECTION (Fig. 1, 2)

1	UNIFIED OPERATION BUTTON			
•	Press to operate all indoor units.		40	L
2	UNIFIED STOP BUTTON		13	Γ
-	Press to stop all indoor units.			
-	OPERATION LAMP (RED)			t
3	Lit white any of the indoor units under control is in operation.			
4	" CIRCUIT " DISPLAY (REFRIGERANT SYSTEM DISPLAY)		14	
	This indication in the square is lit while the refrigerant system is being displayed.			
5	" SET " DISPLAY (ZONE SETTING)		15	
	The lamp is lit while setting zones.			
6	" MONITOR " DISPLAY (OPERATION MONITOR)			
	The lamp is lit while operation is being monitored.		16	F
	" ALL " " ZONE " " INDIVIDUALLY " DISPLAY			
7	The status displays indicates either batch functions or which zone or individual unit			
	(or group) are being used.			
	OPERATION MONITOR		17	ŀ
8	Each square displays the state corresponding to each group.		••	
	" ()" " 🗞 " " ()" " ()" " 🔆 " " 🔅 " " —— "			Ī
9	DISPLAY (OPERATION MODE)		4.0	
	Displays operating state.		18	╞
	"ఊ""ஊ""ஊ""≦‴""<≣" DISPLAY (VENTILATION CLEANING DISPLAY)			
10	This is displayed when a Ventiair total enthalpy			
	heat exchanger unit or other such unit is connected.		19	
	" 💩 TEST " DISPLAY (INSPECTION/TEST)			
11	Pressing the maintenance/test run button (for service) displays this. This button should not normally be used.		20	
	" 🖉 / 🖆 " DISPLAY (TIME TO CLEAN)		20	
12	It lights up when any individual unit (group) has reached the time for the filter or element to be cleaned.	1		1



	" UNIT NO. 18" DISPLAY (OPERATION CODE AND UNIT NUMBER DIS- PLAY)
21	The method of operation (remote controller prohibited, central operation priority after-press operation priority, etc.) is displayed by the corresponding code. This displays the numbers of any indoor units which have stopped due to an error.
	"唑"" 🖆 " DISPLAY (TIME TO
22	CLEAN AIR CLEANER ELEMENT/ TIME TO CLEAN AIR FILTER)
	Displayed to notify the user it is time to clean the air filter or air cleaner element of the group displayed.
_	VENTILATION MODE BUTTON
23	This is pressed to switch the ventilation mode of the total enthalpy heat exchanger.
	ALL/INDIVIDUAL BUTTON
24	Pressing this button scrolls through the "all screen", "zone screen", and "individual screen".
	ARROW KEY BUTTON
25	This button is pressed when calling an individual indoor unit or a zone.
	ON/OFF BUTTON
26	Starts and stops ALL, ZONE, and INDIVIDUAL units.
	TEMPERATURE ADJUSTMENT BUTTON (ZONE NUMBER BUTTON)
27	This button is pressed when setting the temperature. Select the zone number if any zones have been registered.
28	FAN DIRECTION ADJUSTMENT BUTTON
20	This button is pressed when setting the fan direction to "fixed" or "swing".
29	OPERATION MODE SELECTOR BUTTON
	This sets the operation mode. The dry setting cannot be done.
• •	TIME NO. BUTTON
30	Selects time No. (Use in conjunction with the schedule timer only).
31	CONTROL MODE BUTTON
51	Selects control mode.
32	Selects control mode. FILTER SIGN RESET BUTTON

33	SET BUTTON						
55	Sets control mode and time No.						
34	FAN STRENGTH ADJUSTMENT BUTTON						
	Pressing this button scrolls through "weak", "strong", and "fast".						
	ZONE SETTING BUTTON						
35	Zone registration mode can be turned on and off by pressing the start and stop buttons simulta- neously for at least four seconds.						
36	INSPECTION/TEST RUN BUTTON (FOR SERVICE)						
	Pressing this button scrolls through "inspection", "test run", and "system display". This button is not normally used.						
	VENTILATION STRENGTH ADJUSTMENT BUTTON						
37	This button is pressed to switch the ventilation strength ("fresh up") of the total enthalpy heat exchanger.						
i	tes) Please note that all the displays in the figure appear for explanation purposes or when the cover is open. If the unit is used in conjunction with other optional						
	central controllers, the OPERATION LAMP of the unit that is not under operation control may light up and go out a few minutes behind schedule. This shows that the signal is being exchanged, and does not indicate any failure.						

# **OPERATION**

# ■ Individual screen, all screen, zone screen (Fig. 3)

This controller can perform operations in the individual screen, all screen, or zone screen.

- Individual screen The individual screen is used when performing group operations.
   All screen The all screen is used when per-
  - All screen I he all screen is used when performing operations for all units at once.
- Zone screen The zone screen is used when performing zone operations.

#### 1. <sup>(f)</sup> Select the screen by pressing the "ALL/INDIVIDUAL" button.

CD Every time the "ALL/INDIVIDUAL" button is pressed, the selection scrolls through INDIVIDUAL  $\rightarrow$  ALL  $\rightarrow$  ZONE.

If nothing is done in the all or zone screens for one minute, it automatically goes to the individual screen.

If the zone number in the zone screen is displayed as "---," this indicates that no units are registered in a zone.
 Please perform zone registration before pro-

ceeding in the zone screen. (See page 9)

#### Batch operation and stop method (Fig. 4)

This is for operating or stopping all connected units at once.

A. What to do when operating or stopping all connected units at once.

#### 1. Press either ()? " ALL |" or

2 "ALL O".

- Operation can be performed from the individual screen, the all screen, or the zone screen.
- The "TEMPERATURE ADJUSTMENT" and "OPERATION MODE SELECTOR" buttons cannot be used. To set the temperature and operation mode,

use B. batch operation.

#### **B. Batch Operation**

1. <sup>(3)</sup> Press the "ALL/INDIVIDUAL button" to enter the all screen.

The " 🔄 " display lights up on all registered units.

2. <sup>(4)</sup> Press the "SELECT" button.

The " I display lights up on all connected units.

#### <sup>(5)</sup> Press the "RESET" button.

The " **I** " display goes off on all connected units. Operation and stop in the batch screen are done the same as with the batch operation and batch stop buttons.

Image: Second state of the Image and the Imag

The temperature rises 1° every time

the ( $\blacktriangle$ ) button is pressed.

The temperature drops 1° every time

the ( $\mathbf{\nabla}$ ) button is pressed.

Set to " -- " when you do not wish to use batch setting for the temperature setting. Setting to 1° above or below the temperature setting range displays " -- ".

 Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

Set to "--" when you do not wish to use batch setting for the operation setting.

# Group operation and stop method (Fig. 5)

This is for operating or stopping connected units in groups.

#### [Group operation]

1. Press the Tr "ALL/INDIVIDUAL button"

to enter the *realistication* individual screen. The unit will enter the individual screen automatically if nothing is done for one minute.

2. I Using the arrow keys, I move the

" T \* to select the units to operate or stop. Keeping the button pressed down will move it rapidly.

The " 📃 " in this screen has selected unit 1-04.

#### 3. <sup>(5)</sup> Press the "SELECT" button.

The " 🔳 " display lights up in the group.

<sup>(6)</sup> Press the "RESET" button.

The " 🔳 " display goes off in the group.

4. <sup>()</sup> Press the "TEMPERATURE ADJUST-MENT" button.

The temperature rises 1° every time the

(▲) button is pressed.

The temperature drops 1° every time the

(▼) button is pressed.

Temperature adjustment cannot be done if the selected group's air conditioners are in fan mode.

5. Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

#### Registering zones (Fig. 6)

It is possible to set multiple groups as one zone and control each zone separately.

No zones are registered when the unit is shipped from the factory.

Zone registration can be done in the individual screen, all screen, or zone screen.

#### [Registration]

1. Tressing the "ALL/INDIVIDUAL" button for four seconds. To Displays ZONE SET.

Zone Number 1 will be displayed, and if there are any groups already registered in the displayed

zone, a " 🔳 " will light up on the operation monitor.

- 2. <sup>(3)</sup> Select the Zone Number to be registered using the "ZONE NUMBER" button. Keeping the button pressed down will move it rapidly.
- Image: "Image: Second state of the second state of th
- 4. <sup>(C)</sup> Press the "SELECT" button to register that group to the zone.

The " **n** " display lights up on all the selected units.

There are the second to the second term of term of

#### " 🔳 " goes off.

Repeat steps 3 and 4 until all the units you wish to register to the zone have been added.

2	ZONE SET								ZONE						1	
	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
1-																
2-																
3-																
4-																

In this example, a screen is shown with units 1-00, 1-02, 1-03, and 2-00 registered to Zone Number 1.

- 5. Repeat steps 2 to 4 to register to the next zone.
- Once zone registration is complete,
   press the "ALL/INDIVIDUAL" button to turn off "ZONE SET" display and return to the individual screen.

The display returns to the normal screen if nothing is done for one minute when in zone registration mode.

(NOTE)

• It is impossible to register one group to several different zones.

If this is done, the last zone registered to will be valid.

#### [Batch deletion of zone registration]

- Pressing the "ALL O" for at least four seconds while pressing the "FIL-TER SIGN RESET" button when "ZONE SET" is displayed will delete all zone registrations. The zone registrations for all units will be lost.
- Zone operation and stop method (Fig. 7)

This is for operating or stopping connected units in zones.

#### [Zone operation]

- 1. IP Press the "ALL/INDIVIDUAL button" to enter the zone screen.
- 2. <sup>(3)</sup>Using the arrow keys, select the zone number to operate or stop.

Pressing - and - reduces the zone number

while  $\rightarrow$  and  $\uparrow$  raise the number. Keeping the button pressed down will move it rapidly.

• If the zone number is displayed as "---," this indicates that no units are registered in a zone. Please perform zone registration before using a zone. (See page 9)

#### **3.** <sup>(J)</sup> Press the "SELECT" button.

The " 🔳 " display lights up in the group.

**Press the "RESET" button.** 

The " I display goes off in the group.

4. In Press the "TEMPERATURE ADJUST-MENT" button.

The temperature rises 1° every time the ( $\blacktriangle$ ) button is pressed.

The temperature drops  $1^{\circ}$  every time the ( $\mathbf{\nabla}$ ) button is pressed.

Set to " -- " when you do not wish to use zone setting for the temperature setting. Setting to 1° above or below the temperature setting range displays " -- ".

 IP Call up the desired mode by pressing the "OPERATION MODE SELECTOR" button.

Set to "--" when you do not wish to use zone setting for the operation mode.

#### Changing the fan direction and fan strength (Fig. 8)

This changes the fan direction and strength settings in the air conditioner.

Changing the fan direction and strength is done in the individual screen.

#### [Registration]

#### 1. IP Press the "ALL/INDIVIDUAL button"

to enter the I individual screen. The unit will enter the individual screen automatically if nothing is done for one minute.

- 2. ③ Using the arrow keys, ④ move the
  - " " to select the units to fan direction adjustment or fan strength adjustment. Keeping the button pressed down will move it rapidly.
- Image: Second Strain Str

This sets "fixed" or "swing" for the fan direction.

#### Press the "FAN STRENGTH ADJUST-MENT" button.

Pressing this button scrolls through " $\overset{\bullet}{L}$ ", " $\overset{\bullet}{H}$ ", and " $\overset{\bullet}{H}$ ".

Depending on the indoor unit, only "  ${}^{\bullet}_{L}$  " and "  ${}^{\bullet}_{H}$  "

may be available.

The functions included in the indoor units may vary. Pressing a button for a function which is not available will cause "NOT AVAILABLE" to be displayed.

#### Changing the ventilation mode and ventilation strength (Fig. 9)

This changes the ventilation mode and strength settings in the total enthalpy heat exchanger. Changing the ventilation mode and strength is done in the individual screen.

#### [Registration]

1. IP Press the "ALL/INDIVIDUAL button" to

#### enter the $\operatorname{\widehat{ur}}$ individual screen.

The unit will enter the individual screen automatically if nothing is done for one minute.

2. ③ Using the arrow keys, ④ move the

" To select the units to ventilation mode or ventilation strength adjustment. Keeping the button pressed down will move it rapidly. 3. IP Press the "VENTILATION MODE" button.

It will scroll through " $(\underline{\mathbb{A}}_{\mathbb{D}})^{*} \rightarrow (\underline{\mathbb{A}}_{\mathbb{D}})^{*} \rightarrow (\underline{\mathbb{A}}_{\mathbb{D}})^{*}$ "

→ "மீஹ". ⓒ Press the "VENTILATION STRENGTH ADJUSTMENT" button.

It will scroll through "  $\stackrel{\bullet}{\overset{\bullet}{L}}$  "  $\rightarrow$  "  $\stackrel{\bullet}{\overset{\bullet}{H}}$  "  $\rightarrow$  "  $\stackrel{\bullet}{\overset{L}{\underset{\mathsf{FRESH UP}}{\overset{\bullet}{T}}}$  "  $\rightarrow$ 

 $\stackrel{\clubsuit}{}_{\text{FRESH UP}} \overset{*}{\to} \stackrel{*}{}_{\text{L}} \overset{*}{\to} \overset{*}{}_{\text{L}} \overset{*}{\to} \overset{*}{}_{\text{L}} \overset{*}{\to} \overset{*}{$ 

The fresh up function may not be available depending on the connected unit model. The functions included in the indoor units may vary. Pressing a button for a function which is not available will cause "NOT AVAILABLE" to be displayed.

#### Ventilation Mode and Amount

If these are changed using the remote controller depending on the unit model, they cannot be displayed on the central remote controller. To monitor the ventilation mode and amount, check the values on the remote controller.

#### Timer Number Setting (Fig. 10)

(Only when used with the schedule timer) Using this together with the schedule timer makes it possible to set on and off times four times a day.

#### [Registration]

 TPressing the "TIMER NO." button causes the number set for timer number 1 to blink.

If no timer setting has been made

" - " will be displayed. Select the desired timer number by pressing the (1) "TIMER NO." button.



2. In Once the desired timer number is displayed, press the "SET" button.

Press the  $(27)^{-}$  "SET" button within 10 seconds after the timer number is displayed. The display will return to how it was after 10 seconds.



The display for timer number 1

will stop blinking and then timer number 2 will start blinking. 3. I Select the desired timer number by pressing the "TIMER NO." button.

Once the desired timer number is displayed, 127 press the "SET" button. The display for timer number 2

will stop blinking.



The " $\bigoplus_{No.}$  " display will disappear after 3 seconds.

Select " – " in the timer number when you do not wish to set a timer number.

It is possible to set only one timer number. (The times for turning the unit(s) on and off twice a day can be set with a single timer number.)

#### Timer Number Setting

- Group control: select the unit in the individual screen and set the timer number.
- Batch control: set the timer numbers for all connected units.
- Zone control: set the timer numbers for all zone-registered units. Call up the zones which you wish to set in the zone screen and set the timer numbers.
- Since the timer number will be set to afterpress priority, the timer number in the last screen set will be valid for the connected units.

#### Example 1

Setting timer number 1 for unit 1-00 to "1" and timer number 2 to "2" in the individual screen and then setting timer number 1 to "3" and timer number 2 to "4" in the batch screen causes the timer numbers for all units to be set, so timer number 1 for unit 1-00 will be "3" and timer number 2 will be "4".

#### Example 2

To prevent leaving units on, timer number 1 is set to "5" in the batch screen.

Setting timer number 1 in zone number 1 to "–" in the zone screen after that will change the timer number for zone number 1, so the setting to prevent leaving the units on will be lost for zone number 1 only.

If a timer number is set incorrectly by accident, redo the setting in the desired screen.

• What happens when the timer number on time and off time are set to the same time

When the on time and off time are set to the same time for the same timer number, operation does not change.

When the on time and off time are set to the same time for different timer numbers, the off time is given priority.

When using timer operation, make sure the times do not overlap when setting the program of the schedule timer.

#### ■ Setting the Operation Code (Fig. 11)

#### [Registration]

1. TPressing the "CONTROL MODE" button causes the currently set operation code to blink.

Call up the desired code number by pressing the  $\text{CP}^{*}$  "CONTROL MODE" button. Scroll through the code numbers.

2. IP Once the code number is displayed, press the "SET" button.

The display will stop blinking. The operation code display will disappear after 3 seconds.

#### [The Operation Code Setting]

Group control:	select the unit in the individual screen
	and set the operation code.

- Batch control: set the operation code for all connected units.
- Zone control: set the operation code for all zone-registered units. Call up the zones which you wish to set in the zone screen and set the operation code.

Since the operation code will be set for after-press priority, setting the operation code in the zone and individual screens after setting the operation code in the batch screen, will cause the operation codes set afterwards to be valid.

### **OPERATION MODE**

The following five operation control modes can be selected along with the temperature setting and operation mode by remote controller, for a total of twenty different modes. These twenty modes are set and displayed with control modes of 0 to 19. (For further details, see **EXAMPLE OF OPERATION SCHEDULE** on the next page.)

ON/OFF control impossible by remote controller	Use this mode when operating and stopping from the central remote controller only. (ON/OFF control by the remote controller is disabled.)
Only OFF control possible by remote controller	Use this mode when executing the operation only by the central remote controller, and executing only the stop by remote controller.
Centralized	Use this mode when executing the operation only by the central remote controller, and executing start/stop freely by remote controller during the preset hours.
Individual	Use this mode when executing start/stop both by central remote controller and remote controller.
Timer operation possible by remote controller	Use this mode when executing start/stop by remote con- troller during the preset hours, and not starting operation by the central remote controller at the programmed time of system start.

#### [HOW TO SELECT THE CONTROL MODE]

 Select whether to accept or to reject the operation from the remote controller regarding the operation, stop, temperature setting and operation mode setting, respectively, and determine the particular control mode from the rightmost column of the table below.

#### Example



	Control by remote controller									
Operation mode	Operat Unified operation, individ- ual operation by central remote controller, or opera- tion controlled by timer	ion Unified stop, individual stop by central remote controller, or timer stop	Stop	Tempera- ture control	Operation mode setting	Control mode				
				Rejection	Acceptance	0				
ON/OFF control			Rejection	Rejection	Rejection	10				
impossible by remote controller			(Example)	Acceptance	Acceptance (Example)	1 (Example				
	Rejection			(Example)	Rejection	11				
	(Example)			Rejection	Acceptance	2				
Only OFF control possible by		Rejection			Rejection	12				
remote controller		(Example)		Acceptance	Acceptance	3				
					Rejection	13				
				Rejection	Acceptance	4				
Centralized	Acceptance				Rejection	14				
Centralized				Acceptance	Acceptance	5				
			Acceptance	Acceptance	Rejection	15				
	Acceptance		Acceptance	Rejection	Acceptance	6				
Individual		Acceptance		Rejection	Rejection	16				
munuuuai		Acceptance		Accontance	Acceptance	7				
				Acceptance	Rejection	17				
				Bejection	Acceptance	8				
Timer operation possible by	Acceptance	Rejection		Rejection	Rejection	18				
remote controller	(During timer at ON position only)	(During timer at OFF position)		Accontance	Acceptance	9				
				Acceptance	Rejection	19				

Note) Do not select the timer operation possible without the remote controller. In this case, timer operation is disabled.



#### **EXAMPLE OF OPERATION SCHEDULE**

Operation schedule is possible only in conjunction with the schedule timer (optional accessory). Liquid crystal display of schedule timer

ON/OFF control impossible by remote controller





Only OFF control possible by remote controller



■ Setting operation mode (Fig. 12)

#### [Registration]

- 1. IP Press the OPERATION MODE SELEC-TOR BUTTON. Each time you press this button, the display rotates as shown on the below list.
- List of operations which can be set In the below list, "  $\bigcirc$  " refers to the acceptable setting, while " × " refers to the not acceptable setting.

$\square$	A: Zones and groups with no "[]夫]" display.				
Display	Setting	Contents of setting			
	×				
+ R-	0	Can be set in individual zones or groups			
	0 * 1	Can be set in individual zones or groups			
*	0	Can be set in individual zones or groups			
*	0	Can be set in individual zones or groups			
den or <b>≫z</b> or ≁z	0 * 1	Can be set in individual zones or groups * 3			
	0 * 1	Can be set in individual zones or groups			
	0	Select this display if you don't wish to set by zone.			

	B: Zone "⊡太	es and groups with a " display.
Display	Setting	Contents of setting
	0	To be set by zone * 2
* 2	0	Can be set in individual zones or groups
	×	
*	×	The displays are shown by group * 4
*	×	The displays are shown by group * 4
den or ≫azor ≫az	O * 1	Can be set in individual zones or groups * 3
	0 * 1	Can be set in individual zones or groups
	0	Select this display if you don't wish to set by zone.

- \*1: Setting may not be acceptable depending on the type of indoor unit with which this unit is connected.
- \*2: In zone control, the units run in temperature adjustment mode (heating or cooling) for the outdoor system for the groups registered to those zones. Heating or cooling selection is not available.
- \*3: A gradient of the second control of t
- \*4: In group control, the units run in temperature adjustment mode (heating or cooling) for the group outdoor system. Heating or cooling selection is not available.
- The Zone consists of the following two cases.

#### A. Zone without display" 🔄 🙏

The group with master remote controller setting exists in this zone.

Setting the master remote controller enables cool/ heat selection.

Operations other than cool/heat operations can also be set for some operations. For further details, see the list on the left.

#### B. Zone with display" [ ] 人 "

No group with master remote controller setting exists in this zone. The cool/heat selection is not available because the master remote controller has not been set. Some operations other than cool/heat operations can be set. For further details, see the list in the left.

See page 20 if the display" [] 🔀 🙏 " is flashing.

- Fan operation can be performed for each zone using the central remote controller even if there is no cooling/heating selection right during cooling or heating. Also, if a Ventiair is connected in the zone, ventilation and ventilation cleaning operation is possible. See the included operating manuals for details.
- When the indoor unit is in heat operation, change the setting to FAN operation through the central remote controller; then, you can switch the fan speed to the extremely low fan speed. Warm air may blow if any other indoor unit belonging to the same system is in heat operation.
- The indoor fan stops during defrost/hot start.
- DRY cannot be set from the central remote controller.

#### ■ Group monitoring (Fig. 13)

Utilize the group monitor function in each of the following cases:

- 1. Check the malfunction code. (See the next page.)
- 2. Check the group that requires cleaning of the air filter and air cleaner element. (See page 21.)
- 3. Change the setting of the master remote controller. (See page 20.)
- Check the group(s) sharing the same outdoor unit. Or, check the particular group(s) with the master remote controller setting. (See page 20.)
- 5. Check the conditions of other individual groups.

#### When in zone screen

The zone screen will revert to the individual screen automatically if nothing is done in it for one minute.

#### [Registration]

- 1. TPress the "ALL/INDIVIDUAL" button to switch to the T "INDIVIDUAL" screen.
- 2. I Using the arrow key, move the

" [] " to select the unit to be monitored. Keeping the button pressed down will move it rapidly.

 $\bigcirc$  The "  $\square$ " lights up and the status of that unit is displayed in the LCD. The cursor in the screen Fig. 13 has selected unit 2-06.

#### Error diagnosing function (Fig. 14)

This central remote controller is provided with a diagnosing function, for when an indoor unit stops due to malfunction. In case of actuation of a safety device, disconnection in transmission wiring for control or failure of some parts, the operation lamp, inspection display and unit No. start to flash; then, the malfunction code is displayed. Check the contents of the display, and contact your DAIKIN dealer because the above signs can give you the idea on the trouble area.



The display " — " flashes under the group No. where the indoor unit that has stopped due to malfunction.

#### [Registration]

1. IP Press the ARROW KEY BUTTON to call up the group that has stopped due to malfunction.

(2) The unit No. (3) the malfunction code is flashing because of an error failure.



Operation lamp	Maintenance display	Unit No.	Malfunction code	Error content
¢.	•	⇒	64	Indoor air thermistor error
<b>\</b>	•	∻	65	Outdoor air thermistor error
¢.	•	⇒	68	HVU error (Ventiair dust-collecting unit)
¢	•	⇒	6A	Dumper system error
৵	⇒	⇒	6A	Dumper system error + Thermistor error
\$	•	⇒	6F	Simple remote controller error
÷\$-	•	⇒	6H	Door switch (Ventiair dust-collecting unit), relay harness fault (Ventiair dust-collecting/humidifier unit)
÷	⇒	⇒	94	Ventiair internal transmission error (between total enthalpy – fan unit)
⇒	¢	⇒	A0	Indoor unit · external safety device error
*	÷Þ	⇒	A1	Indoor unit · BEV unit (Sky-Air connection unit) PC board assembly fault
¢.	•	⋪	A1	Indoor unit · PC board assembly fault
\$	⇒	⇒	A3	Indoor unit · Drain level error (33H)
৵	⇒	⇒	A6	Indoor unit · Fan motor (51F) lock, overload
¢	•	÷\$	Α7	Indoor unit · Fan direction adjustment motor (MA) error
৵	৵	⇒	A9	Indoor unit · BEV unit, electric expansion valve motor (20E) error
¢.	•	⇒	AF	Indoor unit · Malfunctioning drain
\$	•	⇒	АН	Indoor unit · Dust-collector error
৵	⇒	⇒	AJ	Indoor unit $\cdot$ Insufficient capacity setting, address setting fault

÷Þ	∻	⇒	C4	Indoor unit · Liquid piping thermistor (Th2) Error (faulty connection, cut wire, short circuit, fault)			
÷)	÷Þ	⇒	C5	Indoor unit · BEV unit, gas piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)			
÷Þ	÷Þ	÷Þ	C9	Indoor unit · Intake air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)			
৵	Þ	⇒	СА	Indoor unit · Outlet air thermistor (Th4) Error (faulty connection, cut wire, short circuit, fault)			
¢.	•	¢.	CJ	Indoor unit · remote controller sensor error			
৵	⇒	⇒	E0	Outdoor unit · Safety device operation			
⇒	÷Þ	÷Þ	E1	Outdoor unit · PC board assembly fault			
÷	•	৵	E1	Outdoor unit · PC board assembly fault			
÷	⇒	৵	E3	Outdoor unit · High-pressure switch fault			
÷Þ	⇒	⇒	E4	Outdoor unit · Low-pressure switch fault			
÷.	÷.	÷Þ	E9	Outdoor unit · Electric expansion valve motor (20E) error			
¢	•	⇒	EC	Heat source unit $\cdot$ Intake water temperature inter-lock operation (fan operation)			
÷	⇒	⇒	EF	Outdoor unit · Ice thermal storage unit error			
⇒	⇒	⇒	F3	Outdoor unit · Discharge piping temperature error			
¢.	•	⇒	H3	Outdoor unit · High-pressure switch operation			
÷	÷	৵	H4	Outdoor unit · Low-pressure switch operation			
⇒	⇒	⇒	H9	Outdoor unit · Outdoor air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)			
☆	•	⇒	H9	Outdoor unit · Outdoor air thermistor (Th1) Error (faulty connection, cut wire, short circuit, fault)			
¢.	•	⇒	НС	Outdoor unit · Water temperature sensor system error			
\$	•	৵	HF	Ice thermal storage unit error, ice thermal storage controller err error in outdoor unit during ice thermal storage operation			
⇒	⇒	⇒	HJ	Outdoor unit · water system fault			
৵	⇒	৵	J1	Outdoor unit · pressure sensor error			
৵	⇒	⇒	J3	Outdoor unit · Discharge piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)			
\$	•	⇒	J3	Outdoor unit · Discharge piping thermistor (Th3) Error (faulty connection, cut wire, short circuit, fault)			
÷ <b>þ</b>	÷Þ	÷Þ	J5	Outdoor unit · Intake piping thermistor (Th4) Error (faulty connection, cut wire, short circuit, fault)			
÷\$	⇒	÷\$	J6	Outdoor unit · Heat exchange thermistor (Th2) error			
☆	•	⇒	J6	Outdoor unit · Heat exchange thermistor (Th2) error Error (faulty connection, cut wire, short circuit, fault)			
÷,	÷	⇒	J7	Outdoor unit · Header thermistor (Th6) error			
÷Þ	÷Þ	÷	JA	Outdoor unit · Discharge piping pressure sensor error			
⇒	⇒	⇒	JC	Outdoor unit · Intake piping pressure sensor error			
৵	÷	⇒	JF	Outdoor unit $\cdot$ Oil temperature sensor (Th5) system error			
☆	•	⇒	JH	Outdoor unit $\cdot$ Oil temperature sensor (Th5) system error			
À	⇒	⇒	LO	Outdoor unit · Inverter system fault			
À	- <b>)</b>	- <b>)</b>	L4	Outdoor unit · Inverter cooler fault			
×)		->	L5	Outdoor unit · Ground circuit for compressor motor, short circuit, or power unit short circuit			

	~	~	16	Outdoor unit. Cround airquit for compresses mater, about airquit			
¢-	-Þ	*	L6	Outdoor unit · Ground circuit for compressor motor, short circuit			
÷	- <b>`</b> Þ	÷Þ	L8	Outdoor unit · Compressor overload, compressor motor wire disconnection			
৵	-⊅	⇒	L9	Outdoor unit · Compressor lock			
⊅	⊅	⇒	LA	Outdoor unit · Power unit error			
≯	-≯	৵	LC	Outdoor unit · Transmission error between inverter and outdoor control unit			
☆ or ●	-⊅	⇒	M1	Central controller: PC board fault			
⇔ or ●	.⇔	⇒	M8	Transmission error between central controllers			
⇔ or ♦	÷Þ	⇒	MA	Central controller: Incorrect combination			
⇔ or ♦	->	÷	мс	Central controller: Address setting fault			
\$	٠	÷)	P0	Insufficient gas (thermal storage)			
৵	÷Þ	⇒	P1	Outdoor unit · Power voltage imbalance, phase loss			
- <b>Þ</b>	->	÷	P4	Outdoor unit · Power unit temperature sensor error			
÷¢-	•	⇒	U0	Pressure drop due to insufficient refrigerant, electric expans valve fault, etc.			
⇒	- <b>Þ</b>	⇒	U1	Reversed or lost phase			
.≯	÷Þ	⇒	U2	Power voltage error, momentary electrical stoppage			
*	-⊅	÷Þ	U4	Transmission error between indoor unit/BEV unit and outdoor/BS unit, Transmission error between outdoor unit and BS unit			
⇒	- <b>Þ</b>	⇒	U5	Transmission error between remote controller and indoor control unit			
•	*	•	U5	Remote controller board fault or remote controller setting fault			
⇒	-⊅	⇒	U6	Transmission error between indoor units			
≯	- <b>'</b> Þ	৵	U7	Transmission error between outdoor units Transmission error between outdoor unit and ice thermal storage unit			
¢	•	⇒	U7	Transmission error between outdoor units (cooling/heating batch, low-noise operation)			
*	৵	•	U8	Transmission error between master remote controller and slave remote controller (slave remote controller error) Incorrect combination of indoor unit and remote controller within a single system (model)			
৵	⊅	¢	U9	Transmission error between indoor unit/BEV unit and outdoor unit within a single system Transmission error between BS unit and indoor unit/BEV unit and outdoor unit within a single system			
≫	Þ	৵	UA	Incorrect combination of indoor, BS, and outdoor units within a single system (model, number of units, etc.) Incorrect combination of indoor unit and remote controller (remote controller in question) BS unit connection position fault			
☆	٠	☆	UC	Central control group numbers overlap			
÷.	-\$	⇒	UE	Transmission error between indoor unit and central controller			
-¢-	⊅	∻	UF	Unset system, incorrect settings between BEV unit and indoor unit			
->Þ	- <b>Þ</b>	⇒	UH	System fault			

- error codes (in outline font) do not display "maintenance" and the system will run, but please check the content of the display and contact your dealer.

#### Setting master remote controller (Fig. 15)

You must set the master remote controller of the operation mode for one of the indoor units, if two or more such indoor units with the remote controller are connected with the outdoor unit where the operation modes such as cool/heat operation and FAN operation can be set by remote controller and central remote controller.

#### 1. Preparations

When you want to fix settings

- Check the particular group with the master remote controller setting for the refrigerant system you wish to reset. (See the below.)
- · Call up the group without the display

" 💽 🙏 " (See page 16.)

The Hold the OPERATION MODE SELECTOR BUTTON down for about four seconds while the above group is being called up.

The display " [], " flashes on the liquid crystal display of the remote controller for all the groups sharing the same outdoor unit or BS unit.

When you turn on the power switch for the first

time, the display" [] time, the display. " flashes.



#### **2.** Setting selection right

Pall up the desired group to set the master remote controller, and for press the OPERA-TION MODE SELECTOR BUTTON. The master remote controller is set for this group, and the

display " 💽 🧶 " goes out. The display

"
 "
 "
 "
 "
 appears for the other groups.
 Setting is finished now.

When switching operation

• In case of operation switch Call up the zone including the group with the setting of master remote controller.

(Zone without the display " [] , ")

The Press the OPERATION MODE SELECTOR BUTTON several times, and switch to the desired operation mode.

NOTE

 However, the displays " (A) " " (B) " and "VENTI-LATION MODE" may apper in some zones, depending on the type on indoor unit with which they are connected. (VENTILATION MODE)

📇 or 🕱 or 🏏

#### [System Display]

- 1. Test run mode is necessary to display the system display.
- 2. In order to turn on test run mode, select the appropriate air conditioner on the individual screen with the cursor and then set its operation mode to either cooling or heating. (It makes no difference if the air conditioner is running or not running while this operator is being performed.)
- 3. Press the "inspection/test run" button twice to put it into test run mode.
- 4. Pressing the "inspection/test run" button for four or more seconds in test run mode will display IP the "REF CIRCUIT."



Call the unit whose system you wish to look up using the arrow keys.

The " I on all groups in the same system as the displayed group will light up.

Of those, the " **[**" display in all groups which have cooling/heating selection privilege will blink.



In this example, individual units 1-00, 1-03, 1-05, 1-06, 1-07, 2-02, and 2-03 are in the same system, and 1-05 has the cooling/heating selection privilege.

To look up other systems, call up all the units you wish to look up using the arrow keys.

Pressing the inspection/test run button one more time gets rid of the system display and ends it.

The unit will enter the individual screen automatically if nothing is done for one minute in the system display screen.

This function may not be available for all connected outdoor units, in which case "REF CIRCUIT" will blink. It will also not be correctly displayed if DIII-NET extension ADP is used.

#### ■ Display of time to clean (Fig. 16)

This central remote controller displays the time to clean the air filter or air cleaner element for each group or any given group by utilizing two types of signs. The display " 같이, 플라" tells the time to clean the air filter or the air

cleaner element of some group.

#### If a cleaning sign is displayed

A filter or element in some group is ready to be cleaned.

1. ①<sup>¬</sup> Press the ARROW KEY BUTTON, and search the groups displaying " → " or

" 💒 " (The group may be plural.)

# Clean or change the air filter or air cleaner element.

For further details, see the operation manual attached to each indoor unit. (Clean or change the air filter or air cleaner element of all the groups dis-

playing " 🚰 " or " 🚛 ".)

#### 2. ② Press the FILTER SIGN RESET BUT-TON, and the display " → " disappears. (Including all the groups where the air filter has been cleaned.)

#### NOTE

Be sure to check the display I " J has disappeared at this point. The appearance of the above display is a sign that the air filter or air cleaner element of some group still needs cleaning.

# INSTALLATION TABLE

When installing the equipment, mark the zone No. of each group and installation location in the below table.

#### Setting group No.

(Setting is not possible unless power is activated to both the central remote controller and indoor unit.)

#### Operated by remote controller

- 1. Activate power to both the central remote controller and indoor unit.
- 2. While in the normal mode, hold down the " 圕" button for a minimum of 4 seconds. The unified ON/ OFF controller will enter the FIELD SET MODE.
- 3. Select the MODE No. " 🔐 " with the " 🗐 " button.
- Use the " " button to select the group No. for each group. (Group No. increases in the order of 1-00, 1-01 ... 1-15, 2-00, ... 8-15.)
- 6. Press "🖑 " to return to the NORMAL MODE.



#### Operated by simplified remote controller

- 1. Activate power to both the central remote controller and indoor unit.
- 2. Remove the upper part of the remote controller.
- 3. Press the **BS6** BUTTON (field set) on the PC board. The controller will enter the FIELD SET MODE.
- 4. Select the MODE No. " 10" with the BS2 BUT-

TON and BS3 BUTTON (temperature setting).

- 5. Use the BS9 BUTTON (set A) and BS10 BUTTON (set B) to select the group No. for each group. (Group No. increases in the order of 1-00, 1-01 ... 1-15, 2-00, ... 8-15.)
- 6. Press BS7 BUTTON (set/cancel) to set the selected group No.
- 7. Press BS6 BUTTON (field set) to return to the NORMAL MODE.



Zone No.																
Group No.	-00	-01	-02	-03	-04	05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																
Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																

Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																
Zone No.																
Group No.	-00	-01	-02	-03	-04	-05	-06	-07	-08	-09	-10	-11	-12	-13	-14	-15
Indoor unit Quantity of units Controlled by																
Location																

### **OPTIONAL ACCESSORIES**



You can perform the normal operation, take off the malfunction contact point and unified start/stop by contact point, all by connecting this unit with the unification adaptor for computerized control. For further details, ask your DAIKIN dealer.

(a) Unification adaptor for computerized control (b) Central remote controller

# DOUBLE CENTRAL REMOTE CONTROLLERS



With two central remote controllers, centralized control (indoor units) is possible from different locations.

(a) Central remote controller
(b) Group No. 1 – 00
(c) Group No. 1 – 15
(d) Group No. 2 – 00
(e) Group No. 4 – 15
(f) A maximum of 64 groups

Note)

• For control alignment and settings for double central remote controllers, contact your dealer.

# SPECIFICATIONS

#### Specifications

Power supply	1 ~ 50/60Hz, 100V – 240V
Power consumption	Max. 8W
Forced ON/OFF input	Continuous "a" contact Contact current: approximately 10mA
Size	180 (W) × 120 (H) × 64.5 (D)
Weight	420g

#### ■ Outline drawings



When using this unit an electric parts box of KJB311A is required. For installation, a steel electric parts box to be embedded is mandatory.



Fig. 9



Fig. 10



Fig. 11





Fig. 13



Fig. 14



Fig. 15

Fig. 16



26

3P124623-1E

# 13.7 <DCS301C71> Unified ON/OFF Controller

# 13.7.1 Installation Manual

<text></text>	
<form> A ADDITION  I relation to relation to relation to relation to the interview intervie</form>	installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference.
<form> A ADDITION  I relation to relation to relation to relation to the interview intervie</form>	
Even series of the series	<ul> <li>WARNING Indication a potentially hazardous situation which, if not avoided, could result in death or serious injury.</li> <li>CAUTION Indication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be sued to alert against unsafe practices.</li> </ul>
Air your dealer or qualified personnel to carry our installation work. Do not try to install the machine by yourself. Improver installation may read in water stabulation work after stabulatin after stabulatin wo	As Note
Air your dealer or qualified personnel to carry our installation work. Do not try to install the machine by yourself. Improver installation may read in water stabulation work after stabulatin after stabulatin wo	
Improvementaliation may result in water leakage, electric shocks or fine.  Perform installation may result in water leakage, electric shocks, fine or the unit lang.  Perform installation may result in water leakage, electric shocks, fine or the unit lang.  Perform installation may result in water leakage, electric shocks, fine or the unit lang.  Perform installation work in accordance with the installation manual.  Perform installation work in accordance with the installation manual.  Perform installation work may result in the explanment failing and causing accounts at any match that electrical work is a carried out by qualified personnel according to Local water and you work in accordance with the installation manual.  Perform installation work may result in the explanment failing and causing accounts at any match work is a carried out by qualified personnel according to Local water and you work in accordance with the installation manual.  Perform installation work may result in electric abooks, fine or the terminal connections or wires.  Perform installation work in accordance work in accordance withing and transmission wiring, position the wires so that the electric parts box il discover works.  Perform installation or the all contrictions dow in a prevent in electric abooks, fine or the terminals covertheating.  Perform installation or electrical parts, turn off the unit.  Perform installation or electrical parts, turn off the unit.  Perform installation or electrical parts, turn off the unit.  Perform installation or the protection devices.  Perform installation accounter the installation work and protection devices.  Perform installation accounter the protection devices.  Pe	▲ WARNING
Improgrammaladion may result in water leakage, electric shocks of the.  Be var to use of the specified caresonies and parts for installation work. Failure to use the specified parts may result in the reakenest electric installation work.  Failure to use the specified caresonies and parts for installation mork.  Failure to use the specified caresonies and parts for installation mork.  Failure to use the specified caresonies and parts for installation manual.  An installect proves supply carely to repute level and used and no external forces act on the terminal connections or wires.  Improper connections or installation manual.  When wing the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box is all interprove metal.  The prover supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box is all interprove metal.  The prover supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box is all interprove metal.  The prover supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box is all interprove metal.  The prover supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box is all interprove metal.  The conditioner, Do not connect the ground wire to gas or water pipes. Ilghtning rod or a telephone ground wire.  The provers supply the prover supply and connecting the prove to device is allored and operated kinckly, or parts other than the specified refrigerant (At10A), allo and excent bracket and excent bracket.  The provers supply the specified and the metal and the device is allored and operated kinckly, or parts other than the sequelled parts and the provestion device.  The provestical parts, turn of the provestion device is allored and operated kinckly, or parts other wire	
Failure to use the specified nataliands owerk are taking in electric stocks, fire or the untilling.  From yout the specified installation work are taking in the equipment alling and causing accidents.  Make sure that a specified nataliands owerk are taking in the equipment alling and causing accidents.  Make sure that a specified nataliands owerk are taking in the equipment alling and causing accidents.  Make sure that all wring is accured, the specified writes and used, and no external forces act on the terminal connections or writes.  Improper connections or installation my result in the entityment and that all electrical work is carried out by qualified personnel according to An instillent proves supply cance) or improper electrical and.  When writing the power supply and connecting the remote controller wring and transmission wring, position the wrises so that the electric parts box il due to the second proves and the installation of the electric parts box il due to the second proves according to A on a connect the ground write to gas or water pipes. Iightning rod or a telephone ground write.  Concording to ground write to be second proves the proves the or the terminal eventhating.  Proves supply canced or or the unit.  Concording to ground write to pass or water pipes. Iightning rod or a telephone ground write.  Concording to ground write to pass or water pipes. Iightning rod or a telephone ground write.  Concording to ground write to pass or water pipes.  Proves supply canced or or the protection davidsen.  Proves supply canced or the remote controller write and a coporate forciby, or parts other than these specified py Jakin are used, fire or capcing a subtry with we finger and cause electric parts.  Prove controller breakers and chause electric parts.  Prove controller breakers and chause electric parts.	
Corr or the specific installation work der staking into account advances under strong under, hyboren or earthquakes. Improprie installation work my estall the expanses fully and causing advances advan	
Improgen installation work may result in the acjupment failing and causing accidents. A lease sure that a separate power supply capacit proper decide for this unit and that all decide looks or the. Make sure that all writing is secured, the specified writes and used, and no external forces act on the terminal connections or writes. Improper connections or installation may result in the control or writes and used, and no external forces act on the terminal connections or writes. Improper connections or installation may result in the core specified writes and used, and no external forces act on the terminal connections or writes. Improper connections or installation may result in electric shocks, fire or the terminals overheating. Before backing decide parts box it may result in electric shocks, fire or the terminals overheating. Before backing resonance in the section may result in electric shocks. Incomplete grounding may result in decide shocks. Incomplete grounding may result in decide shocks. Incomplete grounding may result in decide shocks. In the installing or relocating the system, be sure to keep the refrigerant circuit free from subtances other than the specified refrigerant (At19A), as a all. Do not ecconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection devices is shorted and operated locably, or parts other than those specified by Dakin are used, fire or explosion may result with terf or can cause device than any result. Install net k circuit breaker, as required. If a net k circuit breaker, as required. If an electric all protects and protects of the result in water leakage. If where an internal or all off or result in water leakage. If where an internal electric and that off or result in water leakage. If where an internal or all off or result in water leakage. If where an internal or all off or result in the electric plays with a plastic bag with a plastic bag with was not rom apart, they face there in an addi	
local awain of equivations and this installation manual.         An insultient power supply capad to imposer electrical construction may lead to electric shocks or tire.           Make success that all wring is secured, the specified writes and used, and no external forces act on the terminal connections or writes.         Imposer connections or installation may result in fact.           When wring the power supply and connecting the rende controller wring and transmission wring, position the writes so that the electric parts box lid in any result in electric aboxs. If or on the terminals overheating.         Construction of the electric parts box lid may result in electric aboxs. If or one terminals overheating.           Defers touching electrical parts, turn off the unit.         Construction of the electric parts box lid may result in electric aboxs.           Do not econstruct or change the settings of the protection devices.         The pressure switch, thermal work, or other protection device is aborted and operated forciby, or parts other than the sepecified retrigerant (R410A), such as at.           Do not econstruct or change the settings of the protection device is aborted and operated forciby, or parts other than these specified by Dalkin are used, fire or exploans may its add is not install device in down.           Installer all eak circuit breaker, as required.         Installer all eak circuit breaker, as required.           In all eak circuit breaker, as required.         Installer all eak circuit breaker, as required.           In all eak circuit breaker, as required.         Install in the ir contification and fail of result in water lakage.           Corrording oper or	Improper installation work may result in the equipment falling and causing accidents.
Improper positions or installation may result in fire.  Insproper positioning of the electric parts box lid may result in electric shoks, fire or the terminals overheating.  Before touching electrical parts, turn of the unit.  Ground the air conditions: Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire.  Incomplet grounding may result electric shoks.  The installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A),  touch as air.  Do not eccentrate or change the settings of the protection devices. If go resonature or change the settings of the protection devices is shorted and operated forcibly, or parts other than thes specified by Dakin are used, fire or contains which, or other protection devices is shorted and operated forcibly, or parts other than these specified by Dakin are used, fire or a basis parts which with welf fingers. Touching a switch with welf fingers.  Touchinge	local laws and regulations and this installation manual.
When writing the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid may result in electric shocks, fire or the terminals overheating. Before touching electrical parts, turn off the unit. Ground the air conditions: Do not connect the ground wire to gas or water pipes, lighthing rod or a telephone ground wire. Incomplete grounding may result in electric shocks. When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A). Do not reconstruct or change the settings of the protection device. If the source other than the specified refrigerant (R410A). Do not reconstruct or change the settings of the protection device. If the source other than the specified refrigerant (R410A). Do not nouch the switch with welf fingers. To construct or change the settings of the protection device. If the source other than the source other than those specified by Daikin are used, fire or explosion may result. Do not nouch the switch with welf fingers. To construct or the source other there constructed in the following locations: (a) the a nimerial of main of a source other than tensor other in the following locations: (b) correcting on the source other source other in the following locations: (b) correcting on the source other source other in the following locations in the argument. (c) other antimetal of an all spray or vapor is produced, for example in a klachen Passic part and theory source other in the source other source other in the source of installate. (c) other antimetal of an all spray or vapor is produced, for example in a klachen Passic part and theory and the data source other indications may result in efficient in the source of indications in the arg or where volatile flammables such as thinner or ignition wires in stallate.<	
can be securely fastend. Improper positioning of the electrical parts, turn off the unit. Ground the air conditioner. Do not connet the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incompiled grounding may result in electrica bases. When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), to a air. Do not connet the electrical parts, turn off the unit. Ground the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incompiled grounding may result in decrite shock. Installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than these specified by Daikin are used, fire or explosion may result. Do not concent weeks in so in final electric shock. Install in a lesk circuit presents in so in final electric shock may result. Do not install the air conditioner or the remote controller in the following locations: Installing a switch with well fingers. In electrical parts may deferred and gas or y explose its produed, for example in a kitchen Pakit parts may deferred and skil of or result in water leakage. In organo preserve serve serve there are eachon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handed. Operating the unit in such conditions may result in fire.  De to to the power immediately and serve serve of the power preserve serve set by the state set on the fire or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handed. Operating the unit is such conditions may result in fire.  De to trut of the power immediately are set on the form pay with the mile trut in the set or other inputies. Tear appart and hand or the power immediately water pays and the unit in the set or other inputies. Compare the set of set of the power immediately are set of the power immediately are set on the or other power impute set or and	
Before touching electrical parts, turn off the unit. Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incompiled ground wire electric shocks. When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air. Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than these specified by Dakin are used, fire or explosion may result. Touching a switch with wet fingers. Touching a switch with wet fingers can cause electric shock. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than these specified by Dakin are used, fire or explosion may result. Do not touch the switch with wet fingers can cause electric shock. If the last circuit breaker, as required. If an leak circuit breaker is not installed, electrici shock. If an leak circuit breaker is not installed, electrici shock, for example in a klichen Pasic parts may deteriorize and short or result in refrigerant leakage. If or corriding copper pipes or soldered parts, may cause shake on other liquires. To ear and shale with event electrici breaker. If or ear maching leak, where there ear cachon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. If the power fiber dusting breaker is the statil or wooden parts, may cause stabs or other liquires. Tear apart and threaker wave yalesid pacases of that children will not pla	can be securely fastened.
Ground the air conditioner, Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire.         Incomplete grounding may result in electric stocks.         When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.         Do not reconstruct or change the settings of the protection devices.         If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or acyclosion may result.         Do not touch the switch with wet fingers.         Touching a switch with wet fingers can cause electric shock.         Install an leak circuit breaker as not installed, electric shock may result.         Do not install we are and fail of or result in water leakage.         (b) where a mineral of mist or an 01 spray or vapor is produced. for example in a kitchen Plasic parts may deterorise and fail of or result in water leakage.         (c) where a formable gase may disturb the operation of the ortical system and result in a mailunction of the equipment.         (c) where a formable gase.         (c) where a finamable gase.     <	
Incomplete grounding may result in electric shocks.  When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.  Do not reconstruct or change the sufting of the protection device is shorted and operated forcibly, or parts other than those specified by Dakin are used, fire or explosion may result.  Do not control the switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Dakin are used, fire or explosion may result.  Do not control the switch with wet fingers. Touching a switch with wet fingers can cause ellectric shock.  I an leak circuit breaker as required. I an elligit and the result on with relegarant leakage. I and the metal on sort or vargand on of the cort legarant leakage. I and the relegarant difter circuit and the relegarant leakage. I Bectornaptic waves any as leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as talls as the order to prevent integer Packing metal fields. Do not turn of the power inmediately after stopping operatio	
such as alr.           Do not reconstruct or change the settings of the protection devices.           If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Dakin are used, fire or explosion may result.           Do not took the switch with wet fingers.           Touching a switch with wet fingers can cause electric shock.           Install an leak circuit breaker is not installed, electric shock may result.           Do not took the switch with wet fingers.           (a) where a mineral of mist or and ispany or vapor is produced, for example in a kitchen or their owne base studies on dispany or vapor is produced. (and the present electron of the result is preduced, for example in a kitchen or their owne should be studies as utilized of or result is prefigurent leakage.           (a) where a mineral of mist or an ispany or vapor is produced, for example in a kitchen or their owne should be discuss a sufficient of the owne week line and electron appendic wave may result in diffigurant leakage.           (b) where fammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handed.           Operating the unit in such conditions may result in fre.           Select and other metal or wooden parts, may cause stabs or other injuries.           Tare apart and throw away plastic packaging bags so that children will not play with them. It children play with a plastic bag which was not torn apart, they face the risk of sufficient.           Do tot turn off the power immediately after stop	
If the pressure switch, thermai switch, or other protoction device is shorted and operated forcibily, or parts other than those specified by Daikin are used, fire or explosion mary result.  Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.  If an leak circuit breaker, is required. If an leak circuit breaker is not installed, electric shock mary result.  Do not install an leak circuit breaker is not installed, electric shock mary result.  If an leak circuit breaker is not installed, electric shock mary result.  If an leak circuit breaker is not installed, electric shock mary result.  If an leak circuit breaker is not installed, electric shock mary result.  If an leak circuit breaker is not installed, electric shock mary result.  If an advector is present and dent of a result in water leakage.  If an ear maneral of mits or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deletrionale and all of or result in water leakage. If electromaphic wates is and other or result in water leakage. If electromaphic wates is and disturb to operation of the control system and result in a malfunction of the equipment. If where flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire.  De very careful about product transportation.  Set of gasoes of the packing materials. De has nalls and other metal or wooden parts, may cause stabs or other ripuries. Tear apart and three vany leaker stopping operation. Aways wat at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Aways wat at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Records and out off the prover supply wiring and connecting wires at least 3.5.ft. away from televisions or radios in order to prevent image interference or noise. (Depe	
Touching a switch with well fingers can cause electric shock. Install an leak circuit breaker, as required. If an leak circuit breaker, is not installed, electric shock may result. Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral of mits or a nol isorgor or yapor is produced for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage. (b) where corrosive gas, such as suffurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage. (c) near manchinery emitting electromagnetic waves Electromagnetic waves may clastur the operation of the control system and result in a maffunction of the equipment. (c) where finamable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire.  Safey dispose of the packing materials. Packing materials. Tear agart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. Do not un off the power immediately after stopping operation. Aways wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Mays wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Mays wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Menote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps.  (Invert or rapid start types) Install the indoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise.  (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the no	If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or
Install an leak circuit breaker, as required. If an leak circuit breaker is not installed, electric shock may result. Do not install the air conditioner or the remote controller in the following locations: (a) where a mineral oil mist or an oil spary or vapor is produced, for example in a kitchen Pasic porter may clearboare and fail of or result in water leakage. (b) where corrosive gas, such as sulfurous acid gas, is produced Coroding copper pipes or soldered parts may detendine may result in refrigerant leakage. (c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment. (d) where finammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile finammables such as thinner or gasoline are handled. Operating the unit in such conditions may result in fire. <b>Safely dispose of the packing materials.</b> <b>Packing materials.</b> <b>Back models.</b> <b>Suff dispose of the packing materials.</b> <b>Packing materials.</b> <b>Back materia</b>	
<ul> <li>(a) where a mineral of mist or an oil spray or vapor is produced, for example in a kitchen Platis trans deferories and all of result in water leakage.</li> <li>(b) where corrosive gas, such as sulfurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage.</li> <li>(c) near machinery emitting electromagnetic waves Electromagnetic waves may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled.</li> <li>(d) where identify materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffication.</li> <li>Do not turn off the power immediately after stopping operation.</li> <li>Always wait at least live minutes before turning off the power. Otherwise, water leakage and trouble may occur.</li> <li>Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise.</li> <li>(Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.)</li> <li>Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverteor radio stars, and yrom fluorescent lamps as possible.</li> <li>This unit is a class A prod</li></ul>	Install an leak circuit breaker, as required.
Be very careful about product transportation. Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. Do not turn off the power immediately after stopping operation. Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.  Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	<ul> <li>(a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage.</li> <li>(b) where corrosive gas, such as sulturous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage.</li> <li>(c) near machinery emitting electromagnetic waves Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment.</li> <li>(d) where flammable gases may leak, where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled.</li> </ul>
Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. Do not turn off the power immediately after stopping operation. Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur. Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	
Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation. <b>Do not turn off the power immediately after stopping operation.</b> Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur. <b>Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. <b>This unit is a class A product.</b> In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. <b>Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national</b></b>	
Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.	Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face
Install the indoor and outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or radios in order to prevent image interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	
Interference or noise. (Depending on the radio waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.) Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start type) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	▲ NOTE
Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types) Install the indoor unit as far away from fluorescent lamps as possible. This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	interference or noise.
This unit is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	Remote controller (wireless kit) transmitting distance can result shorter than expected in rooms with electronic fluorescent lamps. (inverter or rapid start types)
Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national	This unit is a class A product.
	Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national



Detterm		s as indicated in the	0		1	troller ir				
Unified ON/OF		f optional controllers Central remote cont		Schedule timer		ed ON/C	onnector for setting ma DFF controller		emote controller	Schedule ti
1 to -	16	1 to 4			Se	et all to '	all the rest to "Not used". 'Not used".		(Note)	
		1 to 4		1			all the rest to "Not used". 'Not used".		(Note)	"Not use "Not use
centra 2 Switch for These sw	l remote contro r setting each a itches are usec	iller. iddress (DS1) I to set group contr	ol addres	SS.			emote controller, see			ovided with t
	)~1-15 2-00~2-1	· · ·				) ~ 8-15	NOTE)	•		
DS			SC as				<ul> <li>indicates the position of switches.</li> </ul>			
DS1 setting	1 2 3 Set each adr ON 1 2 3 Set coch adr	ON Set each adr 1 2 3 Set each adr	1 2 3 Set each adre	Set each adre	ON 1 2 3 Set each adr	1 2 3 Set each adr			(To hold reset)	
	ory setting)						Connector f	Ŭ	master controller	<del></del> ►૧ સ
				able to respective on the diagram below		of the	Switz		rced reset switch ng each address	<b>1</b> 6∼ , , , , , , , , , , , , , , , , , , ,
		Evennele)					Switt		ol mode selector	
		Example) n the case of 1-00	to 1-15, a	attach 1.					IN/SUB changeo	¶
							Outdoor unit			
One of the 4 Setting of The unifier	two unified ON/0 the sequential of d ON/OFF contr	DFF controllers (1).(2 operation function roller is equipped wi	!) is set to th a	N/SUB changeover sw "MAIN" while the oth			nified ON/OFF	<u>1–00</u> Max. of	1-15 16 groups	Unified Of controlle
indoor unit operation.	ts on in 2-secon (Sequential ope	ion that sequentially d intervals during un eration is factory set ation ON or OFF, se	nified to "ON.")	Sequential operati "ON" (Factory set)	on 🚽 🔤		g down the unified stop but			Sequential op "OFF"
NOTE: The se	equential opera	tion function is des	signed to	reduce the load or			quipment, but does n er supply equipment			sors will not
	ode selector (E ving four pattern	DS2) ns of control mode	can be s	et.						
Control mode	l.	ndividual		Centralized		Tir	mer operation possible remote controller	by	ON/OFF contr by remote	rol impossible controller
Content		is controlled by both F controller and er.	contro	operated by unified ON oller, operation/stop is f olled by remote controll bed by unified ON/OFF	reely er until	operation controller	ed in conjunction with schedu /stop is controlled freely by r during the set time but oper ble when schedule timer is C	emote ( ation is (	Dperation/stop is con DN/OFF controller on This unit can not be remote controller.)	ily.
DS2 setting	(Factory set)									
				-			-		5	



# **6** SETTING GROUP NO. FOR CENTRALIZED CONTROL



Before starting test operation, supply power to the indoor units, outdoor units, and unified ON/OFF controller and press the ON/OFF BUTTON. If the operation lamp flashes, it indicates a malfunction in the indoor unit of the applicable group. If the display of " \_\_\_\_\_ " flashes, it indicates a malfunction in the optional controllers for centralized control. Check for such malfunctions.

NOTES • For test operation of indoor and outdoor units, refer to the installation manual attached with the outdoor unit.

After turning the power supply ON, if the unit does not accept operation for two minutes or more with the display of "\_\_\_\_\_\_" flashing, check the following points.
 Check that setting of the connector for setting master controller is correct.

Check that the group No. for centralized control has been set.

1P126474-1B

1

# 13.7.2 Operation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the install operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public" Meaning of warning, caution and note symbols.	lation, make sure that the unit
operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public"	
Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public"	
This air conditioner comes under the term "appliances not accessible to the general public"	
Meaning of warning, caution and note symbols.	
X WARNING Indication a potentially hazardous situation which, if not avoided, could result in death or serious injury.	
A CAUTION Indication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be sued to alert again	nst unsafe practices.
NOTEIndication situation that may result in equipment or property-damage-only accidents.	
Keep these warning sheets handy so that you can refer to them if needed.	
Also, if this equipment is transferred to a new user, make sure to hand over this operation manual to the new user.	
In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off power and call your dealer for instructions. Ask your dealer for installation of the air conditioner.	
Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.	
Ask your dealer for improvement, repair, and maintenance.	
Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire. Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipme	nt
In poper instances or accessories made by Dalkin which are specifically designed for use with the equipment and, are to enter installed by a professional. Be sure only to use accessories made by Dalkin which are specifically designed for use with the equipment and, are them installed by a professional.	ant.
Ask your dealer to move and reinstall the air conditioner or the remote controller.	
Incomplete installation may result in a water leakage, electric shock, and fire.	
Never let the indoor unit or the remote controller get wet. It may cause an electric shock or a fire.	
Never use flammable spray such as hair spray, lacquer or paint near the unit.	
It may cause a fire.	
Never replace a fuse with that of wrong ampere ratings or other wires when a fuse blows out.	
Use of wire or copper wire may cause the unit to break down or cause a fire.	
Never inspect or service the unit by yourself. Ask a qualified service person to perform this work.	
Cut off all electric waves before maintenance.	
Do not wash the air conditioner or the remote controller with excessive water.	
Electric shock or fire may result.	
Do not install the air conditioner or the remote controller at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.	
Do not touch the switch with wet fingers.	
Touching a switch with wet fingers can cause electric shock.	
After a long use shock the unit stand and fitting for damage	
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury.	
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it.	
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it. Falling or tumbling may result in injury.	
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it.	
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it. Falling or tumbling may result in injury. Do not let children play on and around the unit.	
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or tumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.	
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or tumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not tet children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not tel children play on and around the unit.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not tel children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not tel control panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not tet children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.	
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not glace a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not glace glower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the	vick of orificantian
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fungation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.	prisk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or tumbling may result in injury.         Do not let children play on and around the unit.       If they souch the unit carelessly, it may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Don termove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.       Avoid placing the controller in a spot splashed with water.         Water roming inside the machine may cause an electric leak or may damage the internal electronic parts.       Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.       Packing materials.         Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries.       Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was	Prisk of suffocation.
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it. Falling or tumbling may result in injury. Do not let children play on and around the unit. If they touch the unit carelessly, it may result in injury. Do not place a flower vase and anything containing water. Water may enter the unit, causing an electric shock or fire. Never touch the internal parts of the controller. Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen. For checking and adjusting the internal parts, contact your dealer. Avoid placing the controller in a spot splashed with water. Water coming inside the machine may cause an electric leak or may damage the internal electronic parts. Do not operate the air conditioner when using a room funigation - type insecticide. Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals. Safely dispose of the packing materials. Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not turn off the power immediately after stopping operation.	Prisk of suffocation.
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.         Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not t	p risk of suffocation.
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.         Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children will not play w	risk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or trumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.       Avoid placing the controller in a spot splashed with water.         Water roming inside the machine may cause an electric leak or may damage the internal electronic parts.       Oo not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.       Safely dispose of the packing materials.         Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries.       Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not turn off the power immediately after stopping operation.         Always wait at least five minutes before turning off the power.       O	risk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or trumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.       Avoid placing the controller in a spot splashed with water.         Water roming inside the machine may cause an electric leak or may damage the internal electronic parts.       Oo not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.       Safely dispose of the packing materials.         Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries.       Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not turn off the power immediately after stopping operation.         Always wait at least five minutes before turning off the power.       O	p risk of suffocation.
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.         Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children will not play with them. It children play with a plastic bag which was not torn apart, they face the Do not t	e risk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fail and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Failing or tumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not let ca flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Do not place a flower vase and anything containing water.         Vater may enter the unit, causing an electric leak or fire.       Prever touch the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.       Prever touch the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.       Do not parate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.       Previouch parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not urn off the power immediately after stopping operation.         Always wait at least five minutes before turning of the po	e risk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Falling or tumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Do not place allow a space and anything containing water.         For checking and adjusting the internal parts, contact your dealer.       Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.       Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.       Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw waxy plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not turn off the power immediately after stopping operation.         Always wait at least live minutes before turning off the power. Otherwise, water leakage and trouble may occur.	Prisk of suffocation.
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.       Failing or tumbling may result in injury.         Do not let children play on and around the unit.       If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.       Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.       Do not place a flower vase and anything containing water.         For checking and adjusting the internal parts, contact your dealer.       Avoid placing the controller in a spot splashed with water.         Water comig inside the machine may cause an electric leak or may damage the internal electronic parts.       Do not operate the air conditioner when using a room fumigation - type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safely dispose of the packing materials.         Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injures.         Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the boon turn off the power immediately after stopping operation.         Aways wait at least five minutes before turning off the power. Otherwise, water leakage and trou	e risk of suffocation.
After a long use, check the unit stand and fitting for damage. If they are left in a damaged condition, the unit may fall and result in injury. Do not allow a child to mount on the unit or avoid placing any object on it. Falling or tumbling may result in injury. Do not let children play on and around the unit. If they touch the unit carelessit, it may result in injury. Do not place a flower vase and anything containing water. Water may enter the unit, clausing an electric shock or fire. Never fouch the internal parts of the controller. Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen. For checking and adjusting the internal parts, contact your dealer. Avoid placing the controller in a spot splashed with water. Water coming inside the machine may cause an electric leak or may damage the internal electronic parts. Do not operate the air conditioner when using a room fumigation - type insecticide. Taket dispose of the packing materials. Safely dispose of the packing materials. Safely dispose of the packing materials. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not urn off the power immediately after stopping operation. Always wait least five minutes before turing of the power. Cherwise, water leakage and trouble may occur. The appliance is not intended for use by young children or infirm persons without supervision. The remote controller should be installed in such away that children cannot play with it. Never press the button of the remote controller with a hard, pointed object. The remote controller should be installed in such away that children cannot play with it. Never pull or twist the electric wire of the remote controller. It may cause the unit omaliunction.	Prisk of suffocation.
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fail and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Failing or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessly, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not place aflower vase and anything containing water.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water consign linside the machine may cause an electric leak or may damage the internal electronic parts.         Do not operate the air conditioner when using a room fumigation - type insecticide.         Failing on throw away plastic packaging materials.         Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children or unif me persons without supervision.         The appliance is not intended for use by young children or infirm persons without supervision.         The remote controller should be installed in such away that children cannot play with it.         Never pres	Prisk of suffocation.
After a long use, check the unit stand and fitting for damage.         If they are left in a damaged condition, the unit may fall and result in injury.         Do not allow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not encove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts. contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not optace of the packing materials.         Safely dispose of the packing materials.         Packing materials, such as nalis and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and threw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the poor timediately after stopping operation.         Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.         The remote controller should be installed in such away that children cannot play with it.         Never press the button of the remote controller.         I	
After a long use, check the unit stand and fitting for damage.       If they are left in a damaged condition, the unit may fall and result in injury.         Do not all ow a child to mount on the unit or avoid placing any object on it.         Falling or tumbling may result in injury.         Do not let children play on and around the unit.         If they touch the unit carelessit, it may result in injury.         Do not place a flower vase and anything containing water.         Water may enter the unit, causing an electric shock or fire.         Never touch the internal parts of the controller.         Do not emove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.         For checking and adjusting the internal parts, contact your dealer.         Avoid placing the controller in a spot splashed with water.         Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.         Do not oplace the pair conditioner when using a room fungigation + type insecticide.         Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.         Safety dispose of the packing materials.         Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.         Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the Do not turn off the power	



Control mode	Individual	Centralized	Timer operation possible by remote controller	ON/OFF control impossible by remote controller
Content	Operation/stop is controlled by both unified ON/OFF controller and remote controller.	After operated by unified ON/OFF controller,operation/stop is freely controlled by remote controller until stopped by unified ON/OFF controller.	When used in conjunction with schedule timer, operation/stop is controlled freely by remote controller during the set time but operation is not available when schedule timer is ON.	Operation/stop is controlled by unified ON/OFF controller only. Indoor units can not be operated/ stopped by remote controller.
DS2 setting	01 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		04 00 000 000 000 000 000 000 000 000 0	

# **4** DISPLAY OF MALFUNCTION

# Flashing of lamos indicates malfunctions. Contact your Daikin dealer.

When turning ower supply on, all lamps may light and UNDER HOST COMPUTER INTEGRATED CONTROL lamp may flash and not accept the operation for about on minute. These conditions are not malfunctions.

	States of lamps	Contents of malfunctions
Flas	shing of operation lamp	Indicates malfunctions in the indoor unit in the group where the operation lamp is flashing.
Flas	hing of UNDER HOST COMPUTER INTEGRATED CONTROL lamp	Indicates malfunctions in optional controllers for centralized control.

2P126475-1

# 13.8 <DST301BA61> Schedule Timer Controller

Enables you to connect and control weekly schedule for up to 128 indoor units all together.



- Simultaneous control of up to 128 indoor units is managed by a week schedule.
- The start and stop time for twice a day can be set for the week in increments of 1 minute.
- By combining with a central remote controller and schedule timer, you can construct a system that matches the size and use of the building.
- If used together with a central remote controller, you can set up to 8 schedule patterns which can be distributed among zones as desired using the central remote controller.
- Is equipped with a compensation function for power failure up to 48 hours.
- Features thin design of a mere 16 mm in thickness. (Uses JIS recessed box for 2.)
- Wiring can be up to 1 km in length. Applicable wiring methods include bus and star in addition to crossover type.
- Can be used in combination with other D-BACS equipment.

# 13.8.1 Specifications / Dimensions SPECIFICATIONS

#### Specifications

Display of time	12-hour digital display
Clock cycle type	Quartz clock type
Clock accuracy	Within ±30 sec./month (environmental temperature from 15°C to 35°C)
Timer programming	Two pairs of programmed time for both system start and system off can be set in units of minute for each day of the week
Power failure compensation time	Approximately 48 hours for a single occurrence of power failure (clock with No. of programmed time)
Size	120 (W) × 120 (H) × 53 (D) mm (Width/Height/Depth)
Weight	Approximately 210g

#### Outline drawings





Specifications and appearance subject to change without notice.

## 13.8.2 Installation Manual

Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained. Also, inform customers that they should store this installation manual along with the operation manual for future reference. This air conditioner comes under the term "appliances not accessible to the general public".
Meaning of warning, caution and note symbols.
<ul> <li>▲ WARNINGIndication a potentially hazardous situation which, if not avoided, could result in death or serious injury.</li> <li>▲ CAUTIONIndication a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.</li> </ul>
A NOTE Indication situation that may result in equipment or property-damage-only accidents.
▲ WARNING
Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself. Improper installation may result in water leakage, electric shocks or fire.
Perform installation work in accordance with this installation manual.
Improper installation may result in water leakage, electric shocks or fire. Be sure to use only the specified accessories and parts for installation work.
Failure to use the specified parts may result in water leakage, electric shocks, fire or the unit falling.
Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes. Improper installation work may result in the equipment falling and causing accidents.
Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual. An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire.
Make sure that all wiring is secured, the specified wires and used, and no external forces act on the terminal connections or wires. Improper connections or installation may result in fire.
When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened. Improper positioning of the electric parts box lid may result in electric shocks, fire or the terminals overheating.
Before touching electrical parts, turn off the unit.
Ground the air conditioner. Do not connect the ground wire to gas or water pipes, lightning rod or a telephone ground wire. Incomplete grounding may result in electric shocks.
When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.
Do not reconstruct or change the settings of the protection devices. If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Daikin are used, fire or explosion may result.
Do not touch the switch with wet fingers. Touching a switch with wet fingers can cause electric shock.
Install an earth leak circuit breaker, as required. If an earth leak circuit breaker is not installed, electric shock may result.
<ul> <li>Do not install the air conditioner or the remote controller in the following locations: <ul> <li>(a) where a mineral oil mist or an oil spray or vapor is produced, for example in a kitchen Plastic parts may deteriorate and fall off or result in water leakage.</li> <li>(b) where corrosive gas, such as sulfurous acid gas, is produced Corroding copper pipes or soldered parts may result in refrigerant leakage.</li> <li>(c) near machinery emitting electromagnetic waves Electromagnetic waves may leak where there are carbon fiber or ignitable dust suspensions in the air, or where volatile flammables such as thinner or gasoline are handled.</li> <li>Operating the unit in such conditions may result in fire.</li> </ul> </li> </ul>
<b>CISPR 22 Class A Warning.</b> This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Be very careful about	product transportation.
ear apart and throw av	<b>packing materials.</b> n as nails and other metal or wooden parts, may cause stabs or other injuries. way plastic packaging bags so that children will not play with them. If children play with a plastic bag rt, they face the risk of suffocation.
	wer immediately after stopping operation. e minutes before turning off the power. Otherwise, water leakage and trouble may occur.
radios in order to prev	outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or vent image interference or noise.
radios in order to prev (Depending on the radi	outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or vent image interference or noise. io waves, a distance of 3.5ft. may not be sufficient enough to eliminate the noise.)
radios in order to prev (Depending on the radi Remote controller (win fluorescent lamps. (in	outdoor units, power supply wiring and connecting wires at least 3.5ft. away from televisions or vent image interference or noise.






Refer to the installation manual attached to the outdoor unit.

In case the schedule timer is used individually and the wiring is changed after the system has been operated, reset the power after energizing for more than five minutes. It may not be possible to control the unit from the schedule timer.

3P162015-1A

#### 13.8.3 Operation Manual



1



[1]



# SAFETY CONSIDER-ATIONS

Please read these "SAFETY CONSIDER-ATIONS " carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.

Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference.

This air conditioner comes under the term " appliances not accessible to the general public ".

Meaning of warning, caution and note symbols.

- WARNING......Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- CAUTION ...... Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE ..... Indicates situation that may result in equipment or property-damage-only accidents.

# Keep these warning sheets handy so that you can refer to them if needed.

Also, if this equipment is transferred to a new user, make sure to hand over this operation manual to the new user.

## — 🥂 WARNING -

In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off power and call your dealer for instructions.

Ask your dealer for installation of the air conditioner.

Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.

# Ask your dealer for improvement, repair, and maintenance.

Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for use with the equipment and have them installed by a professional.

Ask your dealer to move and reinstall the air conditioner or the remote controller. Incomplete installation may result in a water leakage, electric shock, and fire.

Never let the indoor unit or the remote controller get wet.

It may cause an electric shock or a fire.

Never use flammable spray such as hair spray, lacquer or paint near the unit. It may cause a fire.

#### Never replace a fuse with that of wrong ampere ratings or other wires when a fuse blows out.

Use of wire or copper wire may cause the unit to break down or cause a fire.

Never inspect or service the unit by yourself.

Ask a qualified service person to perform this work.

Cut off all electric waves before maintenance.

Do not wash the air conditioner or the remote controller with excessive water. Electric shock or fire may result.

Do not install the air conditioner or the remote controller at any place where flammable gas may leak out.

If the gas leaks out and stays around the air conditioner, a fire may break out.

**Do not touch the switch with wet fingers.** Touching a switch with wet fingers can cause electric shock.

#### **CISPR 22 Class A Warning:**

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## 

# After a long use, check the unit stand and fitting for damage.

If they are left in a damaged condition, the unit may fall and result in injury.

# Do not allow a child to mount on the unit or avoid placing any object on it.

Falling or tumbling may result in injury.

# Do not let children play on and around the unit.

If they touch the unit carelessly, it may result in injury.

# Do not place a flower vase and anything containing water.

Water may enter the unit, causing an electric shock or fire.

#### Never touch the internal parts of the controller.

Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.

For checking and adjusting the internal parts, contact your dealer.

# Avoid placing the controller in a spot splashed with water.

Water coming inside the machine may cause an electric leak or may damage the internal electronic parts.

# Do not operate the air conditioner when using a room fumigation - type insecticide.

Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.

#### **Safely dispose of the packing materials.** Packing materials, such as nails and other metal or wooden parts, may cause stabs or

other injuries. Tear apart and throw away plastic packaging bags so that children will not play with them. If children play with a plastic bag which was not torn apart, they face the risk of suffocation.

# Do not turn off the power immediately after stopping operation.

Always wait at least five minutes before turning off the power. Otherwise, water leakage and trouble may occur.

The appliance is not intended for use by young children or infirm persons without supervision.

The remote controller should be installed in such away that children cannot play with it.

#### 

Never press the button of the remote controller with a hard, pointed object. The remote controller may be damaged.

# Never pull or twist the electric wire of the remote controller.

It may cause the unit to malfunction.

# Do not place the controller exposed to direct sunlight.

The LCD display may get discolored, failing to display the data.

#### Do not wipe the controller operation panel with benzine, thinner, chemical dustcloth, etc.

The panel may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. And wipe it with another dry cloth.

Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

## CONTENTS

SAFETY CONSIDERATIONS1	
FEATURES AND FUNCTIONS3	;
NAMES AND FUNCTIONS OF	
OPERATING SECTION4	
OPERATION	)
Setting present time	)
Setting no. of programmed time6	i

Change and cancellation of no. of	
programmed time	7
Manual operation	
Operation control code	
Error diagnosing function	
QUESTION AND ANSWER	
SPECIFICATIONS	12
Specifications	12
Outline drawings	12

## FEATURES AND FUNCTIONS



• When used in conjunction with central remote controller (Optional Accessory) The operation controlled by programmed time can be set for up to eight different patterns (timer No. 1 - 8). Each schedule pattern can be also selected.

3

# NAMES AND FUNCTIONS OF OPERATING SECTION (Fig. 1, 2)

	UNIFIED OPERATION BUT-	
1	TON " "	
1	Press this button to perform the unified operation regardless of the No. of pro- grammed time.	-
	UNIFIED STOP BUTTON	
2	" <u>ALL</u> <sup>O</sup> "	
L	Press this button to perform the unified stop regardless of the No. of pro- grammed time.	-
	OPERATION LAMP (RED)	
3	The light turns on during the operation of the indoor unit.	
	DISPLAY " 🖱 🎖 " (TIME NO.)	-
4	Displays the time No. only when used in conjunction with the central remote	
	controller.	-
	DISPLAY "PROGRAM ↓START."	-
5	DISPLAY "PROGRAM → START." (PROGRAMMING START) The light turns on when the timer is	-
	DISPLAY "PROGRAM ↓START." (PROGRAMMING START)	-
5	DISPLAY "PROGRAM J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY	-
6	DISPLAY "PROGRAM → START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by	-
	DISPLAY "PROGRAM J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by timer is not available on that day. DISPLAY " — " (SETTING	-
6	DISPLAY "PROGRAM →J START." (PROGRAMMING START) The light turns on when the timer is programmed. DISPLAY " OFF " (HOLIDAY SETTING) Lights above the day of the week set as holiday. The operation controlled by timer is not available on that day. DISPLAY " — " (SETTING OF DAYS OF A WEEK) Flashes below the day of the week pro-	-



4



# OPERATION

#### ■ Setting present time (Fig. 3)

(Example) In case of setting Friday, 5:30 p.m.

Image: Optimized and the second second

(NOTE)

• The present time needs adjusting in case of turning power supply on for the first time or the occurrence of power failure over the period of 48 hours or more.

мо́м-сlock ам

2. <sup>(2)</sup> Press the BUTTON FOR SELECTING DAYS OF A WEEK. Each time the button is pressed, the day display shifts to the right. (NOTE)

The display " MON " follows the display " SUN."

	-)約11/1
CLOCK	^ <b>₩</b> ₽₽:00 <b>K</b>

Set the day to Friday.

3. <sup>(J)</sup> Set the time with the HOUR/ MINUTE BUTTON. Each time the HOUR/MINUTE BUTTON is pressed, the display is put forward minute by minute and hour by hour. When the button is kept pressed, the display is put forward continuously.

#### (NOTES)

- After becoming " AM 11:00 ", when the button is pressed, the display becomes " PM 0:00 ".
- After becoming " 59 " (minute), when the button is pressed, the display becomes " 00 " (minute).



Set the time to 5:30 p.m.

4. <sup>(J)</sup> Press the TIMER ON BUTTON the moment the time signal of TV, radio, telephone, etc. is heard. The mark ":" flashes, and the clock starts.

	FŘI .
CLOCK	рм 930

Press the TIMER ON BUTTON in tune with the time signal at 5:30 p.m.

#### (NOTES)

- The clock used is of 12-hour type.
- When you turn power supply on, the system may display " *BB* " for about one minute and not start to operate after all the liquid crystal displays appear at a time.
- If the CLOCK ADJUSTING BUTTON is pressed by mistake, press it again to return to the original state. As the clock does not stop, the time indicated by the clock is kept correct. In case of power failure within 48 hours, the clock keeps operating by utilizing the built-in battery.

#### Setting no. of programmed time (Fig. 4)

(Example) Time No. 5 (to be programmed only when used in conjunction with the central remote controller)

> Monday to Friday: Operating from 8:45 a.m. till 5:00 p.m. Operating from 5:15 p.m. till 11:00 p.m.

- Saturday and Sunday: Setting the whole day stop operation (application for holidays) controlled by programmed time.
- Image: Constant of the second state of the second sta

PROGRAM J START

- 2. Press the TIME No. BUTTON, and select the desired number. (NOTE)
  - Unless used in conjunction with the central remote controller, The TIME No. is not displayed and can not be selected.

Select the TIME No. 5.



3. <sup>(J)</sup> Press the BUTTON FOR SELECTING DAYS OF A WEEK, and set the proper day of the week. Each time you press it, the flashing display of days of a week shifts to the right.

Ð NO.		J START THU FRI SAT SUN		0 OFF -:
[	CLOCK	Рм 5:30	SET2 ON	O OFF -:

Set to Monday.

- (1) Setting programmed time
- 4. Set the programmed time of system start 1 by using the HOUR/ MINUTE BUTTON. Each time the HOUR/MINUTE BUTTON is pressed, the display is put forward minute by minute and hour by hour. When the button is kept pressed, the display is put forward continuously.

Ð NO.		I START SET I LON O OFF
	слоск Р	<sup>₩</sup> 5:30 -: ► -:

Set the "PROGRAMMED TIME OF SYSTEM START 1" at 8:45 a.m.

 (5) Press the TIMER ON BUTTON, and set the programmed time of system start 1. Each time you press it, the next area to be set flashes.

(NOTE)

Set the other programmed time in the same procedure.



- (2) Set the next day of the week. Set the day of the week to Tuesday, and copy the program of the previous day (Monday). In the same procedure, set the day of the week to Wednesday through Friday in sequence.
- 6. <sup>(J)</sup> Press the BUTTON FOR SELECTING DAYS OF A WEEK and set the following day. Press the BUTTON FOR COPYING PRO-GRAM OF PREVIOUS DAY. The same program as that of the immediately preceding day of the week is set.

(NOTE)

Repeat each procedure 3 - 5 in the above when not copying the contents of the previous day.

#### (3) Holiday setting

 C Press the BUTTON FOR SELECTING DAYS OF A WEEK and set one or more days of the week as holiday. Press the HOLI-DAY SETTING BUTTON, and the display " OFF " is displayed at the top of the day of the week. If you press it again, the display returns to the original state.

Ð NO.		J START	111/	0 off -:
	CLOCK	рм 5:30	SET2   ON   -: ►	O <sup>off</sup> -:

Set Saturday and Sunday as holidays.

#### 8. IP Press the PROGRAMMING START BUTTON, and finish the program setting.

(NOTES)

- Unless the button is pressed within 20 minutes, the display will automatically revert back to the original state. In this case, setting contents up to the point where the TIMER ON BUTTON (or HOL-IDAY SETTING BUTTON or BUTTON FOR COPYING PROGRAM OF PREVI-OUS DAY) is pressed will only take effect.
- The display "PROGRAM J START" and the display of days of a week "—" disappears.

- The flashing display goes off, and the No. of programmed time of the present day is displayed. Then the operation controlled by timer starts.
- The operation controlled by timer is executed even while the program is being set.

0. 5	PROGRAM	THU FRI	J START OFF OFF 8 7 SAT SUN	SET1   ON M B:45 ►	0°™ 5:00
	CLOCK	FŘI PM	s:30	SET2   ON PM 5: /5 ►	0 °FF 1 1:00

This is the end of the setting example.

#### Change and cancellation of no. of programmed time (Fig. 5)

(Example) Time No. 3 (to be set only when used in conjunction with the central remote controller)



- 2. In Press the TIME No. BUTTON, and select the desired No.

⊕ №.		OFF OFF THU FRI SAT SUN B:45 ► 5:00
	CLOCK	<sup>sh</sup> <sub>FRI</sub> SET2   <sup>ON</sup> O <sup>OFF</sup> PM 5:00 S: 15 ► 1 1:00

Select the time No. 3.

3. <sup>(J)</sup> Press the BUTTON FOR SELECTING DAYS OF A WEEK, and set the day of the week to be changed. The set No. of programmed time of the day of the week is displayed.

	OFF OFF AM BYSE STUD
СLOCK	FŘI SET2 ON O OFF PM 6:00 S: IS ► I I:00

Set the day to Wednesday.

#### A. Change/cancel partially

4. <sup>(J)</sup> Press the TIMER ON BUTTON and change, and the display of programmed time flashes. Each time you press it, the next area to be set flashes.

() NO.	3 Non	เบ <u>้ย พร้อ</u> เพิ่ม	OFF OFF 5 8 7 FRI SAT SUN	SET1   ON M 8:45 ►	9 <b>17</b> 5:00
	ci	_оск рм	Å:00	SET2   ON PM 5: /5 ►	0 류   1:00

Shift to the display "PROGRAMMED TIME OF SYSTEM OFF 1".

5. <sup>(3)</sup> Press the HOUR/MINUTE BUTTON and change the programmed time. Press the TIMER ON BUTTON, and finalize the setting of change.

() NO.	Mon Tue <u>w</u> êg	OFF OFF	SET1   ON AM B:45 ►	0 ¶. 1:00
	СГОСК	рм 6:00	SET2   ON PM 5: /5 ►	0 °FF   1:00

Change the "PROGRAMMED TIME OF SYSTEM OFF 1" to 7:00 p.m.

6. <sup>(G)</sup> Press the PROGRAM CAN-CELING BUTTON, and cancel the programmed time. If you press it again, display returns to the original state. Press the TIMER ON BUTTON to finalize the cancellation.

	OFF OFF AM AM FRI SAT SUN 8:45 ► 7:00
сгоск	FÅI PM <b>5:00</b> 5:15€ 11:00

Shift to the "PROGRAMMED TIME OF SYSTEM START 2".

OFF OFF STI   ON OF	D
AM NON TŮE WÊD THU FRI SÂT SUN B:45 ► 7:	D
NO	D
	DFF PM UU

Set the "PROGRAMMED TIME OF SYSTEM START 2" to program cancellation.

In the same procedure, cancel the programmed time of system off 2.

#### B. Cancel the whole

7. The Press the BUTTON FOR SELECTING DAYS OF A WEEK, and shift to the day of the week to be canceled. Then, press the HOL-IDAY SETTING BUTTON, the display "OFF" appears at the top of the particular day of the week. The programmed time is canceled. If you press the button again, the display returns to the original state.

⊕ №.	OFF OFF
	CLOCK PM 5:00 SET2 ON O OFF

Shift the day of the week to Thursday to set as a holiday.

#### 8. <sup>(I)</sup> Press the PROGRAMMING START BUTTON. The program setting is now finished.

(NOTES)

- Unless the button is pressed within 20 minutes, the display will automatically revert back to the original state. In this case, setting contents to the point where the TIMER ON BUTTON (or HOLIDAY SETTING BUTTON or BUTTON FOR COPYING PROGRAM OF PREVIOUS DAY) is pressed will only take effect.
- To continue the change/cancellation, do not press the PROGRAMMING START BUTTON until all change/cancellation are completed.
- The operation controlled by timer is executed even while the program is being set.

#### ■ Manual operation (Fig. 6)

This schedule timer enables the operation/stop by pressing the UNIFIED OPERATION/STOP BUTTON in addition to the operation controlled by timer (operation/stop according to the programmed time) at any time.

- 1. CP Press the UNIFIED OPERA-TION BUTTON, and the OPERA-TION LAMP turns on.
- 2. Press the UNIFIED STOP BUT-TON, and the OPERATION LAMP is turned off.

(NOTES)

- The operation automatically stops according to the programmed time of system off even during the manual operation. In the meantime, the operation starts automatically according to the programmed time of system start even during the stop of operation.
- If the unit is used in conjunction with other optional controllers for centralized control, the OPERATION LAMP of the unit that is not under operation control may be turned on or off a few minutes behind schedule. This shows that the signal is being exchanged, and does not indicate any failure.

Operation lamp

 Turn on: The light turns on when any of the indoor units is in operation whether the operation is controlled by timer or by hand.
 Turn off: The light turns off when all the

indoor units stop.

#### ■ Operation control code

Two different types of operation control codes can be selected when this kit is used independently (when not used in conjunction with the central remote controller, unified ON/OFF controller, etc.).

#### Individual

In case where the operation/stop is controlled by both schedule timer and remote controller.

#### Centralized

The operation is controlled by the schedule timer alone, and the operation/stop is controlled freely with the remote controller during the programmed time.

#### (NOTES)

- For current settings, contact your DAIKIN dealer.
- To change settings, contact your DAIKIN dealer.

Do not change settings yourself.

#### Error diagnosing function (Fig. 7)

This schedule timer is provided with the malfunction diagnosing function. The malfunction code flashes if there occurs any malfunction in communication, etc. between and among the optional controllers for centralized control. In addition, the operation lamp also flashes if there occurs any malfunction in communication with the indoor unit. Check the contents of the display and contact your DAIKIN dealer because the signals give you the idea of the trouble area.

Opera- tion lamp	Malfunc- tion code	Contents of mal- function			Address failure of schedule timer.
Turn off	M1	Failure of PC board of schedule timer. Fixes The following causes are possi- ble. Check each one. 1. PC board prob- lems	Turn on or off	мс	<ul> <li>Fixes The following causes are possible. Check each one. 1. Do the control range addresses in the central remote control- ler overlap? 2. Do the control range addresses </li> </ul>
Turn on		Malfunction of transmission between each optional controllers for centralized con- trol.			<ul> <li>ange addresses in the on/off con- troller overlap?</li> <li>3. Are there 2 or more schedule timers con- nected?</li> </ul>
or off	M8	Fixes Check all central devices which are connected (e.g., power supply, transmission			Malfunction of transmission between indoor unit and optional controllers for cen- tralized control.
		wiring, etc.). Improper combina- tion of optional controllers for cen- tralized control. Fixes	Flash	UE	Fixes Inspect all indoor units which are dis- playing an error (e.g., power supply, transmission wiring, etc.).
Turn on or off	МА	<ul> <li>The following causes are possible. Check each one.</li> <li>1. Are all central devices combined correctly?</li> <li>2. Is the master central connector attached to</li> </ul>	Flash	_	Malfunction in indoor unit (Refer to the malfunction codes of the indoor remote controller, while also read the " CAUTION FOR SERVICING " attached to the indoor unit.)
		two or more cen- tral devices? 3. Are there 128 or more indoor	QUES	ΓΙΟΝ	AND ANSWER
		units con-	Quest	ion	Answer
		nected?	It is possib	ole to	

make settings

it possible to

make only the " off " setting?

(To avoid forget-

ting to turn the unit off.)

twice a day, but is

Yes. Press the PRO-

**GRAM CANCELING** 

to " off ".

BUTTON in the " 3888 "

section in order to set it

		-		
Is it possible to set times which straddle days?	Yes, it is possible. Example: Start operation at 5:00 a.m. on Sunday Stop operation at 6:00 p.m. on Monday		The TIME NO. is not displayed.	The following causes are possible. <b>1.</b> The TIME NO. is not displayed when using the schedule timer alone. (It can be set if using the central remote controller at the same time.)
The unit does not turn on even though the set " on " time has come. (When using the schedule timer alone)	The following causes are possible. 1. Are the " on " time and the " off" time set to the same time?		The display remains " <sup>ser1</sup> · · · · · · · · · <u>ser2</u> · · · · · · · · even though I push the HOUR/MINUTE BUTTON in the timer program settings.	The following causes are possible. 1. Is the day set to a holiday?
The unit does not turn on even though the set " on " time has come. (When using the unit with a central remote controller)	<ul> <li>The following causes are possible. Check each one.</li> <li>1. Was the timer number set with the central remote controller? Was an incorrect timer number set?</li> <li>2. Is another timer no. set with the central remote controller set for " off " at the same time?</li> <li>3. Is the operation code set to " remote control permission timer " using the central remote controller or the on/off controller?</li> </ul>		I cannot set " central manage- ment priority " or " after-push prior- ity " with the schedule timer.	The following causes are possible. 1. Is a central remote controller or on/off controller also installed? * The priority order of the operation codes depends on the central devices which are installed. The below operation codes are set. • Schedule timer Central remote controller is used as well Operation code of the central remote controller • Schedule timer
The unit oper- ates even though that day is set as a holiday. (When using the unit with a central remote controller)	The following causes are possible. <b>1.</b> Is another timer num- ber set with the cen- tral remote controller set for " on " at the same time? (If two timer numbers are set, make sure that the settings for holidays and working days do not overlap between the different timer numbers.)			<ul> <li>Schedule timer On/off controller is used as well Operation code of the on/off control- ler</li> <li>Schedule timer Central remote controller On/off controller is used as well Operation code of the central remote controller</li> </ul>

11

3P124623-5C

## 13.9 <KRP1C75> Adaptor for Wiring



2P263038-1E

## 13.10 <KRP4A74> Wiring Adaptor for Electrical Appendices

Accessories Check if the following accessories are included in the kit.





Remote controller

Indoor unit max. 16 units

Names of parts and function ) Service monitor (H10P: Red) Terminal board for display signal (X3M) Service monitor (H1P: Green) This lamp lights up when trouble Connects operation and error output to a occurs in electrical wiring or setting switches. Remote control is disabled This lamp flashes while the remote point (Central control monitor, etc.). (Normal operation: W1, W2; Error: W3, W4) CPU is operating normally. (This LED is out in constant operation.) Power supply connector Temperature setting ON/OFF switch (SS2) (Factory set: Possible) To connector on indoor unit PCB. Ø ₩1 Do not change to "Impossible". Note) Connector No. X35A Impossible ⊗ W2 Otherwise, temperature setting Possible by the remote control cannot be 8 W3 Transmission wiring (P1,P2) 552 made. ⊗ w To P1 and P2 on indoor unit terminal board. Ċ Control mode selector switch (RS1) Changeover switch (SS1) (Factory set: Volt) (Factory set: 0)  $\bigcirc$ Set to "Non volt" to input a no-voltage For selecting the type of system 88 898 normally open contactor on the remote 0 operation permitted via remote. control input terminal board (TeS1). Temperature setting input Remote control input terminal board (X1M) terminal (X2M) Connects control input from the remote control For details, see (Central control monitor, timer, etc.) This function cannot be used for the electric wiring. this kit. Never apply voltage to this for any reason whatsoever.



1P161220-1A



Licina the	o control modo	coloctor switch (E		at the control mode as	described belo	14/	
Using the		Selector Switch (F	,.	ct the control mode as	described belo	vv.	
			R	Control mode			
			(F	actory set) "0" position			
	cifying individua	ıl display					
PC	osition 0	Individual d	Function	out ignored)			
	•						
<u>vvnen op</u> Position		it with constant in nction	put at inpl	When input A is	N ON		When input A is OFF
1		ntrol impossible	Operation by remo	on (Normally ON/OFF) te controller)		ole	
2	Centralized		remote o	on + ON/OFF control p controller			OFF + ON/OFF control
3	OFF control remote control		Operation controlle controlle	on + OFF control possi er (ON control impossil er)	ble by remote ble by remote		impossible by remote controller
4	ON/OFF cor by remote co	ntrol possible ontroller		control possible by re on impossible by optic			
	instantaneous i	t using instantane input of 200 msec unction		r ON time).			Input R capacity
Position		ntrol impossible	Turne	Input A OFF system with ON	input		Input B capacity
5	by remote co		Turns	ON system with ON i	nput	(wher	B is for forced OFF input ON, OFF control is
			Turns	OFF system with ON	input	i nossir	
6	Individual		(Norn	S ON system with ON i nally ON/OFF control p mote controller)	nput	remot	ble but ON/OFF control by e controller is impossible, put A is ignored)
For them	Individual	using input B	(Norn	nally ON/OFF control p	nput	remot	e controller is impossible,
For them Position	mostat control u	When inp	(Norn by rei	nally ON/OFF control p mote controller)	nput possible	remot and ir When i	e controller is impossible, put A is ignored) nput B is ON
For therr Position C	mostat control u	When inp FF control impose	(Norn by rep out A is Of sible by rep	nally ON/OFF control p mote controller) N mote controller	nput possible Forced therm	remot and ir When i	e controller is impossible, put A is ignored) nput B is ON FF command
For therr Position C D	mostat control u	When inp FF control impose (Same as	(Norn by rel out A is ON sible by rel position 5	nally ON/OFF control p mote controller) N mote controller	nput possible Forced therm Energy savin	when i ostat O g comm	e controller is impossible, put A is ignored) nput B is ON FF command and (*)
For therr Position C	mostat control u	When inp FF control impose	(Norn by rel out A is ON sible by rel position 5	nally ON/OFF control p mote controller) N mote controller	nput possible Forced therm	When i ostat O ostat O	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command
For them Position C D E F Forced th Energy s The indo Note>	ON/OF	When inp FF control imposs (Same as Individual (San command indoor d (*) s at 4°F higher (co	(Norm by rei sible by rei position 5 ne as posi r unit fan o ooling)/low	nally ON/OFF control p mote controller) M mote controller (b) tion 6) Inly operates. ver (heating) the set te	nput possible Forced therm Energy saving Energy saving mperature.	When i oostat O g comm oostat O g comm	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*)
For them Position C D E F Forced th Energy s The indo Note> In such c	nostat control u ON/OF nermostat OFF aving command or unit operates case, even if inp perating the uni	When inp FF control imposs (Same as Individual (San command indoor d (*) s at 4°F higher (co	(Norm by rei bible by rei position 5 ne as posi unit fan o ooling)/low nostat con eous input	nally ON/OFF control p mote controller) mote controller inly operates. ver (heating) the set te trol is turned OFF, and at input A and B	nput possible Forced therm Energy saving Energy saving mperature.	When i oostat O g comm oostat O g comm	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*)
For them Position C D E F Forced th Energy s The indo Note> In such c When op (Use an	mostat control u ON/OF aving command or unit operates case, even if inp perating the uni instantaneous i	When inp FF control imposs (Same as Individual (San command indoor d (*) s at 4°F higher (co but A is ON, therm it using instantane input of 200 msee nction	(Norm by rei sible by rei position 5 ne as posi r unit fan o ooling)/low nostat con eous input c or longe	nally ON/OFF control p mote controller) mote controller (mote controller) (mote controller (mote controller) (mote controller) (mo	nput possible Forced therm Energy savin Forced therm Energy savin mperature.	When i oostat O g comm oostat O g comm same g	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*)
For them Position C D E Forced th Energy s The indo Note> In such c When op (Use an	mostat control u ON/OF aving command or unit operates case, even if inp perating the uni instantaneous i	When inp FF control imposs (Same as Individual (San command indoor d (*) s at 4°F higher (co but A is ON, therm it using instantane input of 200 msec nction itrol impossible	(Norm by rei position 5 ne as posi r unit fan o cooling)/low nostat con eous input c or longe Operatic by remo	nally ON/OFF control p mote controller) mote controller mote controller tion 6) nly operates. ver (heating) the set te trol is turned OFF, and trol is turned OFF, and the controller on the set te When input A on (Normally ON/OFF)	nput possible Forced therm Energy savin Forced therm Energy savin mperature. I all units in the is ON control impossit	When i oostat O g comm joostat O g comm same g	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*) roup will stop.
For them Position C D E Forced th Energy s The indo Note> In such c When op (Use an Position	mostat control u ON/OF aving command or unit operates ase, even if inp perating the uni instantaneous State of the uni instantaneous ON/OFF con	When inp FF control imposs (Same as Individual (San command indoor d (*) s at 4°F higher (co but A is ON, therm it using instantane input of 200 msec nction itrol impossible	(Norm by rei position 5 ne as posi r unit fan o ooling)/lov nostat con eous input c or longe Operatio Operatio controlle	nally ON/OFF control p mote controller) mote controller mote controller i) tion 6) nly operates. ver (heating) the set te trol is turned OFF, and trol is turned OFF, and at input A and B r ON time). When input A on (Normally ON/OFF te controller) on + ON/OFF control p	nput possible Forced therm Energy savin Forced therm Energy savin mperature. I all units in the is ON control impossib	When i oostat O g comm joostat O g comm same g	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*) roup will stop. When input A is OFF
For them Position C D E F Forced th Energy s The indo Note> In such c When op (Use an Position 7	mostat control u ON/OF aving command or unit operates case, even if inp perating the uni instantaneous ON/OFF con by remote co	When inp FF control impose (Same as Individual (San command indoor d (*) s at 4°F higher (co but A is ON, therm it using instantane input of 200 mset nction ntrol impossible pontroller	(Norm by rei position 5 ne as posi- ne as	nally ON/OFF control p mote controller) mote controller mote controller tion 6) tion 6) ver (heating) the set te trol is turned OFF, and trol is turned OFF, and trol is turned OFF, and trol is turned OFF, and when input A on (Normally ON/OFF te controller) on + OFF control possi or (ON control impossi	nput possible Forced therm Energy savin Forced therm Energy savin mperature. I all units in the is ON control impossit ossible by remote	When i oostat O g comm joostat O g comm same g	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*) roup will stop.
For them Position C E F Forced th Energy s The indo Note> In such c When op (Use an Position 7 8	mostat control u ON/OF aving command or unit operates ase, even if inp perating the uni instantaneous ON/OFF con by remote co Centralized OFF control remote contr	When inp FF control impose (Same as Individual (San command indoor d (*) s at 4°F higher (co but A is ON, therm it using instantane input of 200 mset nction ntrol impossible ontroller possible by coller	(Norm by rei position 5 ne as posi r unit fan o ooling)/low nostat con eous input c or longe Operatic by remo Operatic controlle Operatic controlle Operatic	nally ON/OFF control p mote controller) mote controller mote controller tion 6) tion 6) ver (heating) the set te trol is turned OFF, and trol is turned OFF, and trol is turned OFF, and trol is turned OFF, and when input A on (Normally ON/OFF te controller) on + OFF control possi or (ON control impossi	nput possible Forced therm Energy savin Forced therm Energy savin mperature. I all units in the is ON control impossit ossible by remote ble by remote mote controller	When i oostat O g comm jostat O g comm same g ole	e controller is impossible, put A is ignored) nput B is ON FF command and (*) FF command and (*) roup will stop. When input A is OFF OFF + ON/OFF control impossible by remote

<Note>
• When set to position 7-A, and using the constant mode for input B, forced stop capacity is enabled (Input A is ignored).

• At position B, the constant mode for input B is not used.



Display output is as described below.

Output	Both Ry1 and Ry2 OFF	Only Ry1 ON	Only Ry2 ON
Display	OFF	Normal operation	System stopped due to malfunction or transmission error generated between adaptor and indoor unit

1P161221-1A

## 13.11 <KRP1BA101> Installation Box for Adaptor PCB

Accesso	ories Check	the following acc	essories are in	cluded in this	s kit.		
Name	Installation box	Lid of installation box	Clamp	Screw	Cord sticker	Installation manual	Screw
Quantity	x1	x1	xЗ	x3	x3	KRP1B101 English KRP1BA101 Englishx1, Japanesex1	x2
Shape			3	<b>(</b> )	5	(This manual)	(Change) Q

## Method of attaching the adaptor





#### 1P107687-1D

## 13.12 <KRCS01-4B> Remote Sensor

## Notes

- Please check applicable kit model name by catalog etc.
- When installed on SkyAir Round-flow type models, the dehumidification by detection of humidity does not operate.

# Accessories

Check the following accessories.



## Mounting

1) Selection of mounting location.

The thermistor for temperature detection is incorporated into the remote sensor. Select the mounting location taking the following cautions into account.

① Where the average temperature of an air conditioned room can be detected.

- (2) Where it is not exposed to the direct sunlight.
- ③ Where it is not influenced by other heat sources.
- (4) Where it is not exposed to the direct discharge air from the air conditioner.
- (5) Where it is not exposed to the outdoor air infiltrated into the room by opening the door.

#### 2) Mounting

• Remove the cover of the sensor box.

(T

about 6mm width (2) flat blade screw driver Insert a flat blade screw driver into the sensor box concave part (2 locations).
 Remove the cover pushing up the nail to the cover of the sensor box.

#### <Cautions>

Do not push the nail powerfully with a narrow flat blade screw driver, because you may break off the nail.





Conduct cooling and heating operation test after the sensor is mounted and the wiring is completed.

3K019189-1D

## 13.13 <KPW937E4> Air Direction Adjustment Grille

N	parts) Be sure to check that ① Air direction	I	
Name	adjustment grille	② Screw	③ Installation manual
Shape		(2) Managamana	
Q'ty	1 pc.	4 pcs.	1 sheet(this sheet)
<ol> <li>When a garder</li> <li>autions fo</li> <li>Be sure direction</li> <li>Be sure 2. Avoid</li> <li>When a Do nor of the</li> <li>Be ca insta</li> </ol>	n plants. r usage to perform the following as on adjustment grille. re to stop the operation bef short-circuits during insta using the unit in areas with t install the grille to crea e outdoor unit as this may d reful of foreign substances lling the grille to create a	on to prevent exhaust blowin installation precautions to fore installation. Illation. Is snow, install the grille to the an upward airflow to prev lamage the unit. Such as dead leaves, which ma in upward airflow.	ng directly onto passersby or o ensure correct and safe use of the a create a left-right or downward airfl yent snow accumulating in the air outle ay accumulate on the air outlet after ews securely without any looseness.
<ul> <li>Pitch o and hor</li> <li>Install</li> <li>Tempora angle, a</li> <li>Steel</li> </ul>	izontal directions. ation can be performed in 4	or the air direction adjustme directions:top,bottom,left a on adjustment grille(①) usir <b>le&gt;</b>	ent grille(①)is 434mm in the vertical and right. ng 4 screws(②),check the installation



3P397163-1

## 13.14 <KPW063A4> Air Direction Adjustment Grille



### 2 Installation of air direction adjustment grille)



3P398171-1

## 13.15 <KKG067A41> Back Protection Wire Net



3P397444-1

## 13.16 <KKG063A42> Back Protection Wire Net



2P403095-1

## 13.17 <FTDBHMS, FTDBHML, KEH067A41E, KEH063A4E> Drain Pan Heater

	onsiderations carefund the start-up operations	Illy before installing the drain pan heattion.	ater. After completing	g the installation, check if the unit
leaning of DANGER	WARNING and CAU	JTION symbols.		
		ently hazardous situation which, if sult in death or serious injury.		Indicates a potentially hazardou situation which, if not avoided, may result in minor or moderate
		Illy hazardous situation which, if not Ilt in death or serious injury.		injury. It may also be used to alert against unsafe practices.
After completing the All phases of the fie manufacturer's instr This product is a he unit from freezing.	installation, make su d-installation, includi uctions and must cor ater designed to mell	Installation manual for future reference ure that the unit operates properly du ng, but not limited to, electrical, pipir nply with national, state, provincial, a show that is blown into the product	uring the startup open ng, and safety, must h and local codes. from the outside to p	be done in accordance with prevent the drain pan of the outdo
		od on a high stand if this product is u	sed in neavy snow a	ireas.
	ER			
		out wearing gloves.		
		ne high when the heater is turned on. result in burns or injury.		
/!\ WARN	ling			
<ul> <li>Request the deal</li> </ul>	ler or an authoriz	ed technician to install the pro	oduct.	
Improper installation	of the product could res	ult in water leakage, an electric shock, o	r firo	
			1 11 10.	
		cording to the instructions giv	en in this manual	
The Incomplete insta	llation of the product co	uld result in water leakage, an electric sh	en in this manual	
The Incomplete insta	llation of the product co d or specified ins	uld result in water leakage, an electric sh tallation parts.	<b>en in this manual</b> lock, or fire.	
The Incomplete insta • Use the supplie Use of other parts co	llation of the product co d or specified ins uld result in the unit bea	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage,	<b>en in this manual</b> lock, or fire.	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow	llation of the product co d or specified ins uld result in the unit be rer supply at the t	uld result in water leakage, an electric sh tallation parts.	en in this manual lock, or fire. electric shock, or fire.	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric	llation of the product co d or specified ins uld result in the unit bed rer supply at the t al parts may with the p	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation.	en in this manual lock, or fire. electric shock, or fire. ctric shock.	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pov Touching any electric • Use specified wi	llation of the product co d or specified ins uld result in the unit be rer supply at the t al parts may with the pr res. Connect and fi	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec	en in this manual lock, or fire. electric shock, or fire. ctric shock. not put improper	
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or fi • When wiring an	llation of the product co d or specified ins uld result in the unit ber rer supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, i ime of installation. ower supply turned on could result in elec x the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care	en in this manual oock, or fire. electric shock, or fire. ctric shock. not put improper hock, or fire.	force on the terminal junction
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or f • When wiring an put improper fo	llation of the product co d or specified ins uld result in the unit ber rer supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structure	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, i ime of installation. ower supply turned on could result in elec x the wires so that the wires will ssult in terminal overheating, an electric s indoor and outdoor units, care res.	en in this manual ock, or fire. electric shock, or fire. etric shock. not put improper shock, or fire. fully arrange the	force on the terminal junction wiring so that they will not
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or f • When wiring an put improper fo	llation of the product co d or specified ins uld result in the unit ber rer supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structure	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, i ime of installation. ower supply turned on could result in elec x the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care	en in this manual ock, or fire. electric shock, or fire. etric shock. not put improper shock, or fire. fully arrange the	force on the terminal junction wiring so that they will not
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or f • When wiring an put improper fo	llation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rece on the structure wires. Incomplete cove	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, i ime of installation. ower supply turned on could result in elec x the wires so that the wires will ssult in terminal overheating, an electric s indoor and outdoor units, care res.	en in this manual ock, or fire. electric shock, or fire. etric shock. not put improper shock, or fire. fully arrange the	force on the terminal junction wiring so that they will not
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified wi Wires connected or f When wiring an put improper fo Install covers over the CAUT	llation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structu wires. Incomplete cover	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove	en in this manual ock, or fire. electric shock, or fire. etric shock. not put improper shock, or fire. fully arrange the	force on the terminal junction wiring so that they will not
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected of f • When wiring an put improper fo Install covers over the CAUT • Wear protective	llation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structu e wires. Incomplete cover ION gloves at the tim	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove	en in this manual ock, or fire. electric shock, or fire. etric shock. not put improper shock, or fire. fully arrange the	force on the terminal junction wiring so that they will not
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified wi Wires connected or fr When wiring an put improper fo Install covers over the CAUT • Wear protective Touching the suction	Ilation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the pr res. Connect and fi xed improperly could re d connecting the rece on the structure wires. Incomplete cover ION gloves at the tim mouth or aluminum fin	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove e of installation.	en in this manual lock, or fire. electric shock, or fire. stric shock. not put improper hock, or fire. ifully arrange the rheating, an electric sh	force on the terminal junction wiring so that they will not ock, or fire.
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified wi Wires connected of f When wiring an put improper fo Install covers over the CAUT • Wear protective Touching the suction • Do not install the If the gas leaks and the	Ilation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structu e wires. Incomplete cove ION gloves at the tim mouth or aluminum fin e product in plac uilds up around the unit	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove e of installation. of the outdoor unit may result in injury. es where there is danger of ex t, it may catch fire.	en in this manual lock, or fire. electric shock, or fire. stric shock. not put improper hock, or fire. ifully arrange the rheating, an electric sh posure to inflamm	force on the terminal junction wiring so that they will not ock, or fire.
The Incomplete insta Use the supplie Use of other parts co Turn off the pow Touching any electric Use specified wi Wires connected or fo Install covers over the Mhen wiring an put improper fo Install covers over the CAUT Wear protective Touching the suction Do not install the If the gas leaks and the	Ilation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the por res. Connect and fi xed improperly could re d connecting the rce on the structu e wires. Incomplete cove ION gloves at the tim mouth or aluminum fin e product in plac uilds up around the unit	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove e of installation. of the outdoor unit may result in injury. es where there is danger of ex t, it may catch fire. utdoor unit carelessly when re	en in this manual lock, or fire. electric shock, or fire. stric shock. not put improper hock, or fire. ifully arrange the rheating, an electric sh posure to inflamm	force on the terminal junction wiring so that they will not ock, or fire.
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or f • When wiring an put improper fo Install covers over the <b>M</b> CAUT • Wear protective Touching the suction • Do not install the If the gas leaks and the The sharp edge of the • Do not install the	Ilation of the product co d or specified ins uld result in the unit ber ver supply at the t al parts may with the parts may with the parts ares. Connect and fit exed improperly could re d connecting the rce on the structure wires. Incomplete cover ION gloves at the tim mouth or aluminum fin e product in plac uilds up around the unit top plate of the o e top plate may cause i e outdoor unit in de and touch the interna	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elec x the wires so that the wires will sult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove e of installation. of the outdoor unit may result in injury. es where there is danger of ex t, it may catch fire. utdoor unit carelessly when re	en in this manual lock, or fire. electric shock, or fire. stric shock. not put improper shock, or fire. ifully arrange the rheating, an electric sh posure to inflamm emoving the top p ay nest in the out	force on the terminal junction wiring so that they will not ock, or fire. nable gas leakage. plate.
The Incomplete insta • Use the supplie Use of other parts co • Turn off the pow Touching any electric • Use specified wi Wires connected or fi • When wiring an put improper fo Install covers over the • Wear protective Touching the suction • Do not install the If the gas leaks and the The sharp edge of the • Do not grab the The sharp edge of the • Do not install the If small animals intrue Advise the user to ke • Do not touch th	Ilation of the product co d or specified ins uld result in the unit ber rer supply at the t al parts may with the pr res. Connect and fi xed improperly could re d connecting the ree on the structure wires. Incomplete cover ION gloves at the tim mouth or aluminum fin e product in place top plate of the o e top plate of the o e top plate may cause i e outdoor unit in de and touch the interna- ep the place clean.	uld result in water leakage, an electric sh tallation parts. coming loose and falling, water leakage, ime of installation. ower supply turned on could result in elect x the wires so that the wires will esult in terminal overheating, an electric s indoor and outdoor units, care res. er installation could result in terminal ove e of installation. of the outdoor unit may result in injury. es where there is danger of ex t, it may catch fire. utdoor unit carelessly when re njury. places where small animals m al parts of the outdoor unit, the outdoor u	en in this manual lock, or fire. electric shock, or fire. stric shock. not put improper hock, or fire. ifully arrange the rheating, an electric sh posure to inflamm moving the top p ay nest in the out	force on the terminal junction wiring so that they will not ock, or fire. nable gas leakage. late.

Accessories		
	KEH067A41E KEH063A4E FTDBHMS FTDBHML	KEH067A41E KEH063A4E FTDBHMS FTDBHML
A Drain pan heater	1 1	Installation manual (multi-language)     1     1
B M4 piercing screw	3 6	F Electric wiring diagram label   1   1
© Binding band	1 1	G Information label     1     1
Sealing material	1 2	Appearance of the (A) drain pan heater may differ from some models.
Tools Required for Installation		
• Electric drill • ¢*	I/8 inch (ø3.2mm) drill	Phillips screwdriver     Nippers
I	netallation	Procedure (1)
I	IStallation	Procedure (1)
Some stages in the installation proce model of outdoor unit. Refer to the in- relevant model. Type A models : RX09/12, RXN09 Type B models : RX15/18/24, RXN Type C models : 2/3/4MXS, 2/3MX	12, RXL09/12	type A models (F) Electric wiring diagram label (G) Information
1. Remove each comp	onent of	Front plate
the outdoor unit.		
<ol> <li>Remove the top plate.</li> <li>Affix the (P) electric wiring diag where there is enough space the back of the top plate.</li> <li>Remove the screws from the wire mesh if one is fitted. (2 so (For type B and C models onl)</li> <li>Remove the front plate.</li> <li>Remove the anti-drip cover. (For type B and C models onl)</li> </ol>	gram label available on protective crews) y)	type B and C models
<ul> <li>6) Affix the () information label manufacture's label.</li> <li>The appearance of the outdoo the number of screws may dif models.</li> <li>Screw types for each compon indicated as below.</li> <li>No icon: Hexagon tapping scr</li> <li>△ : Truss head tapping s</li> </ul>	or unit and fer from some ent are ew	View A Protective wire mesh









3P421082-1C
# 13.18 <KPS067A41> Snow Hood (Intake Side Plate)





#### 2 Appearance of the snow hood (intake side plate) following installation



3P436077-1

#### 13.19 <KPS067A42> Snow Hood (Intake Rear Plate)







3P436078-1

## 13.20 <KPS067A44> Snow Hood (Outlet)



#### Installing the snow hood (outlet)





3P436079-1

## 13.21 <KPS063A41> Snow Hood (Intake Side Plate)







3P436071-1

#### 13.22 <KPS063A44> Snow Hood (Intake Rear Plate)







3P436072-1

# 13.23 <KPS063A47> Snow Hood (Outlet)







3P436073-1



- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
  - Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
  - Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

#### Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced. 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.