

# Service Manual

## **SUPER MULTI *NX*** G-Series / J-Series



[Applied Models]

● Inverter Multi : Heat Pump

# SUPER MULTI NX G-Series / J-Series Service Manual

## ●Heat Pump Indoor Unit

CTXS07JVJU  
CTXS09HVJU  
CTXS12HVJU  
FTXS15HVJU  
FTXS18HVJU

CTXS07LVJU  
FTXS09LVJU  
FTXS12LVJU  
FTXS15LVJU  
FTXS18LVJU

FDXS09DVJU  
FDXS12DVJU  
FDXS09LVJU  
FDXS12LVJU  
CDXS15LVJU  
CDXS18LVJU

## Outdoor Unit

2MXS18GVJU  
3MXS24JVJU  
4MXS32GVJU

1. Safety Considerations..... vii
  - 1.1 Safety Considerations for Repair ..... vii
  - 1.2 Safety Considerations for Users..... viii

## Part 1

### List of Functions ..... 1

1. Functions.....2

## Part 2

### Specifications ..... 7

1. Indoor Unit.....8
2. Outdoor Unit..... 13

## Part 3

### Printed Circuit Board

### Connector Wiring Diagram ..... 16

1. Indoor Unit.....	17
1.1 CTXS07JVJU, CTXS09/12HVJU, FTXS15/18HVJU.....	17
1.2 CTXS07LVJU, FTXS09/12LVJU .....	19
1.3 FTXS15/18LVJU .....	22
1.4 FDXS09/12DVJU .....	25
1.5 FDXS09/12LVJU, CDXS15/18LVJU .....	27
2. Outdoor Unit.....	29
2.1 2MXS18GVJU .....	29
2.2 3MXS24JVJU, 4MXS32GVJU.....	32

## Part 4

### Function and Control..... 34

1. Main Functions.....	35
1.1 Temperature Control .....	35
1.2 Frequency Principle.....	35
1.3 Airflow Direction Control (CTXS/FTXS Series) .....	37
1.4 Fan Speed Control for Indoor Unit .....	39
1.5 Program Dry Operation .....	40
1.6 Automatic Operation.....	41
1.7 Thermostat Control.....	42
1.8 NIGHT SET Mode .....	44
1.9 ECONO Operation .....	45
1.10 HOME LEAVE Operation .....	46
1.11 INTELLIGENT EYE Operation (CTXS/FTXS Series).....	47
1.12 Inverter POWERFUL Operation .....	48
1.13 Other Functions.....	49
2. Function of Thermistor .....	51
3. Control Specification .....	54
3.1 Mode Hierarchy .....	54
3.2 Frequency Control.....	55
3.3 Controls at Mode Changing / Start-up.....	57
3.4 Discharge Pipe Temperature Control.....	58
3.5 Input Current Control.....	59
3.6 Freeze-up Protection Control .....	59
3.7 Heating Peak-cut Control .....	60
3.8 Outdoor Fan Control.....	61
3.9 Liquid Compression Protection Function.....	61
3.10 Defrost Control .....	62
3.11 Low Hz High Pressure Limit .....	63
3.12 Outdoor Electronic Expansion Valve Control .....	63
3.13 Malfunctions .....	68

## Part 5

### Operation Manual ..... 70

1. System Configuration.....	71
2. CTXS-J, CTXS-H, FTXS-H Series .....	72

2.1	Remote Controller .....	72
2.2	AUTO · DRY · COOL · HEAT · FAN Operation .....	74
2.3	Adjusting the Airflow Direction.....	76
2.4	INTELLIGENT EYE Operation .....	78
2.5	POWERFUL Operation .....	80
2.6	OUTDOOR UNIT QUIET Operation.....	81
2.7	HOME LEAVE Operation .....	82
2.8	TIMER Operation .....	84
2.9	Note for Multi System .....	86
3.	CTXS-L, FTXS-L Series.....	88
3.1	Remote Controller .....	88
3.2	AUTO · DRY · COOL · HEAT · FAN Operation .....	90
3.3	Adjusting the Airflow Direction and Rate .....	92
3.4	COMFORT AIRFLOW / INTELLIGENT EYE Operation.....	95
3.5	POWERFUL Operation .....	97
3.6	OUTDOOR UNIT QUIET Operation.....	98
3.7	ECONO Operation .....	99
3.8	OFF TIMER Operation .....	100
3.9	ON TIMER Operation .....	101
3.10	WEEKLY TIMER Operation .....	102
3.11	Note for Multi System .....	108
3.12	Quick Reference.....	110
4.	FDXS-D Series.....	111
4.1	Remote Controller .....	111
4.2	AUTO · DRY · COOL · HEAT · FAN Operation .....	112
4.3	POWERFUL Operation .....	114
4.4	OUTDOOR UNIT QUIET Operation.....	115
4.5	HOME LEAVE Operation .....	116
4.6	TIMER Operation .....	118
5.	CDXS-L, FDXS-L Series.....	120
5.1	Remote Controller .....	120
5.2	AUTO · DRY · COOL · HEAT · FAN Operation .....	122
5.3	Adjusting the Airflow Rate .....	124
5.4	POWERFUL Operation .....	125
5.5	OUTDOOR UNIT QUIET Operation.....	126
5.6	ECONO Operation .....	127
5.7	OFF TIMER Operation .....	128
5.8	ON TIMER Operation .....	129
5.9	Note for Multi System .....	130
5.10	Quick Reference.....	132

## Part 6

### Service Diagnosis..... 133

1.	Troubleshooting with LED .....	135
1.1	Indoor Unit.....	135
1.2	Outdoor Unit .....	136
2.	Problem Symptoms and Measures .....	137



3. Service Check Function .....	138
3.1 ARC452 Series Remote Controller .....	138
3.2 ARC433 Series Remote Controller .....	141
4. Code Indication on Remote Controller .....	144
4.1 Indoor Unit.....	144
4.2 Outdoor Unit.....	145
5. Troubleshooting for Indoor Unit.....	146
5.1 Indoor Unit PCB Abnormality .....	146
5.2 Freeze-up Protection Control or Heating Peak-cut Control.....	148
5.3 Fan Motor or Related Abnormality .....	150
5.4 Thermistor or Related Abnormality (Indoor Unit).....	153
5.5 Signal Transmission Error (between Indoor Unit and Outdoor Unit) .....	154
5.6 Unspecified Voltage (between Indoor Unit and Outdoor Unit) .....	155
6. Troubleshooting for Outdoor Unit.....	156
6.1 Refrigerant Shortage .....	156
6.2 Low-voltage Detection or Over-voltage Detection.....	159
6.3 Signal Transmission Error (on Outdoor Unit PCB) (24/32 Class Only) ....	161
6.4 Unspecified Voltage (between Indoor Unit and Outdoor Unit) / Anti-icing Function in Other Rooms .....	162
6.5 Anti-icing Function.....	163
6.6 Outdoor Unit PCB Abnormality (24/32 Class Only).....	165
6.7 OL Activation (Compressor Overload) .....	166
6.8 Compressor Lock .....	167
6.9 DC Fan Lock .....	168
6.10 Input Overcurrent Detection .....	169
6.11 Four-Way Valve Abnormality (18 Class Only).....	170
6.12 Discharge Pipe Temperature Control.....	172
6.13 High Pressure Control in Cooling .....	173
6.14 Compressor Sensor System Abnormality (24/32 Class Only).....	174
6.15 Position Sensor Abnormality .....	176
6.16 CT or Related Abnormality .....	179
6.17 Thermistor or Related Abnormality (Outdoor Unit).....	181
6.18 Electrical Box Temperature Rise.....	183
6.19 Radiation Fin Temperature Rise .....	186
6.20 Output Overcurrent Detection .....	189
7. Check.....	191
7.1 Thermistor Resistance Check .....	191
7.2 Fan Motor Connector Check .....	192
7.3 Hall IC Check .....	192
7.4 Power Supply Waveform Check.....	193
7.5 Outdoor Electronic Expansion Valve Check.....	194
7.6 Four Way Valve Performance Check.....	195
7.7 Inverter Unit Refrigerant System Check.....	195
7.8 “Inverter Checker” Check .....	196
7.9 Rotation Pulse Check on the Outdoor Unit PCB.....	197
7.10 Installation Condition Check.....	198
7.11 Discharge Pressure Check.....	198
7.12 Outdoor Fan System Check.....	199
7.13 Main Circuit Short Check.....	199

7.14 Capacitor Voltage Check.....	200
7.15 Power Module Check .....	201

## Part 7

### Removal Procedure ..... 202

1. Outdoor Unit: 2MXS18GVJU .....	203
1.1 Removal of Outer Panels .....	203
1.2 Removal of Electrical Box .....	204
1.3 Removal of PCBs .....	209
1.4 Removal of Fan Motor.....	212
1.5 Removal of Sound Blankets .....	213
1.6 Removal of Coils / Thermistors .....	215
1.7 Removal of Four Way Valve / Defrost Solenoid Valve .....	217
1.8 Removal of Distributor.....	219
1.9 Removal of Compressor.....	220
2. Outdoor Unit: 3MXS24JVJU, 4MXS32GVJU .....	222
2.1 Removal of Outer Panels .....	222
2.2 Removal of Electrical Box .....	234
2.3 Removal of PCBs .....	240
2.4 Removal of Fan Motor.....	244
2.5 Removal of Coils / Thermistors .....	245
2.6 Removal of Sound Blankets .....	250
2.7 Removal of Compressor.....	253

## Part 8

### Trial Operation and Field Settings..... 254

1. Pump Down Operation.....	255
2. Forced Operation .....	256
3. Wiring Error Check Function .....	257
4. Trial Operation .....	259
5. Field Settings .....	261
5.1 Outdoor Unit.....	261
5.2 Indoor Unit.....	264
6. Application of Silicon Grease to Power Transistor and Diode Bridge .....	267





## Part 9

### Appendix..... 268

1. Piping Diagrams.....	269
1.1 Indoor Unit.....	269
1.2 Outdoor Unit.....	271
2. Wiring Diagrams.....	273
2.1 Indoor Unit.....	273
2.2 Outdoor Unit.....	276

# 1. Safety Considerations

Read these **SAFETY CONSIDERATIONS** carefully before performing any repair work. Comply with these safety symbols without fail. Meanings of **DANGER**, **WARNING**, **CAUTION**, and **NOTE** Symbols:

-  **DANGER** ..... Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
-  **WARNING** ..... Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
-  **CAUTION** ..... Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
-  **NOTE** ..... Indicates situations that may result in equipment or property-damage accidents only.

## 1.1 Safety Considerations for Repair

- If refrigerant gas leaks during repair or service, ventilate the area immediately. Refrigerant gas may produce toxic gas if it comes into contact with flames. Refrigerant gas is heavier than air and replaces oxygen. In the event of an accident, a massive leak could lead to oxygen depletion, especially in basements, and an asphyxiation hazard could occur leading to serious injury or death.
- Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug if a plug is used. Plugging or unplugging the power cable plug to operate the equipment may cause an electrical shock or fire.
- Use parts listed in the service parts list and appropriate tools to conduct repair work. The use of inappropriate parts or tools may cause an electrical shock or fire.
- Disconnect power before disassembling the equipment for repairs. Working on the equipment that is connected to the power supply may cause an electric shock. If it is necessary to supply power to the equipment to conduct repairs or to inspect the circuits, do not touch any electrically charged sections of the equipment.
- The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Discharge the capacitor completely before conducting repair work. A charged capacitor may cause an electrical shock.
- If refrigerant gas is discharged during repair work, do not touch the discharged refrigerant gas. The refrigerant gas may cause frostbite.
- Use only pipes, flare nuts, tools, and other materials designed specifically for R410A refrigerant systems. Never use tools or materials designed for R22 refrigerant systems on an R410A refrigerant system. Doing so can cause a serious accident or an equipment failure.
- Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire, or electrical shock.
- Prior to disconnecting the suction or discharge pipe from the compressor at the welded section, pump-down the refrigerant gas completely in a well-ventilated place first. If there is refrigerant gas or oil remaining inside the compressor, the refrigerant gas or oil can discharge when the pipe is being disconnected and it may cause an injury.
- Wear a safety helmet, gloves, and a safety belt when working at an elevated height of more than 6.5 ft (2 m). Insufficient safety measures may cause a fall resulting in injury.
- Do not mix air or gas other than the specified refrigerant R410A to the refrigerant system. If air enters the refrigerant systems, it can cause an excessive high pressure resulting in equipment damage and injury.
- When relocating the equipment, check if the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and the equipment is not properly secured, the equipment may fall and cause injury.
- Securely fasten the outside unit terminal cover (panel). If the terminal cover/panel is not fastened properly, dust or water may enter the outside unit causing fire or electric shock.
- When relocating the system, keep the refrigerant circuit free from substances other than the specified refrigerant (R-410A) such as air. Any presence of air or other foreign substance in the refrigerant circuit can cause an abnormal pressure rise or rupture, resulting in injury.
- If refrigerant gas leaks, locate the leaking point and repair it before charging refrigerant. After charging refrigerant, check for refrigerant leaks. If the leaking point cannot be located and the repair work must be stopped, perform a pump-down and close the service valve to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it may generate toxic gases if it comes into contact with flames.

- Do not repair the electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.
- Do not clean the air conditioner by splashing water on it. Washing the unit with water may cause an electrical shock.
- Ground the unit when repairing equipment in a humid or wet place to avoid electrical shocks.
- Turn off the power when cleaning the equipment to prevent internal fans that rotate at high speed from starting suddenly as they can cause injury.
- Let the refrigerant lines cool down before performing any repair work. Working on the unit when the refrigerant lines are hot may cause burns.
- All welding and cutting operations must be done in a well-ventilated place to prevent the accumulation of toxic fumes or possibly oxygen deficiency to occur.
- Check the grounding and repair it if the equipment is not properly grounded. Improper grounding may cause an electrical shock.
- Measure the insulation resistance after the repair. The resistance must be 1M  $\Omega$  or higher. Faulty insulation may cause an electrical shock.
- Check the drainage of the indoor unit after finishing repair work. Faulty drainage may cause water to enter the room resulting in wet floors and furniture.
- Do not tilt the unit when removing it. The water inside the unit may spill resulting in wet floors and furniture.
- Dismantling of the unit, disposal of the refrigerant, oil, and additional parts, should be done in accordance with the relevant local, state, and national regulations.
- Do not damage or modify the power cable. Damaged or modified power cables may cause an electrical shock or fire. Placing heavy items on the power cable or pulling the power cable may damage the cable.
- Check the unit foundation for damage on a continual basis, especially if it has been in use for a long time. If left in a damaged condition, the unit may fall and cause injury. If the installation platform or frame has corroded, have it replaced. A corroded platform or frame may cause the unit to fall resulting in injury.
- If the unit has a power cable plug and it is dirty, clean the plug before securely inserting it into a power outlet. If the plug has a loose connection, tighten it or it may cause electrical shock or fire.
- After replacing the battery in the remote controller, dispose of the old battery to prevent children from swallowing it. If a child swallows the battery, see a doctor immediately.
- Never remove the fan guard of the unit. A fan rotating at high speed without the fan guard is very dangerous.
- Before cleaning the unit, stop the operation of the unit by turning the power off or by pulling the power cable plug out from its receptacle. Otherwise an electrical shock or injury may result.
- Do not wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discolored or the coating can peel off. If it is extremely dirty, soak a cloth in a water-diluted neutral detergent, squeeze it well, and wipe the panel clean. Then wipe it with another dry cloth.

## 1.2 Safety Considerations for Users

- Never attempt to modify the equipment. Doing so can cause electrical shock, excessive heat generation, or fire.
- If the power cable and lead wires have scratches or have become deteriorated, have them replaced. Damaged cable and wires may cause an electrical shock or fire.
- Do not use a joined power cable or an extension cord, or share the same power outlet with other electrical appliances as it may cause an electrical shock or fire.
- Use an exclusive power circuit for the equipment. Insufficient circuit amperage capacity may cause an electrical shock or fire.

# Part 1

# List of Functions

1. Functions.....	2
-------------------	---

# 1. Functions

Category	Functions	CTXS07JVJU CTXS09/12HVJU	FTXS15/18HVJU	Category	Functions	CTXS07JVJU CTXS09/12HVJU	FTXS15/18HVJU
Basic Function	Inverter (with Inverter Power Control)	●	●	Health & Clean	Air-Purifying Filter	—	—
	Operation Limit for Cooling (°FDB)	—	—		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Heating (°FWB)	—	—		Air-Purifying Filter with Photocatalytic Deodorizing Function	●	●
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—
Compressor	Oval Scroll Compressor	—	—		Air Filter (Prefilter)	●	●
	Swing Compressor	—	—		Wipe-Clean Flat Panel	●	●
	Rotary Compressor	—	—		Washable Grille	—	—
	Reluctance DC Motor	—	—		Filter Cleaning Indicator	—	—
Comfortable Airflow	Power-Airflow Louver (Horizontal Blade)	—	—		Good-Sleep Cooling Operation	—	—
	Power-Airflow Dual Louvers	●	●	Timer	WEEKLY TIMER Operation	—	—
	Power-Airflow Diffuser	—	—		24-Hour ON/OFF TIMER	●	●
	Wide-Angle Fins (Vertical Blades)	●	●		NIGHT SET Mode	●	●
	Vertical Auto-Swing (Up and Down)	●	●		Auto-Restart (after Power Failure)	●	●
	Horizontal Auto-Swing (Right and Left)	●	●	Flexibility	Self-Diagnosis (Digital, LED) Display	●	●
	3-D Airflow	●	●		Wiring Error Check Function	—	—
	COMFORT AIRFLOW Operation	—	—		Anti-Corrosion Treatment of Outdoor Heat Exchanger	—	—
Comfort Control	Auto Fan Speed	●	●		Multi-Split / Split Type Compatible Indoor Unit	—	●
	Indoor Unit Quiet Operation	●	●		Flexible Power Supply Correspondence	—	—
	NIGHT QUIET Mode (Automatic)	—	—		High Ceiling Application	—	—
	OUTDOOR UNIT QUIET Operation (Manual)	●	●		Chargeless	—	—
	INTELLIGENT EYE Operation	●	●		Either Side Drain (Right or Left)	●	●
	Quick Warming Function	—	—		Power Selection	—	—
	Hot-Start Function	●	●		°F/°C Changeover R/C Temperature Display (factory setting: °F)	●	●
	Automatic Defrosting	—	—		5-Room Centralized Controller (Option)	●	●
Operation	Automatic Operation	●	●	Remote Control	Remote Control Adaptor (Normal Open Pulse Contact) (Option)	●	●
	Program Dry Operation	●	●		Remote Control Adaptor (Normal Open Contact) (Option)	●	●
	Fan Only	●	●		DIII-NET Compatible (Adaptor) (Option)	●	●
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	—	—	Remote Controller	Wireless	●	●
	Inverter POWERFUL Operation	●	●		Wired (Option)	●	●
	Priority-Room Setting	—	—				
	COOL / HEAT Mode Lock	—	—				
	HOME LEAVE Operation	●	●				
	ECONO Operation	—	—				
	Indoor Unit [ON/OFF] Button	●	●				
	Signal Receiving Sign	●	●				
	R/C with Back Light	●	●				
	Temperature Display	—	—				

**Note:** ● :Includes Function

— : Function not Included

Category	Functions	CTXS07LVJU	FTXS09/12/15/18LVJU	Category	Functions	CTXS07LVJU	FTXS09/12/15/18LVJU
Basic Function	Inverter (with Inverter Power Control)	●	●	Health & Clean	Air-Purifying Filter	—	—
	Operation Limit for Cooling (°FDB)	—	—		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Heating (°FWB)	—	—		Air-Purifying Filter with Photocatalytic Deodorizing Function	—	—
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	●	●
Compressor	Oval Scroll Compressor	—	—		Air Filter (Prefilter)	●	●
	Swing Compressor	—	—		Wipe-clean Flat Panel	●	●
	Rotary Compressor	—	—		Washable Grille	—	—
	Reluctance DC Motor	—	—		Filter Cleaning Indicator	—	—
Comfortable Airflow	Power-Airflow Louver (Horizontal Blade)	—	—		Good-Sleep Cooling Operation	—	—
	Power-Airflow Dual Louvers	●	●	Timer	WEEKLY TIMER Operation	●	●
	Power-Airflow Diffuser	—	—		24-Hour ON/OFF TIMER	●	●
	Wide-Angle Fins (Vertical Blades)	●	●		NIGHT SET Mode	●	●
	Vertical Auto-Swing (Up and Down)	●	●	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	●	●
	Horizontal Auto-Swing (Right and Left)	●	●		Self-Diagnosis (Digital, LED) Display	●	●
	3-D Airflow	●	●		Wiring Error Check Function	—	—
	COMFORT AIRFLOW Operation	●	●	Flexibility	Anticorrosion Treatment of Outdoor Heat Exchanger	—	—
Comfort Control	Auto Fan Speed	●	●		Multi-Split / Split Type Compatible Indoor Unit	—	●
	Indoor Unit Quiet Operation	●	●		Flexible Power Supply Correspondence	—	—
	NIGHT QUIET Mode (Automatic)	—	—		High Ceiling Application	—	—
	OUTDOOR UNIT QUIET Operation (Manual)	●	●		Chargeless	—	—
	INTELLIGENT EYE Operation	●	●		Either Side Drain (Right or Left)	●	●
	Quick Warming Function	—	—		Power Selection	—	—
	Hot-Start Function	●	●		°F/°C Changeover R/C Temperature Display (factory setting: °F)	●	●
	Automatic Defrosting	—	—	Remote Control	5-Room Centralized Controller (Option)	●	●
Operation	Automatic Operation	●	●		Remote Control Adaptor (Normal Open-Pulse Contact) (Option)	●	●
	Program Dry Function	●	●		Remote Control Adaptor (Normal Open Contact) (Option)	●	●
	Fan Only	●	●		DIII-NET Compatible (Adaptor) (Option)	●	●
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	—	—	Remote Controller	Wireless	●	●
	Inverter POWERFUL Operation	●	●		Wired (Option)	●	●
	Priority-Room Setting	—	—				
	COOL / HEAT Mode Lock	—	—				
	HOME LEAVE Operation	—	—				
	ECONO Operation	●	●				
	Indoor Unit [ON/OFF] Button	●	●				
	Signal Receiving Sign	●	●				
	R/C with Back Light	●	●				
	Temperature Display	—	—				

**Note:** ● :Includes Function  
 — : Function not Included

Category	Functions	FDXS09/12DVJU	Category	Functions	FDXS09/12DVJU
Basic Function	Inverter (with Inverter Power Control)	●	Health & Clean	Air-Purifying Filter	—
	Operation Limit for Cooling (°FDB)	—		Photocatalytic Deodorizing Filter	—
	Operation Limit for Heating (°FWB)	—		Air-Purifying Filter with Photocatalytic Deodorizing Function	—
	PAM Control	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—
Compressor	Oval Scroll Compressor	—		Air Filter (Prefilter)	●
	Swing Compressor	—		Wipe-Clean Flat Panel	—
	Rotary Compressor	—		Washable Grille	—
	Reluctance DC Motor	—		Filter Cleaning Indicator	—
Comfortable Airflow	Power-Airflow Louver (Horizontal Blade)	—		Good-Sleep Cooling Operation	—
	Power-Airflow Dual Louvers	—	Timer	WEEKLY TIMER Operation	—
	Power-Airflow Diffuser	—		24-Hour ON/OFF TIMER	●
	Wide-Angle Fins (Vertical Blades)	—		NIGHT SET Mode	●
	Vertical Auto-Swing (Up and Down)	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	●
	Horizontal Auto-Swing (Right and Left)	—		Self-Diagnosis (Digital, LED) Display	●
	3-D Airflow	—		Wiring Error Check Function	—
	COMFORT AIRFLOW Mode	—	Flexibility	Anticorrosion Treatment of Outdoor Heat Exchanger	—
Comfort Control	Auto Fan Speed	●		Multi-Split / Split Type Compatible Indoor Unit	●
	Indoor Unit Quiet Operation	●		Flexible Power Supply Correspondence	—
	NIGHT QUIET Mode (Automatic)	—		High Ceiling Application	—
	OUTDOOR UNIT QUIET Operation (Manual)	●		Chargeless	—
	INTELLIGENT EYE Operation	—		Either Side Drain (Right or Left)	—
	Quick Warming Function	—		Power Selection	—
	Hot-Start Function	●		°F/°C Changeover R/C Temperature Display (factory setting: °F)	—
	Automatic Defrosting	—		5-Room Centralized Controller (Option)	●
Operation	Automatic Operation	●	Remote Control	Remote Control Adaptor (Normal Open Pulse Contact) (Option)	●
	Program Dry Operation	●		Remote Control Adaptor (Normal Open Contact) (Option)	●
	Fan Only	●		DIII-NET Compatible (Adaptor) (Option)	●
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	—	Remote Controller	Wireless	●
	Inverter POWERFUL Operation	●		Wired (Option)	●
	Priority-Room Setting	—			
	COOL / HEAT Mode Lock	—			
	HOME LEAVE Operation	●			
	ECONO Operation	—			
	Indoor Unit [ON/OFF] Button	●			
	Signal Receiving Sign	●			
	R/C with Back Light	—			
	Temperature Display	—			

**Note:** ● :Includes Function

— : Function not Included



Category	Functions	FDXS09/12LVJU	CDXS15/18LVJU	Category	Functions	FDXS09/12LVJU	CDXS15/18LVJU
Basic Function	Inverter (with Inverter Power Control)	●	●	Health & Clean	Air-Purifying Filter	—	—
	Operation Limit for Cooling (°FDB)	—	—		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Heating (°FWB)	—	—		Air-Purifying Filter with Photocatalytic Deodorizing Function	—	—
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—
Compressor	Oval Scroll Compressor	—	—		Air Filter (Prefilter)	●	●
	Swing Compressor	—	—		Wipe-clean Flat Panel	—	—
	Rotary Compressor	—	—		Washable Grille	—	—
	Reluctance DC Motor	—	—		Filter Cleaning Indicator	—	—
Comfortable Airflow	Power-Airflow Louver (Horizontal Blade)	—	—		Good-Sleep Cooling Operation	—	—
	Power-Airflow Dual Louvers	—	—	Timer	WEEKLY TIMER Operation	—	—
	Power-Airflow Diffuser	—	—		24-Hour ON/OFF TIMER	●	●
	Wide-Angle Fins (Vertical Blades)	—	—		NIGHT SET Mode	●	●
	Vertical Auto-Swing (Up and Down)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	●	●
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	●	●
	3-D Airflow	—	—		Wiring Error Check Function	—	—
	COMFORT AIRFLOW Operation	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—
Comfort Control	Auto Fan Speed	●	●	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	●	—
	Indoor Unit Quiet Operation	●	●		Flexible Power Supply Correspondence	—	—
	NIGHT SET Mode (Automatic)	—	—		High Ceiling Application	—	—
	OUTDOOR UNIT QUIET Operation (Manual)	●	●		Chargeless	—	—
	INTELLIGENT EYE Operation	—	—		Either Side Drain (Right or Left)	—	—
	Quick Warming Function	—	—		Power Selection	—	—
	Hot-Start Function	●	●		°F/°C Changeover R/C Temperature Display (factory setting: °F)	●	●
	Automatic Defrosting	—	—		5-Room Centralized Controller (Option)	●	●
Operation	Automatic Operation	●	●	Remote Control	Remote Control Adaptor (Normal Open-Pulse Contact) (Option)	●	●
	Program Dry Function	●	●		Remote Control Adaptor (Normal Open Contact) (Option)	●	●
	Fan Only	●	●		DIII-NET Compatible (Adaptor) (Option)	●	●
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	—	—	Remote Controller	Wireless	●	●
	Inverter POWERFUL Operation	●	●		Wired (Option)	●	●
	Priority-Room Setting	—	—				
	COOL / HEAT Mode Lock	—	—				
	HOME LEAVE Operation	—	—				
	ECONO Operation	●	●				
	Indoor Unit [ON/OFF] Button	●	●				
	Signal Receiving Sign	●	●				
	R/C with Back Light	●	●				
	Temperature Display	—	—				

**Note:** ● :Includes Function  
 — : Function not Included

Category	Functions	2MXS18GVJU	3MXS24JVJU 4MXS32GVJU	Category	Functions	2MXS18GVJU	3MXS24JVJU 4MXS32GVJU
Basic Function	Inverter (with Inverter Power Control)	●	●	Health & Clean	Air-Purifying Filter	—	—
	Operation Limit for Cooling (°CDB)	-10 ~ 46	-10 ~ 46		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Cooling (°FDB)	14 ~ 114.8	14 ~ 114.8		Air-Purifying Filter with Photocatalytic Deodorizing Function	—	—
	Operation Limit for Heating (°CWB)	-15 ~ 15.5	-15 ~ 15.5		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—
	Operation Limit for Heating (°FWB)	5 ~ 59.9	5 ~ 59.9		Air Filter (Prefilter)	—	—
	PAM Control	●	●		Wipe-clean Flat Panel	—	—
Compressor	Oval Scroll Compressor	—	—	Timer	Washable Grille	—	—
	Swing Compressor	●	●		Filter Cleaning Indicator	—	—
	Rotary Compressor	—	—		Good-Sleep Cooling Operation	—	—
	Reluctance DC Motor	●	●		WEEKLY TIMER Operation	—	—
Comfortable Airflow	Power-Airflow Louver (Horizontal Blade)	—	—	Worry Free "Reliability & Durability"	24-Hour ON/OFF Timer	—	—
	Power-Airflow Dual Louvers	—	—		NIGHT SET Mode	—	—
	Power-Airflow Diffuser	—	—		Auto-Restart (after Power Failure)	—	—
	Wide-Angle Fins (Vertical Blades)	—	—		Self-Diagnosis (Digital, LED) Display	●	●
	Vertical Auto-Swing (Up and Down)	—	—		Wiring Error Check Function	●	●
	Horizontal Auto-Swing (Right and Left)	—	—		Anti-Corrosion Treatment of Outdoor Heat Exchanger	●	●
	3-D Airflow	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	—	—
	COMFORT AIRFLOW Operation	—	—		Flexible Power Supply Correspondence	—	—
Comfort Control	Auto Fan Speed	—	—		High Ceiling Application	—	—
	Indoor Unit Quiet Operation	—	—		Chargeless	98.4 ft (30 m)	131.6 ft (40 m)
	NIGHT QUIET Mode (Automatic)	●	●		Either Side Drain (Right or Left)	—	—
	OUTDOOR UNIT QUIET Operation (Manual)	●	●		Power Selection	—	—
	INTELLIGENT EYE Operation	—	—		°F/°C Changeover R/C Temperature Display (factory setting: °F)	—	—
	Quick Warming Function	●	●		5-Room Centralized Controller (Option)	—	—
	Hot-Start Function	—	—		Remote Control Adaptor (Normal Open-Pulse Contact) (Option)	—	—
	Automatic Defrosting	●	●		Remote Control Adaptor (Normal Open Contact) (Option)	—	—
Operation	Automatic Operation	—	—	Remote Control	DIII-NET Compatible (Adaptor) (Option)	—	—
	Program Dry Function	—	—		Wireless	—	—
	Fan Only	—	—		Wired (Option)	—	—
Lifestyle Convenience	New POWERFUL Operation (Non-Inverter)	—	—	Remote Controller			
	Inverter POWERFUL Operation	—	—				
	Priority-Room Setting	●	●				
	COOL / HEAT Mode Lock	●	●				
	HOME LEAVE Operation	—	—				
	ECONO Operation	—	—				
	Indoor Unit [ON/OFF] Button	—	—				
	Signal Receiving Sign	—	—				
	R/C with Back Light	—	—				
	Temperature Display	—	—				

Notes: ● :Includes Function

— : Function not Included

# Part 2

# Specifications

1. Indoor Unit.....	8
2. Outdoor Unit.....	13

# 1. Indoor Unit

## CTXS, FTXS Series

60 Hz, 208 - 230 V

Model			CTXS07JVJU	
			Cooling	Heating
Rated Capacity			7 kBtu/h Class	
Front Panel Color			White	
Airflow Rate	H	cfm (m <sup>3</sup> /min)	388 (11.0)	400 (11.3)
	M		335 (9.5)	357 (10.1)
	L		283 (8.0)	314 (8.9)
Fan	Type	Cross Flow Fan		
	Motor Output	W	40	
	Speed	Steps	5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.18	0.2
Power Consumption (Rated)		W	40	45
Power Factor (Rated)		%	96.6	97.8
Temperature Control			Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	11-7/16 × 31-5/16 × 9-3/8 (290 × 795 × 238)	
Packaged Dimensions (H × W × D)		in. (mm)	11 × 33-1/16 × 13-5/16 (280 × 840 × 338)	
Weight (Mass)		Lbs (kg)	20 (9)	
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)	
Sound Pressure Level	H / M / L	dB(A)	44 / 40 / 35	44 / 39 / 34
Heat Insulation			Both Liquid and Gas Pipes	
Piping Connection	Liquid	in. (mm)	φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)	
	Drain	in. (mm)	φ 11/16 (φ 18.0)	
Drawing No.			3D066156A	

Model			CTXS09HVJU		CTXS12HVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m <sup>3</sup> /min)	388 (11.0)	400 (11.3)	388 (11.0)	400 (11.3)
	M		335 (9.5)	357 (10.1)	335 (9.5)	357 (10.1)
	L		283 (8.0)	314 (8.9)	283 (8.0)	314 (8.9)
Fan	Type	Cross Flow Fan				Cross Flow Fan
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.18	0.2	0.18	0.2
Power Consumption (Rated)		W	40	45	40	45
Power Factor (Rated)		%	96.6	97.8	96.6	97.8
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	11-7/16 × 31-5/16 × 9-3/8 (290 × 795 × 238)		11-7/16 × 31-5/16 × 9-3/8 (290 × 795 × 238)	
Packaged Dimensions (H × W × D)		in. (mm)	11 × 33-1/16 × 13-5/16 (280 × 840 × 338)		11 × 33-1/16 × 13-5/16 (280 × 840 × 338)	
Weight (Mass)		Lbs (kg)	20 (9)		20 (9)	
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)		29 (13)	
Sound Pressure Level	H / M / L	dB(A)	44 / 40 / 35	44 / 39 / 34	45 / 41 / 36	45 / 40 / 35
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	φ 11/16 (φ 18.0)		φ 11/16 (φ 18.0)	
Drawing No.			3D062870A		3D062871A	

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m <sup>3</sup> /min × 35.3

60 Hz, 230 V

Model			FTXS15HVJU		FTXS18HVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m³/min)	519 (14.7)	515 (14.6)	549 (15.5)	609 (17.2)
	M		436 (12.3)	459 (13.0)	476 (13.5)	529 (15.0)
	L		353 (10.0)	402 (11.4)	402 (11.4)	448 (12.7)
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	43		43	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.18		0.18	
Power Consumption (Rated)		W	40		40	
Power Factor (Rated)		%	96.6		96.6	
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	11-7/16 × 41-5/16 × 9-3/8 (290 × 1,050 × 238)		11-7/16 × 41-5/16 × 9-3/8 (290 × 1,050 × 238)	
Packaged Dimensions (H × W × D)		in. (mm)	13-1/4 × 45-3/16 × 14-7/16 (337 × 1,147 × 366)		13-1/4 × 45-3/16 × 14-7/16 (337 × 1,147 × 366)	
Weight (Mass)		Lbs (kg)	26.5 (12)		26.5 (12)	
Gross Weight (Gross Mass)		Lbs (kg)	38 (17)		38 (17)	
Sound Pressure Level	H / M / L	dB(A)	45 / 41 / 36	44 / 40 / 35	45 / 41 / 36	44 / 40 / 35
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	in. (mm)	ϕ 1/4 (ϕ 6.4)		ϕ 1/4 (ϕ 6.4)	
	Gas	in. (mm)	ϕ 1/2 (ϕ 12.7)		ϕ 1/2 (ϕ 12.7)	
	Drain	in. (mm)	ϕ 11/16 (ϕ 18.0)		ϕ 11/16 (ϕ 18.0)	
Drawing No.			3D062866A		3D062868A	

60 Hz, 208 - 230 V

Model			CTXS07LVJU	
			Cooling	Heating
Rated Capacity			7 kBtu/h Class	
Front Panel Color			White	
Airflow Rate	H	cfm (m³/min)	332 (9.4)	350 (9.9)
	M		261 (7.4)	290 (8.2)
	L		194 (5.5)	233 (6.6)
	SL		145 (4.1)	219 (6.2)
Fan	Type		Cross Flow Fan	
	Motor Output	W	23	
	Speed	Steps	5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.09 - 0.08	0.11 - 0.10
Power Consumption (Rated)		W	18 - 18	21 - 21
Power Factor (Rated)		%	96.2 - 97.8	91.8 - 91.3
Temperature Control			Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	11-5/8 × 31-1/2 × 8-7/16 (295 × 800 × 215)	
Packaged Dimensions (H × W × D)		in. (mm)	10-13/16 × 34-1/4 × 14-7/16 (274 × 870 × 366)	
Weight (Mass)		Lbs (kg)	20 (9)	
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)	
Sound Pressure Level	H / M / L / SL	dB(A)	38 / 32 / 25 / 22	38 / 33 / 28 / 25
Sound Power Level		dB	54	54
Heat Insulation			Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	ϕ 1/4 (ϕ 6.4)	
	Gas	in. (mm)	ϕ 3/8 (ϕ 9.5)	
	Drain	in. (mm)	ϕ 5/8 (ϕ 16.0)	
Drawing No.			3D075490	

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m³/min × 35.3

60 Hz, 208 - 230 V

Model			FTXS09LVJU		FTXS12LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m <sup>3</sup> /min)	381 (10.8)	420 (11.9)	403 (11.4)	438 (12.4)
	M		279 (7.9)	321 (9.1)	307 (8.7)	335 (9.5)
	L		194 (5.5)	233 (6.6)	205 (5.8)	240 (6.8)
	SL		145 (4.1)	219 (6.2)	155 (4.4)	212 (6.0)
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	23		23	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.09 - 0.08	0.11 - 0.10	0.13 - 0.12	0.14 - 0.13
Power Consumption (Rated)		W	18 - 18	21 - 21	26 - 26	28 - 28
Power Factor (Rated)		%	96.2 - 97.8	91.8 - 91.3	96.2 - 94.2	96.2 - 93.6
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	11-5/8 × 31-1/2 × 8-7/16 (295 × 800 × 215)		11-5/8 × 31-1/2 × 8-7/16 (295 × 800 × 215)	
Packaged Dimensions (H × W × D)		in. (mm)	10-13/16 × 34-1/4 × 14-7/16 (274 × 870 × 366)		10-13/16 × 34-1/4 × 14-7/16 (274 × 870 × 366)	
Weight (Mass)		Lbs (kg)	20 (9)		22 (10)	
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)		31 (14)	
Sound Pressure Level	H / M / L / SL	dB(A)	41 / 33 / 25 / 22	42 / 35 / 28 / 25	45 / 37 / 29 / 23	45 / 39 / 29 / 26
Sound Power Level		dB	57	58	61	61
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	ϕ 1/4 (ϕ 6.4)		ϕ 1/4 (ϕ 6.4)	
	Gas	in. (mm)	ϕ 3/8 (ϕ 9.5)		ϕ 3/8 (ϕ 9.5)	
	Drain	in. (mm)	ϕ 5/8 (ϕ 16.0)		ϕ 5/8 (ϕ 16.0)	
Drawing No.			3D075491		3D075492	

Model			FTXS15LVJU		FTXS18LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m <sup>3</sup> /min)	568 (16.1)	593 (16.8)	583 (16.5)	625 (17.7)
	M		477 (13.5)	505 (14.3)	484 (13.7)	526 (14.9)
	L		385 (10.9)	417 (11.8)	385 (10.9)	431 (12.2)
	SL		360 (10.2)	371 (10.5)	360 (10.2)	399 (11.3)
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	48		48	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.31 - 0.29	0.31 - 0.29	0.32 - 0.30	0.32 - 0.30
Power Consumption (Rated)		W	38 - 38	38 - 38	38 - 38	38 - 38
Power Factor (Rated)		%	58.9 - 57.0	58.9 - 57.0	57.1 - 55.1	57.1 - 55.1
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	13-3/8 × 41-5/16 × 9-3/4 (340 × 1,050 × 248)		13-3/8 × 41-5/16 × 9-3/4 (340 × 1,050 × 248)	
Packaged Dimensions (H × W × D)		in. (mm)	13 × 45-11/16 × 16-7/8 (331 × 1,160 × 429)		13 × 45-11/16 × 16-7/8 (331 × 1,160 × 429)	
Weight (Mass)		Lbs (kg)	31 (14)		31 (14)	
Gross Weight (Gross Mass)		Lbs (kg)	44 (20)		44 (20)	
Sound Pressure Level	H / M / L / SL	dB(A)	45 / 40 / 35 / 32	43 / 38 / 33 / 30	46 / 41 / 36 / 33	45 / 40 / 35 / 32
Sound Power Level		dB	61	59	62	61
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	ϕ 1/4 (ϕ 6.4)		ϕ 1/4 (ϕ 6.4)	
	Gas	in. (mm)	ϕ 1/2 (ϕ 12.7)		ϕ 1/2 (ϕ 12.7)	
	Drain	in. (mm)	ϕ 5/8 (ϕ 16.0)		ϕ 5/8 (ϕ 16.0)	
Drawing No.			3D075043		3D075044	

## Conversion Formulae

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m<sup>3</sup>/min × 35.3

## CDXS, FDXS Series

60 Hz, 230 V

Model			FDXS09DVJU		FDXS12DVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
External Static Pressure		inAq (Pa)	0.12 (30)		0.12 (30)	
Airflow Rate	H	cfm (m³/min)	305 (8.6)	305 (8.6)	305 (8.6)	305 (8.6)
	M		280 (7.9)	280 (7.9)	280 (7.9)	280 (7.9)
	L		260 (7.4)	260 (7.4)	260 (7.4)	260 (7.4)
Fan	Type		Sirocco Fan		Sirocco Fan	
	Motor Output	W	62		62	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.52	0.52	0.52	0.52
Power Consumption (Rated)		W	72	72	72	72
Power Factor (Rated)		%	60.2	60.2	60.2	60.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	7-7/8 × 27-9/16 × 24-7/16 (200 × 700 × 620)		7-7/8 × 27-9/16 × 24-7/16 (200 × 700 × 620)	
Packaged Dimensions (H × W × D)		in. (mm)	10-13/16 × 36-5/16 × 30-1/4 (274 × 923 × 768)		10-13/16 × 36-5/16 × 30-1/4 (274 × 923 × 768)	
Weight (Mass)		Lbs (kg)	47 (21)		47 (21)	
Gross Weight (Gross Mass)		Lbs (kg)	64 (29)		64 (29)	
Sound Pressure Level	H / M / L	dB(A)	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))		VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))	
Drawing No.			3D051781A		3D051782A	

60 Hz, 208 - 230 V

Model			FDXS09LVJU		FDXS12LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
External Static Pressure		inAq (Pa)	0.12 (30)		0.12 (30)	
Airflow Rate	H	cfm (m³/min)	305 (8.6)	305 (8.6)	305 (8.6)	305 (8.6)
	M		280 (7.9)	280 (7.9)	280 (7.9)	280 (7.9)
	L		260 (7.4)	260 (7.4)	260 (7.4)	260 (7.4)
	SL		235 (6.7)	235 (6.7)	235 (6.7)	235 (6.7)
Fan	Type		Sirocco Fan		Sirocco Fan	
	Motor Output	W	62		62	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.58 - 0.52	0.58 - 0.52	0.58 - 0.52	0.58 - 0.52
Power Consumption (Rated)		W	72 - 72	72 - 72	72 - 72	72 - 72
Power Factor (Rated)		%	59.7 - 60.2	59.7 - 60.2	59.7 - 60.2	59.7 - 60.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	7-7/8 × 27-9/16 × 24-7/16 (200 × 700 × 620)		7-7/8 × 27-9/16 × 24-7/16 (200 × 700 × 620)	
Packaged Dimensions (H × W × D)		in. (mm)	10-13/16 × 36-5/16 × 30-1/4 (274 × 923 × 768)		10-13/16 × 36-5/16 × 30-1/4 (274 × 923 × 768)	
Weight (Mass)		Lbs (kg)	47 (21)		47 (21)	
Gross Weight (Gross Mass)		Lbs (kg)	64 (29)		64 (29)	
Sound Pressure Level	H / M / L	dB(A)	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31
Sound Power Level		dB	51	51	51	51
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))		VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))	
Drawing No.			3D075493		3D075494	

## Conversion Formulae

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m³/min × 35.3

60 Hz, 208 - 230 V

Model			CDXS15LVJU		CDXS18LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
External Static Pressure		inAq (Pa)	0.16 (40)		0.16 (40)	
Airflow Rate	H	cfm (m <sup>3</sup> /min)	424 (12.0)	424 (12.0)	424 (12.0)	424 (12.0)
	M		388 (11.0)	388 (11.0)	388 (11.0)	388 (11.0)
	L		353 (10.0)	353 (10.0)	353 (10.0)	353 (10.0)
	SL		297 (8.4)	297 (8.4)	297 (8.4)	297 (8.4)
Fan	Type		Sirocco Fan		Sirocco Fan	
	Motor Output	W	130		130	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.79	0.79	0.79	0.79
Power Consumption (Rated)		W	172	172	172	172
Power Factor (Rated)		%	94.4	94.4	94.4	94.4
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)		in. (mm)	7-7/8 × 35-7/16 × 24-7/16 (200 × 900 × 620)		7-7/8 × 35-7/16 × 24-7/16 (200 × 900 × 620)	
Packaged Dimensions (H × W × D)		in. (mm)	10-1/2 × 43-9/16 × 29-9/16 (266 × 1,106 × 751)		10-1/2 × 43-9/16 × 29-9/16 (266 × 1,106 × 751)	
Weight (Mass)		Lbs (kg)	60 (27)		60 (27)	
Gross Weight (Gross Mass)		Lbs (kg)	75 (34)		75 (34)	
Sound Pressure Level	H / M / L	dB(A)	37 / 35 / 33 / 31	37 / 35 / 33 / 31	37 / 35 / 33 / 31	37 / 35 / 33 / 31
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 1/2 (φ 12.7)		φ 1/2 (φ 12.7)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))		VP20 (O.D. φ 1-1/32 (φ 26.0), I.D. φ 25/32 (φ 20.0))	
Drawing No.			C: 3D075721		C: 3D075722	

## Conversion Formulae

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m<sup>3</sup>/min × 35.3



## 2. Outdoor Unit

60 Hz, 208 - 230 V

Model			2MXS18GVJU	
			Cooling	Heating
Casing Color			Ivory White	
Compressor	Type		Hermetically Sealed Swing Type	
	Model		2YC45EXD	
	Motor Output	W	1,380	
Refrigerant Oil	Model		FVC50K	
	Charge	oz (L)	26.5 (0.75)	
Refrigerant	Type		R-410A	
	Charge	Lbs (kg)	5.73 (2.6)	
Airflow Rate	H	m³/min	49	41
	L		43	39
	H	cfm	1,730	1,448
	L		1,518	1,377
Fan	Type		Propeller	
	Motor Output	W	53	
	Running Current	A	H: 0.31 / L: 0.28	H: 0.27 / L: 0.25
	Power Consumption	W	H: 65 / L: 57	H: 55 / L: 52
Starting Current		A	10.6	
Dimension (H × W × D)		in. (mm)	28-15/16 × 32-1/2 × 11-13/16 (735 × 825 × 300)	
Packaged Dimension (H × W × D)		in. (mm)	31-7/16 × 39-5/16 × 15-3/8 (806 × 999 × 390)	
Weight (Mass)		Lbs (kg)	139 (63)	
Gross Weight (Gross Mass)		Lbs (kg)	144 (65)	
Sound Pressure Level		dB(A)	50	51
Piping Connections	Liquid	in. (mm)	ϕ 1/4 × 2 (ϕ 6.4 × 2)	
	Gas	in. (mm)	ϕ 3/8 × 2 (ϕ 9.5 × 2)	
	Drain	in. (mm)	ϕ 11/16 (ϕ 18.0)	
Heat Insulation			Both Liquid and Gas Pipes	
No. of Wiring Connection			3 for Power Supply, 4 for Interunit Wiring	
Max. Interunit Piping Length		ft (m)	164 (50) (for Total of Each Room)	
			82 (25) (for One Room)	
Amount of Additional Charge of Refrigerant		oz/ft (g/m)	0.22 (20) (98.4 ft (30 m) or more)	
Max. Installation Height Difference		ft (m)	49.2 (15) (between Indoor Unit and Outdoor Unit)	
			24.6 (7.5) (between Indoor Units)	
Drawing No.			3D058840	

**Note:**

■ The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB)	Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB)	25 ft (7.5 m)
Outdoor ; 95°FDB (35°CDB) / 75°FWB (24°CWB)	Outdoor ; 47°FDB (8.3°CDB) / 43°FWB (6°CWB)	

**Conversion Formulae**

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m<sup>3</sup>/min × 35.3

60 Hz, 208 - 230 V

Model			3MXS24JVJU	
			Cooling	Heating
Casing Color			Ivory White	
Compressor	Type		Hermetically Sealed Swing Type	
	Model		2YC63EXD	
	Motor Output	W	1,920	
Refrigerant Oil	Model		FVC50K	
	Charge	oz (L)	26.5 (0.75)	
Refrigerant	Type		R-410A	
	Charge	Lbs (kg)	6.61 (3.0)	
Airflow Rate	H	m³/min	58.4	52.1
	M		52.1	52.1
	L		46.5	13.0
	H	cfm	2,062	1,840
	M		1,840	1,840
	L		1,642	459
Fan	Type		Propeller	
	Motor Output	W	66	
	Running Current	A	H: 1.02 / M: 0.87 / L: 0.69	H: 0.87 / M: 0.87 / L: 0.05
	Power Consumption	W	H: 95 / M: 74 / L: 55	H: 74 / M: 74 / L: 9
Starting Current		A	17.8	
Dimension (H × W × D)		in. (mm)	30-5/16 × 35-7/16 × 12-5/8 (770 × 900 × 320)	
Packaged Dimension (H × W × D)		in. (mm)	35-7/8 × 37-11/16 × 15-15/16 (911 × 958 × 405)	
Weight (Mass)		Lbs (kg)	168 (76)	
Gross Weight (Gross Mass)		Lbs (kg)	196 (89)	
Sound Pressure Level		dB(A)	52	54
Piping Connections	Liquid	in. (mm)	ϕ 1/4 × 3 (ϕ 6.4 × 3)	
	Gas	in. (mm)	ϕ 3/8 × 1, ϕ 1/2 × 1, ϕ 5/8 × 1 (ϕ 9.5 × 1, ϕ 12.7 × 1, ϕ 16.0 × 1)	
	Drain	in. (mm)	ϕ 1 (ϕ 25)	
Heat Insulation			Both Liquid and Gas Pipes	
No. of Wiring Connection			3 for Power Supply, 4 for Interunit Wiring	
Max. Interunit Piping Length		ft (m)	230 (70) (for Total of Each Room)	
			82 (25) (for One Room)	
Amount of Additional Charge of Refrigerant		oz/ft (g/m)	0.22 (20) (131.6 ft (40 m) or more)	
Max. Installation Height Difference		ft (m)	49.2 (15) (between Indoor Unit and Outdoor Unit)	
			24.6 (7.5) (between Indoor Units)	
Drawing No.			3D066155	

**Note:** ■ The data are based on the conditions shown in the table below.

Cooling		Heating	Piping Length
Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB)		Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB)	25 ft (7.5 m)
Outdoor ; 95°FDB (35°CDB) / 75°FWB (24°CWB)		Outdoor ; 47°FDB (8.3°CDB) / 43°FWB (6°CWB)	

## Conversion Formulae

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m<sup>3</sup>/min × 35.3

60 Hz, 208 - 230 V

Model			4MXS32GVJU	
			Cooling	Heating
Casing Color			Ivory White	
Compressor	Type		Hermetically Sealed Swing Type	
	Model		2YC63EXD	
	Motor Output	W	1,920	
Refrigerant Oil	Model		FVC50K	
	Charge	oz (L)	26.5 (0.75)	
Refrigerant	Type		R-410A	
	Charge	Lbs (kg)	6.83 (3.1)	
Airflow Rate	H	m³/min	58.4	52.1
	M		52.1	52.1
	L		46.5	13.0
	H	cfm	2,062	1,840
	M		1,840	1,840
	L		1,642	459
Fan	Type		Propeller	
	Motor Output	W	66	
	Running Current	A	H: 1.02 / M: 0.87 / L: 0.69	H: 0.87 / M: 0.87 / L: 0.05
	Power Consumption	W	H: 95 / M: 74 / L: 55	H: 74 / M: 74 / L: 9
Starting Current		A	18.0	
Dimension (H × W × D)		in. (mm)	30-5/16 × 35-7/16 × 12-5/8 (770 × 900 × 320)	
Packaged Dimension (H × W × D)		in. (mm)	35-7/8 × 37-11/16 × 15-15/16 (911 × 958 × 405)	
Weight (Mass)		Lbs (kg)	168 (76)	
Gross Weight (Gross Mass)		Lbs (kg)	196 (89)	
Sound Pressure Level		dB(A)	52	54
Piping Connections	Liquid	in. (mm)	ϕ 1/4 × 4 (ϕ 6.4 × 4)	
	Gas	in. (mm)	ϕ 3/8 × 1, ϕ 1/2 × 1, ϕ 5/8 × 2 (ϕ 9.5 × 1, ϕ 12.7 × 1, ϕ 16.0 × 2)	
	Drain	in. (mm)	ϕ 1 (ϕ 25)	
Heat Insulation			Both Liquid and Gas Pipes	
No. of Wiring Connection			3 for Power Supply, 4 for Interunit Wiring	
Max. Interunit Piping Length		ft (m)	230 (70) (for Total of Each Room)	
			82 (25) (for One Room)	
Amount of Additional Charge of Refrigerant		oz/ft (g/m)	0.22 (20) (131.6 ft (40 m) or more)	
Max. Installation Height Difference		ft (m)	49.2 (15) (between Indoor Unit and Outdoor Unit)	
			24.6 (7.5) (between Indoor Units)	
Drawing No.			3D058873A	

**Note:** ■ The data are based on the conditions shown in the table below.

Cooling		Heating	Piping Length
Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB)		Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB)	25 ft (7.5 m)
Outdoor ; 95°FDB (35°CDB) / 75°FWB (24°CWB)		Outdoor ; 47°FDB (8.3°CDB) / 43°FWB (6°CWB)	

## Conversion Formulae

kcal/h = kW × 860  
 Btu/h = kW × 3412  
 cfm = m<sup>3</sup>/min × 35.3

# Part 3

# Printed Circuit Board

# Connector Wiring Diagram

- 1. Indoor Unit..... 17
  - 1.1 CTXS07JVJU, CTXS09/12HVJU, FTXS15/18HVJU..... 17
  - 1.2 CTXS07LVJU, FTXS09/12LVJU ..... 19
  - 1.3 FTXS15/18LVJU ..... 22
  - 1.4 FDXS09/12DVJU ..... 25
  - 1.5 FDXS09/12LVJU, CDXS15/18LVJU ..... 27
- 2. Outdoor Unit.....29
  - 2.1 2MXS18GVJU ..... 29
  - 2.2 3MXS24JVJU, 4MXS32GVJU..... 32

# 1. Indoor Unit

## 1.1 CTXS07JVJU, CTXS09/12HVJU, FTXS15/18HVJU

### Connectors and Other Parts

#### PCB (1): Control PCB

- |                   |   |
|-------------------|---|
| 1) S1             | Connector for fan motor   |
| 2) S6             | Connector for swing motor (horizontal blades)                                     |
| 3) S8             | Connector for swing motor (vertical blades)                                       |
| 4) S21            | Connector for centralized control (HA)  |
| 5) S26            | Connector for buzzer PCB  |
| 6) S28            | Connector for signal receiver PCB   |
| 7) S32            | Connector for indoor heat exchanger thermistor                                    |
| 8) S35            | Connector for INTELLIGENT EYE sensor PCB  |
| 9) H1, H2, H3, FG | Connector for terminal board  |
| 10)JA             | Address setting jumper<br>* Refer to page 265 for detail.                         |
| 11)JB             | Fan speed setting when compressor stops for thermostat OFF                        |
| JC                | Power failure recovery function (auto-restart)<br>* Refer to page 266 for detail. |
| 12)LED A          | LED for service monitor (green)   |
| 13)FU1            | Fuse (3.15 A, 250 V)  |
| 14)V1             | Varistor  |

#### PCB (2): Signal Receiver PCB

- |              |                                  |
|--------------|----------------------------------|
| 1) S29       | Connector for control PCB        |
| 2) SW1 (S1W) | Forced operation [ON/OFF] button |

#### PCB (3): Buzzer PCB

- |               |                             |
|---------------|-----------------------------|
| 1) S27        | Connector for control PCB   |
| 2) S38        | Connector for display PCB   |
| 3) RTH1 (R1T) | Room temperature thermistor |

#### PCB (4): Display PCB

- |               |                                    |
|---------------|------------------------------------|
| 1) S37        | Connector for buzzer PCB           |
| 2) LED1 (H1P) | LED for operation (green)          |
| 3) LED2 (H2P) | LED for timer (yellow)             |
| 4) LED3 (H3P) | LED for HOME LEAVE operation (red) |

#### PCB (5): INTELLIGENT EYE Sensor PCB

- |        |                           |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|




### Caution

**Replace the PCB if you accidentally cut the jumpers other than JA, JB, and JC.**


Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

## PCB Detail


## PCB (1): Control PCB




## PCB (2): Signal Receiver PCB




## PCB (3): Buzzer PCB



## PCB (4): Display PCB



## PCB (5): INTELLIGENT EYE Sensor PCB



## 1.2 CTXS07LVJU, FTXS09/12LVJU

### Connectors and Other Parts

#### PCB (1): Control PCB

- |                   |   |
|-------------------|---|
| 1) S1             | Connector for DC fan motor  |
| 2) S21            | Connector for centralized control (HA)  |
| 3) S25            | Connector for INTELLIGENT EYE sensor PCB  |
| 4) S32            | Indoor heat exchanger thermistor  |
| 5) S41            | Connector for swing motors  |
| 6) S46            | Connector for display PCB   |
| 7) S47            | Connector for signal receiver PCB   |
| 8) H1, H2, H3, FG | Connector for terminal board  |
| 9) JA             | Address setting jumper<br>* Refer to page 265 for detail.                         |
| 10) JB            | Fan speed setting when compressor stops for thermostat OFF                        |
| JC                | Power failure recovery function (auto-restart)<br>* Refer to page 266 for detail. |
| 11) LED A         | LED for service monitor (green)   |
| 12) FU1 (F1U)     | Fuse (3.15 A, 250 V)  |
| 13) V1            | Varistor  |

#### PCB (2): Signal Receiver PCB

- |        |                           |
|--------|---------------------------|
| 1) S48 | Connector for control PCB |
|--------|---------------------------|

#### PCB (3): Display PCB

- |               |                                  |
|---------------|----------------------------------|
| 1) S49        | Connector for control PCB        |
| 2) SW1        | Forced operation [ON/OFF] button |
| 3) LED1 (H1P) | LED for operation (green)        |
| 4) LED2 (H2P) | LED for timer (yellow)           |
| 5) LED3 (H3P) | LED for INTELLIGENT EYE (green)  |
| 6) RTH1 (R1T) | Room temperature thermistor      |

#### PCB (4): INTELLIGENT EYE Sensor PCB

- |        |                           |
|--------|---------------------------|
| 1) S26 | Connector for control PCB |
|--------|---------------------------|




### Caution

**Replace the PCB if you accidentally cut the jumpers other than JA, JB, and JC.**

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.




## PCB Detail

### PCB (1): Control PCB



2P206687-4



**PCB (2): Signal Receiver PCB****PCB (3): Display PCB****PCB (4): INTELLIGENT EYE Sensor PCB**

## 1.3 FTXS15/18LVJU

### Connectors and Other Parts

#### PCB (1): Control PCB

- |                   |   |
|-------------------|---|
| 1) S1             | Connector for DC fan motor  |
| 2) S21            | Connector for centralized control (HA)  |
| 3) S25            | Connector for INTELLIGENT EYE sensor PCB  |
| 4) S32            | Indoor heat exchanger thermistor  |
| 5) S41            | Connector for swing motors  |
| 6) S46            | Connector for display PCB   |
| 7) S47            | Connector for signal receiver PCB   |
| 8) H1, H2, H3, FG | Connector for terminal board  |
| 9) JA             | Address setting jumper<br>* Refer to page 265 for detail.                         |
| 10)JB             | Fan speed setting when compressor stops for thermostat OFF                        |
| JC                | Power failure recovery function (auto-restart)<br>* Refer to page 266 for detail. |
| 11)LED A          | LED for service monitor (green)   |
| 12)FU1 (F1U)      | Fuse (3.15 A, 250 V)  |
| 13)V1             | Varistor  |

#### PCB (2): Signal Receiver PCB

- |        |                           |
|--------|---------------------------|
| 1) S48 | Connector for control PCB |
|--------|---------------------------|

#### PCB (3): Display PCB

- |               |                                 |
|---------------|---------------------------------|
| 1) S49        | Connector for control PCB       |
| 2) SW1        | Forced operation ON/OFF button  |
| 3) LED1 (H1P) | LED for operation (green)       |
| 4) LED2 (H2P) | LED for timer (yellow)          |
| 5) LED3 (H3P) | LED for INTELLIGENT EYE (green) |
| 6) RTH1 (R1T) | Room temperature thermistor     |

#### PCB (4): INTELLIGENT EYE Sensor PCB

- |        |                           |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|




### Caution




**Replace the PCB if you accidentally cut the jumpers other than JA, JB, and JC.**

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

## PCB Detail

### PCB (1): Control PCB



**PCB (2): Signal Receiver PCB****PCB (3): Display PCB****PCB (4): INTELLIGENT EYE Sensor PCB**

## 1.4 FDXS09/12DVJU

### Connectors and Other Parts

#### PCB (1): Control PCB

- |               |  |
|---------------|--|
| 1) S1         | Connector for fan motor                                    |
| 2) S7         | Connector for fan motor (Hall IC)                          |
| 3) S21        | Connector for centralized control (HA)                     |
| 4) S26        | Connector for display PCB                                  |
| 5) S32        | Connector for indoor heat exchanger thermistor             |
| 6) H1, H2, H3 | Connector for terminal board                               |
| 7) GND        | Connector for terminal board (ground)                      |
| 8) JA         | Address setting jumper                                     |
|               | * Refer to page 265 for detail.                            |
| 9) JB         | Fan speed setting when compressor stops for thermostat OFF |
| JC            | Power failure recovery function (auto-restart)             |
|               | * Refer to page 266 for detail.                            |
| 10) LED A     | LED for service monitor (green)                            |
| 11) FU1 (F1U) | Fuse (3.15 A, 250 V)                                       |
| 12) V1 (V1TR) | Varistor   |

#### PCB (2): Display PCB

- |               |                                    |
|---------------|------------------------------------|
| 1) S1         | Connector for control PCB          |
| 2) SW1 (S1W)  | Forced operation [ON/OFF] button   |
| 3) LED1 (H1P) | LED for HOME LEAVE operation (red) |
| 4) LED2 (H2P) | LED for timer (yellow)             |
| 5) LED3 (H3P) | LED for operation (green)          |
| 6) RTH1 (R1T) | Room temperature thermistor        |




### Caution

**Replace the PCB if you accidentally cut the jumpers other than JA, JB, and JC.**


Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

## PCB Detail

## PCB (1): Control PCB



## PCB (2): Display PCB



## 1.5 FDXS09/12LVJU, CDXS15/18LVJU

### Connectors and Other Parts

#### A1P: Control PCB

- |               |  |
|---------------|--|
| 1) S1         | Connector for AC fan motor                                 |
| 2) S7         | Connector for AC fan motor (Hall IC)                       |
| 3) S21        | Connector for centralized control (HA)                     |
| 4) S26        | Connector for display PCB                                  |
| 5) S32        | Connector for indoor heat exchanger thermistor             |
| 6) H1, H2, H3 | Connector for terminal board                               |
| 7) FG (GND)   | Connector for terminal board (ground)                      |
| 8) JA         | Address setting jumper                                     |
|               | * Refer to page 265 for detail.                            |
| 9) JB         | Fan speed setting when compressor stops for thermostat OFF |
| JC            | Power failure recovery function (auto-restart)             |
|               | * Refer to page 266 for detail.                            |
| 10) LED A     | LED for service monitor (green)                            |
| 11) FU1 (F1U) | Fuse (3.15 A, 250 V)                                       |
| 12) V1 (V1TR) | Varistor   |

#### A2P: Display PCB

- |               |                                  |
|---------------|----------------------------------|
| 1) S1         | Connector for control PCB        |
| 2) SW1 (S1W)  | Forced operation [ON/OFF] button |
| 3) LED2 (H2P) | LED for timer (yellow)           |
| 4) LED3 (H3P) | LED for operation (green)        |
| 5) RTH1 (R1T) | Room temperature thermistor      |




### Caution

**Replace the PCB if you accidentally cut the jumpers other than JA, JB, and JC.**

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.


## PCB Detail

### A1P: Control PCB



2P292535-1

## A2P: Display PCB



2P084375-1

★LED 1 does not function.



## 2. Outdoor Unit

### 2.1 2MXS18GVJU

#### Connectors and Other Parts

#### Main PCB

- |                |  |
|----------------|--|
| 1) S10         | Connector for MID1 (indoor - outdoor transmission)   |
| 2) S15         | Connector for COOL / HEAT mode lock<br>* Refer to page 262 for detail.                     |
| 3) S20 (white) | Connector for electronic expansion valve coil A port                                       |
| 4) S21 (red)   | Connector for electronic expansion valve coil B port                                       |
| 5) S31, S32    | Connector for SPM  |
| 6) S33, S71    | Connector for MID2 (inverter PCB)  |
| 7) S40         | Connector for overload protector   |
| 8) S51, S101   | Connector for service monitor PCB  |
| 9) S80         | Connector for four-way valve coil, defrost solenoid valve coil                             |
| 10) S90        | Connector for thermistors<br>(outdoor temperature, outdoor heat exchanger, discharge pipe) |
| 11) S91        | Connector for fin thermistor   |
| 12) S92        | Connector for gas pipe thermistor  |
| 13) S93        | Connector for liquid pipe thermistor   |
| 14) AC1, AC2   | Connector for MID1 (power supply)  |
| 15) E          | Connector for ground   |
| 16) H1, H2     | Connector for diode bridge   |
| 17) FU2        | Fuse (3.15 A, 250 V)   |
| 18) V2, V5     | Varistor   |

#### Service Monitor PCB

- |                               |   |
|-------------------------------|---|
| 1) S52, S102                  | Connector for main PCB  |
| 2) LED A (H1P)                | LED for service monitor (green)                                     |
| 3) LED1 - LED4<br>(H2P - H5P) | LED for service monitor (red)                                       |
| 4) SW1 (S1W)                  | Forced operation [ON/OFF] switch<br>* Refer to page 256 for detail. |
| 5) SW2 (S2W)                  | Operation mode switch<br>* Refer to page 256 for detail.            |
| 6) SW3 (S3W)                  | Wiring error check switch<br>* Refer to page 257 for detail.        |
| 7) SW4 (S4W)                  | Priority room setting switch<br>* Refer to page 261 for detail.     |
| 8) SW5 (S5W)                  | NIGHT QUIET mode setting switch<br>* Refer to page 263 for detail.  |

#### MID1



- |                |                        |
|----------------|------------------------|
| 1) S11, HL, HN | Connector for main PCB |
| 2) HE          | Connector for ground   |
| 3) FU1         | Fuse (30 A, 250 V)     |
| 4) V3          | Varistor               |

**MID2 (Inverter PCB)**


- |               |                                 |
|---------------|---------------------------------|
| 1) S34, S72   | Connector for main PCB          |
| 2) S70        | Connector for outdoor fan motor |
| 3) FU201      | Fuse (3.15 A, 250 V)            |
| 4) W, V, U, N | Connector for compressor        |

**SPM**


- |               |                        |
|---------------|------------------------|
| 1) CN11, CN14 | Connector for main PCB |
| 2) L1, L2     | Connector for reactor  |

**PCB Detail****Main PCB****Service Monitor PCB**


## MID1



## MID2 (Inverter PCB)



## SPM



## 2.2 3MXS24JVJU, 4MXS32GVJU

### Connectors and Other Parts

#### PCB (1): Main PCB


- |                          |  |
|--------------------------|--|
| 1) S10                   | Connector for terminal board (indoor - outdoor transmission)                               |
| 2) S15                   | Connector for COOL / HEAT mode lock<br>* Refer to page 262 for detail.                     |
| 3) S20 (white)           | Connector for electronic expansion valve coil A port                                       |
| 4) S21 (red)             | Connector for electronic expansion valve coil B port                                       |
| 5) S22 (blue)            | Connector for electronic expansion valve coil C port                                       |
| 6) S23 (yellow)          | Connector for electronic expansion valve coil D port (32 class)                            |
| 7) S40                   | Connector for overload protector   |
| 8) S51, S101             | Connector for service monitor PCB  |
| 9) S70                   | Connector for outdoor fan motor  |
| 10) S80                  | Connector for four way valve coil  |
| 11) S90                  | Connector for thermistors<br>(outdoor temperature, outdoor heat exchanger, discharge pipe) |
| 12) S92                  | Connector for gas pipe thermistor  |
| 13) S93                  | Connector for liquid pipe thermistor   |
| 14) AC1, AC2             | Connector for terminal board (power supply)  |
| 15) HR1, HR2             | Connector for reactor  |
| 16) E1, E2               | Connector for ground   |
| 17) U, V, W              | Connector for compressor   |
| 18) FU1                  | Fuse (30 A, 250 V)   |
| 19) FU2, FU3             | Fuse (3.15 A, 250 V)   |
| 20) V2, V3, V5, V9, V100 | Varistor   |

#### PCB (2): Service Monitor PCB


- |                |   |
|----------------|---|
| 1) S52, S102   | Connector for main PCB  |
| 2) LED A       | LED for service monitor (green)                                     |
| 3) LED1 - LED4 | LED for service monitor (red)                                       |
| 4) SW1         | Forced operation [ON/OFF] switch<br>* Refer to page 256 for detail. |
| 5) SW2         | Operation mode switch<br>* Refer to page 256 for detail.            |
| 6) SW3         | Wiring error check switch<br>* Refer to page 257 for detail.        |
| 7) SW4         | Priority room setting switch<br>* Refer to page 261 for detail.     |
| 8) SW5         | NIGHT QUIET mode setting switch<br>* Refer to page 263 for detail.  |

## PCB Detail

## PCB (1): Main PCB



## PCB (2): Service Monitor PCB



# Part 4

## Function and Control

1. Main Functions .....	35
1.1 Temperature Control .....	35
1.2 Frequency Principle.....	35
1.3 Airflow Direction Control (CTXS/FTXS Series) .....	37
1.4 Fan Speed Control for Indoor Unit .....	39
1.5 Program Dry Operation .....	40
1.6 Automatic Operation.....	41
1.7 Thermostat Control.....	42
1.8 NIGHT SET Mode .....	44
1.9 ECONO Operation .....	45
1.10 HOME LEAVE Operation .....	46
1.11 INTELLIGENT EYE Operation (CTXS/FTXS Series).....	47
1.12 Inverter POWERFUL Operation .....	48
1.13 Other Functions.....	49
2. Function of Thermistor .....	51
3. Control Specification .....	54
3.1 Mode Hierarchy .....	54
3.2 Frequency Control.....	55
3.3 Controls at Mode Changing / Start-up.....	57
3.4 Discharge Pipe Temperature Control.....	58
3.5 Input Current Control.....	59
3.6 Freeze-up Protection Control .....	59
3.7 Heating Peak-cut Control .....	60
3.8 Outdoor Fan Control.....	61
3.9 Liquid Compression Protection Function.....	61
3.10 Defrost Control .....	62
3.11 Low Hz High Pressure Limit .....	63
3.12 Outdoor Electronic Expansion Valve Control .....	63
3.13 Malfunctions .....	68


# 1. Main Functions

## 1.1 Temperature Control

### Definitions of Temperatures

The definitions of temperatures are classified as following.

- ◆ Room temperature: temperature of lower part of the room
- ◆ Set temperature: temperature set by remote controller
- ◆ Room thermistor temperature: temperature detected by room temperature thermistor
- ◆ Target temperature: temperature determined by microcomputer



★ The illustration is for CTXS/FTXS series as representative.

### Temperature Control

The temperature of the room is detected by the room temperature thermistor. However, there is difference between the “temperature detected by room temperature thermistor” and the “temperature of lower part of the room”, depending on the type of the indoor unit or installation condition. Practically, the temperature control is done by the “target temperature appropriately adjusted for the indoor unit” and the “temperature detected by room temperature thermistor”.

## 1.2 Frequency Principle

### Main Control Parameters

The frequency of the compressor is controlled by the following 2 parameters:

- The load condition of the operating indoor unit
- The difference between the room thermistor temperature and the target temperature

### Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling operation


## Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to alter the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	<p>The DC power source is reconverted into the three phase AC power source with variable frequency.</p> <ul style="list-style-type: none"> <li>■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit.</li> <li>■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.</li> </ul>

## Drawing of Inverter

The following drawing shows a schematic view of the inverter principle:



## Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor temperature and cooling / heating load.
- Quick heating and quick cooling  
The compressor rotational speed is increased when starting the heating (or cooling). This enables reaching the set temperature quickly.
- Even during extremely cold weather, high capacity is achieved. It is maintained even when the outdoor temperature is 35.6°F (2°C).
- Comfortable air conditioning  
A fine adjustment is integrated to keep the room temperature constant.
- Energy saving heating and cooling  
Once the set temperature is reached, the energy saving operation activates to maintain the room temperature at low power.



**Frequency Limits**

The following functions regulate the minimum and maximum frequency:

Frequency	Functions
Low	<ul style="list-style-type: none"> <li>■ Four-way valve operation compensation. Refer to page 57.</li> </ul>
High	<ul style="list-style-type: none"> <li>■ Compressor protection function. Refer to page 58.</li> <li>■ Discharge pipe temperature control. Refer to page 58.</li> <li>■ Input current control. Refer to page 59.</li> <li>■ Freeze-up protection control. Refer to page 59.</li> <li>■ Heating peak-cut control. Refer to page 60.</li> <li>■ Defrost control. Refer to page 62.</li> </ul>

**Forced Operation**

Refer to page 256 for detail.

## 1.3 Airflow Direction Control (CTXS/FTXS Series)

**Power-Airflow Dual Louvers**

The large louver sends a large volume of air downward to the floor and provides an optimum control in cooling, dry, and heating operation.

**<Cooling / Dry>**

During cooling or dry operation, the louver retracts into the indoor unit. Then, cool air can be blown far and distributed all over the room.

**<Heating>**

During heating operation, the large louver directs airflow downward to spread the warm air to the entire room.






**Wide-Angle Fins**

The fins, made of elastic synthetic resin, provide a wide range of airflow that guarantees comfortable air distribution.





**Auto-Swing**

The following table explains the auto swing process for cooling, dry, heating, and fan:





**CTXS07JVJU, CTXS09/12HVJU, FTXS15/18HVJU**

Vertical Swing (up and down)				Horizontal Swing (right and left)
Cooling	Dry	Heating	Fan	
 (R2814)	 (R2815)	 (R2813)	 (R2816)	 (R2817)

**CTXS07LVJU, FTXS09/12LVJU**

Vertical Swing (up and down)			Horizontal Swing (right and left)
Cooling / Dry	Heating	Fan	
 (R13527)	 (R11402)	 (R11403)	 (R11404)

**FTXS15/18LVJU**


Vertical Swing (up and down)			Horizontal Swing (right and left)
Cooling / Dry	Heating	Fan	
 (R9303)	 (R9304)	 (R9305)	 (R9306)

**3-D Airflow**





Alternative repetition of vertical and horizontal swing motions enables uniform air-conditioning of the entire room. This function is effective for starting the air conditioner.

When the horizontal swing and vertical swing are both set to automatic operation, the airflow becomes 3-D airflow. The horizontal and vertical swing motion is altered and the airflow direction changes in the order shown in the following diagram.

- (1) The vertical blades (fins) move from the right to the left.
- (2) The horizontal blades (louvers) move downward.
- (3) The vertical blades (fins) move from the left to the right.
- (4) The horizontal blades (louvers) move upward.

**COMFORT  
AIRFLOW  
Operation****CTXS/FTXS-L Series**

The horizontal blades (louvers) are controlled not to blow the air directly at the people in the room.

	Cooling	Heating
CTXS07LVJU FTXS09/12LVJU	 (R4302)	 (R8413)
FTXS15/18LVJU	 (R9655)	 (R9654)

## 1.4 Fan Speed Control for Indoor Unit

### Outline

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H, and HH. The airflow rate can be automatically controlled depending on the difference between the room thermistor temperature and the target temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to the troubleshooting for fan motor on page 150, 152.

### Automatic Fan Speed Control

In automatic fan speed operation, the step "SL" is not available.


	CTXS-J, CTXS/FTXS-H, FDXS-D series		CTXS/FTXS-L, CDXS/FDXS-L series	
Step	Cooling	Heating	Cooling	Heating
LLL				
LL				
L				
ML				
M				
MH				
H				
HH (POWERFUL)				
	(R6833)	(R6834)	(R11681)	(R6834)

= The airflow rate is automatically controlled within this range when the FAN setting button is set to automatic.


#### <Cooling>

The following drawing explains the principle of fan speed control for cooling.

#### CTXS-J, CTXS/FTXS-H, FDXS-D Series



#### CTXS/FTXS-L, CDXS/FDXS-L Series



\*For CTXS/FTXS-L series, the upper limit is M tap in 30 minutes from the operation start.

#### <Heating>

In heating operation, the fan speed is regulated according to the indoor heat exchanger temperature and the difference between the room thermistor temperature and the target temperature.



- Note:**
1. During POWERFUL operation, the fan rotates at H tap + 50 ~ 90 rpm.
  2. The fan stops during defrost operation.

## COMFORT AIRFLOW Operation

### CTXS/FTXS-L Series

- The fan speed is controlled automatically within the following steps.

#### <Cooling>

L tap ~ MH tap (same as AUTOMATIC)

#### <Heating>

ML tap ~ MH tap

- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

## 1.5 Program Dry Operation


### Outline

Program dry operation removes humidity while preventing the room temperature from lowering. Since the microcomputer controls both the temperature and airflow rate, the temperature adjustment and [FAN] setting buttons are inoperable.

### Detail

The microcomputer automatically sets the temperature and airflow rate. The difference between the room thermistor temperature at start-up and the target temperature is divided into two zones. Then, the unit operates in an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room thermistor temperature at start-up	Target temperature X	Thermostat OFF point Y	Thermostat ON point Z
(75.2°F (24°C) or more	Room thermistor temperature at start-up	$X - 2.5^{\circ}\text{C} (-4.5^{\circ}\text{F})$	$X - 0.5^{\circ}\text{C} (-0.9^{\circ}\text{F})$ or $Y + 0.5^{\circ}\text{C} (0.9^{\circ}\text{F})$ (zone B) continues for 10 min.
23.5°C (74.3°F) ↓ 18°C (64.4°F)		$X - 2.0^{\circ}\text{C} (-3.6^{\circ}\text{F})$	$X - 0.5^{\circ}\text{C} (-0.9^{\circ}\text{F})$ or $Y + 0.5^{\circ}\text{C} (0.9^{\circ}\text{F})$ (zone B) continues for 10 min.
17.5°C (63.5°F) ↓		$X - 2.0^{\circ}\text{C} (-3.6^{\circ}\text{F})$	$X - 0.5^{\circ}\text{C} (-0.9^{\circ}\text{F}) = 17.5^{\circ}\text{C} (63.5^{\circ}\text{F})$ or $Y + 0.5^{\circ}\text{C} (0.9^{\circ}\text{F})$ (zone B) continues for 10 min.



(R11587)

## 1.6 Automatic Operation

### Outline

#### Automatic Cooling / Heating Function

When the automatic operation is selected with the remote controller, the microcomputer automatically determines the operation mode as cooling or heating according to the room temperature and the set temperature at start-up.


The unit automatically switches the operation mode to maintain the room temperature at the set temperature.

### Detail

Ts: set temperature (set by remote controller)  
 Tt: target temperature (determined by microcomputer)  
 Tr: room thermistor temperature (detected by room temperature thermistor)  
 C: correction value

1. The set temperature (Ts) determines the target temperature (Tt).  
 (Ts = 64.4 ~ 86°F, 18 ~ 30°C).
2. The target temperature (Tt) is calculated as;  
 $Tt = Ts + C$   
 where C is the correction value.  
 $C = 0^\circ\text{F} (0^\circ\text{C})$
3. Thermostat ON/OFF point and operation mode switching point are as follows.
  - (1) Heating → Cooling switching point:  
 $Tr \geq Tt + +5.4^\circ\text{F} (3.0^\circ\text{C})$  (CTXS/FTXS-L series)  
 $Tr \geq Tt + +4.5^\circ\text{F} (2.5^\circ\text{C})$  (other models)
  - (2) Cooling → Heating switching point:  
 $Tr < Tt - 4.5^\circ\text{F} (2.5^\circ\text{C})$
  - (3) Thermostat ON/OFF point is the same as the ON/OFF point of cooling or heating operation.
4. During initial operation  
 $Tr \geq Ts$  : Cooling operation  
 $Tr < Ts$  : Heating operation

#### CTXS/FTXS-L series




Ex: When the target temperature is 25°C (77°F)

Cooling → 73.4°F (23°C): Thermostat OFF → 71.6°F (22°C): Switch to heating

Heating → 80.6°F (27°C): Thermostat OFF → 82.4°F (28°C): Switch to cooling

#### Other models



Ex: When the target temperature is 77°F (25°C)

Cooling → 73.4°F (23°C): Thermostat OFF → 71.6°F (22°C): Switch to heating

Heating → 79.7°F (26.5°C): Thermostat OFF → 81.5°F (27.5°C): Switch to cooling

## 1.7 Thermostat Control

Thermostat control is based on the difference between the room thermistor temperature and the target temperature.

### Thermostat OFF Condition


- ♦ The temperature difference is in the zone A.

### Thermostat ON Condition


- ♦ The temperature difference returns to the zone C after being in the zone A.
- ♦ The system resumes from defrost control in any zones except A.
- ♦ The operation turns on in any zones except A.
- ♦ The monitoring time has passed while the temperature difference is in the zone B.  
(Cooling / Dry: 10 minutes, Heating: 10 seconds)

### <Cooling / Dry>

#### CTXS/FTXS series






#### CDXS/FDXS series



### <Heating>

#### CTXS-J, CTXS/FTXS-H series



**CTXS/FTXS-L series****CDXS/FDXS series**

Refer to “Temperature Control” on page 35 for detail.

## 1.8 NIGHT SET Mode

### Outline


When the OFF timer is set, the NIGHT SET Mode is automatically activated. The NIGHT SET Mode keeps the airflow rate setting.

### Detail

The NIGHT SET Mode continues operation at the target temperature for the first one hour, then automatically raises the target temperature slightly in the case of cooling, or lowers it slightly in the case of heating. This prevents excessive cooling in summer and excessive heating in winter to ensure comfortable sleeping conditions, and also conserves electricity.


#### <Cooling>

Ex: CTXS/FTXS Series



(R14453)

#### <Heating>



(R14454)



## 1.9 ECONO Operation

### Outline


#### CTXS/FTXS-L, CDXS/FDXS-L Series

ECONO operation reduces the maximum operating current and the power consumption.

This operation is particularly convenient for energy-saving-oriented users. It is also a major bonus for those whose breaker capacities do not allow the use of multiple electrical devices and air conditioners.

It is easily activated from the wireless remote controller by pushing the [ECONO] button.

- When this function is activated, the maximum capacity also decreases.
- The remote controller can send the ECONO command when the unit is in COOL, HEAT, DRY, or AUTO operation. This function can only be set when the unit is running. Pressing the [ON/OFF] button on the remote controller cancels the function.
- This function and POWERFUL operation cannot be used at the same time. The latest command has the priority.



(R9288)

## 1.10 HOME LEAVE Operation

### Outline

#### FDXS-D Series

HOME LEAVE operation is a function that allows you to record your favorite set temperature and airflow rate. You can start your favorite operation mode simply by pressing the [HOME LEAVE] button on the remote controller.

### Detail

#### 1. Start of Function

The function starts when the [HOME LEAVE] button is pressed in cooling mode, heating mode (including POWERFUL operation), or while the operation is stopped. If this button is pressed in POWERFUL operation, the POWERFUL operation is canceled and this function becomes effective.

■ The [HOME LEAVE] button is ineffective in dry mode and fan mode.

#### 2. Details of Function


A mark representing HOME LEAVE is indicated on the display of the remote controller. The indoor unit is operated according to the set temperature and airflow rate for HOME LEAVE which were pre-set in the memory of the remote controller.

The LED (red) of indoor unit representing HOME LEAVE lights up. (It goes out when the operation is stopped.)

#### 3. End of Function

The function ends when the [HOME LEAVE] button is pressed again during HOME LEAVE operation or when the [POWERFUL] button is pressed.

#### <Cooling>



“HOME LEAVE operation”  
set temp.



#### <Heating>



“HOME LEAVE operation”  
set temp.



### Others

The set temperature and airflow rate are memorized in the remote controller. When the remote controller is reset due to replacement of battery, it is necessary to set the temperature and airflow rate again for HOME LEAVE operation.


## 1.11 INTELLIGENT EYE Operation (CTXS/FTXS Series)

### Outline

This function detects the existence of humans in the room with a motion sensor (INTELLIGENT EYE) and reduces the capacity when there is nobody in the room in order to save electricity.


### Detail

#### 1. Detection method by INTELLIGENT EYE



- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- The microcomputer in the indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in 1 second in total (corresponding to  $20 \text{ msec.} \times 10 = 200 \text{ msec.}$ ), it judges humans are in the room as the motion signal is ON.

#### 2. The motions (for example: in cooling)



- When the microcomputer does not have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit at a temperature shifted from the target temperature. (Cooling / Dry:  $1.8 \sim 3.6^\circ\text{F}$  ( $1 \sim 2^\circ\text{C}$ ) higher, Heating:  $3.6^\circ\text{F}$  ( $2^\circ\text{C}$ ) lower, Auto: according to the operation mode at that time.)

★ In FAN operation, the fan speed is reduced by 50 ~ 60 rpm.

### Others

- For dry operation, you cannot set the temperature with a remote controller, but the target temperature is shifted internally.

## 1.12 Inverter POWERFUL Operation

### Outline

In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.


### Detail

When [POWERFUL] button is pressed, the fan speed and target temperature are converted to the following states for 20 minutes.

Operation mode	Fan speed	Target temperature
COOL	H tap + <b>A</b> rpm	64.4°F (18°C)
DRY	Dry rotating speed + <b>A</b> rpm	Lowered by 3.6 ~ 4.5°F (2 ~ 2.5°C)
HEAT	H tap + <b>A</b> rpm	86 ~ 88.7°F (30 ~ 31.5°C)
FAN	H tap + <b>A</b> rpm	—
AUTO	Same as cooling / heating in POWERFUL operation	The target temperature is kept unchanged.

**A** = 50 ~ 90 rpm

Ex: POWERFUL operation in cooling



(R13571)

## 1.13 Other Functions

### 1.13.1 Hot-Start Function

In order to prevent the cold air blast that normally comes when heating operation is started, the temperature of the indoor heat exchanger is detected, and the airflow is either stopped or made very weak thereby carrying out comfortable heating of the room.

\*The cold air blast is also prevented using similar control when the defrosting operation is started or when the thermostat is turned ON.

### 1.13.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote controller, the unit emits a signal receiving sound.

### 1.13.3 Indoor Unit [ON/OFF] Button


An [ON/OFF] button is provided on the display of the unit.

- Press the [ON/OFF] button once to start operation. Press once again to stop it.
- The [ON/OFF] button is useful when the remote controller is missing or the battery has run out.
- The operation mode refers to the following table.

Operation mode	Temperature setting	Airflow rate
AUTO	25°C (77°F)	Automatic

- In the case of multi system operation, there are times when the unit does not activate with the [ON/OFF] button.

**Ex: CTXS/FTXS-L series**



ON/OFF button (R13555)

### 1.13.4 Air-Purifying Filter with Photocatalytic Deodorizing Function

#### CTXS-J, CTXS/FTXS-H Series

This filter incorporates the benefits the Air-Purifying Filter and Photocatalytic Deodorizing Filter in a single unit. Combining the two filters in this way increases the active surface area of the new filter. This larger surface area allows the filter to effectively trap microscopic particles, decompose odors and deactivate bacteria and viruses even for the large living rooms. The filter can be used for approximately 3 years if periodic maintenance is performed.

### 1.13.5 Titanium Apatite Photocatalytic Air-Purifying Filter

#### CTXS/FTXS-L Series

This filter combines the Air-Purifying Filter and Titanium Apatite Photocatalytic Deodorizing Filter as a single highly effective filter. The filter traps microscopic particles, decomposes odors and even deactivates bacteria and viruses. It lasts for 3 years without replacement if washed about once every 6 months.

### 1.13.6 Auto-restart Function

If a power failure (including one for just a moment) occurs during the operation, the operation restarts automatically when the power is restored in the same condition as before the power failure.



**Note:** It takes 3 minutes to restart the operation because the 3-minute standby function is activated.

### 1.13.7 WEEKLY TIMER Operation

#### CTXS/FTXS-L Series


Up to 4 timer settings can be saved for each day of the week (up to 28 settings in total). Those 3 items of “ON/OFF”, “temperature” and “time” can be set.




Refer to page 102 for detail.

## 2. Function of Thermistor


<2MXS18GVJU>



<3MXS24JVJU>



<4MXS32GVJU>



**(1) Outdoor Heat Exchanger Thermistor**

1. The outdoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the outdoor electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
2. In cooling operation, the outdoor heat exchanger thermistor is used for detecting the disconnection of the discharge pipe thermistor. When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
3. In cooling operation, the outdoor heat exchanger thermistor is used for high pressure protection.

**(2) Discharge Pipe Thermistor**

1. The discharge pipe thermistor is used for controlling discharge pipe temperature. If the discharge pipe temperature (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency becomes lower or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge pipe thermistor.

**(3) Gas Pipe Thermistor**

1. In cooling operation, the gas pipe thermistor is used for gas pipe isothermal control. The system controls outdoor electronic expansion valve opening so that the gas pipe temperature in each room becomes equal.

**(4) Indoor Heat Exchanger Thermistor**

1. The indoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the outdoor electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
2. In cooling operation, the indoor heat exchanger thermistor is used for freeze-up protection control. If the indoor heat exchanger temperature drops abnormally, the operating frequency becomes lower or the operation halts.
3. In cooling operation, the indoor heat exchanger thermistor is used for anti-icing function. If any of the following conditions are met in the room where operation halts, it is assumed as icing.  
The conditions are  

$$T_c \leq -30.2^{\circ}\text{F} (-1^{\circ}\text{C})$$

$$T_a - T_c \geq 18^{\circ}\text{F} (10^{\circ}\text{C})$$
 where  $T_a$  is the room temperature and  $T_c$  is the indoor heat exchanger temperature.
4. In heating operation, the indoor heat exchanger thermistor is used for heating peak-cut control. If the indoor heat exchanger temperature rises abnormally, the operating frequency becomes lower or the operation halts.
5. In heating operation, the indoor heat exchanger thermistor is used for detecting the disconnection of the discharge pipe thermistor. When the discharge pipe temperature becomes lower than the maximum indoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
6. When only one indoor unit is operating, the indoor heat exchanger thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the indoor heat exchanger temperature. The system controls the outdoor electronic expansion valve openings to obtain the target subcool.
7. The indoor heat exchanger thermistor is used for wiring error check function. The refrigerant flows in order from the port A to detect the indoor heat exchanger temperature one by one, and then wiring and piping can be checked.



---

**(5) Liquid Pipe Thermistor**


1. When only one indoor unit is in heating, the liquid pipe thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the maximum indoor heat exchanger temperature. The system controls the outdoor electronic expansion valve openings to obtain the target subcool.
2. In heating operation, the liquid pipe thermistor is used for liquid pipes isothermal control. The system controls the outdoor electronic expansion valve opening so that the liquid pipe temperatures in each room becomes equal.

# 3. Control Specification

## 3.1 Mode Hierarchy

**Outline** Air conditioner control has normal operation mode, forced operation mode, and power transistor test mode for installation and servicing.

**Detail**



(R17361)



- Note:**
- Unless specified otherwise, a dry operation command is regarded as cooling operation.
  - Indoor fan operation cannot be made in multiple indoor units. (A forced fan command is made during forced operation.)

**Determine Operation Mode**

The system judges the operation mode command which is set by each room in accordance with the procedure, and determines the operation mode of the system.

The following procedure is taken when the modes conflict with each other.

- \*1. The system follows the mode which is set first. (First-push, first-set)
- \*2. For the rooms where the different mode is set, standby mode is activated. (The operation lamp blinks.)

## 3.2 Frequency Control


### Outline

Frequency that corresponds to each room's capacity is determined according to the difference between the target temperature and the temperature of each room.

The function is explained as follows.

1. How to determine frequency
2. Frequency command from an indoor unit (Difference between a room thermistor temperature and the target temperature)
3. Frequency command from an indoor unit (The ranked capacity of the operating room)
4. Frequency initial setting
5. PI control

When the shift of the frequency is less than zero ( $\Delta F < 0$ ) by PI control, the target frequency is used as the command frequency.



(R14951)

### Detail

#### How to Determine Frequency

The compressor's frequency is determined by taking the following steps.

##### 1. Determine command frequency

- ◆ Command frequency is determined in the following order of priority.
  1. Limiting defrost control time
  2. Forced cooling / heating
  3. Indoor frequency command

##### 2. Determine upper limit frequency

- ◆ The minimum value is set as upper limit frequency among the frequency upper limits of the following functions:  
Compressor protection, input current, discharge pipe temperature, low Hz high pressure limit, heating peak-cut, freeze-up protection, defrost.

##### 3. Determine lower limit frequency

- ◆ The maximum value is set as the lower limit frequency among the frequency lower limits of the following functions:  
Four way valve operation compensation, draft prevention, pressure difference upkeep.

##### 4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

**Indoor Frequency Command ( $\Delta D$  signal)**

The difference between a room thermistor temperature and the target temperature is taken as the " $\Delta D$  signal" and is used for frequency command.

Temperature difference	$\Delta D$ signal	Temperature difference	$\Delta D$ signal	Temperature difference	$\Delta D$ signal	Temperature difference	$\Delta D$ signal
-3.6°F (-2.0°C)	*Th OFF	0°F (0°C)	4	3.6°F (2.0°C)	8	7.2°F (4.0°C)	C
-2.7°F (-1.5°C)	1	0.9°F (0.5°C)	5	4.5°F (2.5°C)	9	8.1°F (4.5°C)	D
-1.8°F (-1.0°C)	2	1.8°F (1.0°C)	6	5.4°F (3.0°C)	A	9°F (5.0°C)	E
-0.9°F (-0.5°C)	3	2.7°F (1.5°C)	7	6.3°F (3.5°C)	B	9.9°F (5.5°C)	F

Values depend on the type of indoor unit.

\*Th OFF = Thermostat OFF

**Indoor Unit Capacity (S value)**

The capacity of the indoor unit is a "S" value and is used for frequency command.

Ex:	Capacity	S value	Capacity	S value
	9 kBtu/h	25	18 kBtu/h	50
	12 kBtu/h	35	24 kBtu/h	60

**Frequency Initial Setting****<Outline>**

When starting the compressor, or when conditions are varied due to the change of the operating room, the frequency must be initialized according to the total of a maximum  $\Delta D$  value of each room and a total value of Q ( $\Sigma Q$ ) of the operating room (the room in which the thermos is set to ON).

Q value: Indoor unit output determined from indoor unit volume, airflow rate and other factors.

**PI Control (Determine Frequency Up / Down by  $\Delta D$  Signal)****1. P control**

A total of the  $\Delta D$  value is calculated in each sampling time (20 seconds), and the frequency is adjusted according to its difference from the frequency previously calculated.

**2. I control**

If the operating frequency is not change more than a certain fixed time, the frequency is adjusted according to the  $\Sigma \Delta D$  value.

When the  $\Sigma \Delta D$  value is low, the frequency is lowered.

When the  $\Sigma \Delta D$  value is high, the frequency is increased.

**3. Limit of frequency increasing range**

When the difference between input current and input current dropping value is less than 1.5 A, the frequency increasing range must be limited.

**4. Frequency management when other controls are functioning**

- ◆ When each frequency is dropping;  
Frequency management is carried out only when the frequency drops.
- ◆ For limiting lower limit  
Frequency management is carried out only when the frequency rises.

**5. Upper and lower limit of frequency by PI control**

The frequency upper and lower limits are set according to the total of S values. When the indoor unit quiet operation commands come from more than one room or when the outdoor unit quiet operation commands come from all the rooms, the upper limit frequency is lower than the usual setting.

## 3.3 Controls at Mode Changing / Start-up

### 3.3.1 Preheating Operation

**Outline** The inverter operation in open phase starts with the conditions of the outdoor temperature and the preheating command from the indoor unit.

**Detail**

**ON Condition**

- When the outdoor temperature is below 50.9°F (10.5°C), the inverter operation in open phase starts.

**OFF Condition**

- When the outdoor temperature is higher than 53.6°F (12°C), the inverter operation in open phase stops.

### 3.3.2 Four Way Valve Switching

**Outline** In heating operation, current is conducted, and in cooling and defrosting operation, current is not conducted. In order to eliminate the switching sound, as the four way valve coil switches from ON to OFF when the heating is stopped, the OFF delay switch of the four-way valve is carried out.

**Detail**

**OFF delay switch of four-way valve:**  
The four-way valve coil is energized for 150 seconds after the operation is stopped.

### 3.3.3 Four Way Valve Operation Compensation

**Outline** At the beginning of the operation as the four-way valve is switched, the pressure difference to activate the four-way valve is acquired by having output frequency which is more than a certain fixed frequency, for a certain fixed time.

**Detail**

**Starting Conditions**

- When starting the compressor for heating
- When the operation mode changes from the previous time
- When starting the compressor for defrosting
- When starting the compressor for the first time after resetting with the power ON.

The lower limit of frequency keeps **A** Hz for 70 seconds with any conditions 1 through 4 above.


<b>A</b> (Hz)	Cooling	Heating
18 class	40	55
24/32 class	28	

### 3.3.4 3-Minute Standby

Turning on the compressor is prohibited for 3 minutes after turning off.  
(Except when defrosting.)

3.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency is set as follows. (The function is not used when defrosting.)




A (Hz)	55
B (Hz)	65
C (Hz)	80
D (seconds)	120
E (seconds)	200
F (seconds)	470

3.4 Discharge Pipe Temperature Control

Outline

The discharge pipe temperature is used as the internal temperature of the compressor. If the discharge pipe temperature rises above a certain level, the upper limit of frequency is set to keep the discharge pipe temperature from rising further.

Detail



A	248°F (120°C)
B	231.8°F (111°C)
C	228.2°F (109°C)
D	224.6°F (107°C)
E	224.6°F (107°C)

★ The temperatures D and E are the same.

Zone	Control
Stop zone	When the temperature reaches the stop zone, the compressor stops.
Dropping zone	The upper limit of frequency decreases.
Keep zone	The upper limit of frequency is kept.
Reset zone	The upper limit of frequency is canceled.


## 3.5 Input Current Control

### Outline

An input current is detected by the CT while the compressor is running, and the frequency upper limit is set from the input current.

In case of heat pump models, this control which is the upper limit control of the frequency takes priority over the lower limit control of four way valve operation compensation.

### Detail



#### Frequency control in each zone

##### Stop zone

- After 2.5 seconds in this zone, the compressor is stopped.

##### Dropping zone

- The upper limit of the compressor frequency is defined as operation frequency – 2 Hz.
- After this, the output frequency is lowered by 2 Hz every second until it reaches the keep zone.

##### Keep zone

- The present maximum frequency goes on.

##### Reset zone

- Limit of the frequency is canceled.

#### Limitation of current dropping and stop value according to the outdoor temperature

- The current drops when outdoor temperature becomes higher than a certain level (depending on the model).


## 3.6 Freeze-up Protection Control

### Outline

During cooling operation, the signals sent from the indoor units control the operating frequency limitation and prevent freezing of the indoor heat exchanger. (The signals from the indoor units are divided into zones.)

### Detail

The operating frequency limitation is judged with the indoor heat exchanger temperature 2 seconds after operation starts and 30 seconds after the number of operation room is changed.



(R17362)


## 3.7 Heating Peak-cut Control

### Outline

During heating operation, the indoor heat exchanger temperature determines the frequency upper limit to prevent abnormal high pressure.

### Detail

- The operating frequency is judged with the indoor heat exchanger temperature 2 minutes after the operation starts and **F** seconds after the number of operation room is changed.
- The maximum value of the indoor heat exchanger temperature controls the following (excluding stopped rooms).



Zone	Control
Stop zone	When the temperature reaches the stop zone, the compressor stops.
Dropping zone	The upper limit of frequency decreases.
Keep zone	The upper limit of frequency is kept.
Up zone	The upper limit of frequency increases.
Reset zone	The upper limit of frequency is canceled.

	18 class	24/32 class
<b>A</b>	149°F (65°C)	149°F (65°C)
<b>B</b>	122°F (50°C)	129.2°F (54°C)
<b>C</b>	118.4°F (48°C)	127.4°F (53°C)
<b>D</b>	117.5°F (47.5°C)	123.8°F (51°C)
<b>E</b>	115.7°F (46.5°C)	120.2°F (49°C)

	<b>F</b> (seconds)
When increase	30
When decrease	2



## 3.8 Outdoor Fan Control

### 1. Fan ON control to cool down the electrical box

The outdoor fan is turned ON when the electrical box temperature is high while the compressor is OFF.

### 2. Fan OFF control during defrosting

The outdoor fan is turned OFF while defrosting.

### 3. Fan OFF delay when stopped

The outdoor fan is turned OFF 60 seconds after the compressor stops.

### 4. Fan speed control for pressure difference upkeep

The rotation speed of the outdoor fan is controlled for keeping the pressure difference during cooling operation with low outdoor temperature.

- ◆ When the pressure difference is low, the rotation speed of the outdoor fan is reduced.
- ◆ When the pressure difference is high, the rotation speed of the outdoor fan is controlled as well as normal operation.

### 5. Fan control when the number of heating room decreases

When the outdoor temperature is more than 50°F (10°C), the fan is turned off for 30 seconds.

### 6. Fan speed control during forced operation

The outdoor fan is controlled as well as normal operation during the forced operation.

### 7. Fan speed control during POWERFUL operation

The rotation speed of the outdoor fan is increased during the POWERFUL operation.

### 8. Fan speed control during indoor / outdoor unit quiet operation

The rotation speed of the outdoor fan is reduced by the command of the indoor / outdoor unit quiet operation.

### 9. Fan ON/OFF control when operation starts / stops

The outdoor fan is turned ON when the operation starts. The outdoor fan is turned OFF when the operation stops.

## 3.9 Liquid Compression Protection Function

### Outline

In order to obtain the dependability of the compressor, the compressor is stopped according to the outdoor temperature and the outdoor heat exchanger temperature.

### Detail

- Operation stops depending on the outdoor temperature

The compressor turns off under the conditions that the system is in cooling operation and the outdoor temperature is below 10.4°F (−12°C).

## 3.10 Defrost Control

### Outline

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than a certain value to finish.


### Detail

#### Conditions for Starting Defrost

- The starting conditions are determined with the outdoor temperature and the outdoor heat exchanger temperature.
- The system is in heating operation.
- The compressor operates for 6 minutes.
- More than **A** minutes of accumulated time pass after the start of the operation, or ending the previous defrosting.

#### Conditions for Canceling Defrost

The target heat exchanger temperature as the canceling condition is selected in the range of 39.2 ~ 53.6°F (4 ~ 12°C) according to the outdoor temperature.



(R17363)

	18 class	24/32 class
<b>A</b> (minutes)	43	38
<b>B</b> (Hz)	54	39
<b>C</b> (Hz)	82	62
<b>D</b> (seconds)	30	60
<b>E</b> (pulses)	450	350
<b>F</b> (pulses)	450	400
<b>G</b> (pulses)	140	160


★18 class: The pulses **E** and **F** are the same.

## 3.11 Low Hz High Pressure Limit

### Outline

The system controls the upper limit of the frequency to prevent abnormal high pressure while the frequency is low.  
Control is carried out according to three zones.

### Detail



	18 class	24/32 class
<b>A</b>	140°F (60°C)	134.6°F (57°C)
<b>B</b>	138.2°F (59°C)	132.8°F (56°C)
<b>C</b>	132.8°F (56°C)	127.4°F (53°C)



**Note:** Dropping: The system stops 2 minutes after staying in the dropping zone.

## 3.12 Outdoor Electronic Expansion Valve Control

### Outline

The following items are included in the outdoor electronic expansion valve control.

#### Outdoor electronic expansion valve is fully closed

1. Outdoor electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

#### Room Distribution Control

1. Gas pipe isothermal control
2. SC (subcooling) control
3. Liquid pipe temperature control (with all ports connected and all rooms being air-conditioned)
4. Liquid pipe temperature control for stopped rooms
5. Dew prevention control for indoor rotor

#### Open Control

1. Outdoor electronic expansion valve control when starting operation
2. Outdoor electronic expansion valve control when the frequency changes
3. Outdoor electronic expansion valve control for defrosting
4. Outdoor electronic expansion valve control for oil recovery
5. Outdoor electronic expansion valve control when a discharge pipe temperature is abnormally high
6. Outdoor electronic expansion valve control when the discharge pipe thermistor is disconnected
7. Outdoor electronic expansion valve control for indoor unit freeze-up protection

#### Feedback Control

1. Target discharge pipe temperature control

## Detail

The followings are the examples of outdoor electronic expansion valve control which function in each operation mode.

Operation pattern		Gas pipe isothermal control	SC (subcooling) control	Control when the frequency changes	Control for abnormally high discharge pipe temperature	Oil recovery control	Indoor freeze-up protection control	Liquid pipe temperature control	Liquid pipe temperature control for non-operating units	Dew prevention control for indoor rotor
	● : Holding Functions — : No Functions									
When power is turned on	Fully closed when power is turned on	—	—	—	—	—	—	—	—	—
Cooling, 1 room operation	Open control when starting	—	—	—	●	●	●	—	—	—
	(Control of target discharge pipe temperature)	—	—	●	●	●	●	—	—	●
Cooling, 2 rooms operation to Cooling, 4 rooms operation	Control when the operating room is changed	—	—	—	●	●	●	—	—	●
	(Control of target discharge pipe temperature)	●	—	●	●	●	●	—	—	●
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—
Heating, 1 room operation	Open control when starting	—	—	—	●	—	—	—	—	—
	(Control of target discharge pipe temperature)	—	● ★2	●	●	—	—	● ★1	● ★3	—
Heating, 2 rooms operation	Control when the operating room is changed	—	—	—	●	—	—	—	—	—
	(Control of target discharge pipe temperature)	—	● ★2	●	●	—	—	● ★1	● ★3	—
	(Defrost control)	—	—	—	—	—	—	—	—	—
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—
Heating operation	Open control when starting	—	—	—	●	—	—	—	—	—
Control of discharge pipe thermistor disconnection	Continue	—	● ★2	—	—	—	—	● ★1	● ★3	—
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—

(R16007)

★1 : When all the indoor units are operating, “liquid pipe temperature control” is conducted.

★2: “SC (subcooling) control” is conducted for the operating indoor units, when some of the units are not operating.

★3: “Liquid pipe temperature control for stopped room” is conducted for the non-operating indoor units.

### 3.12.1 Fully Closing with Power on

The outdoor electronic expansion valve is initialized when the power is turned on. The opening position is set and the pressure equalization is developed.

### 3.12.2 Pressure Equalizing Control

When the compressor is stopped, the pressure equalizing control is activated. The outdoor electronic expansion valve opens, and develops the pressure equalization.

### 3.12.3 Opening Limit Control

---

**Outline**

The maximum and minimum opening of the outdoor electronic expansion valve are determined.

---

**Detail**

- Maximum outdoor electronic expansion valve opening in the operating room: 450 pulses
  - Minimum outdoor electronic expansion valve opening in the operating room: 75 pulses
- The outdoor electronic expansion valve is fully closed in a room where cooling operation is stopped and is opened at a fixed degree during defrosting.

### 3.12.4 Starting Operation Control / Changing Operation Room

The outdoor electronic expansion valve opening is controlled when the operation starts, and prevents superheating or liquid compression.

### 3.12.5 Control when the Frequency Changes

When the target discharge pipe temperature control is active, if the target frequency is changed to a specified value in a certain time period, the target discharge pipe temperature control is canceled and the target opening of the outdoor electronic expansion valve is changed.

### 3.12.6 Oil Recovery Function

---

**Outline**

Outdoor electronic expansion valve opening in a room where cooling operation is stopped is set to open for a certain time at specified intervals so that the oil does not accumulate.

---

**Detail**

During cooling operation, after every 1 hour of continuous operation, the outdoor electronic expansion valves in the operation stopped room is opened by 80 pulses for specified time.

### 3.12.7 High Discharge Pipe Temperature Control

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, the outdoor electronic expansion valve opens and the refrigerant runs to the low pressure side. This procedure lowers the discharge pipe temperature.

### 3.12.8 Control for Disconnection of the Discharge Pipe Thermistor

#### Outline

The disconnection of the discharge pipe thermistor is detected by comparing the discharge pipe temperature with the condensing temperature. If the discharge pipe thermistor is disconnected, the outdoor electronic expansion valve opens according to the outdoor temperature and the operation frequency, operates for a specified time, and then stops.

After 3 minutes, the operation restarts and checks if the discharge pipe thermistor is disconnected. If the discharge pipe thermistor is disconnected, the system stops after operating for a specified time.

If the disconnection is detected repeatedly, the system is shut down. When the compressor runs for 60 minutes without any error, the error counter is reset.

#### Detail

##### Detect Disconnection

When the starting control (630 seconds) finishes, the following adjustment is made.

1. When the operation mode is cooling

When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.

Discharge pipe temperature + 10.8°F (6°C) < outdoor heat exchanger temperature

2. When the operation mode is heating

When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.

Discharge pipe temperature + 10.8°F (6°C) < highest indoor heat exchanger temperature

##### Adjustment when the thermistor is disconnected

When the disconnection is ascertained, the compressor continues operation for 9 minutes and then stops.

If the compressor stops repeatedly, the system is shut down.

### 3.12.9 Gas Pipe Isothermal Control During Cooling

When the units are operating in multiple rooms, the gas pipe temperature is detected and the outdoor electronic expansion valve opening is adjusted so that the temperature of the gas pipe in each room becomes equal.

- When the gas pipe temperature > the average gas pipe temperature, → open the outdoor electronic expansion valve in that room
- When the gas pipe temperature < the average gas pipe temperature, → close the outdoor electronic expansion valve in that room

The temperatures are monitored every 40 seconds.

### 3.12.10 SC (Subcooling) Control

#### Outline

The liquid pipe temperature and the heat exchanger temperature are detected and the outdoor electronic expansion valve opening is compensated so that the SC of each room becomes the target SC.

- When the actual SC is > target SC, open the outdoor electronic expansion valve of the room.
- When the actual SC is < target SC, close the outdoor electronic expansion valve of the room.

#### Detail

##### Start Conditions


After finishing the starting control (630 seconds), (all) the outdoor electronic expansion valve(s) for the operating room is/are controlled.

##### Determine Outdoor Electronic Expansion Valve Opening

The outdoor electronic expansion valve opening is adjusted so that the temperature difference between the maximum heat exchanger temperature of connected room and the liquid pipe temperature thermistor becomes constant.

### 3.12.11 Target Discharge Pipe Temperature Control

The target discharge pipe temperature is obtained from the indoor and outdoor heat exchanger temperature, and the outdoor electronic expansion valve opening is adjusted so that the actual discharge pipe temperature becomes close to the target discharge pipe temperature. (Indirect SH (superheating) control using the discharge pipe temperature)



The outdoor electronic expansion valve opening and the target discharge pipe temperature are adjusted every 20 seconds. The target discharge pipe temperature is controlled by indoor heat exchanger temperature and outdoor heat exchanger temperature. The opening degree of the outdoor electronic expansion valve is controlled by the followings.

- ♦ Target discharge pipe temperature
- ♦ Actual discharge pipe temperature
- ♦ Previous discharge pipe temperature

## 3.13 Malfunctions

### 3.13.1 Sensor Malfunction Detection

Sensor malfunction may occur either in the thermistor or current transformer (CT) system.

#### Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Radiation fin thermistor
4. Gas pipe thermistor for each room
5. Outdoor temperature thermistor
6. Liquid pipe thermistor



#### Relating to CT Malfunction

Refer to “CT or related abnormality” on page 179 for detail.

### 3.13.2 Detection of Overcurrent and Overload

#### Outline

In order to protect the inverter, an excessive output current is detected and the OL temperature is observed to protect the compressor.

#### Detail

- If the inverter current exceeds 17 ~ 20 A (depending on the model), the system shuts down the compressor.
- If the OL (compressor head) temperature exceeds 266°F (130°C), the compressor stops.


### 3.13.3 Refrigerant Shortage Control

#### Outline

#### I : Detecting by power consumption


If the power consumption is below the specified value and the frequency is higher than the specified frequency, it is regarded as refrigerant shortage.

The power consumption is low comparing with that in the normal operation when refrigerant is insufficient, and refrigerant shortage is detected by checking power consumption.



#### II : Detecting by discharge pipe temperature

If the discharge pipe temperature is higher than the target discharge pipe temperature, and the outdoor electronic expansion valve is fully open for more than the specified time, it is regarded as refrigerant shortage.



Refer to “Refrigerant shortage” on page 156 for detail.



### 3.13.4 Anti-icing Function

If the indoor heat exchanger's temperature drops below the specified temperature during cooling, the outdoor electronic expansion valve will open and the *fully-closed operation* is carried out in the room. After this, if an abnormal freezing occurs for longer than a specified time, the system will shut down.

# Part 5

## Operation Manual

1. System Configuration .....	71
2. CTXS-J, CTXS-H, FTXS-H Series .....	72
2.1 Remote Controller .....	72
2.2 AUTO · DRY · COOL · HEAT · FAN Operation .....	74
2.3 Adjusting the Airflow Direction .....	76
2.4 INTELLIGENT EYE Operation .....	78
2.5 POWERFUL Operation .....	80
2.6 OUTDOOR UNIT QUIET Operation .....	81
2.7 HOME LEAVE Operation .....	82
2.8 TIMER Operation .....	84
2.9 Note for Multi System .....	86
3. CTXS-L, FTXS-L Series .....	88
3.1 Remote Controller .....	88
3.2 AUTO · DRY · COOL · HEAT · FAN Operation .....	90
3.3 Adjusting the Airflow Direction and Rate .....	92
3.4 COMFORT AIRFLOW / INTELLIGENT EYE Operation .....	95
3.5 POWERFUL Operation .....	97
3.6 OUTDOOR UNIT QUIET Operation .....	98
3.7 ECONO Operation .....	99
3.8 OFF TIMER Operation .....	100
3.9 ON TIMER Operation .....	101
3.10 WEEKLY TIMER Operation .....	102
3.11 Note for Multi System .....	108
3.12 Quick Reference .....	110
4. FDXS-D Series .....	111
4.1 Remote Controller .....	111
4.2 AUTO · DRY · COOL · HEAT · FAN Operation .....	112
4.3 POWERFUL Operation .....	114
4.4 OUTDOOR UNIT QUIET Operation .....	115
4.5 HOME LEAVE Operation .....	116
4.6 TIMER Operation .....	118
5. CDXS-L, FDXS-L Series .....	120
5.1 Remote Controller .....	120
5.2 AUTO · DRY · COOL · HEAT · FAN Operation .....	122
5.3 Adjusting the Airflow Rate .....	124
5.4 POWERFUL Operation .....	125
5.5 OUTDOOR UNIT QUIET Operation .....	126
5.6 ECONO Operation .....	127
5.7 OFF TIMER Operation .....	128
5.8 ON TIMER Operation .....	129
5.9 Note for Multi System .....	130
5.10 Quick Reference .....	132

# 1. System Configuration

After installation and trial operation of the room air conditioner are completed, the air conditioner should be handled and operated as described in the following pages. Every user should be informed on the correct method of operation and how to check if it can cool (or heat) well, and how to use it efficiently.

Providing instructions to the user can reduce requests for servicing by 80%. However proficient the installation and operating functions of the AC system are, the customer may fault either the room air conditioner or its installation work when it is actually due to improper handling. The installation work and the handing-over of the unit can only be considered completed when its handling has been fully explained to the user without using technical terms, and while imparting full knowledge of the equipment.


## 2. CTXS-J, CTXS-H, FTXS-H Series

### 2.1 Remote Controller

# Name of Parts

## Remote Controller: ARC452A9

### Signal transmitter



- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is approximately 23ft. (7m).

### FAN setting button

- Selects the airflow rate setting.

▶ Page 11

### POWERFUL button

- POWERFUL operation. ▶ Page 16

### Display (LCD)

- Displays the current settings. (In this illustration, each section is shown with its displays on for the purpose of explanation.)

### TEMPERATURE adjustment buttons

- Changes the temperature setting.

▶ Page 10

### ON/OFF button


- Press this button once to start operation. Press once again to stop it.

▶ Page 10

### Front cover


- Open the front cover. ▶ Page 7

Open the front cover



## 2.2 AUTO · DRY · COOL · HEAT · FAN Operation

### AUTO · DRY · COOL · HEAT · FAN Operation




The air conditioner operates with the operation mode of your choice.

From the next time on, the air conditioner will operate with the same operation mode.

#### ■ To start operation


##### 1. Press **MODE** and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.



##### 2. Press .

- “**ON**” is displayed on the LCD.
- The OPERATION lamp lights up.





Display

#### ■ To stop operation

Press  again.


- “**ON**” is no longer displayed on the LCD.
- The OPERATION lamp goes off.

#### ■ To change the temperature setting

Press  or  .

- The displayed items on the LCD will change whenever either one of the buttons is pressed.

DRY or FAN operation	COOL operation	HEAT operation	AUTO operation
The temperature setting is not variable.	64-90°F (18-32°C)	50-86°F (10-30°C)	64-86°F (18-30°C)
	Press ▲ to raise the temperature and press ▼ to lower the temperature.		



## ■ To change the airflow rate setting

Press .

DRY operation	AUTO or COOL or HEAT or FAN operation
The airflow rate setting is not variable.	5 levels of airflow rate setting from "" to "" plus "

- Indoor unit quiet operation  
When the airflow is set to "
- Each pressing of the button advances the airflow rate setting in sequence.



## NOTE

### ■ Notes on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT operation, it takes some time before the room gets warmer.
- In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

### ■ Note on COOL operation

- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, the performance of the air conditioner drops.

### ■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.

### ■ Notes on AUTO operation

- In AUTO operation, the system selects a temperature setting and an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.

### ■ Note on FAN operation


- This is valid for fan only.

### ■ Note on airflow rate setting

- At smaller airflow rates, the cooling (heating) effect is also smaller.

## 2.3 Adjusting the Airflow Direction

# Adjusting the Airflow Direction




You can adjust the airflow direction to increase your comfort.


### Adjusting the upper and lower airflow direction

#### ■ To adjust the louvers (horizontal blades)

**1. Press** .

- “” is displayed on the LCD and the louvers will begin to swing.

**2. When the louvers have reached the desired position, press**  **once more.**

- The louvers will stop moving.
- “” is no longer displayed on the LCD.


### Adjusting the right and left airflow direction

#### ■ To adjust the fins (vertical blades)

**3. Press** .


- “” is displayed on the LCD.

**4. When the fins have reached the desired position, press**  **once more.**

- The fins will stop moving.
- “” is no longer displayed on the LCD.



### ■ To start 3-D airflow


1. 3. Press the  and the  :  
the “” and “” display will light up and the louvers and fins will move in turn.

### ■ To cancel 3-D airflow

2. 4. Press either the  or the  .

## NOTE

#### ■ Note on the angles of the louvers


- When  is selected, the louvers swinging range depends on the operation. (See the figure.)

#### ■ Note on 3-D airflow

- Using 3-D airflow circulates cold air, which tends to be collected at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.


#### ■ ATTENTION

- Always use a remote controller to adjust the angles of the louvers and fins. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Always use a remote controller to adjust the fins angles. Inside the air outlet, a fan is rotating at a high speed.



## 2.4 INTELLIGENT EYE Operation

# INTELLIGENT EYE Operation



“INTELLIGENT EYE” is the infrared sensor which detects the human movement.


### ■ To start INTELLIGENT EYE operation

#### 1. Press .

- “” is displayed on the LCD.

### ■ To cancel INTELLIGENT EYE operation

#### 2. Press again.


- “” is no longer displayed on the LCD.

### [Example]

#### When somebody in the room

##### • Normal operation


The air conditioner is in normal operation while the sensor is detecting the movement of people.



#### When nobody in the room

##### • 20 minutes after, start energy saving operation.


The set temperature is shifted in  $\pm 3.6^{\circ}\text{F}$  ( $\pm 2^{\circ}\text{C}$ ) steps.



#### Somebody back in the room

##### • Back to normal operation.

The air conditioner will return to normal operation when the sensor detects the movement of people again.



## “INTELLIGENT EYE” is useful for energy saving


### ■ Energy saving operation

- Change the temperature  $-3.6^{\circ}\text{F}$  ( $-2^{\circ}\text{C}$ ) in HEAT /  $+3.6^{\circ}\text{F}$  ( $+2^{\circ}\text{C}$ ) in COOL /  $+1.8^{\circ}\text{F}$  ( $+1^{\circ}\text{C}$ ) in DRY operation from set temperature.
- Decrease the airflow rate slightly in FAN operation only.
- If no presence detected in the room for 20 minutes.

## NOTE

### ■ Notes on INTELLIGENT EYE operation

- Application range is as follows.




- Sensor may not detect moving objects further than 23ft. (7m) away. (Check the application range.)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during POWERFUL operation.
- NIGHT SET mode [▶ Page 20](#) will not go on during use of INTELLIGENT EYE operation.

## ⚠ CAUTION

- Do not place large objects near the sensor.  
Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or forcefully push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

## 2.5 POWERFUL Operation


# POWERFUL Operation



POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.

### ■ To start POWERFUL operation

Press  during operation.

- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- “” is displayed on the LCD.
- When using POWERFUL operation, there are some functions which are not available.

### ■ To cancel POWERFUL operation

Press  again.

- “” is no longer displayed on the LCD.


## NOTE

### ■ Notes on POWERFUL operation

- POWERFUL operation cannot be used together with QUIET operation.  
Priority is given to the function of whichever button is pressed last.
- **In COOL and HEAT operation**  
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the airflow rate be fixed to the maximum setting.  
The temperature and airflow settings are not variable.
- **In DRY operation**  
The temperature setting is lowered by 4.5°F (2.5°C) and the airflow rate is slightly increased.
- **In FAN operation**  
The airflow rate is fixed to the maximum setting.
- **In AUTO operation**  
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the airflow rate be fixed to the maximum setting.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum capacity demonstrated.

## 2.6 OUTDOOR UNIT QUIET Operation

# OUTDOOR UNIT QUIET Operation



OUTDOOR UNIT QUIET operation lowers the sound level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

### ■ To start OUTDOOR UNIT QUIET operation

Press .

- " " is displayed on the LCD.


### ■ To cancel OUTDOOR UNIT QUIET operation

Press  again.

- " " is no longer displayed on the LCD.


## NOTE

### ■ Notes on OUTDOOR UNIT QUIET operation

- If using a multi system, this function will work only when the OUTDOOR UNIT QUIET operation is set on all operated indoor units. However, if using priority room setting, see note for multi system. [▶Page 22](#)
- This function is available in COOL, HEAT, and AUTO operation.  
(This is not available in FAN and DRY operation)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.  
Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, " " will remain on the remote controller display.
- OUTDOOR UNIT QUIET operation will drop neither the frequency nor fan speed if the frequency and fan speed have been already dropped low enough.

## 2.7 HOME LEAVE Operation


# HOME LEAVE Operation




HOME LEAVE operation is a function which allows you to record your preferred temperature and airflow rate settings.

### ■ To start HOME LEAVE operation


#### 1. Press .

- “” is displayed on the LCD.
- The HOME LEAVE lamp lights up.



### ■ To cancel HOME LEAVE operation





#### 2. Press again.



- “” is no longer displayed on the LCD.
- The HOME LEAVE lamp goes off.

### Before using HOME LEAVE operation.

#### ■ To set the temperature and airflow rate for HOME LEAVE operation


When using HOME LEAVE operation for the first time, please set the temperature and airflow rate for HOME LEAVE operation. Record your preferred temperature and airflow rate.

	Initial setting		Selectable range	
	Temperature	Airflow rate	Temperature	Airflow rate
Cooling	77°F (25°C)	AUTO	64-90°F (18-32°C)	5 step, “  ” and “  ”
Heating	77°F (25°C)	AUTO	50-86°F (10-30°C)	5 step, “  ” and “  ”

1. Press  . Make sure “” is displayed in the remote controller display.
2. Adjust the set temperature with ▲ or ▼ as you like.
3. Adjust the airflow rate with FAN setting button as you like.

HOME LEAVE operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1-3.

## ■ What's the HOME LEAVE operation?

Is there a set temperature and airflow rate which is most comfortable, a set temperature and airflow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and airflow rate. You can start your favorite operation mode simply by pressing  on the remote controller. This function is convenient in the following situations.


## ■ Useful in these cases

### 1. Use as an energy-saving mode.

Set the temperature 3-5°F(2-3°C) higher (COOL) or lower (HEAT) than normal. Setting the fan speed to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.

#### • Every day before you leave the house...




When you go out, press  and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE operation.



When you return, you will be welcomed by a comfortably air conditioned room.



Press  again, and the air conditioner will adjust capacity to the set temperature for normal operation.


#### • Before bed...



Set the unit to HOME LEAVE operation before leaving the living room when going to bed.




The unit will maintain the temperature in the room at a comfortable level while you sleep.




When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

### 2. Use as a favorite mode.


Once you record the temperature and airflow rate settings you most often use, you can retrieve them by pressing . You do not have to make all the selections again.

## NOTE

- Once the temperature and airflow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the before using HOME LEAVE operation section above.
- HOME LEAVE operation is only available in COOL and HEAT operation. It cannot be used in AUTO, DRY, and FAN operation.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time. Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote controller or the indoor unit ON/OFF switch, " " will remain on the remote controller display.

## 2.8 TIMER Operation

# TIMER Operation



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

### ■ To use OFF TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **OFF**.



"0:00" is displayed.


"OFF" blinks.

#### 2. Press **SELECT** until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

#### 3. Press **OFF** again.

- The TIMER lamp lights up.



Display

### ■ To cancel OFF TIMER operation

Press **CANCEL**.

- The TIMER lamp goes off.

## NOTE


### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approximately 10 minutes)

### ■ NIGHT SET mode

- When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.9°F (0.5°C) up in COOL, 3.6°F (2.0°C) down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.






### ■ To use ON TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **ON**.



"6:00" is displayed.

"ON" blinks.


#### 2. Press **SELECT** until the time setting reaches the point you like.



- Each pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

#### 3. Press **ON** again.

- The TIMER lamp lights up.



Display


### ■ To cancel ON TIMER operation

Press **CANCEL**.

- The TIMER lamp goes off.

### ■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.



### ATTENTION

#### ■ In the following cases, set the timer again.

- After a breaker has turned off.
- After a power failure.
- After replacing batteries in the remote controller.

## 2.9 Note for Multi System

# Note for Multi System

### What is a multi system?

This system has one outdoor unit connected to multiple indoor units.

### ■ Selecting the operation mode

#### 1. With the priority room setting present but inactive or not present.


When more than one indoor unit is operating, priority is given to the first unit that was turned on.

In this case, set the units that are turned on later to the same operation mode (\*1) as the first unit.

Otherwise, they will enter the standby state, and the OPERATION lamp will flash: this does not indicate malfunction.

(\*1)

- COOL, DRY and FAN operation may be used at the same time.
- AUTO operation automatically selects COOL operation or HEAT operation based on the room temperature. Therefore, AUTO operation is available when selecting the same operation mode as that of the room with the first unit to be turned on.



### ⚠ CAUTION

- Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.  
If the operation mode of the first room is FAN operation, then using HEAT operation in any room after this will give priority to HEAT operation. In this situation, the air conditioner running in FAN operation will go on standby, and the OPERATION lamp will flash.

#### 2. With the priority room setting active.

See priority room setting on the next page.

### ■ NIGHT QUIET mode (Available only for COOL operation)

NIGHT QUIET mode requires initial programming during installation. Please consult your retailer or dealer for assistance.

NIGHT QUIET mode reduces the operation noise of the outdoor unit during the nighttime hours to prevent annoyance to neighbors.

- The NIGHT QUIET mode is activated when the temperature drops 9°F (5°C) or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 9°F (5°C), this function will not be activated.
- NIGHT QUIET mode reduces slightly the cooling efficiency of the unit.

## ■ OUTDOOR UNIT QUIET operation ▶ Page 17

### 1. With the priority room setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using its remote controller.

The OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms.

We recommend you release all rooms using their remote controllers.

### 2. With the priority room setting active.

See priority room setting.

## ■ COOL/HEAT mode lock (Available only for heat pump models)

The COOL/HEAT mode lock requires initial programming during installation. Please consult your authorized dealer for assistance.

The COOL/HEAT mode lock sets the unit forcibly to either COOL or HEAT operation. This function is convenient when you wish to set all indoor units connected to the multi system to the same operation mode.

## ■ Priority room setting

The priority room setting requires initial programming during installation. Please consult your authorized dealer for assistance.

The room designated as the priority room takes priority in the following situations;

### 1. Operation mode priority.

As the operation mode of the priority room takes precedence, the user can select a different operation mode from other rooms.

< Example >

\* Room A is the priority room in the examples.

When COOL operation is selected in room A while operating the following modes in room B:

Operation mode in room B	Status of room B when the unit in room A is in COOL operation
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters standby mode. Operation resumes when the room A unit stops operating.
AUTO	If the unit is set to COOL operation, it continues. If the unit is set to HEAT operation, it enters standby mode. Operation resumes when the room A unit stops operating.

### 2. Priority when POWERFUL operation is used.

< Example >

\* Room A is the priority room in the examples.

The indoor units in rooms A and B are all operating. If the unit in room A enters POWERFUL operation, operation capacity will be concentrated in room A. In such a case, the cooling (heating) efficiency of the units in room B may be slightly reduced.

### 3. Priority when using OUTDOOR UNIT QUIET operation.

< Example >

\* Room A is the priority room in the examples.

Just by setting the unit in room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation.

You don't have to set all the operated indoor units to QUIET operation.


## 3. CTXS-L, FTXS-L Series

### 3.1 Remote Controller

# Names of Parts

## Remote Controller

### Signal transmitter



- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is approximately 23ft. (7m).

### FAN setting button

- Selects the airflow rate setting. ▶ Page 14

### POWERFUL button

- POWERFUL operation. ▶ Page 17

### Display (LCD)

- Displays the current settings. (In this illustration, each section is shown with all its displays on for the purpose of explanation.)

### TEMPERATURE adjustment buttons

- Changes the temperature setting. ▶ Page 12

### ON/OFF button


- Press this button once to start operation. Press once again to stop it. ▶ Page 11

### Front cover

- Open the front cover. ▶ Page 8

<ARC452A21>


## ■ Open the front cover



## 3.2 AUTO · DRY · COOL · HEAT · FAN Operation



# AUTO · DRY · COOL · HEAT · FAN Operation




The air conditioner operates with the operation mode of your choice.  
From the next time on, the air conditioner will operate with the same operation mode.

### ■ To start operation


#### 1. Press **MODE** and select an operation mode.

- Each pressing of the button advances the mode setting in sequence.



#### 2. Press .

- “**ON**” is displayed on the LCD.
- The OPERATION lamp lights green.




### ■ To stop operation

#### Press again.

- “**ON**” is no longer displayed on the LCD.
- The OPERATION lamp goes off.

### NOTE

MODE	Notes on each operation mode
HEAT	<ul style="list-style-type: none"> <li>Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.</li> <li>The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT operation, it takes some time before the room gets warmer.</li> <li>In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.</li> <li>During defrosting operation, hot air does not flow out of indoor unit.</li> </ul>
COOL	<ul style="list-style-type: none"> <li>This air conditioner cools the room by releasing the heat in the room outside. Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high.</li> </ul>
DRY	<ul style="list-style-type: none"> <li>The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.</li> </ul>
AUTO	<ul style="list-style-type: none"> <li>In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outside temperatures and starts the operation.</li> <li>The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.</li> </ul>
FAN	<ul style="list-style-type: none"> <li>This mode is valid for fan only.</li> </ul>



### ■ To change the temperature setting

Press  or  .

- The displayed items on the LCD will change whenever either one of the buttons is pressed.

COOL operation	HEAT operation	AUTO operation	DRY or FAN operation
64-90°F (18-32°C)	50-86°F (10-30°C)	64-86°F (18-30°C)	The temperature setting is not variable.
Press ▲ to raise the temperature and press ▼ to lower the temperature.			

## ■ Operating conditions

### ■ Recommended temperature setting

- For cooling: 78-82°F (26-28°C)
- For heating: 68-75°F (20-24°C)

### ■ Tips for saving energy

- Be careful not to cool (heat) the room too much.  
Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain.  
Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every 2 weeks.

### ■ Notes on the operating conditions

- The air conditioner always consumes a small amount of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker off.
- Use the air conditioner in the following conditions.


MODE	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature : 50-115°F (10-46°C) Indoor temperature : 64-90°F (18-32°C) Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.)</li> <li>• Condensation may occur on the indoor unit and drip.</li> </ul>
HEAT	Outdoor temperature : 5-75°F (-15-24°C) Indoor temperature : 50-86°F (10-30°C)	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation.</li> </ul>
DRY	Outdoor temperature : 50-115°F (10-46°C) Indoor temperature : 64-90°F (18-32°C) Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation.</li> <li>• Condensation may occur on the indoor unit and drip.</li> </ul>

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

### 3.3 Adjusting the Airflow Direction and Rate



## Adjusting the Airflow Direction and Rate




You can adjust the airflow direction to increase your comfort.

#### ■ To start auto swing

##### Upper and lower airflow direction

Press .


- “” is displayed on the LCD.
- The louvers (horizontal blades) will begin to swing.



##### Right and left airflow direction

Press .


- “” is displayed on the LCD.
- The fins (vertical blades) will begin to swing.



##### The 3-D airflow direction

Press and .

- “” and “” are displayed on the LCD.
- The louvers and fins move in turn.
- To cancel 3-D airflow, press either or again. The louvers or fins will stop moving.



#### ■ To set the louvers or fins at desired position


- This function is effective while louvers or fins are in auto swing mode.

Press and when the louvers or fins have reached the desired position.

- In the 3-D airflow, the louvers and fins move in turn.
- “” or “” is no longer displayed on the LCD.





## CTXS07LVJU, FTXS09/12LVJU




### ■ To adjust the airflow rate setting

Press .

- Each pressing of  advances the airflow rate setting in sequence.






- When the airflow is set to “”, indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- In DRY operation, the airflow rate setting is not variable.

## NOTE

### ■ Notes on the angles of the louvers

- The louvers swinging range depends on the operation. (See the figure.)



### ■ Note on 3-D airflow

- Using 3-D airflow circulates cold air, which tends to be collected at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.


### ■ Note on airflow rate setting

- At smaller airflow rates, the cooling (heating) effect is also smaller.

## CAUTION


- Always use a remote controller to adjust the angles of the louvers and fins. If you attempt to move the louvers and fins forcibly with hand when they are swinging, the mechanism may be broken.
- Always use a remote controller to adjust the fins angles. Inside the air outlet, a fan is rotating at a high speed.


## FTXS15/18LVJU




### ■ To adjust the airflow rate setting

Press .

- Each pressing of  advances the airflow rate setting in sequence.






- When the airflow is set to “”, indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- In DRY operation, the airflow rate setting is not variable.

## NOTE

### ■ Notes on the angles of the louvers

- The louvers swinging range depends on the operation. (See the figure.)



### ■ Note on 3-D airflow

- Using 3-D airflow circulates cold air, which tends to collect at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.

### ■ Note on airflow rate setting

- At smaller airflow rates, the cooling (heating) effect is also smaller.

## ⚠ CAUTION

- Always use a remote controller to adjust the angles of the louvers and fins. If you attempt to move the louvers and fins forcibly with hand when they are swinging, the mechanism may be broken.
- Always use a remote controller to adjust the fins angles. Inside the air outlet, a fan is rotating at a high speed.


## 3.4 COMFORT AIRFLOW / INTELLIGENT EYE Operation




# COMFORT AIRFLOW / INTELLIGENT EYE Operation

### ■ COMFORT AIRFLOW operation

The flow of air will be in the upward direction while in COOL operation and in the downward direction while in HEAT operation, providing comfortable cool or warm air that does not come in direct contact with people.



COOL operation




HEAT operation

### ■ INTELLIGENT EYE operation

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.

If no one is in the room for more than 20 minutes, the operation automatically changes to energy saving operation.

#### [Example]




### INTELLIGENT EYE operation is useful for energy saving

#### ■ Energy saving operation

- If no presence detected in the room for 20 minutes, the energy saving operation will start.
- This operation changes the temperature  $-3.6^{\circ}\text{F}$  ( $-2^{\circ}\text{C}$ ) in HEAT /  $+3.6^{\circ}\text{F}$  ( $+2^{\circ}\text{C}$ ) in COOL /  $+3.6^{\circ}\text{F}$  ( $+2^{\circ}\text{C}$ ) in DRY operation from set temperature. When the room temperature exceeds  $86^{\circ}\text{F}$  ( $30^{\circ}\text{C}$ ), the operation changes the temperature  $+1.8^{\circ}\text{F}$  ( $+1^{\circ}\text{C}$ ) in COOL /  $+1.8^{\circ}\text{F}$  ( $+1^{\circ}\text{C}$ ) in DRY operation from set temperature.
- This operation decreases the airflow rate slightly in FAN mode only.


### ■ Combination COMFORT AIRFLOW and INTELLIGENT EYE operation

The air conditioner can go into operation with the COMFORT AIRFLOW and INTELLIGENT EYE functions combined.




### ■ To start operation


Press  and select the desired mode.

- Each time the  is pressed a different setting option is displayed on the LCD.
- The INTELLIGENT EYE lamp lights green.



Display

- By selecting “” from the following icons, the air conditioner will be in COMFORT AIRFLOW operation combined with INTELLIGENT EYE operation.



- When the louvers (horizontal blades) are swinging, the operating as above will stop movement of them.
- The lamp will be lit while human movements are detected.

### ■ To cancel operation

Press  and select “blank” on the LCD.

- The INTELLIGENT EYE lamp goes off.


## NOTE


#### ■ Notes on COMFORT AIRFLOW operation

- The louver position will change, preventing air from blowing directly on the occupants of the room.
- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW function will be canceled.

#### ■ Notes on INTELLIGENT EYE operation

- Application range is as follows.



- Sensor may not detect moving objects further than 23ft (7m) away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during POWERFUL operation.
- NIGHT SET mode  Page 20 will not go on during use of INTELLIGENT EYE operation.

#### ■ Notes on combination of COMFORT AIRFLOW operation and INTELLIGENT EYE operation

- The airflow rate will be set to AUTO. If the upper and lower airflow direction is selected, the COMFORT AIRFLOW operation will be canceled. Priority is given to the function of whichever button is pressed last.


## ⚠ CAUTION

- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect undesirable objects.
- Do not hit or forcefully push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

## 3.5 POWERFUL Operation




# POWERFUL Operation



POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.


### ■ To start POWERFUL operation

Press  during operation.


- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- “” is displayed on the LCD.

### ■ To cancel POWERFUL operation

Press  again.



- “” is no longer displayed on the LCD.

### [Example]



## NOTE


### ■ Notes on POWERFUL operation

- When using POWERFUL operation, there are some functions which are not available.
- POWERFUL operation cannot be used together with ECONO, COMFORT AIRFLOW or OUTDOOR UNIT QUIET operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL operation can only be set when the unit is running. Pressing  causes the settings to be canceled, and “” is no longer displayed on the LCD.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum capacity demonstrated.
- **In COOL, HEAT and AUTO operation**  
To maximize the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting. The temperature and airflow settings are not variable.
- **In DRY operation**  
The temperature setting is lowered by 4.5°F (2.5°C) and the airflow rate is slightly increased.
- **In FAN operation**  
The airflow rate is fixed to the maximum setting.

## 3.6 OUTDOOR UNIT QUIET Operation



# OUTDOOR UNIT QUIET Operation



OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during the night.


### ■ To start OUTDOOR UNIT QUIET operation

Press .


- “” is displayed on the LCD.

### ■ To cancel OUTDOOR UNIT QUIET operation

Press  again.

- “” is no longer displayed on the LCD.


[Example] Using the OUTDOOR UNIT QUIET operation during the night.



- The sound level of the outdoor unit will be lower.  
This is convenient in consideration of your neighbors.

## NOTE


### ■ Notes on OUTDOOR UNIT QUIET operation

- If using a multi system, the OUTDOOR UNIT QUIET operation will work only when this function is set on all operated indoor units. However, if using priority room setting, refer to “Note for multi system”. [▶ Page 28](#)
- This function is available in COOL, HEAT, and AUTO operation.  
This is not available in FAN and DRY operation.
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.  
Priority is given to the function of whichever button is pressed last.
- Even the operation is stopped using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, “” will remain on the remote controller display.
- OUTDOOR UNIT QUIET operation will drop neither the frequency nor fan speed if they have been already dropped low enough.

## 3.7 ECONO Operation



# ECONO Operation



ECONO operation is a function which enables efficient operation by limiting the maximum power consumption value.

This function is useful for cases in which attention should be paid to ensure a circuit breaker will not trip when the product runs alongside other appliances.


### ■ To start ECONO operation

Press  during operation.

- “” is displayed on the LCD.

### ■ To cancel ECONO operation

Press  again.

- “” is no longer displayed on the LCD.


#### [Example]

##### Normal operation




- In case the air conditioner and other appliances which require high power consumption are used at same time, a circuit breaker may trip if the air conditioner operate with its maximum capacity.

##### ECONO operation





- The maximum power consumption of the air conditioner is limited by using ECONO operation. The circuit breaker is unlikely to trip even if the air conditioner and other appliances are used at same time.



- This diagram is a representation for illustrative purposes only. The maximum running current and power consumption of the air conditioner in ECONO operation vary with the connecting outdoor unit.

## NOTE


### ■ Notes on ECONO operation

- ECONO operation can only be set when the unit is running. Pressing  causes the settings to be canceled, and “” is no longer displayed on the LCD.
- ECONO operation functions in AUTO, COOL, DRY, and HEAT operation.
- POWERFUL and ECONO operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- If the level of power consumption is already low, ECONO operation will not drop the power consumption.

## 3.8 OFF TIMER Operation



# OFF TIMER Operation



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

### ■ To use OFF TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **OFF** .



"0:00" is displayed on the LCD.  
"OFF" blinks.

- "⊙" is no longer displayed on the LCD.

#### 2. Press **SELECT** until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.  
Holding down either button changes the time setting rapidly.

#### 3. Press **OFF** again.

- "OFF" and setting time are displayed on the LCD.
- The TIMER lamp lights yellow.



Display

### ■ To cancel OFF TIMER operation

#### Press **CANCEL** .

- "OFF" and setting time are no longer displayed on the LCD.
- "⊙" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

## NOTE

### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approximately 10 minutes)

### ■ NIGHT SET mode


- When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.9°F (0.5°C) up in COOL, 3.6°F (2.0°C) down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.



## 3.9 ON TIMER Operation




# ON TIMER Operation



### ■ To use ON TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **ON**.



- "6:00" is displayed on the LCD.
- "ON" blinks.

- "☉" and day of the week are no longer displayed on the LCD.

#### 2. Press **SELECT** until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.  
Holding down either button changes the setting rapidly.

#### 3. Press **ON** again.

- "ON" and setting time are displayed on the LCD.
- The TIMER lamp lights yellow.



Display


### ■ To cancel ON TIMER operation

#### Press **CANCEL**.

- "ON" and setting time are no longer displayed on the LCD.
- "☉" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

### ■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the 2 timers is shown below.



## NOTE

### ■ In the following cases, set the timer again.

- After a breaker has turned off.
- After a power failure.
- After replacing batteries in the remote controller.

## 3.10 WEEKLY TIMER Operation



# WEEKLY TIMER Operation

Up to 4 timer settings can be saved for each day of the week. It is convenient if the WEEKLY TIMER is set according to the family's life style.

### ■ Using in these cases of WEEKLY TIMER


**Example:** The same timer settings are made for the week from Monday through Friday while different timer settings are made for the weekend.

<b>[Monday]</b>	<p>Make timer settings up to programs 1-4. ▶ Page 23</p> <div> <div> <b>Program 1</b> ON 77°F (25°C) 6:00 8:30 OFF </div> <div> <b>Program 2</b> OFF </div> <div> <b>Program 3</b> ON 81°F (27°C) 17:30 22:00 OFF </div> <div> <b>Program 4</b> OFF </div> </div>
<b>[Tuesday] to [Friday]</b>	<p>Use the copy mode to make settings for Tuesday to Friday, because these settings are the same as those for Monday. ▶ Page 25</p> <div> <div> <b>Program 1</b> ON 77°F (25°C) 6:00 8:30 OFF </div> <div> <b>Program 2</b> OFF </div> <div> <b>Program 3</b> ON 81°F (27°C) 17:30 22:00 OFF </div> <div> <b>Program 4</b> OFF </div> </div>
<b>[Saturday]</b>	No timer settings
<b>[Sunday]</b>	<p>Make timer settings up to programs 1-4. ▶ Page 23</p> <div> <div> <b>Program 1</b> ON 77°F (25°C) 8:00 10:00 OFF </div> <div> <b>Program 2</b> OFF </div> <div> <b>Program 3</b> OFF 81°F (27°C) 19:00 21:00 ON </div> <div> <b>Program 4</b> ON 81°F (27°C) </div> </div>

- Up to 4 reservations per day and 28 reservations per week can be set in the WEEKLY TIMER. The effective use of the copy mode ensures ease of making reservations.
- The use of ON-ON-ON-ON settings, for example, makes it possible to schedule operating mode and set temperature changes. Furthermore, by using OFF-OFF-OFF-OFF settings, only the turn off time of each day can be set. This will turn off the air conditioner automatically if the user forgets to turn it off.




# WEEKLY TIMER Operation




## ■ To use WEEKLY TIMER operation

### Setting mode

- Make sure the day of the week and time are set. If not, set the day of the week and time.



### Setting Displays



### 1. Press .

- The day of the week and the reservation number of the current day will be displayed.
- 1 to 4 settings can be made per day.


### 2. Press to select the desired day of the week and reservation number.


- Pressing  changes the reservation number and the day of the week.

### 3. Press .

- The day of the week and reservation number will be set.
- "WEEKLY" and "ON" blink.

### 4. Press to select the desired mode.


- Pressing  changes "ON" or "OFF" setting in sequence.




- In case the reservation has already been set, selecting "blank" deletes the reservation.
- Go to STEP 9 if "blank" is selected.

### 5. Press .


- The ON/OFF TIMER mode will be set.
- "WEEKLY" and the time blink.




## 6. Press to select the desired time.

- The time can be set between 0:00 and 23:50 in 10 minute intervals.
- To return to the ON/OFF TIMER mode setting, press .
- Go to **STEP 9** when setting the OFF TIMER.

## 7. Press .

- The time will be set.
- “ WEEKLY” and the temperature blink.


## 8. Press to select the desired temperature.

- The temperature can be set between 50°F (10°C) and 90°F (32°C).  
Cooling: The unit operates at 64°F (18°C) even if it is set at 50 (10) to 63°F (17°C).  
Heating: The unit operates at 86°F (30°C) even if it is set at 87 (31) to 90°F (32°C).
- To return to the time setting, press .
- The set temperature is only displayed when the mode setting is on.

## 9. Press .

- The temperature will be set and go to the next reservation setting.
- To continue further settings, repeat the procedure from **STEP 4**.

## 10. Press to complete the setting.

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone and flashing the OPERATION lamp.
- “ WEEKLY” is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights yellow.






Display

- A reservation made once can be easily copied and the same settings used for another day of the week. Refer to . ▶ **Page 25**


## NOTE

### ■ Notes on WEEKLY TIMER operation

- Do not forget to set the clock on the remote controller first.
- The day of the week, ON/OFF TIMER mode, time and set temperature (only for ON TIMER mode) can be set with WEEKLY TIMER. Other settings for ON TIMER are based on the settings just before the operation.
- Both WEEKLY TIMER and ON/OFF TIMER operation cannot be used at the same time. The ON/OFF TIMER operation has priority if it is set while WEEKLY TIMER is still active. The WEEKLY TIMER will go into standby state, and “ WEEKLY” will be no longer displayed on the LCD. When ON/OFF TIMER is up, the WEEKLY TIMER will automatically become active.
- Only the time and set temperature with the WEEKLY TIMER are sent with the . Set the WEEKLY TIMER only after setting the operation mode, the airflow rate and the airflow direction ahead of time.
- Shutting the breaker off, power failure, and other similar events will render operation of the indoor unit's internal clock inaccurate. Reset the clock.
- The  can be used only for the time and temperature settings. It cannot be used to go back to the reservation number.




# WEEKLY TIMER Operation




## Copy mode

- A reservation made once can be copied to another day of the week. The whole reservation of the selected day of the week will be copied.



## Setting Displays



- Press .
- Press to confirm the day of the week to be copied.
- Press .
- Press to select the destination day of the week.
- Press .
- Press to complete the setting.

- The whole reservation of the selected day of the week will be copied.

- The reservation will be copied to the selected day of the week. The whole reservation of the selected day of the week will be copied.
- To continue copying the settings to other days of the week, repeat **STEP 4** and **STEP 5**.


- " WEEKLY" is displayed on the LCD and WEEKLY TIMER operation is activated.

## NOTE

### ■ Note on COPY MODE


- The entire reservation of the source day of the week is copied in the copy mode.

In the case of making a reservation change for any day of the week individually after copying the content of weekly reservations, press and change the settings in the steps of **Setting mode**. **Page 23**



## ■ Confirming a reservation


- The reservation can be confirmed.



### 1. Press .


- The day of the week and the reservation number of current day will be displayed.

### 2. Press to select the day of the week and the reservation number to be confirmed.

- Pressing  displays the reservation details.
- To change the confirmed reserved settings, select the reservation number and press **NEXT**.  
The mode is switched to setting mode. Go to **Setting mode STEP 4.** ▶ Page 23

### 3. Press to exit confirming mode.

- “**WEEKLY**” is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights yellow.




## ■ To deactivate WEEKLY TIMER operation

Press **WEEKLY** while “**WEEKLY**” is displayed on the LCD.

- “**WEEKLY**” will be no longer displayed on the LCD.
- The TIMER lamp goes off.
- To reactivate the WEEKLY TIMER operation, press **WEEKLY** again.
- If a reservation deactivated with **WEEKLY** is activated once again, the last reservation mode will be used.



# WEEKLY TIMER Operation



## ■ To delete reservations

### The individual reservation

1. Press .  
• The day of the week and the reservation number will be displayed.
2. Press to select the day of the week and the reservation number to be deleted.
3. Press .  
• "WEEKLY" and "ON" or "OFF" blink.
4. Press and select "blank".  
• Pressing changes ON/OFF TIMER mode.  
• The reservation has no setting when selecting "blank".
5. Press .  
• The selected reservation will be deleted.
6. Press .  
• If there are still other reservations, WEEKLY TIMER operation will be activated.

### The reservations for each day of the week

- This function can be used for deleting reservations for each day of the week.
  - It can be used while confirming or setting reservations.
1. Press to select the day of the week to be deleted.
  2. Hold for 5 seconds.  
• The reservation of the selected day of the week will be deleted.

### All reservations

**Hold for 5 seconds while normal display.**

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone.
- This operation is not effective on the setting display of WEEKLY TIMER.
- All reservations will be deleted.

## 3.11 Note for Multi System

# Note for Multi System

Multi system has one outdoor unit connected to multiple indoor units.


### ■ Selecting the operation mode

#### With the priority room setting present but inactive or not present.

When more than one indoor unit is operating, priority is given to the first unit that was turned on.

In this case, set the units that are turned on later to the same operation mode as the first unit.

Otherwise, they will enter the standby state, and the OPERATION lamp will flash: this does not indicate malfunction.



### NOTE

#### ■ Notes on operation mode for multi system

- COOL, DRY and FAN operation may be used at the same time.
  - AUTO operation automatically selects COOL operation or HEAT operation based on the room temperature.
- Therefore, AUTO operation is available when selecting the same operation mode as that of the room with the first unit to be turned on.

### ⚠ CAUTION

- Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.

If the operation mode of the first room is **FAN operation**, then using **HEAT operation** in any room after this will give priority to **HEAT operation**. In this situation, the air conditioner running in FAN operation will go on standby, and the OPERATION lamp will flash.

#### With the priority room setting active.

Refer to "Priority room setting" on the next page.

### ■ NIGHT QUIET mode (Available only for COOL operation)

NIGHT QUIET mode requires initial programming during installation. Please consult your retailer or dealer for assistance. NIGHT QUIET mode reduces the operation noise of the outdoor unit during the nighttime hours to prevent annoyance to neighbors.

- The NIGHT QUIET mode is activated when the temperature drops 10.8°F (6°C) or more below the highest temperature recorded that day.
- Therefore, when the temperature difference is less than 7.2°F (4°C), this function will not be activated.
- NIGHT QUIET mode reduces slightly the cooling efficiency of the unit.

### ■ OUTDOOR UNIT QUIET operation

Refer to "OUTDOOR UNIT QUIET operation". ▶ Page 18

#### With the priority room setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the Multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote controller. However OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms.

We recommend you release all rooms using their remote controllers.

#### With the priority room setting active.

Refer to "Priority room setting" on the next page.



# Note for Multi System

## ■ COOL / HEAT mode lock

The COOL / HEAT mode lock requires initial programming during installation. Please consult your authorized dealer for assistance. The COOL / HEAT mode lock sets the unit forcibly to either COOL or HEAT operation. This function is convenient when you wish to set all indoor units connected to the multi system to the same operation mode.

## ■ Priority room setting

The priority room setting requires initial programming during installation. Please consult your authorized dealer for assistance. The room designated as the priority room takes priority in the following situations.

### Operation mode priority

- As the operation mode of the priority room takes precedence, the user can select a different operation mode from other rooms.

#### [Example]

- Room A is the priority room in the examples.  
When COOL operation is selected in room A while operating the following modes in room B, C and D :

Operation mode in room B, C and D	Status of room B, C and D when the unit in room A is in COOL operation
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters standby mode. Operation resumes when the room A unit stops operating.
AUTO	If the unit is set to COOL operation, it continues. If the unit is set to HEAT operation, it enters standby mode. Operation resumes when the room A unit stops operating.

### Priority when POWERFUL operation is used

#### [Example]

- Room A is the priority room in the examples.  
The indoor units in rooms A, B, C and D are all operating. If the unit in room A enters POWERFUL operation, operation capacity will be concentrated in room A. In such a case, the cooling (heating) efficiency of the units in room B, C and D may be slightly reduced.


### Priority when using OUTDOOR UNIT QUIET operation

#### [Example]

- Room A is the priority room in the examples.  
Just by setting the unit in room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation. You don't have to set all the operated indoor units to QUIET operation.

## 3.12 Quick Reference


# Quick Reference



## 4. FDXS-D Series

### 4.1 Remote Controller

#### ■ Remote Controller



**1. Signal transmitter:**

- It sends signals to the indoor unit.

**2. Display:**

- It displays the current settings.  
(In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

**3. HOME LEAVE button:**

HOME LEAVE operation (page 14.)

**4. POWERFUL button:**

POWERFUL operation (page 12.)

**5. TEMPERATURE adjustment buttons:**

- It changes the temperature setting.

**6. ON/OFF button:**

- Press this button once to start operation.  
Press once again to stop it.

**7. MODE selector button:**

- It selects the operation mode.  
(AUTO/DRY/COOL/HEAT/FAN) (page 10.)

**8. QUIET button:** OUTDOOR UNIT QUIET operation (page 13.)

**9. FAN setting button:**

- It selects the air flow rate setting.

**10. ON TIMER button:** (page 17.)

**11. OFF TIMER button:** (page 16.)

**12. TIMER Setting button:**

- It changes the time setting.

**13. TIMER CANCEL button:**

- It cancels the timer setting.

**14. CLOCK button**

**15. RESET button:**

- Restart the unit if it freezes.  
• Use a thin object to push.

## 4.2 AUTO · DRY · COOL · HEAT · FAN Operation

# AUTO · DRY · COOL · HEAT · FAN Operation

The air conditioner operates with the operation mode of your choice.

From the next time on, the air conditioner will operate with the same operation mode.

### ■ To start operation

#### 1. Press “MODE selector button” and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.

Ⓐ: AUTO

Ⓑ: DRY

❄: COOL



☀: HEAT

🌀: FAN



#### 2. Press “ON/OFF button”.

- The OPERATION lamp lights up.



### ■ To stop operation

#### 3. Press “ON/OFF button” again.

- Then OPERATION lamp goes off.






### ■ To change the temperature setting

#### 4. Press “TEMPERATURE adjustment button”.


DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press “▲” to raise the temperature and press “▼” to lower the temperature.
	Set to the temperature you like. ① 20°F

## ■ To change the air flow rate setting

### 5. Press “FAN setting button”.

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from “  ” to “  ” plus “  ” “  ” are available. 

- Indoor unit quiet operation

When the air flow is set to “”, the noise from the indoor unit will become quieter.

Use this when making the indoor unit quieter.

The unit might lose capacity when the fan strength is set to a weak level.

## NOTE

### ■ Note on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

### ■ Note on COOL operation

- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, performance drops.

### ■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

### ■ Note on AUTO operation

- In AUTO operation, the system selects a temperature setting and an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.

### ■ Note on air flow rate setting

- At smaller air flow rates, the cooling (heating) effect is also smaller.


## 4.3 POWERFUL Operation

# POWERFUL Operation

POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.


### ■ To start POWERFUL operation


#### 1. Press “POWERFUL button”.

- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
- When using POWERFUL operation, there are some functions which are not available.
- “” is displayed on the LCD.

### ■ To cancel POWERFUL operation


#### 2. Press “POWERFUL button” again.

- “” is no longer displayed on the LCD.



## NOTE

### ■ Notes on POWERFUL operation

- POWERFUL Operation cannot be used together with QUIET Operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the “” is no longer displayed on the LCD.
- **In COOL and HEAT mode**  
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting.  
The temperature and air flow settings are not variable.
- **In DRY mode**  
The temperature setting is lowered by 4.5°F (-15.3°C) and the air flow rate is slightly increased.
- **In FAN mode**  
The air flow rate is fixed to the maximum setting.

## 4.4 OUTDOOR UNIT QUIET Operation

# OUTDOOR UNIT QUIET Operation

OUTDOOR UNIT QUIET operation lowers the sound level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

### ■ To start OUTDOOR UNIT QUIET operation


**1. Press “QUIET button”.**

- “” is displayed on the LCD.

### ■ To cancel OUTDOOR UNIT QUIET operation


**2. Press “QUIET button” again.**

- “” disappears from the LCD.



## NOTE

### ■ Note on OUTDOOR UNIT QUIET operation

- This function is available in COOL, HEAT, and AUTO modes. (This is not available in FAN and DRY modes.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote controller or the main unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, “” will remain on the remote controller display.


## 4.5 HOME LEAVE Operation


# HOME LEAVE Operation

HOME LEAVE operation is a function which allows you to record your preferred temperature and air flow rate settings.

### ■ To start HOME LEAVE operation


#### 1. Press “HOME LEAVE button”.


- “” is displayed on the LCD.
- The HOME LEAVE lamp lights up.



### ■ To cancel HOME LEAVE operation

#### 2. Press “HOME LEAVE button” again.







- “” disappears from the LCD.
- The HOME LEAVE lamp goes off.






### Before using HOME LEAVE operation.

#### ■ To set the temperature and air flow rate for HOME LEAVE operation

When using HOME LEAVE operation for the first time, please set the temperature and air flow rate for HOME LEAVE operation. Record your preferred temperature and air flow rate.

	Initial setting		Selectable range	
	Temperature	Air flow rate	Temperature	Air flow rate
Cooling	77°F	“  ”	64-90°F(18-32°C)	5 step, “  ” and “  ”
Heating	77°F	“  ”	50-86°F(10-30°C)	5 step, “  ” and “  ”

1. Press “HOME LEAVE button”. Make sure “” is displayed in the remote controller display.
2. Adjust the set temperature with “” or “” as you like.
3. Adjust the air flow rate with “FAN” setting button as you like.

Home leave operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1 – 3.



## ■ What's the HOME LEAVE operation?

Is there a set temperature and air flow rate which is most comfortable, a set temperature and air flow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and air flow rate. You can start your favorite operation mode simply by pressing the HOME LEAVE button on the remote controller. This function is convenient in the following situations.

### ■ Useful in these cases

#### 1. Use as an energy-saving mode.

Set the temperature 4-5°F higher (cooling) or lower (heating) than normal. Setting the fan strength to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.

##### • Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.



When you return, you will be welcomed by a comfortably air conditioned room.



Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.

##### • Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

#### 2. Use as a favorite mode.

Once you record the temperature and air flow rate settings you most often use, you can retrieve them by pressing HOME LEAVE button. You do not have to go through troublesome remote controller operations.

### NOTE

- Once the temperature and air flow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the "Before using HOME LEAVE operation" section above.
- HOME LEAVE operation is only available in COOL and HEAT mode. Cannot be used in AUTO, DRY, and FAN mode.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time. Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote controller or the indoor unit ON/OFF switch, "🏠" will remain on the remote controller display.

## 4.6 TIMER Operation

### TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

#### ■ To use OFF TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.

##### 1. Press “OFF TIMER button”.

0:00 is displayed.



⦿-○ blinks.

##### 2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

##### 3. Press “OFF TIMER button” again.

- The TIMER lamp lights up.



#### ■ To cancel the OFF TIMER operation

##### 4. Press “CANCEL button”.

- The TIMER lamp goes off.

#### NOTE

- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)

#### ■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (1°F (-17 °C) up in COOL, 4°F (-15.5°C) down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

## ■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.

### 1. Press “ON TIMER button”.

8:00 is displayed.



⊕/⊖ blinks.

### 2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

### 3. Press “ON TIMER button” again.

- The TIMER lamp lights up.




## ■ To cancel ON TIMER operation

### 4. Press “CANCEL button”.

- The TIMER lamp goes off.

## ■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.



## ATTENTION

### ■ In the following cases, set the timer again.

- After a breaker has turned OFF.
- After a power failure.
- After replacing batteries in the remote controller.


## 5. CDXS-L, FDXS-L Series

### 5.1 Remote Controller

# Names of Parts

## Remote Controller

### Signal transmitter




- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is approximately 13ft (4m).

### FAN setting button

- Selects the airflow rate setting. ▶ Page 13

### POWERFUL button

- POWERFUL operation. ▶ Page 14



### Display (LCD)

- Displays the current settings. (In this illustration, each section is shown with all its displays on for the purpose of explanation.)

### TEMPERATURE adjustment buttons

- Changes the temperature setting. ▶ Page 12

### ON/OFF button


- Press this button once to start operation. Press once again to stop it. ▶ Page 11

### Front cover

- Open the front cover. ▶ Page 8

<ARC452A23>


## ■ Open the front cover



## 5.2 AUTO · DRY · COOL · HEAT · FAN Operation



# AUTO · DRY · COOL · HEAT · FAN Operation




The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

### ■ To start operation


#### 1. Press **MODE** and select an operation mode.

- Each pressing of the button advances the mode setting in sequence.



#### 2. Press .

- “**ON**” is displayed on the LCD.
- The OPERATION lamp lights green.



Display


### ■ To stop operation

Press  again.

- “**ON**” is no longer displayed on the LCD.
- The OPERATION lamp goes off.

### NOTE

MODE	Notes on each operation mode
HEAT	<ul style="list-style-type: none"> <li>Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.</li> <li>The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEAT operation, it takes some time before the room gets warmer.</li> <li>In HEAT operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.</li> <li>During defrosting operation, hot air does not flow out of indoor unit.</li> </ul>
COOL	<ul style="list-style-type: none"> <li>This air conditioner cools the room by releasing the heat in the room outside. Therefore, the cooling performance of the air conditioner may be degraded if the outdoor temperature is high.</li> </ul>
DRY	<ul style="list-style-type: none"> <li>The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.</li> </ul>
AUTO	<ul style="list-style-type: none"> <li>In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room and outside temperatures and starts the operation.</li> <li>The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.</li> </ul>
FAN	<ul style="list-style-type: none"> <li>This mode is valid for fan only.</li> </ul>



### ■ To change the temperature setting

Press  or  .

- The displayed items on the LCD will change whenever either one of the buttons is pressed.

COOL operation	HEAT operation	AUTO operation	DRY or FAN operation
64-90°F (18-32°C)	50-86°F (10-30°C)	64-86°F (18-30°C)	The temperature setting is not variable.
Press ▲ to raise the temperature and press ▼ to lower the temperature.			

### ■ Operating conditions

#### ■ Recommended temperature setting

- For cooling: 78-82°F (26-28°C)
- For heating: 68-75°F (20-24°C)

#### ■ Tips for saving energy

- Be careful not to cool (heat) the room too much.  
Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain.  
Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every 2 weeks.

#### ■ Notes on the operating conditions

- The air conditioner always consumes a small amount of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker off.
- Use the air conditioner in the following conditions.


MODE	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature : 50-115°F (10-46°C) Indoor temperature : 64-90°F (18-32°C) Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.)</li> <li>• Condensation may occur on the indoor unit and drip.</li> </ul>
HEAT	Outdoor temperature : 5-75°F (-15-24°C) Indoor temperature : 50-86°F (10-30°C)	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation.</li> </ul>
DRY	Outdoor temperature : 50-115°F (10-46°C) Indoor temperature : 64-90°F (18-32°C) Indoor humidity : 80% max.	<ul style="list-style-type: none"> <li>• A safety device may work to stop the operation.</li> <li>• Condensation may occur on the indoor unit and drip.</li> </ul>

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

## 5.3 Adjusting the Airflow Rate





# Adjusting the Airflow Rate




### ■ To adjust the airflow rate setting

Press .

- Each pressing of  advances the airflow rate setting in sequence.



- When the airflow is set to “”, indoor unit quiet operation will start and the noise from the unit will become quieter.
- In indoor unit quiet operation, the airflow rate is set to a weak level.
- In DRY operation, the airflow rate setting is not variable.

### NOTE

#### ■ Note on airflow rate setting


- At smaller airflow rates, the cooling (heating) effect is also smaller.



## 5.4 POWERFUL Operation




# POWERFUL Operation



POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.


### ■ To start POWERFUL operation

Press  during operation.


- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- “” is displayed on the LCD.

### ■ To cancel POWERFUL operation

Press  again.


- “” is no longer displayed on the LCD.

#### [Example]



### NOTE


#### ■ Notes on POWERFUL operation

- When using POWERFUL operation, there are some functions which are not available.
- POWERFUL operation cannot be used together with ECONO and OUTDOOR UNIT QUIET operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and “” is no longer displayed on the LCD.
- POWERFUL operation will not increase the capacity of the air conditioner if the air conditioner is already in operation with its maximum capacity demonstrated.
- **In COOL, HEAT and AUTO operation**  
To maximize the cooling (heating) effect, the capacity of outdoor unit is increased and the airflow rate is fixed to the maximum setting. The temperature and airflow settings are not variable.
- **In DRY operation**  
The temperature setting is lowered by 4.5°F (2.5°C) and the airflow rate is slightly increased.
- **In FAN operation**  
The airflow rate is fixed to the maximum setting.
- **When using priority-room setting**  
See “Note for multi system”. ▶ Page 19

## 5.5 OUTDOOR UNIT QUIET Operation



# OUTDOOR UNIT QUIET Operation



OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

### ■ To start OUTDOOR UNIT QUIET operation

Press .


- “” is displayed on the LCD.

### ■ To cancel OUTDOOR UNIT QUIET operation

Press again.

- “” is no longer displayed on the LCD.

**[Example]** Using the OUTDOOR UNIT QUIET operation during the night.



- The sound level of the outdoor unit will be lower.  
This is convenient in consideration of your neighbors.

## NOTE


### ■ Notes on OUTDOOR UNIT QUIET operation

- If using a multi system, the OUTDOOR UNIT QUIET operation will work only when this function is set on all operated indoor units. However, if using priority room setting, refer to note for multi system. [▶ Page 19](#)
- This function is available in COOL, HEAT, and AUTO operation.  
(This is not available in FAN and DRY operation.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.  
Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote controller or the indoor unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, “” will remain on the remote controller display.
- OUTDOOR UNIT QUIET operation will drop neither the frequency nor fan speed if the frequency and fan speed have been already dropped low enough.

## 5.6 ECONO Operation



# ECONO Operation



ECONO operation is a function which enables efficient operation by limiting the maximum power consumption value.

This function is useful for cases in which attention should be paid to ensure a circuit breaker will not trip when the product runs alongside other appliances.


### ■ To start ECONO operation

Press  during operation.

- “” is displayed on the LCD.

### ■ To cancel ECONO operation

Press  again.

- “” is no longer displayed on the LCD.


### [Example]

#### Normal operation




- In case the air conditioner and other appliances which require high power consumption are used at same time, a circuit breaker may trip if the air conditioner operate with its maximum capacity.

#### ECONO operation




- The maximum power consumption of the air conditioner is limited by using ECONO operation. The circuit breaker is unlikely to trip even if the air conditioner and other appliances are used at same time.
- This diagram is a representation for illustrative purposes only. The maximum running current and power consumption of the air conditioner in ECONO operation vary with the connecting outdoor unit.



## NOTE


### ■ Notes on ECONO operation

- ECONO operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the “” is no longer displayed on the LCD.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY, and HEAT operation.
- POWERFUL and ECONO operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- If the level of power consumption is already low, ECONO operation will not drop the power consumption.

## 5.7 OFF TIMER Operation



# OFF TIMER Operation



Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

### ■ To use OFF TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **OFF** .



"0:00" is displayed on the LCD.  
"OFF" blinks.


- "⌚" is no longer displayed on the LCD.

#### 2. Press **SELECT** until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.  
Holding down either button changes the time setting rapidly.

#### 3. Press **OFF** again.

- "OFF" and setting time are displayed on the LCD.
- The TIMER lamp lights yellow.



Display

### ■ To cancel OFF TIMER operation

#### Press **CANCEL** .

- "OFF" and setting time are no longer displayed on the LCD.
- "⌚" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

### NOTE

#### ■ Notes on TIMER operation

- When TIMER is set, the present time is not displayed.
- Once you set ON/OFF TIMER, the time setting is kept in the memory. The memory is canceled when remote controller batteries are replaced.
- When operating the unit via the ON/OFF TIMER, the actual length of operation may vary from the time entered by the user. (Maximum approximately 10 minutes)


#### ■ NIGHT SET mode

- When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.9°F (0.5°C) up in COOL, 3.6°F (2.0°C) down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

## 5.8 ON TIMER Operation



### ON TIMER Operation



#### ■ To use ON TIMER operation

- Check that the clock is correct.  
If not, set the clock to the present time.

#### 1. Press **ON** .



"6:00" is displayed on the LCD.

"ON" blinks.


- "⊕" is no longer displayed on the LCD.

#### 2. Press **SELECT** until the time setting reaches the point you like.

- Each pressing of either button increases or decreases the time setting by 10 minutes.  
Holding down either button changes the setting rapidly.

#### 3. Press **ON** again.

- "ON" and setting time are displayed on the LCD.
- The TIMER lamp lights yellow.



Display


#### ■ To cancel ON TIMER operation

#### Press **CANCEL** .

- "ON" and setting time are no longer displayed on the LCD.
- "⊕" and day of the week are displayed on the LCD.
- The TIMER lamp goes off.

#### ■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the 2 timers is shown below.



#### NOTE

##### ■ In the following cases, set the timer again.

- After a breaker has turned off.
- After a power failure.
- After replacing batteries in the remote controller.

## 5.9 Note for Multi System


# Note for Multi System

Multi system has one outdoor unit connected to multiple indoor units.

### ■ Selecting the operation mode

#### With the priority room setting present but inactive or not present.

When more than one indoor unit is operating, priority is given to the first unit that was turned on.  
In this case, set the units that are turned on later to the same operation mode as the first unit.  
Otherwise, they will enter the standby state, and the OPERATION lamp will flash: this does not indicate malfunction.



### NOTE

#### ■ Notes on operation mode for multi system

- COOL, DRY and FAN operation may be used at the same time.
- AUTO operation automatically selects COOL operation or HEAT operation based on the room temperature.  
Therefore, AUTO operation is available when selecting the same operation mode as that of the room with the first unit to be turned on.

### ⚠ CAUTION

- Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.  
If the operation mode of the first room is FAN operation, then using HEAT operation in any room after this will give priority to HEAT operation. In this situation, the air conditioner running in FAN operation will go on standby, and the OPERATION lamp will flash.

#### With the priority room setting active.

Refer to priority room setting on the next page.

### ■ NIGHT QUIET mode (Available only for COOL operation)

NIGHT QUIET mode requires initial programming during installation. Please consult your retailer or dealer for assistance.  
NIGHT QUIET mode reduces the operation noise of the outdoor unit during the nighttime hours to prevent annoyance to neighbors.

- The NIGHT QUIET mode is activated when the temperature drops 10.8°F (6°C) or more below the highest temperature recorded that day.  
Therefore, when the temperature difference is less than 7.2°F (4°C), this function will not be activated.
- NIGHT QUIET mode reduces slightly the cooling efficiency of the unit.

### ■ OUTDOOR UNIT QUIET operation

Refer to OUTDOOR UNIT QUIET operation. ▶Page 15

#### With the priority room setting present but inactive or not present.

When using the OUTDOOR UNIT QUIET operation feature with the multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controllers.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote controller. However OUTDOOR UNIT QUIET operation display remains on the remote controller for other rooms.

We recommend you release all rooms using their remote controllers.

#### With the priority room setting active.

Refer to priority room setting on the next page.

## ■ COOL/HEAT mode lock

The COOL/HEAT mode lock requires initial programming during installation. Please consult your authorized dealer for assistance. The COOL/HEAT mode lock sets the unit forcibly to either COOL or HEAT operation. This function is convenient when you wish to set all indoor units connected to the multi system to the same operation mode.

### NOTE

- The COOL/HEAT mode lock cannot be activated together with the priority room setting.

## ■ Priority room setting

The priority room setting requires initial programming during installation. Please consult your authorized dealer for assistance. The room designated as the priority room takes priority in the following situations.

### Operation mode priority

- As the operation mode of the priority room takes precedence, the user can select a different operation mode from other rooms.

#### [Example]

- Room A is the priority room in the examples.  
When COOL operation is selected in room A while operating the following modes in room B, C and D :

Operation mode in room B, C and D	Status of room B, C and D when the unit in room A is in COOL operation
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters standby mode. Operation resumes when the room A unit stops operating.
AUTO	If the unit is set to COOL operation, it continues. If the unit is set to HEAT operation, it enters standby mode. Operation resumes when the room A unit stops operating.

### Priority when POWERFUL operation is used

#### [Example]

- Room A is the priority room in the examples.  
The indoor units in rooms A, B, C and D are all operating. If the unit in room A enters POWERFUL operation, operation capacity will be concentrated in room A. In such a case, the cooling (heating) efficiency of the units in room B, C and D may be slightly reduced.


### Priority when using OUTDOOR UNIT QUIET operation

#### [Example]

- Room A is the priority room in the examples.  
Just by setting the unit in room A to QUIET operation, the air conditioner starts OUTDOOR UNIT QUIET operation. You don't have to set all the operated indoor units to QUIET operation.

## 5.10 Quick Reference

# Quick Reference





# Part 6

## Service Diagnosis

1. Troubleshooting with LED .....	135
1.1 Indoor Unit.....	135
1.2 Outdoor Unit.....	136
2. Problem Symptoms and Measures .....	137
3. Service Check Function .....	138
3.1 ARC452 Series Remote Controller .....	138
3.2 ARC433 Series Remote Controller .....	141
4. Code Indication on Remote Controller .....	144
4.1 Indoor Unit.....	144
4.2 Outdoor Unit.....	145
5. Troubleshooting for Indoor Unit.....	146
5.1 Indoor Unit PCB Abnormality .....	146
5.2 Freeze-up Protection Control or Heating Peak-cut Control.....	148
5.3 Fan Motor or Related Abnormality .....	150
5.4 Thermistor or Related Abnormality (Indoor Unit).....	153
5.5 Signal Transmission Error (between Indoor Unit and Outdoor Unit) .....	154
5.6 Unspecified Voltage (between Indoor Unit and Outdoor Unit) .....	155
6. Troubleshooting for Outdoor Unit.....	156
6.1 Refrigerant Shortage .....	156
6.2 Low-voltage Detection or Over-voltage Detection.....	159
6.3 Signal Transmission Error (on Outdoor Unit PCB) (24/32 Class Only) ....	161
6.4 Unspecified Voltage (between Indoor Unit and Outdoor Unit) / Anti-icing Function in Other Rooms.....	162
6.5 Anti-icing Function.....	163
6.6 Outdoor Unit PCB Abnormality (24/32 Class Only) .....	165
6.7 OL Activation (Compressor Overload) .....	166
6.8 Compressor Lock .....	167
6.9 DC Fan Lock .....	168
6.10 Input Overcurrent Detection .....	169
6.11 Four Way Valve Abnormality (18 Class Only) .....	170
6.12 Discharge Pipe Temperature Control.....	172
6.13 High Pressure Control in Cooling .....	173
6.14 Compressor Sensor System Abnormality (24/32 Class Only).....	174
6.15 Position Sensor Abnormality .....	176
6.16 CT or Related Abnormality .....	179
6.17 Thermistor or Related Abnormality (Outdoor Unit).....	181
6.18 Electrical Box Temperature Rise.....	183
6.19 Radiation Fin Temperature Rise .....	186
6.20 Output Overcurrent Detection .....	189
7. Check.....	191
7.1 Thermistor Resistance Check .....	191

7.2	Fan Motor Connector Check .....	192
7.3	Hall IC Check .....	192
7.4	Power Supply Waveform Check.....	193
7.5	Outdoor Electronic Expansion Valve Check.....	194
7.6	Four Way Valve Performance Check .....	195
7.7	Inverter Unit Refrigerant System Check.....	195
7.8	“Inverter Checker” Check .....	196
7.9	Rotation Pulse Check on the Outdoor Unit PCB .....	197
7.10	Installation Condition Check.....	198
7.11	Discharge Pressure Check.....	198
7.12	Outdoor Fan System Check .....	199
7.13	Main Circuit Short Check.....	199
7.14	Capacitor Voltage Check.....	200
7.15	Power Module Check .....	201

# 1. Troubleshooting with LED

## 1.1 Indoor Unit


### Operation Lamp

The operation lamp blinks when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated, or when the thermistor malfunctions.
  2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following pages.


#### CTXS/FTXS series

(Ex: CTXS07LVJU, FTXS09/12LVJU)



#### CDXS/FDXS series

(Ex: FDXS09/12LVJU, CDXS15/18LVJU)



### Caution:

When operation stops suddenly and the operation lamp blinks, it could be "operation mode conflict".

Check followings;

Are the operation modes all the same for the indoor units connected to multi system outdoor unit?  
If not, set all the indoor units to the same operation mode and confirm that the operation lamp is not blinking.

Moreover, when the operation mode is automatic, set all the indoor unit operation mode as "cooling" or "heating" and check again if the operation lamp is normal.


If the lamp stops blinking after the above steps, there is no malfunction.

\* Operation stops and operation lamp blinks only for indoor unit which different operation mode is set later. (The first set operation mode has priority.)

### Service Monitor

The indoor unit has one green LED (LED A) on the control PCB. When the microcomputer works in order, the LED A blinks.

## 1.2 Outdoor Unit



The outdoor unit has a green LED (LED A) and red LEDs (LED 1 ~ LED 4) on the PCB. When the microcomputer works in order, the LED A blinks, and when the system is in normal condition, the red LEDs are OFF. Even after the error is canceled and the unit operates in normal condition, the LED indication remains.


## 2. Problem Symptoms and Measures


Problem Symptom	Check Item	Details of Measure	Reference Page
None of the units operates.	Check the power supply.	Check if the rated voltage is supplied.	—
	Check the types of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor temperature.	Heating operation cannot be used when the outdoor temperature is 59.9°F (15.5°C) or higher, and cooling operation cannot be used when the outdoor temperature is below 14°F (−10°C).	—
	Diagnose with remote controller indication	—	144, 145
	Check the remote controller addresses.	Check if address settings for the remote controller and indoor unit are correct.	265
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor temperature.	Heating operation cannot be used when the outdoor temperature is 59.9°F (15.5°C) or higher, and cooling operation cannot be used when the outdoor temperature is below 14°F (−10°C).	—
	Diagnose with remote controller indication.	—	144, 145
Some indoor units do not operate.	Check the type of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	—
	Diagnose with remote controller indication	—	144, 145
Units operate but do not cool, or do not heat.	Check for wiring and piping errors in the connection between the indoor and outdoor units.	Check the wiring and piping. Conduct the wiring error check.	—
	Check for thermistor detection errors.	Check if the thermistor is mounted securely.	—
	Check for faulty operation of the outdoor electronic expansion valve.	Set all the units to cooling operation, and compare the temperatures of the liquid pipes to see if the each outdoor electronic expansion valve works.	—
	Diagnose with remote controller indication.	—	144, 145
	Diagnose by service port pressure and operating current.	Check for refrigerant shortage.	156
Large operating noise and vibrations	Check the output voltage of the power module.	—	201
	Check the power module.	—	—
	Check the installation condition.	Check if the required spaces for installation (specified in the installation manual) are provided.	—

## 3. Service Check Function

### 3.1 ARC452 Series Remote Controller

#### Check Method 1

1. When the timer cancel button is held down for 5 seconds,  is displayed on the temperature display screen.



(R14460)

2. Press the timer cancel button repeatedly until a long beep sounds.
  - The code indication changes in the sequence shown below.


No.	Code	No.	Code	No.	Code
1	00	13	07	25	UR
2	04	14	R3	26	UH
3	LS	15	H8	27	P4
4	E6	16	H9	28	L3
5	H6	17	09	29	L4
6	H0	18	04	30	H7
7	R6	19	05	31	U2
8	07	20	J3	32	ER
9	U0	21	J6	33	RM
10	F3	22	E5	34	FR
11	R5	23	R1	35	H1
12	F6	24	E1	36	P9


**Note:**


1. A short beep or two consecutive beeps indicate non-corresponding codes.
2. To return to the normal mode, hold the timer cancel button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
3. Not all the error codes are displayed. When you cannot find the error code, try the check method 2. (→ Refer to page 139.)

**Check Method 2**


1. Press the 3 buttons (TEMP▲, TEMP▼, MODE) at the same time to enter the diagnosis mode.



The left-side number blinks.




2. Press the [TEMP] ▲ or ▼ button and change the number until you hear the two consecutive beeps or the long beep.




3. Diagnose by the sound.

- ★beep : The left-side number does not correspond with the error code.
- ★two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
- ★long beep : Both the left-side and right-side number correspond with the error code.  
The numbers indicated when you hear the long beep are the error code.  
Error codes and description → Refer to page 144, 145.


4. Press the [MODE] button.




The right-side number blinks.




5. Press the [TEMP] ▲ or ▼ button and change the number until you hear the long beep.




6. Diagnose by the sound.
- ★beep : The left-side number does not correspond with the error code.
  - ★two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
  - ★long beep : Both the left-side and right-side number corresponds with the error code.
7. Determine the error code.  
The numbers indicated when you hear the long beep are the error code.  
Error codes and description → Refer to page 144, 145.
8. Press the [MODE] button to exit from the diagnosis mode.



The display 7~ means the trial operation mode.  
Refer to page 259 for trial operation.



9. Press the [ON/OFF] button twice to return to the normal mode.





**Note:** When the remote controller is left untouched for 60 seconds, it returns to the normal mode.



## 3.2 ARC433 Series Remote Controller

### Check Method 1

1. When the timer cancel button is held down for 5 seconds,  is displayed on the temperature display screen.



2. Press the timer cancel button repeatedly until a long beep sounds.
  - The code indication changes in the sequence shown below.


No.	Code	No.	Code	No.	Code
1	00	12	E7	23	H0
2	U4	13	H8	24	E1
3	F3	14	J3	25	P4
4	E6	15	R3	26	L3
5	L5	16	R1	27	L4
6	R6	17	E4	28	H6
7	E5	18	E5	29	H7
8	F6	19	H9	30	U2
9	E9	20	J6	31	U4
10	U0	21	U8	32	E8
11	E7	22	R5	33	R4


**Note:**


1. A short beep or two consecutive beeps indicate non-corresponding codes.
2. To return to the normal mode, hold the timer cancel button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
3. Not all the error codes are displayed. When you cannot find the error code, try the check method 2. (→ Refer to page 142.)

## Check Method 2


1. Press the center of the [TEMP] button and the [MODE] button at the same time to enter the diagnosis mode.



The left-side number blinks.




2. Press the [TEMP] ▲ or ▼ button and change the number until you hear the two consecutive beeps or the long beep.




3. Diagnose by the sound.

- ★ beep : The left-side number does not correspond with the error code.
- ★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
- ★ long beep : Both the left-side and right-side numbers correspond with the error code.  
The numbers indicated when you hear the long beep are the error code.  
Error codes and description → Refer to page 144, 145.


4. Press the [MODE] button.



The right-side number blinks.




5. Press the [TEMP] ▲ or ▼ button and change the number until you hear the long beep.




6. Diagnose by the sound.
- ★ beep : The left-side number does not correspond with the error code.
  - ★ two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
  - ★ long beep : Both the left-side and right-side numbers correspond with the error code.

7. Determine the error code.  
The numbers indicated when you hear the long beep are the error code.  
Error codes and description → Refer to page 144, 145.


8. Press the [MODE] button to exit from the diagnosis mode.



The display **7<sup>-</sup>** means the trial operation mode.  
Refer to page 259 for trial operation.



9. Press the [ON/OFF] button twice to return to the normal mode.



**Note:** When the remote controller is left untouched for 60 seconds, it returns to the normal mode.

## 4. Code Indication on Remote Controller

### 4.1 Indoor Unit



























































































Error Codes	Description		Reference Page
00	Normal condition		—
P1	Indoor unit PCB abnormality		146
P5	Freeze-up protection control or heating peak-cut control		148
P6	Fan motor or related abnormality	DC motor (CTXS/FTXS series)	150
		AC motor (CDXS/FDXS series)	152
C4	Indoor heat exchanger thermistor or related abnormality		153
C9	Room temperature thermistor or related abnormality		153
U4	Signal transmission error (between indoor unit and outdoor unit)		154
UR	Unspecified voltage (between indoor unit and outdoor unit)		155

## 4.2 Outdoor Unit

☀: ON, ●: OFF, ⚡: Blinks

Green : Blinks in normal condition

Red : OFF in normal condition

Outdoor Unit LED Indication					Error Codes	Description	Reference Page
Green	Red						
A	1	2	3	4			
					00	Normal condition	—
					UR	Unspecified voltage (between indoor unit and outdoor unit)	162
					UH	Anti-icing function in other rooms	162
					(UQ)	Refrigerant shortage	156
					U2	Low-voltage detection or over-voltage detection	159
					U7	Signal transmission error (on outdoor unit PCB) (24/32 class only)	161
					RS	Anti-icing function	163
					E1	Outdoor unit PCB abnormality (24/32 class only)	165
					(ES)	OL activation (compressor overload)	166
					(EE)	Compressor lock	167
					E7	DC fan lock	168
					E8	Input overcurrent detection	169
					ER	Four-way valve abnormality (18 class only)	170
					F3	Discharge pipe temperature control	172
					FE	High pressure control in cooling	173
					H0	Compressor sensor system abnormality (24/32 class only)	174
					H5	Position sensor abnormality	176
					H8	CT or related abnormality	179
					H9	Outdoor temperature thermistor or related abnormality	181
					U3	Discharge pipe thermistor or related abnormality	181
					U5	Outdoor heat exchanger thermistor or related abnormality	181
					U8	Liquid pipe thermistor or related abnormality	181
					U9	Gas pipe thermistor or related abnormality	181
					P4	Radiation fin thermistor or related abnormality	181
					L3	Electrical box temperature rise	183
					L4	Radiation fin temperature rise	186
					L5	Output overcurrent detection	189



### Note:

- The error codes in the parenthesis ( ) are displayed only when the system is shut down.
- When a sensor error occurs, check the remote controller display to determine which sensor is malfunctioning.  
If the remote controller does not indicate the error code, conduct the following procedure.  
\* Turn the power switch off and back on again. If the same LED indication appears again immediately after the power is turned on, the fault is in the thermistor.  
\* If the above condition does not result, the fault is in the CT.
- The indoor unit error code may take the precedence in the remote controller display.

## 5. Troubleshooting for Indoor Unit

### 5.1 Indoor Unit PCB Abnormality

Remote  
Controller  
Display

81

Method of  
Malfunction  
Detection

The system checks if the circuit works properly within the microcomputer of the indoor unit.


Malfunction  
Decision  
Conditions

The system cannot set the internal settings.

Supposed  
Causes

- Wrong models interconnected
- Defective indoor unit PCB
- Disconnection of connector
- Reduction of power supply voltage

# Troubleshooting



(R15270)

**i Note:** Check the following connector.

Model Type	Connector
CTXS/FTXS series	Terminal board ~ Control PCB
CDXS/FDXS series	Terminal board ~ Control PCB

## 5.2 Freeze-up Protection Control or Heating Peak-cut Control

Remote  
Controller  
Display

RS

Method of  
Malfunction  
Detection

- Freeze-up protection control  
During cooling operation, the freeze-up protection control (operation halt) is activated according to the temperature detected by the indoor heat exchanger thermistor.
- Heating peak-cut control  
During heating operation, the temperature detected by the indoor heat exchanger thermistor is used for the heating peak-cut control (operation halt, outdoor fan stop, etc.)

Malfunction  
Decision  
Conditions

- Freeze-up protection control  
During cooling operation, the indoor heat exchanger temperature is below (32°F (0°C)).
- Heating peak-cut control  
During heating operation, the indoor heat exchanger temperature is above 149°F (65°C).

Supposed  
Causes

- Short-circuited air
- Clogged air filter of the indoor unit
- Dust accumulation on the indoor heat exchanger
- Defective indoor heat exchanger thermistor
- Defective indoor unit PCB



# Troubleshooting




**Check No.01**  
**Refer to P.191**



## Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15715)

## 5.3 Fan Motor or Related Abnormality

### 5.3.1 DC Motor (CTXS/FTXS Series)

Remote  
Controller  
Display

RG

Method of  
Malfunction  
Detection

The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction  
Decision  
Conditions

The detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.

Supposed  
Causes

- Layer short inside the fan motor winding
- Breaking of wire inside the fan motor
- Breaking of the fan motor lead wires
- Defective capacitor of the fan motor
- Defective indoor unit PCB

# Troubleshooting




**Check No.02**  
Refer to P.192



## Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R14970)

### 5.3.2 AC Motor (CDXS/FDXS Series)

Remote  
Controller  
Display



Method of  
Malfunction  
Detection

The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction  
Decision  
Conditions

The detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.


Supposed  
Causes

- Layer short inside the fan motor winding
- Breaking of wire inside the fan motor
- Breaking of the fan motor lead wires
- Defective capacitor of the fan motor
- Defective indoor unit PCB

#### Troubleshooting



Check No.04  
Refer to P.192



(R17393)

# 5.4 Thermistor or Related Abnormality (Indoor Unit)

Remote  
Controller  
Display

Ⓔ4, Ⓔ9

Method of  
Malfunction  
Detection

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction  
Decision  
Conditions

The thermistor input is more than 4.96 V or less than 0.04 V during compressor operation.

Supposed  
Causes

- Disconnection of connector
- Defective thermistor
- Defective indoor unit PCB

Troubleshooting




Check No.01  
Refer to P.191



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15717)

Ⓔ4 : Indoor heat exchanger thermistor  
Ⓔ9 : Room temperature thermistor

## 5.5 Signal Transmission Error (between Indoor Unit and Outdoor Unit)

Remote  
Controller  
Display



Method of  
Malfunction  
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction  
Decision  
Conditions

The data sent from the outdoor unit cannot be received normally, or the content of the data is abnormal.

Supposed  
Causes

- Wiring error
- Breaking of the connection wires between the indoor and outdoor units (wire No. 3)
- Defective outdoor unit PCB
- Defective indoor unit PCB
- Disturbed power supply waveform

Troubleshooting




Check No.11  
Refer to P.193



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15782)

# 5.6 Unspecified Voltage (between Indoor Unit and Outdoor Unit)

Remote  
Controller  
Display



Method of  
Malfunction  
Detection

The supply power is detected for its requirements (different from pair type and multi type) by the indoor / outdoor transmission signal.

Malfunction  
Decision  
Conditions

The pair type and multi type are interconnected.

Supposed  
Causes


- Wrong models interconnected
- Wrong wiring of connecting wires
- Wrong indoor unit PCB or outdoor unit PCB mounted
- Defective indoor unit PCB
- Defective outdoor unit PCB

Troubleshooting



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R11707)

## 6. Troubleshooting for Outdoor Unit

### 6.1 Refrigerant Shortage

Remote  
Controller  
Display



Outdoor Unit LED  
Display



Method of  
Malfunction  
Detection

#### Refrigerant shortage detection I :

Refrigerant shortage is detected by checking the input current value and the compressor output frequency. If the refrigerant is short, the input current is smaller than the normal value.

#### Refrigerant shortage detection II :

Refrigerant shortage is detected by checking the discharge pipe temperature and the opening of the outdoor electronic expansion valve. If the refrigerant is short, the discharge pipe temperature tends to rise.

Malfunction  
Decision  
Conditions

#### Refrigerant shortage detection I:

The following conditions continue for 7 minutes.

##### <18 class>

- ◆ Input current × input voltage ≤ **A** × output frequency + **B**
- ◆ Output frequency > **C**

<b>A</b> (–)	<b>B</b> (W)	<b>C</b> (Hz)
1756/256	50	55

##### <24/32 class>

- ◆ Input current ≤ **D** × output frequency + **E**
- ◆ Output frequency > **F**

<b>D</b> (–)	<b>E</b> (A)	<b>F</b> (Hz)
27/1000	2	40

#### Refrigerant shortage detection II:

The following conditions continue for 80 seconds.

- ◆ Opening of the outdoor electronic expansion valve ≥ **G**
- ◆ Discharge pipe temperature (°C) > **H** × target discharge pipe temperature (°C) + **J** (°C)  
(Discharge pipe temperature (°F) > **H** × target discharge pipe temperature (°F) + **K** (°F))

<b>G</b> (pulse)	<b>H</b> (–)	<b>J</b> (°C)	<b>K</b> (°F)
450	255/256	cooling: 20, heating: 40	cooling: 36.1, heating: 72.1

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

Supposed  
Causes

- Disconnection of the discharge pipe thermistor, indoor or outdoor heat exchanger thermistor, room or outdoor temperature thermistor
- Closed stop valve
- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Defective outdoor electronic expansion valve



Troubleshooting



Check No.01  
Refer to P.191




Check No.12  
Refer to P.194

18 class



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R17365)

## Troubleshooting



Check No.01  
Refer to P.191




Check No.12  
Refer to P.194

24/32 class

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.








(R17254)

## 6.2 Low-voltage Detection or Over-voltage Detection

### Remote Controller Display

U2

### Outdoor Unit LED Display

A  1  2  3  4 

### Method of Malfunction Detection

#### ★ Indoor Unit

The zero-cross detection of the power supply is evaluated by the indoor unit PCB.

#### ★ Outdoor Unit

##### Low-voltage detection:

An abnormal voltage drop is detected by the DC voltage detection circuit.

##### Over-voltage detection:

An abnormal voltage rise is detected by the over-voltage detection circuit.

### Malfunction Decision Conditions

#### ★ Indoor Unit

There is no zero-cross detection in approximately 10 seconds.

#### ★ Outdoor Unit

##### Low-voltage detection:

- The voltage detected by the DC voltage detection circuit is below 150 V for 0.1 second.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

##### Over-voltage detection:

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer.
- The compressor stops if the error occurs, and restarts automatically after 3-minute standby.

### Supposed Causes


- Supply voltage is not as specified.
- Defective DC voltage detection circuit
- Defective over-voltage detection circuit
- Defective PAM control part
- Disconnection of compressor harness
- Noise
- Momentary fall of voltage
- Momentary power failure
- Defective indoor unit PCB

## Troubleshooting









### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R17269)

# 6.3 Signal Transmission Error (on Outdoor Unit PCB) (24/32 Class Only)

Remote Controller Display	
Outdoor Unit LED Display	A  1  2  3  4 
Method of Malfunction Detection	Communication error between microcomputer mounted on the main PCB and PM1.
Malfunction Decision Conditions	<ul style="list-style-type: none"><li>■ The abnormality is determined when the data sent from the PM1 can not be received for 9 seconds.</li><li>■ The error counter is reset when the data from the PM1 can be successfully received.</li></ul>
Supposed Causes	<ul style="list-style-type: none"><li>■ Defective outdoor unit PCB</li></ul>

## Troubleshooting








(R7185)

## 6.4 Unspecified Voltage (between Indoor Unit and Outdoor Unit) / Anti-icing Function in Other Rooms

Remote  
Controller  
Display

UR, UR

Outdoor Unit LED  
Display

A  1  2  3  4 

Method of  
Malfunction  
Detection

A wrong connection is detected by checking the combination of indoor and outdoor units on the microcomputer.

Malfunction  
Decision  
Conditions

- Anti-icing function in other rooms
- Unspecified internal and/or external voltages
- Mismatching of indoor and outdoor units

Supposed  
Causes


- Anti-icing function in other rooms
- Wrong models interconnected
- Wrong indoor unit PCB or outdoor unit PCB mounted

### Troubleshooting



#### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15723)








**Note:** Refer to “Anti-icing function” on page 163 for detail.

## 6.5 Anti-icing Function

### Remote Controller Display

RS

### Outdoor Unit LED Display

A  1  2  3  4 

### Method of Malfunction Detection

During cooling operation, indoor unit icing is detected by checking the temperatures sensed by the indoor heat exchanger thermistor and room temperature thermistor that are located in a shut-down room.

### Malfunction Decision Conditions

- In cooling operation, the both conditions (A) and (B) are met for 5 minutes.  
(A) Room temperature – Indoor heat exchanger temperature  $\geq 18^{\circ}\text{F}$  ( $10^{\circ}\text{C}$ )  
(B) Indoor heat exchanger temperature  $\leq 30.2^{\circ}\text{F}$  ( $-1^{\circ}\text{C}$ )
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

### Supposed Causes

- Wrong wiring or piping
- Defective outdoor electronic expansion valve
- Short-circuited air
- Defective indoor heat exchanger thermistor
- Defective room temperature thermistor

## Troubleshooting




**Check No.01**  
Refer to P.191



**Check No.12**  
Refer to P.194

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R17255)




# 6.6 Outdoor Unit PCB Abnormality (24/32 Class Only)

Remote  
Controller  
Display



Outdoor Unit LED  
Display



Method of  
Malfunction  
Detection

Detect within the program of the microcomputer.


Malfunction  
Decision  
Conditions

The program of the microcomputer is in abnormal running order.

Supposed  
Causes

- Defective outdoor unit PCB
- Noise
- Momentary fall of voltage
- Momentary power failure

## Troubleshooting



(R7183)

## 6.7 OL Activation (Compressor Overload)

Remote  
Controller  
Display



Outdoor Unit LED  
Display

A 1 2 3 4

Method of  
Malfunction  
Detection

A compressor overload is detected through compressor OL.

Malfunction  
Decision  
Conditions

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error
- \* The operating temperature condition is not specified.

Supposed  
Causes

- Defective discharge pipe thermistor
- Defective outdoor electronic expansion valve or coil
- Defective four way valve or coil
- Defective outdoor unit PCB
- Refrigerant shortage
- Water mixed in refrigerant
- Defective stop valve

### Troubleshooting



**Check No.01**  
Refer to P.191



**Check No.12**  
Refer to P.194



**Check No.13**  
Refer to P.195




**Check No.14**  
Refer to P.195



#### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R14438)

# 6.8 Compressor Lock

Remote  
Controller  
Display



Outdoor Unit LED  
Display



Method of  
Malfunction  
Detection

A compressor lock is detected by checking the compressor running condition through the position detection circuit.

Malfunction  
Decision  
Conditions

- Judging from the current waveform generated when high-frequency voltage is applied to the compressor.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed  
Causes

- Compressor locked

## Troubleshooting




**Check No.15**  
Refer to P.196



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.  
(Precaution before turning on the power again)  
Make sure the power has been off for at least 30 seconds.



(R14439)

## 6.9 DC Fan Lock

Remote  
Controller  
Display



Outdoor Unit LED  
Display

A 1 2 3 4

Method of  
Malfunction  
Detection

An error is determined with the high-voltage fan motor rotation speed detected by the Hall IC.

Malfunction  
Decision  
Conditions

- The fan does not start in 30 seconds even when the fan motor is running.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed  
Causes

- Disconnection of the fan motor
- Foreign matter stuck in the fan
- Defective fan motor
- Defective outdoor unit PCB

### Troubleshooting




Check No.16  
Refer to P.197



#### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R15890)

# 6.10 Input Overcurrent Detection

Remote  
Controller  
Display



Outdoor Unit LED  
Display



Method of  
Malfunction  
Detection

Detected by checking the input current value

Malfunction  
Decision  
Conditions

- The input current is at a certain value (depending on the condition) for 2.5 seconds.
- The compressor halts if the error occurs, and restarts automatically after 3-minute standby.

Supposed  
Causes

- Outdoor temperature is out of operation range.
- Defective compressor
- Defective power module
- Defective outdoor unit PCB
- Short circuit

## Troubleshooting



**Check No.15**  
Refer to P.196



**Check No.17**  
Refer to P.198




**Check No.18**  
Refer to P.198



### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

\* An input overcurrent may result from wrong internal wiring. If the system is interrupted by an input overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.







(R15325)

## 6.11 Four Way Valve Abnormality (18 Class Only)

Remote  
Controller  
Display

ER

Outdoor Unit LED  
Display

A  1  2  3  4 

Method of  
Malfunction  
Detection

The liquid pipe thermistor and the outdoor heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.

Malfunction  
Decision  
Conditions

Either of the following conditions occurs 6 minutes after the compressor has started.

- Cooling operation  
The lowest liquid pipe temperature among the rooms in operation –Tde > 5°C (41°F)
- Heating operation  
The highest liquid pipe temperature among the rooms in operation –Tde < 0°C (32°F)

Tde: outdoor heat exchanger temperature

Supposed  
Causes

- Poor connector contact
- Defective thermistor
- Defective outdoor unit PCB
- Defective four-way valve, coil, or harness
- Foreign substance mixed in refrigerant

# Troubleshooting



**Check No.01**  
Refer to P.191



**Check No.13**  
Refer to P.195




**Check No.14**  
Refer to P.195



## Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



## 6.12 Discharge Pipe Temperature Control

Remote  
Controller  
Display



Outdoor Unit LED  
Display

A 1 2 3 4

Method of  
Malfunction  
Detection

Detected by the discharge pipe thermistor

Malfunction  
Decision  
Conditions

- If the temperature detected by the discharge pipe thermistor rises above **A**, the compressor stops.
- The error is cleared when the discharge pipe temperature is dropped below **B**.

A	B
248°F(120°C)	224.6°F(107°C)

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

Supposed  
Causes

- Defective discharge pipe thermistor  
(Defective outdoor heat exchanger thermistor or outdoor temperature thermistor)
- Defective outdoor electronic expansion valve or coil
- Refrigerant shortage
- Defective four-way valve
- Water mixed in refrigerant
- Defective stop valve
- Defective outdoor unit PCB

### Troubleshooting



Check No.01  
Refer to P.191



Check No.12  
Refer to P.194




Check No.14  
Refer to P.195



#### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.





# 6.13 High Pressure Control in Cooling

Remote  
Controller  
Display



Outdoor Unit LED  
Display

A 1 2 3 4

Method of  
Malfunction  
Detection

High pressure control (operation halt, frequency drop, etc.) is activated in cooling operation if the temperature sensed by the outdoor heat exchanger thermistor exceeds the limit.

Malfunction  
Decision  
Conditions

- The temperature sensed by the outdoor heat exchanger thermistor rises above about 65°C (149°F).
- The error is cleared when the temperature drops below about 50°C (122°F).

Supposed  
Causes

- The installation space is not large enough.
- Dirty outdoor heat exchanger
- Defective outdoor fan motor
- Defective stop valve
- Defective outdoor electronic expansion valve or coil
- Defective outdoor heat exchanger thermistor
- Defective outdoor unit PCB

## Troubleshooting



Check No.01  
Refer to P.191



Check No.12  
Refer to P.194



Check No.17  
Refer to P.198



Check No.18  
Refer to P.198





Check No.19  
Refer to P.199



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.


Check the installation space.



NG

Change the installation location or direction.  
Clean the outdoor heat exchanger.


OK



NG

Replace the outdoor fan motor.  
Reconnect the connector or fan motor lead wires.


OK



NG

Replace the stop valve.


OK



NG

Replace the outdoor electronic expansion valve or the coil.  
Replace the outdoor unit PCB.

OK



NG






Replace the outdoor heat exchanger thermistor.

OK

Replace the outdoor unit PCB.

(R17394)

## 6.14 Compressor Sensor System Abnormality (24/32 Class Only)


<b>Remote Controller Display</b>	HO
<b>Outdoor Unit LED Display</b>	A  1  2  3  4 
<b>Method of Malfunction Detection</b>	<ul style="list-style-type: none"> <li>■ Fault condition is identified by the supply voltage and the DC voltage which is detected before the compressor startup.</li> <li>■ Fault condition is identified by the compressor current which is detected right after the compressor startup.</li> <li>■ If the error repeats, the system is shut down.</li> <li>■ Reset condition: Continuous run for about 5 minutes without any other error</li> </ul>
<b>Malfunction Decision Conditions</b>	<ul style="list-style-type: none"> <li>■ The detected value of the supply voltage and the DC voltage is obviously low or high.</li> <li>■ The compressor current does not run when the compressor is started.</li> </ul>
<b>Supposed Causes</b>	<ul style="list-style-type: none"> <li>■ Disconnection of reactor</li> <li>■ Disconnection of compressor harness</li> <li>■ Defective outdoor unit PCB</li> <li>■ Defective compressor</li> </ul>

# Troubleshooting



## Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.








(R15891)

## 6.15 Position Sensor Abnormality

Remote  
Controller  
Display

HE

Outdoor Unit LED  
Display

A  1  2  3  4 

Method of  
Malfunction  
Detection

A compressor start-up failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction  
Decision  
Conditions

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed  
Causes

- Disconnection of the compressor relay cable
- Defective compressor
- Defective outdoor unit PCB
- Start-up failure caused by the closed stop valve
- Input voltage is outside the specified range.

Troubleshooting

 **Check No.15**  
Refer to P.196

 **Check No.18**  
Refer to P.198


 **Check No.20**  
Refer to P.199

18 class



**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R15300)

## Troubleshooting



**Check No.15**  
Refer to P.196



**Check No.18**  
Refer to P.198

## 24/32 class

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Turn off the power.

Check the power supply voltage.

Voltage as rated?

NO

Correct the power supply.

YES

**Check No. 18**  
Check the discharge pressure.

OK?

NO

Replace the stop valve.

YES

Check the connection.

Electrical components or compressor harnesses connected as specified?

NO

Reconnect the electrical components or compressor harnesses as specified.

YES

Turn on the power.  
Check the electrolytic capacitor voltage.

$320 \pm 50$  VDC?

NO

Replace the outdoor unit PCB.

YES

Turn off the power. Disconnect the harnesses U, V, and W.

**Check No.15**  
Check with the inverter checker (\*).

\* Inverter checker  
Part No.: 1225477

Any LED OFF?

YES

Correct the power supply or replace the outdoor unit PCB.

NO

Replace the compressor.





(R15892)

## 6.16 CT or Related Abnormality

### Remote Controller Display

H8

### Outdoor Unit LED Display

A  1  2  3  4

### Method of Malfunction Detection

A CT or related error is detected by checking the compressor running frequency and CT-detected input current.

### Malfunction Decision Conditions

- The compressor running frequency is more than **A** Hz and input current is less than **B** A.

	<b>A</b> (Hz)	<b>B</b> (A)
18 class	55	1.25
24/32 class	32	0.5

- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 60 minutes without any other error

### Supposed Causes

- Defective power module
- Broken or disconnected wiring
- Defective reactor
- Defective outdoor unit PCB

## Troubleshooting



**Check No.15**  
Refer to P.196



**Check No.21**  
Refer to P.200



**Caution** Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.


Turn off the power and turn it on again.

Start operation.

\* Running current as shown at right with relay cable 1 or 2?

YES

Replace the outdoor unit PCB.



NO

**Check No. 21**  
Check the capacitor voltage.

320 ± 50 VDC?

YES

Turn off the power. Disconnect the harnesses U, V, and W.

**Check No. 15**  
Check with the inverter checker (\*).

\* Inverter checker  
Part No.: 1225477

Any LED OFF?

YES

Correct the power supply or replace the outdoor unit PCB.

NO

Turn off the power and reconnect the harnesses. Then turn on the power again and restart operation.

Compressor running?

YES

Replace the outdoor unit PCB.

NO

Replace the compressor.

Voltage within the allowable range (Supply voltage ± 15%)?

YES

Replace the outdoor unit PCB.

NO

Check the supply voltage.

(R15326)








## 6.17 Thermistor or Related Abnormality (Outdoor Unit)

Remote  
Controller  
Display

H9, U3, U6, U8, U9, P4

Outdoor Unit LED  
Display

A  1  2  3  4 

Method of  
Malfunction  
Detection

This type of error is detected by checking the thermistor input voltage to the microcomputer.  
A thermistor error is detected by checking the temperature sensed by each thermistor.

Malfunction  
Decision  
Conditions

- The thermistor input is above 4.96 V or below 0.04 V with the power on.
- U3 error is judged if the discharge pipe temperature is lower than the heat exchanger temperature.
- The system is shut down if all the units are judged as the U8 error.


Supposed  
Causes

- Disconnection of the connector for the thermistor
- Defective thermistor corresponding to the error code
- Defective heat exchanger thermistor in the case of U3 error (outdoor heat exchanger thermistor in cooling operation, or indoor heat exchanger thermistor in heating operation)
- Defective outdoor unit PCB

## Troubleshooting



**Check No.01**  
Refer to P.191



(R17366)

U3 : Outdoor temperature thermistor  
 U3 : Discharge pipe thermistor  
 U5 : Outdoor heat exchanger thermistor  
 U8 : Liquid pipe thermistor  
 U9 : Gas pipe thermistor  
 P4 : Radiation fin thermistor



**Note:** In case of P4 for 24/32 class models

**Caution**


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

**Replace the outdoor unit PCB.**



**Note:** For 3MXS24JVJU

The short thermistors which locate near the connectors [S92] and [S93] each are indispensable for control. When you check the liquid pipe thermistors or the gas pipe thermistors, check the short thermistor also.



(R17392)

## 6.18 Electrical Box Temperature Rise

Remote  
Controller  
Display



Outdoor Unit LED  
Display

A 1 2 3 4

Method of  
Malfunction  
Detection

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

Malfunction  
Decision  
Conditions

- With the compressor off, the radiation fin temperature is above **A**.
- The error is cleared when the temperature drops below **B**.
- To cool the electrical components, the outdoor fan starts when the radiation fin temperature rises above **C** and stops when it drops below **B**.

	<b>A</b>	<b>B</b>	<b>C</b>
18 class	176°F (80°C)	158°F (70°C)	167°F (75°C)
24/32 class	212°F (100°C)	158°F (70°C)	185°F (85°C)

Supposed  
Causes

- Defective outdoor fan motor
- Short circuit
- Defective radiation fin thermistor
- Disconnection of connector
- Defective outdoor unit PCB

## Troubleshooting



**Check No.01**  
Refer to P.191



**Check No.17**  
Refer to P.198



**Check No.19**  
Refer to P.199

## 18 class


**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Turn off the power and turn it on again.

**WARNING**

To cool the electrical components, the outdoor fan starts when the radiation fin temperature rises above **C** and stops when it drops below **B**.



(R17367)

	<b>A</b>	<b>B</b>	<b>C</b>
18 class	176°F (80°C)	158°F (70°C)	167°F (75°C)

Troubleshooting



**Check No.17**  
Refer to P.198



**Check No.19**  
Refer to P.199

24/32 class



**Caution**


Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

Turn off the power and turn it on again.



**WARNING**

To cool the electrical components, the outdoor fan starts when the radiation fin temperature rises above **C** and stops when it drops below **B**.



(R16695)

	A	B	C
24/32 class	212°F (100°C)	158°F (70°C)	185°F (85°C)

## 6.19 Radiation Fin Temperature Rise

Remote Controller Display






Outdoor Unit LED Display

Method of Malfunction Detection

Malfunction Decision Conditions

Supposed Causes

L4

A  1  2  3  4 

A radiation fin temperature rise is detected by checking the radiation fin temperature with the compressor on.

■ The radiation fin temperature with the compressor on is above **A**.

■ The error is cleared when the temperature drops below **B**.

	A	B
18 class	194°F (90°C)	185°F (85°C)
24/32 class	221°F (105°C)	206.6°F (97°C)

■ If the error repeats, the system is shut down.

■ Reset condition: Continuous run for about 60 minutes without any other error

■ Defective outdoor fan motor

■ Short circuit

■ Defective radiation fin thermistor

■ Disconnection of connector

■ Defective outdoor unit PCB

■ Silicon grease is not applied properly on the radiation fin after replacing the outdoor unit PCB.

# Troubleshooting



**Check No.01**  
Refer to P.191



**Check No.17**  
Refer to P.198




**Check No.19**  
Refer to P.199

## 18 class



### Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.  
(Precaution before turning on the power again)  
Make sure the power has been off for at least 30 seconds.



(R17368)

	A
18 class	194°F (90°C)



### Note:

Refer to “Application of silicon grease to a power transistor and a diode bridge” on page 267 for detail.

## Troubleshooting



**Check No.17**  
Refer to P.198




**Check No.19**  
Refer to P.199

## 24/32 class

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



	<b>A</b>
24/32 class	221°F (105°C)

**Note:**

Refer to “Application of silicon grease to a power transistor and a diode bridge” on page 267 for detail.








## 6.20 Output Overcurrent Detection

Remote  
Controller  
Display

L5

Outdoor Unit LED  
Display

A  1  2  3  4 

Method of  
Malfunction  
Detection

An output overcurrent is detected by checking the current that flows in the inverter DC section.

Malfunction  
Decision  
Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- An output overcurrent signal is fed from the output overcurrent detection circuit to the microcomputer.
- If the error repeats, the system is shut down.
- Reset condition: Continuous run for about 5 minutes without any other error

Supposed  
Causes

- Poor installation condition
- Closed stop valve
- Defective power module
- Wrong internal wiring
- Abnormal power supply voltage
- Defective outdoor unit PCB
- Defective compressor

## Troubleshooting



**Check No.15**  
Refer to P.196



**Check No.17**  
Refer to P.198



**Check No.18**  
Refer to P.198




**Check No.22**  
Refer to P.201

**Caution**

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

\* An output overcurrent may result from wrong internal wiring. If the system is interrupted by an output overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.



(R16014)

## 7. Check

### 7.1 Thermistor Resistance Check

#### Check No.01



Disconnect the connectors of the thermistors from the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the table and the graph below.


The data is for reference purpose only.

Temperature (°F/°C )	Resistance (kΩ)
-4 / -20	197.8
5 / -15	148.2
14 / -10	112.1
23 / -5	85.60
32 / 0	65.93
41 / 5	51.14
50 / 10	39.99
59 / 15	31.52
68 / 20	25.02
77 / 25	20.00
86 / 30	16.10
95 / 35	13.04
104 / 40	10.62
113 / 45	8.707
122 / 50	7.176

(R 77°F (25°C) = 20 kΩ, B = 3950 K)



(R11906)



(R17417)


- The room temperature thermistor is directly mounted on the display PCB. Remove the display PCB from the control PCB to measure the resistance.
- When the indoor heat exchanger thermistor is soldered on the PCB, remove the thermistor and measure the resistance.

## 7.2 Fan Motor Connector Check

### Check No.02

#### CTXS/FTXS Series

1. Check the connection of connector.
2. Check motor power supply voltage output (pins 4 - 7).
3. Check motor control voltage (pins 4 - 3).
4. Check rotation command voltage output (pins 4 - 2).
5. Check rotation pulse input (pins 4 - 1).



(R12404)

## 7.3 Hall IC Check

### Check No.04


#### CDXS/FDXS Series

1. Check the connector connection.
2. With the power on, operation off, and the connector connected, check the following.
  - \*Output voltage of about 5 V between pins 1 and 3.
  - \*Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

If NG in step 1 → Defective PCB → Replace the PCB.

If NG in step 2 → Defective Hall IC → Replace the fan motor.

If OK in both steps 1 and 2 → Replace the PCB.



(R14211)


## 7.4 Power Supply Waveform Check

### Check No.11

Measure the power supply waveform between No. 1 and No. 2 on the terminal board, and check the waveform disturbance.


- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]



(R1736)

[Fig.2]



(R1444)

## 7.5 Outdoor Electronic Expansion Valve Check

### Check No.12

Conduct the followings to check the outdoor electronic expansion valve (EV).

1. Check to see if the EV connector is correctly inserted in the PCB. Match the EV unit number and the connector number.
2. Turn the power off and on again, and check to see if all the EVs generate latching sound.
3. If any of the EVs does not generate latching sound in the above step 2, disconnect that connector and check the continuity using a tester.  
Check the continuity between the pins 1 - 6 and 3 - 6, and between the pins 2 - 5 and 4 - 5. If there is no continuity between the pins, the EV coil is faulty.
4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the continuity is confirmed in the above step 3, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.  
\*If latching sound is generated, the outdoor unit PCB is faulty.  
\*If latching sound is not generated, the EV unit is faulty.




**Note:** Please note that the latching sound varies depending on the valve type.

If the system keeps operating with a defective outdoor electronic expansion valve, the following problem may occur.


Valve opening position	Possible problem	Check method
Open	Cooling: ■ Flowing noise of refrigerant in the unit which is not in operation ■ Water leakage at the unit which is not in operation ■ Operation half due to anti-icing function  Heating: ■ Flowing noise of refrigerant in the unit which is not in operation ■ The unit does not heat the room.	Reset power supply and conduct cooling operation unit by unit.  <div> <div>Check the liquid pipe temperature of no-operation unit.</div> <div> <div>Almost the same as the outdoor temperature?</div> <div>           NO → The EV is not defective.            YES → Replace the EV of the room.            (R16019)         </div> </div> </div>
Close	Cooling: ■ The problem unit does not cool the room. ■ Only the problem unit is in operation, the unit starts pump down. (The low pressure of the unit becomes vacuum.) ■ Abnormal discharge pipe temperature  Heating: ■ Refrigerant shortage due to stagnation of liquid refrigerant inside the faulty indoor unit ■ The unit does not heat the room. ■ Abnormal discharge pipe temperature	Reset power supply and conduct cooling operation unit by unit.  <div> <div>Check the low pressure.</div> <div> <div>Does the pressure become into vacuum zone?</div> <div>           NO → The EV is not defective.            YES → Replace the EV of the room.            (R16020)         </div> </div> </div>

## 7.6 Four Way Valve Performance Check

### Check No.13




(Fig. 1)



(R11717)

## 7.7 Inverter Unit Refrigerant System Check

### Check No.14



## 7.8 “Inverter Checker” Check

### Check No.15

#### ■ Characteristics

If abnormal stop occurs due to compressor startup failure or overcurrent output when using an inverter unit, it is difficult to judge whether the stop is caused by the compressor failure or some other failure (control PCB, power module, etc.). The inverter checker makes it possible to judge the cause of trouble easily and securely. (Connect this checker as a quasi-compressor instead of the compressor and check the output of the inverter.)

#### ■ Operation Method

##### Step 1


Be sure to turn the power off.

##### Step 2

Install the inverter checker instead of a compressor.

##### Note:

Make sure the charged voltage of the built-in smoothing electrolytic capacitor drops to 10 VDC or below before carrying out the service work.



##### Reference:

If the terminals of the compressor are not FASTON terminals (difficult to remove the wire on the terminals), it is possible to connect wires available on site to the outdoor unit from output side of PCB. (Do not connect them to the compressor at the same time, otherwise it may result in incorrect detection.)

##### Step 3

Activate the power transistor test operation from the outdoor unit.

1) Press the forced operation [ON/OFF] switch for 5 seconds.

(Refer to page 256 for the position.)

→ Power transistor test operation starts.




### ■ Diagnose method (Diagnose according to 6 LEDs lighting status.)

- (1) If all the LEDs are lit uniformly, the compressor is defective.  
→ Replace the compressor.
- (2) If the LEDs are not lit uniformly, check the power module.  
→ Refer to **Check No.22**.
- (3) If NG in **Check No.22**, replace the power module.  
**18 class:** Replace the power module (SPM).  
**24/32 class:** Replace the main PCB. The power module (PM1) is united with the main PCB.
- (4) If any solder cracking is found, replace the PCB or repair the soldered section.  
If there is no solder cracking, replace the PCB.



### Caution

- (1) When the output frequency is low, the LEDs blink slowly. As the output frequency increases, the LEDs blink quicker. (The LEDs look like they are lit.)
- (2) On completion of the inverter checker diagnosis, be sure to re-crimp the FASTON terminals. Otherwise, the terminals may be burned due to loosening.



## 7.9 Rotation Pulse Check on the Outdoor Unit PCB

### Check No.16

<Outdoor fan motor>

Make sure that the voltage of  $320 \pm 30$  V is applied.


1. Set operation off and power off. Disconnect the connector S70.
2. Check that the voltage between the pins 4 - 7 is 320 VDC.
3. Check that the control voltage between the pins 3 - 4 is 15 VDC.
4. Check that the rotation command voltage between the pins 2 - 4 is 0 ~ 15 VDC.
5. Keep operation off and power off. Connect the connector S70.
6. Check whether 2 pulses (0 ~ 15 VDC) are output at the pins 1 - 4 when the fan motor is rotated 1 turn by hand.

When the fuse is melted, check the outdoor fan motor for proper function.

If NG in step 2 → Defective PCB → Replace the PCB.

If NG in step 4 → Defective Hall IC → Replace the outdoor fan motor.


If OK in both steps 2 and 4 → Replace the PCB.



(R10811)

## 7.10 Installation Condition Check


### Check No.17



(R17119)

## 7.11 Discharge Pressure Check


### Check No.18



(R15738)

## 7.12 Outdoor Fan System Check

### Check No.19



## 7.13 Main Circuit Short Check


### Check No.20



**Note:** Check to make sure that the voltage between (+) and (–) of the diode bridge (DB1) is approx. 0 V before checking.

- Measure the resistance between the pins of the DB1 referring to the table below.
- If the resistance is  $\infty$  or less than 1 k $\Omega$ , short circuit occurs on the main circuit.

(–) terminal of the tester (in case of digital, (+) terminal)	(~)	(+)	(~)	(–)
(+) terminal of the tester (in case of digital, (–) terminal)	(+)	(~)	(–)	(~)
Resistance is OK.	several k $\Omega$ ~several M $\Omega$	$\infty$	$\infty$	several k $\Omega$ ~several M $\Omega$
Resistance is NG.	0 or $\infty$	0	0	0 or $\infty$




## 7.14 Capacitor Voltage Check

### Check No.21

Before this check, be sure to check the main circuit for short circuit.  
With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.

#### 18 class


Multimeter  
(DC. voltage range)



(R11308)

#### 24/32 class

Multimeter  
(DC. voltage range)



(R12869)

## 7.15 Power Module Check

### Check No.22




**Note:** Check to make sure that the voltage between (+) and (–) of the power module (PM1) is approx. 0 V before checking.


- Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.
- Follow the procedure below to measure resistance between the terminals of the power module and the terminals of the compressor with a multi-tester. Evaluate the measurement results referring to the following table.

Negative (–) terminal of tester (positive terminal (+) for digital tester)	Power module (+)	UVW	Power module (–)	UVW
Positive (+) terminal of tester (negative terminal (–) for digital tester)	UVW	Power module (+)	UVW	Power module (–)
Resistance is OK.	several k $\Omega$ ~ several M $\Omega$			
Resistance is NG.	0 $\Omega$ or $\infty$			

#### 18 class



#### 24/32 class



# Part 7

## Removal Procedure

1. Outdoor Unit: 2MXS18GVJU .....	203
1.1 Removal of Outer Panels .....	203
1.2 Removal of Electrical Box .....	204
1.3 Removal of PCBs .....	209
1.4 Removal of Fan Motor.....	212
1.5 Removal of Sound Blankets .....	213
1.6 Removal of Coils / Thermistors .....	215
1.7 Removal of Four Way Valve / Defrost Solenoid Valve .....	217
1.8 Removal of Distributor.....	219
1.9 Removal of Compressor.....	220
2. Outdoor Unit: 3MXS24JVJU, 4MXS32GVJU .....	222
2.1 Removal of Outer Panels .....	222
2.2 Removal of Electrical Box .....	234
2.3 Removal of PCBs .....	240
2.4 Removal of Fan Motor.....	244
2.5 Removal of Coils / Thermistors .....	245
2.6 Removal of Sound Blankets .....	250
2.7 Removal of Compressor.....	253




# 1. Outdoor Unit: 2MXS18GVJU

## 1.1 Removal of Outer Panels

Procedure

 **Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Appearance features	
2	Remove the 4 screws of the top panel and the 6 screws of the front panel.	
3	Remove the 4 screws of the discharge grille.	
4	Remove the 2 screws of the stop valve cover.	








## 1.2 Removal of Electrical Box

### Procedure











### Warning





Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.




Step	Procedure	Points
1. Disconnect the connecting wires.		<ul style="list-style-type: none"> <li>■ The US model has a protection plate on the right side panel. Remove the 2 screws to remove the protection plate.            </li> <li>■ The wires are fixed to the terminal board with screws.</li> </ul>
1 Remove the terminal board fixing screw. 2 Remove all the screws of the connecting wires and the power supply wires. 3 Remove the screw of the ground wire.		
2. Disconnect the harnesses.		[S20]: White [S21]: Red
1 Disconnect the 2 connectors for the electronic expansion valve coil [S20] [S21].		<ul style="list-style-type: none"> <li>■ Bundle the harnesses of the electronic expansion valve coil with clamp.</li> <li>■ Pull out the clamp.</li> <li>■ When reassembling, insert the clamp into one of the holes.</li> </ul> 



Step		Procedure	Points
2	Disconnect the connector for the four-way valve coil [S80].	 <p>(R17398)</p>	<p>■ When reassembling, insert the clamp into the hole as below.</p>  <p>(R17397)</p>
3	Disconnect the connectors for the thermistors [S90] [S92] [S93] and the overload protector [S40].	 <p>(R17399)</p>	<p>[S40]: overload protector  [S90]: thermistors (outdoor temperature, outdoor heat exchanger, discharge pipe)  [S92]: gas pipe thermistors  [S93]: liquid pipe thermistors</p> <p>■ Pull out the clamp.  ■ When reassembling, insert each clamp of the thermistors into one of the holes as below.</p>  <p>(R17401)</p> <p>■ When reassembling, insert each clamp into the holes.  ■ When reassembling, the thermistor harness should be placed between the electrical box and the reactor harness as below.</p>  <p>(R17093)</p>

Step		Procedure	Points
4	Disconnect the relay connector of the compressor.	 <p>(R17065)</p>	
5	Release the clamp with pliers.	 <p>(R17066)</p>	
6	Disconnect the reactor lead wires.	 <p>Reactor</p> <p>(R2170)</p>	

Step	Procedure	Points
3. Remove the electrical box.		
1	<p data-bbox="204 243 496 306">Remove the screw of the shield plate.</p>  <p data-bbox="992 569 1065 590">(R17345)</p>	
2	<p data-bbox="204 600 496 663">Unfasten the 2 hooks and remove the shield plate.</p>  <p data-bbox="1016 1020 1089 1041">(R17346)</p>	
3	<p data-bbox="204 1083 496 1167">Remove the screw on the right side of the electrical box.</p>  <p data-bbox="967 1587 1040 1608">(R10361)</p>	
4	<p data-bbox="204 1629 496 1713">Remove the screw on the front side of the electrical box.</p>  <p data-bbox="967 1965 1040 1986">(R17402)</p>	

Step		Procedure	Points
5	Remove the drip proof cover.	 <p>Drip proof cover</p> <p>(R2174)</p>	
6	Disconnect the connector for the fan motor [S70] from the inverter PCB (MID2). Release the fan motor lead wire from the hooks.	 <p>Inverter PCB (MID2)</p> <p>[S70]</p> <p>(R2175)</p>	
7	Remove the electrical box.	 <p>(R2176)</p>	





1.3 Removal of PCBs



Procedure



**Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the screw of the main PCB, and unfasten the 2 hooks.	<div>■ When reassembling, insert the base bar into the hole of the main PCB.</div>
2	Unfasten the hook of the terminal board, and open the terminal board.	
3	Disconnect each connector [S11] [HE] [HL] [HN] on the back of the terminal board.	
4	Disconnect the connectors [S52] [S102] from the service monitor PCB.	

Step		Procedure	Points
5	Lift up the main PCB.		
6	Disconnect the connectors [S31] [S32] [S33] [S71] [H1] [H2].	 	
7	The figure shows the main PCB.		■ Refer to page 30 for detail.

Step	Procedure	Points
8	Unfasten the 2 hooks and remove the service monitor PCB. 	
9	Remove the 7 screws and remove the inverter PCB (MID2). 	







1.4 Removal of Fan Motor

Procedure



**Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the nut and remove the outdoor fan.	<div><b>Preparation</b> Disconnect the connector for the fan motor and release the fan motor lead wire according to the “Removal of Electrical Box”.</div> <div><div>■ When reassembling, align the ▼ mark of outdoor fan with the D-cut section of motor shaft.</div><div>■ Nut size : M6</div><div><div>10 mm (0.39 inch)</div><div>(R17404)</div></div></div>
2	Remove the 2 screws of the fan motor fixing frame.	<div><div>Fan motor fixing frame</div><div>(R17350)</div></div>
3	Open the 2 hooks and release the fan motor lead wire.	<div><div>(Backside)</div><div>(R5567)</div></div>
4	Remove the 4 screws and remove the fan motor.	<div><div>(R5568)</div></div>






# 1.5 Removal of Sound Blankets


Procedure



**Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the 5 screws of the right side panel.	
2	Release the clamp with pliers.	
3	Remove the 2 screws of the partition plate and remove it.	



Step		Procedure	Points
4	Remove the sound blankets (top upper, top inner, outer, inner).	 <p>Sound blanket (top upper)</p> <p>Sound blanket (top inner)</p> <p>Sound blanket (inner)</p> <p>Sound blanket (outer)</p> <p>(R17405)</p>	<ul style="list-style-type: none"> <li>■ Carefully remove the sound blanket, which is easily torn in the piping section.</li> </ul>





## 1.6 Removal of Coils / Thermistors

### Procedure






### Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the screw and remove the four-way valve coil.	 <p>(R2194)</p>  <p>(R2195)</p>  <p>(R2196)</p>  <p>(R10367)</p>
2	Remove the screw and remove the defrost solenoid valve coil.	
3	Pull out the electronic expansion valve coil for each room.	
4	Remove the discharge pipe thermistor.	

- Place the thermistor so that its edge comes up to the edge of the fixture.
- Be careful not to lose the fixture for the thermistor.



Step		Procedure	Points
5	Remove the putty, and remove each thermistor.	 <p>Gas pipe thermistor (R17406)</p>	<ul style="list-style-type: none"> <li>■ Place the thermistor so that its edge comes up to the edge of the fixture.</li> <li>■ Be careful not to lose the clip and fixture for the thermistors.</li> </ul>
6	Release the wire harnesses.	 <p>(R10369)</p>	<p>[S90]: outdoor temperature thermistor (blue) outdoor heat exchanger thermistor (gray) discharge pipe thermistor (black)</p> <p>[S92]: gas pipe thermistor room A (black) room B (gray)</p> <p>[S93]: liquid pipe thermistor room A (black) room B (gray)</p>




## 1.7 Removal of Four-Way Valve / Defrost Solenoid Valve




### Procedure




#### Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1  2	<p>Remove the screw and remove the four way valve coil.</p> <p>Remove the screw and remove the defrost solenoid valve coil.</p> 	<p><b>Warning</b> Be careful not to burn yourself with the pipes and other parts that are heated by the gas brazing machine.</p> <p><b>Warning</b> If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas may be generated.)</p> <p><b>Caution</b> For environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.</p>
<p>■ Before working, make sure that the refrigerant gas is empty in the circuit.</p> <p>■ Be sure to apply nitrogen replacement when heating up the brazed part.</p>		
3	<p>Heat the 4 brazed points of the four-way valve. Disconnect the point (a) first.</p> 	<p><b>Cautions for restoration</b></p> <ol style="list-style-type: none"><li>Restore the piping by non-oxidation brazing.</li><li>It is required to prevent the carbonization of the oil inside the four-way valve and the deterioration of the gaskets affected by heat. Keep below 248°F(120°C). Wrap the four-way valve with wet cloth and provide water so that the cloth does not dry.</li></ol>
4	<p>Disconnect the points (b) and (c).</p>	<p><b>In case of difficulty with gas brazing machine</b></p> <ol style="list-style-type: none"><li>Disconnect the brazed part where is easy to disconnect and restore.</li><li>Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.</li></ol>
5	<p>Disconnect the point (d) and remove the four-way valve.</p> 	



Step		Procedure	Points
6	<p>Disconnect the 2 brazed points, first (e), and then (f). Remove the defrost solenoid valve.</p>	 <p>(R12395)</p>	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Do not use a metal saw for cutting pipes or sawdust will enter the circuit.</li> <li>■ When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.</li> <li>■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.</li> </ul>

## 1.8 Removal of Distributor

### Procedure



#### Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> <li>Before working, make sure that the refrigerant gas is empty in the circuit.</li> <li>Be sure to apply nitrogen replacement when heating up the brazed part.</li> </ul>		<p> <b>Warning</b> Be careful not to burn yourself with the pipes and other parts that are heated by the gas brazing machine.</p> <p> <b>Warning</b> If the refrigerant gas leaks during work, immediately ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas may be generated.)</p> <p> <b>Caution</b> For global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.</p> <p><b>Cautions for restoration</b></p> <ol style="list-style-type: none"> <li>Restore the piping by non-oxidation brazing.</li> <li>It is required to prevent the carbonization of the oil inside the four-way valve and the deterioration of the gaskets affected by heat. Keep below 248°F(120°C). Wrap the four-way valve with wet cloth and provide water so that the cloth does not dry.</li> </ol> <p><b>In case of difficulty with gas brazing machine</b></p> <ol style="list-style-type: none"> <li>Disconnect the brazed part where is easy to disconnect and restore.</li> <li>Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.</li> </ol>
<ol style="list-style-type: none"> <li>Remove the putty.</li> <li>Heat up and disconnect the 5 brazed parts to remove the distributor.</li> </ol>		
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Do not use a metal saw for cutting pipes or sawdust will enter the circuit.</li> <li>When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.</li> <li>Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.</li> </ul>		

1.9 Removal of Compressor

Procedure




**Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the terminal cover.	
2	Disconnect the compressor lead wires.	
3	Remove the 2 sheets of putty.	
4	Remove the 3 nuts.	



Step	Procedure	Points
<ul style="list-style-type: none"> <li>Before working, make sure that the refrigerant gas is empty in the circuit.</li> <li>Be sure to apply nitrogen replacement when heating up the brazed part.</li> </ul>		<p><b>Warning</b> Be careful not to get yourself burnt with pipes and other parts that are heated by the gas brazing machine.</p>
5	Disconnect the brazed part (a) at discharge side of the compressor.	
6	Disconnect the brazed part (b) at suction side of the compressor.	<p><b>Warning</b> If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas may be generated.)</p>
7	Lift the compressor up and remove it.	<p><b>Warning</b> Since it may happen that the refrigerant oil in the compressor catches fire, prepare wet cloth so as to extinguish fire immediately.</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Do not use a metal saw for cutting pipes or sawdust will enter the circuit.</li> <li>When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.</li> <li>Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.</li> <li>Be careful so as not to burn the compressor terminals, the name plate, the outdoor heat exchanger fin.</li> </ul>		<p><b>Caution</b> For environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.</p> <p><b>Cautions for restoration</b></p> <ol style="list-style-type: none"> <li>Restore the piping by non-oxidation brazing.</li> <li>It is required to prevent the carbonization of the oil inside the four-way valve and the deterioration of the gaskets affected by heat. Keep below 248°F(120°C). Wrap the four-way valve with wet cloth and provide water so that the cloth does not dry.</li> </ol> <p><b>In case of difficulty with gas brazing machine</b></p> <ol style="list-style-type: none"> <li>Disconnect the brazed part where is easy to disconnect and restore.</li> <li>Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.</li> </ol>



2. Outdoor Unit: 3MXS24JVJU, 4MXS32GVJU




2.1 Removal of Outer Panels

Procedure









Warning




Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.






Step	Procedure	Points
	<div>Appearance features</div> <div></div>	
1. Remove the suction grille.	<div><div>1</div><div>Unfasten the 2 hooks at the bottom first.</div></div> <div><div>Rear side</div><div></div><div><div>Suction grille</div><div></div></div></div>	<div>■ The hooks are secured in the clearances of the outdoor heat exchanger fins.</div>

Step	Procedure	Points
2	Slide the suction grille downward to unfasten the 3 top hooks.	
3	Remove the suction grille.	
2. Remove the top panel.	1 Remove the 4 screws on the back and the screw on the left side.	











Step		Procedure	Points
2	Remove the 2 screws on the front and the screw on the right side panel.	 <p>Right side panel</p> <p>(R6374)</p>	
3	Lift the top panel and remove it.	 <p>(R6375)</p>	
3.	Remove the right side panel.	 <p>Right side panel</p> <p>(R6376)</p>	
1	Remove the 5 screws.		

Step	Procedure	Points
2	<p data-bbox="203 212 495 304">Slide the right side panel downward to unfasten the 2 hooks on the back side.</p>  <p data-bbox="974 714 1039 735">(R6377)</p>  <p data-bbox="990 1123 1063 1144">(R14614)</p>  <p data-bbox="1153 1753 1226 1774">(R14615)</p>	




Step		Procedure	Points
3	Remove the right side panel.	 <p>(R10441)</p>	<p>■ The US model has a service lid on the stop valve mounting plate. Remove the 2 screws to remove the service lid.</p>  <p>Screw Service lid (R10372)</p> <p>■ This model has a conduit mounting plate.</p>  <p>Lock nut Knockout hole Conduit mounting plate Conduit (R17351)</p>
4.	Remove the front panel (2).	<p>1 Remove the 2 screws.</p>  <p>Front Panel (1) Front Panel (2) (R10629)</p> <p>2 Slide the front panel (2) panel downward to unfasten the hook.</p>  <p>(R10374)</p>	<p>★ This screw is M5 × 16</p>









Step		Procedure	Points
3	Remove the front panel (2).	 <p>(R6383)</p>  <p>(R10375)</p>	
5.	Remove the front panel (1).	 <p>Front Panel (1)</p> <p>Discharge grille</p> <p>(R10376)</p>  <p>(R10377)</p>	<p>■ Remove the discharge grille and outdoor fan first to remove the front panel (1).</p>
1	Remove the 4 screws on the discharge grille.		
2	Pull the bottom of the discharge grille.		




Step		Procedure	Points
3	Slide the discharge grille downward to unfasten the 2 hooks at the top.		
4	Remove the discharge grille.		
5	Remove the nut and remove the outdoor fan.		<p>■ Nut size : M8</p>  <p>(R17410)</p> <p>■ When reassembling, align the ▼ mark of the outdoor fan with the D-cut section of the motor shaft.</p>






Step		Procedure	Points
6	Remove the 2 screws of the partition plate (1).	 <p>Partition plate (1)</p> <p>(R10382)</p>	
7	Remove the screw at the bottom left of the front panel (1).	 <p>Front panel (1)</p> <p>(R10383)</p>	
8	Remove the screw at the bottom of the left side.	 <p>(R6393)</p>	

Step		Procedure	Points
9	Remove the screw at the bottom of the back side.	 <p>(R6394)</p>	
10	The front panel (1) has a hook. Lift the front panel (1).	 <p>(R17174)</p>	
11	Remove the front panel (1).	 <p>(R10385)</p> <p>(R6396)</p>	<p>■ Be sure to detach the front panel (1) carefully so as not to deform it.</p>

Step	Procedure	Points
6. Remove the rear panel.		
1	Remove the 2 screw on the partition plate (2).	
	 <p>Rear panel</p> <p>Partition plate (2)</p> <p>(R10386)</p>	
2	Slide the partition plate (2) to the left and remove it.	
	 <p>Hook</p> <p>(R10387)</p>	<ul style="list-style-type: none"><li>■ When reassembling, bundle the wires with clamp.</li><li>■ When reassembling, pass the wires through the partition plate (2).</li></ul>
3	Release the holder of the outdoor temperature thermistor.	
	 <p>Outdoor temperature thermistor</p> <p>(R10388)</p>	<ul style="list-style-type: none"><li>■ The holder is secured in the clearances of the heat exchanger fins.</li></ul>

Step		Procedure	Points
4	Release the thermistor wire from the groove.	 <p>(R10389)</p>	
5	Remove the 3 screws on the rear panel.	 <p>(R10390)</p>	
6	Remove the screw on the bottom frame.	 <p>(R10391)</p>	

Step		Procedure	Points
7	Remove the screw on the stop valve mounting plate.	 <p>Stop valve mounting plate</p> <p>(R10392)</p>	
8	Lift the rear panel to unfasten the 2 hooks.	 <p>Hook</p> <p>(R12918)</p>	
9	Remove the rear panel.	 <p>(R10394)</p>	




2.2 Removal of Electrical Box



Procedure



Warning







Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the 2 screws to detach the ground wires. <div><div>(R10396)</div></div>	
2	Disconnect the connector for the fan motor [S70]. <div><div>(R10397)</div></div>	
3	Release the fan motor lead wire. <div><div>(R17268)</div></div>	★ : When reassembling, do not use these 2 hooks.




Step	Procedure	Points
4	Disconnect the connector for the four-way valve coil [S80]. 	■ Pull out the clamp.
5	Disconnect the 4 connectors for the electronic expansion valve coils (for room A, B, C, D) and pull out the clamp. 	■ A : [S20] (white) B : [S21] (red) C : [S22] (blue) D : [S23] (yellow)  ■ The 3MXS model does not have [S23].  ■ When reassembling, insert each clamp into the hole. <div><div><div><div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div></div></div> <div><div></div><div></div><div></div><div></div><div></div></div> <div><div></div><div></div><div></div><div></div><div></div></div> <div><div></div><div></div><div></div><div></div><div></div></div> <div><div></div><div></div><div></div><div></div><div></div></div>




</





Step		Procedure	Points
7	Disconnect the connector for the gas pipe thermistors [S92] and pull out the clamp.		<p>■ When reassembling, insert the clamp into the hole.</p> 
8	Disconnect the connector for the thermistors [S90] and pull out the clamp.		<p>■ When reassembling, insert the clamp into the hole.</p> 
9	The wire harness of the thermistors is hooked under the electrical box. Unhook it and pull out the clamp.		<p>■ When reassembling, insert the clamp into the small hole.</p> 



Step		Procedure	Points
10	Disconnect the connector for the overload protector [S40].	 <p>(R10539)</p>	
11	The wire harness for the compressor is attached to the partition plate (1) by the clamp.	 <p>Clamp</p> <p>(R6422)</p>	
12	Pull out the clamp with pliers.	 <p>Clamp</p> <p>(R6423)</p>	

Step		Procedure	Points
13	Disconnect the relay connector of the compressor.	 <p>(R6469)</p>	
14	Remove the screw on the stop valve mounting plate.	 <p>(R10395)</p>	
15	Remove the screw on the partition plate (1).	 <p>(R6411)</p>	

Step		Procedure	Points
16	Slide the electrical box leftward to unfasten the hook on the right side.	 <p>(R10401)</p>	
17	Remove the electrical box.	 <p>(R10402)</p>	


2.3 Removal of PCBs





Procedure









Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the main PCB.		
1	Open the cover of the electrical box.	<div>■ Unfasten the 4 hooks. The hooks are marked with ▼.</div>  <div>(R6427)</div>
2	Remove the 3 screws.	
3	Unfasten the 4 hooks.	
4	Lift up the main PCB.	

Step		Procedure	Points
5	Disconnect the connectors.	 <p>(R10407)</p>	<p>■ Refer to page 33 for detail.</p> <p>[S51] [S101] : service monitor PCB  [S10] : terminal board (transmission)  [HR1] [HR2] : reactor  [AC1] [AC2] : terminal board (power supply)  [U] [V] [W] : compressor</p>
6	Remove the main PCB.	 <p>(R10408)</p>	
2. Remove the reactor.			
1	Remove the screw.	 <p>(R10409)</p>	
2	Remove the 3 screws and lift the reactor upward to remove it.	 <p>(R6434)</p>	

Step	Procedure	Points
3. Remove the service monitor PCB.		
1	<p>Disconnect the connectors from the service monitor PCB [S52] [S102].</p>  <p>(R10410)</p>	
2	<p>Slightly lift the top hook to unfasten it.</p>  <p>(R6436)</p>	
3	<p>Unfasten the bottom hook to remove the service monitor PCB.</p>  <p>(R6437)</p>	

Step	Procedure	Points
4. Remove the terminal board.		
1 Remove the screw.	 <p>Diagram (R10411) shows the terminal board being removed from the outdoor unit. A screw is being removed from the terminal board. The terminal board is labeled "Terminal board".</p>	
2 Unfasten the hook.	 <p>Diagram (R10412) shows the terminal board being unfastened from the outdoor unit. A hook is being unfastened from the terminal board.</p>	
3 Remove the terminal board.	 <p>Diagram (R10413) shows the terminal board being removed from the outdoor unit. The terminal board is being pulled out of the unit.</p>	





## 2.4 Removal of Fan Motor

Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure		Points
1	Remove the 2 lower screws of the fan motor.	 (R10414)	<div>■ Be sure to remove the lower screws first. If the upper screws are removed first, the fan motor may tilt or fall because the center of its gravity is toward the front. It may cause injuries.</div>
2	Remove the 2 upper screws.	 (R6442)	
3	Remove the fan motor.	 (R10542)	
		 (R6444)	<div>■ When reassembling, be sure to place the wire harness lower.</div>







## 2.5 Removal of Coils / Thermistors




Procedure









Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the electronic expansion valve coil.	 	
1 Pull the electronic expansion valve coils.		
2. Remove the thermistors.	 	<ul style="list-style-type: none"><li>■ Place the thermistor so that its edge comes up to the edge of the fixture.</li><li>■ Be careful not to lose the clips for the thermistors.</li></ul>
1 Pull out the gas pipe thermistors.		

Step		Procedure	Points
2	Peel the putty, and pull out the liquid pipe thermistors.	 <p data-bbox="971 415 1068 478">Liquid pipe thermistor</p> <p data-bbox="987 720 1052 741">(R17413)</p>  <p data-bbox="971 1035 1068 1077">Liquid pipe thermistor</p> <p data-bbox="987 1192 1052 1213">Fixture</p> <p data-bbox="1019 1329 1084 1350">(R6450)</p>	<p data-bbox="1109 783 1450 846">■ Be careful not to lose the fixtures for the thermistors.</p>
3	Pull out the outdoor heat exchanger thermistor.	 <p data-bbox="719 1413 1052 1434">Outdoor heat exchanger thermistor</p> <p data-bbox="987 1938 1052 1959">(R10541)</p>	

Step		Procedure	Points
4	Remove the clip from the outdoor heat exchanger thermistor.	 <p>Clip</p> <p>(R6452)</p>	<p>■ Be careful not to lose the clip for the thermistor.</p>
5	Slightly open the sound blanket (outer).	 <p>Sound blanket (outer) (R10418)</p>	
6	Remove the sound blanket (top upper).	 <p>Sound blanket (top upper)</p> <p>(R10419)</p>	

Step		Procedure	Points
7	Remove the discharge pipe thermistor.	 <p>Discharge pipe thermistor (R10420)</p>	
8	Remove the fixture.	 <p>Fixture (R10430)</p>	<p>■ Be careful not to lose the fixture for the thermistor.</p>
3.	Remove the four-way valve coil.	 <p>(R10431)</p>	
1	Remove the screw.		

Step	Procedure		Points
2	Remove the four-way valve coil.	 <p>Four-way valve coil</p> <p>(R10432)</p>	

## 2.6 Removal of Sound Blankets




### Procedure







### Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Open the sound blanket (outer).	<p>■ The sound blanket is fragile. Carefully pass the discharge pipe through it.</p>
2	Remove the sound blanket (top upper).	
3	Remove the screw from the partition plate (1) and push the plate to the left slightly for easy work.	



Step		Procedure	Points
4	Remove the sound blanket (outer).	 <p>Sound blanket (outer) (R10436)</p>	<ul style="list-style-type: none"> <li>■ The sound blanket is fragile. Carefully pass the discharge pipe through it.</li> </ul>
5	Remove the sound blanket (top inner).	 <p>Sound blanket (top inner) (R10437)</p>	<ul style="list-style-type: none"> <li>■ The sound blanket is fragile. Carefully pass the discharge pipe through it.</li> </ul>
6	Open the sound blanket (inner) and pass it through the part of the mufflers.	 <p>Mufflers Sound blanket (inner) (R10438)</p>	<ul style="list-style-type: none"> <li>■ The sound blanket is fragile. Be careful of the notches of the compressor mount (3 locations).</li> </ul>

Step		Procedure	Points
7	Remove the sound blanket (inner).	 <p>(R10439)</p>	






# 2.7 Removal of Compressor

Procedure



**Warning** Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the terminal cover.	<div><p>(R6466)</p><p>(R9471)</p><p>(R10440)</p></div>
2	Disconnect the compressor lead wires.	
3	Remove the overload protector.	
4	Remove the 2 nuts.	

# Part 8

## Trial Operation and Field Settings

1. Pump Down Operation .....	255
2. Forced Operation .....	256
3. Wiring Error Check Function .....	257
4. Trial Operation .....	259
5. Field Settings .....	261
5.1 Outdoor Unit .....	261
5.2 Indoor Unit .....	264
6. Application of Silicon Grease to a Power Transistor and a Diode Bridge .....	267


# 1. Pump Down Operation

## Outline

In order to protect the environment, be sure to conduct pump down operation when relocating or disposing the unit.

## Detail

- 1) Remove the valve caps from the liquid stop valve and the gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After 5 to 10 minutes, close the liquid stop valve with a hexagonal wrench.
- 4) After 2 to 3 minutes, close the gas stop valve and stop the forced cooling operation.



(R14566)



Refer to page 256 for forced operation.


## 2. Forced Operation

### Outline

Forced operation mode includes forced cooling and forced heating. Operation mode can be selected by the operation mode switch (SW2) on the outdoor unit. Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit to start the operation.

### Detail

Item	Forced Cooling	Forced Heating
Conditions	1) The indoor unit is not abnormal, but the indoor unit which is not in the freezing prohibiting zone is present in more than 1 room.	1) The indoor unit is not abnormal. The indoor unit which is not in the peak-cut prohibited zone is present in more than 1 room.
	2) The outdoor unit is not abnormal and not in the 3-minute standby mode.	←
	3) The operating mode of the outdoor unit is the stop mode.	←
	4) The operation mode switch (SW2) on the outdoor unit is set to the cooling mode.	4) The operation mode switch (SW2) on the outdoor unit is set to the heating mode.
Start	Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit.	←
Operating room	All rooms: The command is sent to all the rooms where the transmission is normal.	■ Only 1 room: The command is sent to one of the rooms which can be operate and the order of priority is A > B > C > D. Other rooms operation must be stopped.
Command frequency	<ul style="list-style-type: none"> <li>18 class : 42 Hz</li> <li>24/32 class : 31 Hz</li> </ul>	(Outdoor temperature : 2°C (35.6°F)) <ul style="list-style-type: none"> <li>18 class : 35 Hz</li> <li>24/32 class : 26 Hz</li> </ul>
End	1) Press the forced operation [ON/OFF] switch (SW1) on the outdoor unit again.	←
	2) The operation ends automatically after 15 minutes.	2) The operation ends automatically after 60 minutes.
Others	The protection functions are prior to all others in the forced operation.	←



(R12870)

### 3. Wiring Error Check Function

#### Outline

The convenient wiring error check function is designed for the microcomputer to correct wiring errors itself.

If local wiring is unclear in the case of buried piping, for example, just press the wiring error check switch that is behind the stop valve cover of the outdoor unit. Even if the connections for Room A and Room B are confused, the system may run without a hassle. Note that this check function does not work in the following cases.

- For about 1 minute after the power is turned on (during initial setup).
- For 3-minute standby period after the compressor has stopped.
- When the outdoor temperature is below 5°C (41°F).
- If the indoor unit is in trouble (also in case of all-room transmission failure).

When the piping and wiring are perfect, there is no need to use this function.

#### Operation

1. Remove the stop valve cover.
2. Press the wiring error check switch (SW3) on the service monitor PCB of the outdoor unit, and the wiring error check function is activated.
3. In about 10 ~ 20 minutes, the check finishes automatically.
4. When the check is over, the service monitor LED indicators start blinking.

LED	1	2	3	4	Judgment
Status	All blinking at once				Self-correction impossible
	Blinking one after another				Self-correction complete


- Self-correction complete...The LED indicators 1 ~ 2 (18 class), 1 ~ 3 (24 class), or 1 ~ 4 (32 class) blink one after another.
- Self-correction impossible...The LED indicators blink all at the same time.
  - \* Transmission failure occurs at any of the indoor units.
  - \* The indoor unit heat exchanger thermistor is disconnected.
  - \* An indoor unit is in trouble (if a trouble occurs during the wiring error checking).
- Emergency stop...Any of the LED indicators stays on.



#### Note:

1. It takes about 10 ~ 20 minutes (after pressing the wiring error check switch) to complete the checking.
2. Wrongly connected liquid and gas pipes cannot be self-corrected. Be sure to make the liquid pipe and the gas pipe in pairs.
3. To cancel the wiring error check procedure halfway, press the wiring error check switch again. In this case, the memory of the microcomputer returns to its initial status (Room A wiring → Port A piping, Room B wiring → Port B piping).
4. When replacing the outdoor unit PCB, be sure to use this function.
5. Make the power side setting after doing the wiring error check. (Otherwise, if the wiring is reversed, the air-conditioners being connected are set up in the reverse way.)

Service monitor PCB



(R17371)

**Basic Knowledge**

- Refrigerant flows from Port A and on. The temperatures of the indoor heat exchanger thermistors are detected one by one to check up the matching between the piping and wiring.
- With this function on, freezing (crackling) noise may be heard from the indoor unit. This is not a problem. (This is because the heat exchanger temperature is made to drop below 0°C in order to increase the detection accuracy.)
- The indoor fan is made to turn on or off at the same time.

**Checking the current setting data on the microcomputer memory**

Those data can be checked by looking at the service monitor LED indicators, when the wiring error checking is over, during forced operation, at the stop of the system.

The LED indicators stop blinking when the forced operation is over.


LED1...Room A wiring, LED2...Room B wiring

1st blinking LED...Port A piping, 2nd blinking LED...Port B piping


The 1st blinking LED means the room that is connected with Port A. The 2nd blinking LED means the one connected with Port B.

**Example**

Ex: Suppose the LED indicators are blinking as follows.



The above means that Port A is connected with Port B, and Port B with Room A (or self-corrected this way.)



## 4. Trial Operation

### Outline

1. Measure the power supply voltage and make sure that it falls in the specified range.
  2. Trial operation should be carried out in either cooling or heating operation.
  3. Carry out the trial operation in accordance with the operation manual to ensure that all functions and parts, such as louver movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
  - If the circuit breaker trips to shut off the power to the air conditioner, the system backs up the operation mode. The system then restarts operation with the previous operation mode when the circuit breaker is restored.


In cooling operation, select the lowest programmable temperature; in heating operation, select the highest programmable temperature.

- Trial operation may be disabled in either operation mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level.  
(26 ~ 28°C (78.8 ~ 82.4°F) in cooling, 20 ~ 24°C (68 ~ 75.2°F) in heating)
- For protection, the system does not start for 3 minutes after it is turned off.

### Detail


#### ARC452 Series

- (1) Press the [ON/OFF] button to turn on the system.
- (2) Press the both of [TEMP] buttons and the [MODE] button at the same time.
- (3) Press the [MODE] button twice.  
(? appears on the display to indicate that trial operation is selected.)
- (4) Press the [MODE] button and select the operation mode.
- (5) Trial operation terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press the [ON/OFF] button.



**ARC433 Series**

- (1) Press the [ON/OFF] button to turn on the system.
- (2) Press the center of the [TEMP] button and the [MODE] button at the same time.
- (3) Press the [MODE] button twice.  
(? appears on the display to indicate that trial operation is selected.)
- (4) Press the [MODE] button and select the operation mode.
- (5) Trial operation terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press the [ON/OFF] button.





## 5. Field Settings

### 5.1 Outdoor Unit

#### 5.1.1 Priority Room Setting

Outdoor electronic expansion valves are controlled to provide more capacity to the prioritized room.

- Setting method

Turn off the circuit breaker before changing the setting.

Only one room can be set as the priority room (By turning on one of the SW4 on the service monitor PCB of the outdoor unit).

- The control starts when all the following conditions are met.

- \* Priority room setting is made.


- \* “POWERFUL” signal from the priority room unit is received.



**Note:** The operation mode of the priority room unit has precedence.

- Cancellation of control


The control function is canceled when the “POWERFUL” operation mode is switched off or 20 minutes elapse after “POWERFUL Operation” started.



The prioritized room will be heated/cooled much more quickly

(R1396)

Service monitor PCB



(R17373)

## 5.1.2 COOL / HEAT Mode Lock

Use the [S15] connector to set the unit to cooling only or heating only.

Setting to heating only (H): Short-circuit pins 1 and 3 of the connector [S15].

Setting to cooling only (C): Short-circuit pins 3 and 5 of the connector [S15].


The following specifications apply to the connector housing and pins.

JST products Housing: VHR-5N

Pin: SVH-21T-1, 1

Note that forced operation is also possible in cooling / heating mode.

\* The illustration is for 24/32 class models as representative.



### 5.1.3 NIGHT QUIET Mode

If NIGHT QUIET mode is to be used, initial settings must be made when the unit is installed.

Explain the function of NIGHT QUIET mode, as described below, to the customer, and confirm whether or not the customer wants to use NIGHT QUIET mode.


NIGHT QUIET mode function reduces operating noise of the outdoor unit at nighttime. This function is useful if the customer is worried about the effects of the operating noise on the neighbors.

However, if NIGHT QUIET mode is running, cooling capacity is reduced.


■ Procedure

1. Remove the SW5 jumper switch on the service monitor PCB of the outdoor unit.

Once the settings are complete, reset the power.



2. Install the removed jumper switch as described below. This jumper switch is needed later to disable this setting.




## 5.2 Indoor Unit

### 5.2.1 Model Type Setting

#### ARC452A21, ARC452A23


- The remote controller is common to the heat pump model and cooling only model. Use the DIP switch on the remote controller to set the model type.
- Set the DIP switch as shown in the illustration. (The factory set is the heat pump side.)
  - Heat pump model: Set the DIP switch to H/P.
  - Cooling only model: Set the DIP switch to C/O.



### 5.2.2 Temperature Display Switch

#### ARC452 Series

- You can select Fahrenheit or Celsius for temperature display.
- Press the TEMP▲ and ▼ buttons simultaneously for 5 seconds to change the unit of temperature display.



## 5.2.3 When 2 Units are Installed in 1 Room

### Outline

When 2 indoor units are installed in 1 room, 1 of the 2 indoor units and the corresponding wireless remote controller can be set for different address.

Both the indoor unit PCB and the wireless remote controller need alteration.



The method of address setting varies depending on the type of indoor unit and the series of wired remote controller. Refer to the following pages for the appropriate indoor unit and wireless remote controller.

### CTXS/FTXS Series


- (1) Remove the front grille.
- (2) Remove the electrical box.
- (3) Remove the shield plate of the electrical box.
- (4) Cut the address setting jumper JA on the PCB.

#### CTXS-J, CTXS/FTXS-H Series

#### CTXS07LVJU, FTXS09/12LVJU




#### FTXS15/18LVJU



### CDXS/FDXS Series


- Cut the jumper JA on PCB.




## Wireless Remote Controller

- (1) Remove the cover and take it off.
- (2) Cut the address setting jumper.

### ARC452 series



### ARC433 series



## 5.2.4 Jumper Settings

Jumper (on indoor unit PCB)	Function	When connected (factory set)	When cut
JB	Fan speed setting when compressor stops for thermostat OFF. (effective only at cooling operation)	Fan speed setting ; Remote controller setting	Fan speed setting; "0" (The fan stops.)
JC	Power failure recovery function	Auto-restart	The unit does not resume operation after recovering from a power failure. Timer settings are cleared.



For the location of the jumper, refer to the following pages.

CTXS/FTXS series: page 18, 20, 23

CDXS/FDXS series: page 26, 28

## 6. Application of Silicon Grease to a Power Transistor and a Diode Bridge

### Applicable Models

All outdoor units using inverter type compressor for room air conditioner.

When the printed circuit board (PCB) of an outdoor unit is replaced, it is required that silicon grease (\*1) is certainly applied to the heat radiation part (the contact point to the radiation fin) of the power transistor and diode bridge.

\*1: Parts number of the silicon grease – 1172698 (Drawing number 3FB03758-1)

### Details


The silicon grease is an essential article for encouraging the heat radiation of the power transistor and the diode bridge. Applying the paste should be implemented in accordance with the following instruction.

Note: There is the possibility of failure with smoke in case of bad heat radiation.


- Wipe off the old silicon grease completely on a radiation fin.
- Apply the silicon grease evenly to the whole.
- Do not leave any foreign objects, such as solder or paper waste, between the power transistor and the radiation fin, and also the diode bridge, and the radiation fin.
- Tighten the screws of the power transistor and the diode bridge, and contact to the radiation fin without any gap.

#### <Example>


The shape of electrical box and PCB vary depending on the model.



**OK : Evenly applied silicon grease.**



**NG : Not evenly applied**



**NG : Foreign object**

(R9056)

# Part 9

# Appendix

- 1. Piping Diagrams.....269
  - 1.1 Indoor Unit..... 269
  - 1.2 Outdoor Unit..... 271
- 2. Wiring Diagrams.....273
  - 2.1 Indoor Unit..... 273
  - 2.2 Outdoor Unit..... 276





# 1. Piping Diagrams

## 1.1 Indoor Unit

CTXS07JVJU, CTXS09/12HVJU

FTXS15/18HVJU





	A
FTXS15	1/2
FTXS18	1/2
FTXS24	5/8

4D048251C

4D047162A

CTXS07LVJU, FTXS09/12LVJU

FTXS15/18LVJU




4D074606


4D074609

FDXS09/12DVJU

FDXS09/12LVJU




4D051787



4D074621


CDXS15/18LVJU



4D075271


## 1.2 Outdoor Unit

### 2MXS18GVJU




3D048177A

### 3MXS24JVJU



3D066157

## 4MXS32GVJU




3D058508


## 2. Wiring Diagrams

### 2.1 Indoor Unit


CTXS07JVJU, CTXS09/12HVJU



FTXS15/18HVJU




## CTXS07LVJU, FTXS09/12LVJU




3D045012M

## FTXS15/18LVJU




3D060942H

## FDXS09/12DVJU



3D045012L


## FDXS09/12LVJU, CDXS15/18LVJU




3D073998B

## 2.2 Outdoor Unit

### 2MXS18GVJU



### 3MXS24JVJU





## 4MXS32GVJU

