

Commercial 7.5 / 8.5 Ton 2-Speed Package Heat Pump

DCH0900163VRXAAA
DCH0900163VVDDAA
DCH0900163VWXLAA
DCH0900163VWXXAA
DCH0900164VFXXAA
DCH0900164VHBEAA
DCH0900164VMDXAA
DCH0900303VRMMAA
DCH0900303VWXAAA
DCH0900304VJXFAA
DCH090XXX3V1DDAA
DCH090XXX3VVDDAA
DCH090XXX3VVDXAA
DCH090XXX3VWXDAA
DCH090XXX3VXDXAA
DCH090XXX3VXXBAA
DCH090XXX3VXXNAA
DCH090XXX3VXXXAA
DCH090XXX4VFXXAA
DCH090XXX4VHXNAA
DCH090XXX4VXXXAA
DCH090XXX7VXXXAA
DCH102XXX3VXXXAA
DCH102XXX4VXXXAA
DCH102XXX7VXXXAA



This manual is to be used by qualified technicians only.

This manual replaces RP-D1049H.

Important Information

Index

Functional Parts List	3
Illustration and Parts	4 - 15

Views shown are for parts illustrations only, not servicing procedures

Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model Example (M1) (If M Code not shown, then part is used on all Models)

Expanded Model Nomenclature:

Example M1 - Model#1 M2 - Model#2 M3 - Model#3

Daikin Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Daikin Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Daikin Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:

Equipment Support
Daikin North America, LLC
19001 Kermier Road
Waller, Texas 77484
855-770-5678-Telephone
713-863-2382-Facsimile

For assistance outside the U.S.A. contact:

International Division
Daikin North America, LLC
19001 Kermier Road
Waller, Texas 77484
713-861-2500-Telephone
713-863-2382-Facsimile

Functional Parts


Part No: **Description:**

0130M00242	24V RELAY (QTY 3)
03-77429	BLOWER WHEEL
CAP030000440LA	CAPACITOR 3/440V (M12, M25)
CAP050000370LA	CAPACITOR 5/370V (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M22, M23)
CAP075000370LA	CAPACITOR 7.5/370V (M9, M10, M11, M17, M18, M19, M22, M24)
ZP39K5ETFD130	COMP, 39000, 460/60/3 (M9, M10, M11, M17, M18, M19, M22)
ZP39K5ETF5130	COMP, 39000,200/230/60/3 (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21)
ZP39K5ETFE130	COMP, 39000,575/60/3 (M12)
0131M00431	COND MOTOR 575V (M12, M25)
CONT3P025024V	CONTACTOR 25 AMP, 3P, 24V (QTY 4)
CONT2P040024V	CONTACTOR 40 AMP, 2P, 24V
0130M00103	CONTROL, DEFROST
0130M00102	CONTROL, DEFROST
0130M00031	CUT-OUT SWITCH, HIGH PRESSURE
0130M00030	CUT-OUT SWITCH, HIGH PRESSURE
0130L00003	CUT-OUT SWITCH, LOW PRESSURE (QTY 2)
PCBCG100	DDC Controller (M9, M13, M17, M19, M20)
0130L00112	Duct Temp Sensor (M9, M13, M17, M19, M20)
0131L00041	MOTOR 2 HP BELT DRIVE 208-230V (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M23)
0131L00043	MOTOR 2HP BELT DRIVE 460V (M9, M10, M11, M17, M18, M19, M22, M24)
0131L00042	MOTOR 2HP BELT DRIVE 575V (M12, M25)
0131M00847	MOTOR, 1/4 HP, 1 SP, 6 PL (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M16, M20, M21, M23)
0131L00061	MOTOR, 1/4 HP, 1SP, 6PL (M15)
0131M00857	MOTOR, 380/460 50/60 HZ (M9, M10, M11, M17, M18, M19, M24)
0131L00062	MOTOR, COND, 1/4 HP, 460V (M22)
0164L00000	NOTCHED FAN BELT AX51
0130L00108	OD Air Temp Sensor (M9, M13, M17, M19,
PCBDM101	PCB, DEFROST CONTROL
PCBFM103	PCB, TIME DELAY, EBTDR
0130L00105	PHASE MONITOR (M18, M20)
10135604	RELAY (QTY 4)
RS400	REMOTE SENSOR (M8)
0151R00071	REVERSING VALVE
0130L00107	ROOM SENSOR-OE213-G (M9, M13, M17, M19, M20)
B1225022	SOLENOID COIL
ECP400-5	SURVEYOR ECP (M8)
0130M00274	TERMINAL BOARD (M9, M13, M17, M19, M20)
0130M00038	TERMINAL BOARD (M1, M2, M3, M4, M5, M6, M7, M8, M10, M11, M12, M14, M15, M16, M18, M21, M22, M23, M24, M25)
0130M00275	TERMINAL BOARD (M9, M13, M17, M19, M20)
0130M00594	TRANSFORMER (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M23)
0130M00595	TRANSFORMER, 75VA, 480V TO 24V (M9, M10, M11, M17, M18, M19, M22, M24)
0130M00598	TRANSFORMER, 75VA, 575V TO 24V (M12, M25)

Expanded Model Nomenclature

M1 - DCH090XXX3VVDDAA
M2 - DCH090XXX3VVDXAA
M3 - DCH090XXX3VWXDAA
M4 - DCH090XXX3VXDAA
M5 - DCH090XXX3VXXBAA
M6 - DCH090XXX3VXXNAA
M7 - DCH090XXX3VXXXAA
M8 - DCH090XXX3V1DDAA
M9 - DCH090XXX4VFXXAA
M10 - DCH090XXX4VHXNAA
M11 - DCH090XXX4VXXXAA
M12 - DCH090XXX7VXXXAA
M13 - DCH0900163VRXAAA
M14 - DCH0900163VVDDAA
M15 - DCH0900163VWXLAA
M16 - DCH0900163VWXXAA
M17 - DCH0900164VFXXAA
M18 - DCH0900164VHBEAA
M19 - DCH0900164VMDXAA
M20 - DCH0900303VRMMAA
M21 - DCH0900303VWXAAA
M22 - DCH0900304VJXFAA
M23 - DCH102XXX3VXXXAA
M24 - DCH102XXX4VXXXAA
M25 - DCH102XXX7VXXXAA

Cabinet Assembly



Cabinet Assembly

Ref. Part No:	Description:	Ref. Part No:	Description:
Image 1:		Expanded Model Nomenclature	
11	0121L00065RFNG CORNER POST (QTY 3)	M1	- DCH090XXX3VVDDAA
11	0121L01407RFNG CORNER POST (M1, M2, M4, M8, M14, M19, M20)	M2	- DCH090XXX3VVDXAA
21	0121L00511NG LOUVERED SIDE PANEL (QTY 2)	M3	- DCH090XXX3VWXDAA
31	0121L00738RFNG SIDE POST (M3, M5, M6, M7, M9, M10, M11, M12, M13, M15, M16, M17, M18, M21, M22, M23, M24, M25)	M4	- DCH090XXX3VXDAA
31	0121L01400RFNG SIDE POST (M1, M2, M4, M8, M14, M19, M20)	M5	- DCH090XXX3VXXBAA
41	0121L00737NG FILTER DOOR	M6	- DCH090XXX3VXXNAA
51	0121L00739RFNG FILTER DOOR POST (M3, M5, M6, M7, M9, M10, M11, M12, M13, M15, M16, M17, M18, M21, M22, M23, M24, M25)	M7	- DCH090XXX3VXXXAA
51	0121L01432RFNG FILTER DOOR POST (M1, M2, M4, M8, M14, M19, M20)	M8	- DCH090XXX3V1DDAA
61	0121L00510NG ECONOMIZER DOOR (M4, M5, M6, M7, M8, M9, M10, M11, M12, M13, M17, M18, M19, M20, M23, M24, M25)	M9	- DCH090XXX4VFXAA
71	0121L01364NG DUCT PANEL (M1, M2, M4, M5, M6, M7, M9, M11, M12, M14, M17, M23, M24, M25)	M10	- DCH090XXX4VHXNAA
71	0121L01365NG DUCT PANEL (M3, M8, M10, M13, M15, M16, M18, M19, M20, M21, M22)	M11	- DCH090XXX4VXXXAA
81	0121L00082NG COVER- DUCT RETURN	M12	- DCH090XXX7VXXXAA
91	0121L00099NG COVER-DUCT SUPPLY	M13	- DCH0900163VRXAAA
101	0121L00974NG CONTROL DOOR	M14	- DCH0900163VVDAA
111	0121L02517RFNG RF, PAINTED CNTL POST HINGED (M1, M2, M4, M8, M14, M19, M20)	M15	- DCH0900163VWXLAA
111	0121L02303RFNG RF, PAINTED CONTROL POST (M3, M5, M6, M7, M9, M10, M11, M12, M13, M15, M16, M17, M18, M21, M22, M23, M24, M25)	M16	- DCH0900163VWXXAA
121	0121L00767NG HEAT EXCHANGE DOOR	M17	- DCH0900164VFXAA
131	0121L00763NG BLOWER DOOR	M18	- DCH0900164VHBEAA
141	0121L00765RFNG BURNER BOX POST	M19	- DCH0900164VMDXAA
161	0121L00828NG BURNER DOOR	M20	- DCH0900303VRMMAA
231	0121L01099RF RAIL, BASE SIDES RF (QTY 2)	M21	- DCH0900303VWXAAA
241	0121L00834RF RAIL-BASE COND END	M22	- DCH0900304VJXFAA
251	0121L00071RF RAIL, BASE DUCT END	M23	- DCH102XXX3VXXXAA
261	0121G00301 RAIL CORNER BRACKET (QTY 4)	M24	- DCH102XXX4VXXXAA
NS	0121L00055 BRACKET-FORK BOARD (QTY 4)	M25	- DCH102XXX7VXXXAA
NS	0121L00727 ECONOMIZER COVER (M1, M2, M3, M14, M15, M16, M21)		
NS	0121L01310 ECONOMIZER COVER (M22)		
NS	0141L00006X FORK BOARD (QTY 2)		
NS	0164L00009 GASKET-RUBBER, CPOST (QTY 3)		
NS	0164L00011 GASKET-RUBBER, SIDE POST (QTY 5)		

Top Panel and Tubing Assembly

IMAGE 1






IMAGE 2




Condenser, Evaporator and Partition Assy



Condenser, Evaporator and Partition Assy

Ref. Part No:	Ref. Part No:	Description:	Description:
Image 1:		Expanded Model Nomenclature	
11	0201L00002	TUBING ASSY, COND COIL (M1, M2, M3, M4, M5, M6, M7, M8, M9, M10, M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22)	M1 - DCH090XXX3VVDAA M2 - DCH090XXX3VVDXAA M3 - DCH090XXX3VWXDAA M4 - DCH090XXX3VXDAA M5 - DCH090XXX3VXXBAA M6 - DCH090XXX3VXXNAA M7 - DCH090XXX3VXXXAA M8 - DCH090XXX3V1DDAA M9 - DCH090XXX4VFXAA M10 - DCH090XXX4VHXNAA M11 - DCH090XXX4VXXXAA M12 - DCH090XXX7VXXXAA M13 - DCH0900163VRXAAA M14 - DCH0900163VVDAA M15 - DCH0900163VWXLAA M16 - DCH0900163VWXXAA M17 - DCH0900164VFXAA M18 - DCH0900164VHBEAA M19 - DCH0900164VMDXAA M20 - DCH0900303VRMMAA M21 - DCH0900303VWXAAA M22 - DCH0900304VJXFAA M23 - DCH102XXX3VXXXAA M24 - DCH102XXX4VXXXAA M25 - DCH102XXX7VXXXAA
11	0201L00096	TUBING ASSY, COND COIL C1 (M23, M24, M25)	
21	0121L00650	FILTER ANGLE-VERTICAL (RETURN SIDE)	
31	0121L00210	EVAP EXTENSION-RETURN SIDE	
41	0121L00843	EXTENSION-EVAP HPIN	
51	0121L00649	FILTER ANGLE - HORIZONTAL (QTY 2)	
61	0121L01257	FILTER ANGLE - VERTICAL	
71	0121L00358	FILTER ANGLE-VERTICAL (HAIRPIN SIDE)	
81	0130M00102	CONTROL, DEFROST	
91	0130M00103	CONTROL, DEFROST	
101	0202L00004	TUBING ASSY, EVAP COIL (M1, M2, M3, M4, M5, M6, M7, M8, M9, M10, M11, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22)	
101	0202L00050	TUBING ASSY, EVAP COIL (M23, M24, M25)	
101	0202L00058	TUBING ASSY, EVAP COIL (M12)	
111	0121L00508	DRAIN PAN SUPPORT	
141	0161L00002	DRAIN PAN	
151	0121L00374	DECK SIDE CHANNEL	
161	0121L00365	ELECTRIC HEAT PANEL	
171	0121L00177	ELECTRIC HEAT COVER (M17, M18, M19, M22)	
181	0121L00090	BLOWER TRANSITION, RH END	
191	0121L00092	BLOWER TRANSITION, FRONT	
201	0121L03117	DECK, BLOWER	
211	0121L00097	BLOWER TRANSITION, LH END	
221	0121L00145	BLOWER TRANSITION, BACK	
231	0121L00513	BRACE-CONDENSER (QTY 2)	
241	ZP44K5ETFD130	COMP, 44000, 460/60/3 (M24)	
241	ZP39K5ETFD130	COMP, 39000, 460/60/3 (M9, M10, M11, M17, M18, M19, M22)	
241	ZP39K5ETFD5130	COMP, 39000,200/230/60/3 (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21)	
241	ZP39K5ETFE130	COMP, 39000,575/60/3 (M12)	
241	ZP44K5ETFD5130	COMP, 44000, 200/230/60/3 (M23)	
241	ZP44K5ETFE130	COMP, 44000, 575/60/3 (M25)	
261	M0221641	TF SHOULDER SCREW (QTY 8)	
271	B1339533	COMPRESSOR GROMMET (QTY 8)	
281	0121L02128	MOUNTING PLATE, COMP (QTY 2)	
291	0159L00066	Harness, comp scroll	
291	0159L00067	Harness, comp scroll	
301	0201L00002	TUBING ASSY, COND COIL (M1, M2, M3, M4, M5, M6, M7, M8, M9, M10, M11, M12, M13, M14, M15, M16, M17, M18, M19, M20, M21, M22)	
301	0201L00097	TUBING ASSY, COND COIL C2 (M23, M24, M25)	
331	0154L00009	GASKET-DRAIN PAN	
341	0163L00071	DRAIN PLUG	
NS	0121L01398	DECK, SUPPORT BLOWER (M1, M2, M4, M8, M14, M19, M20)	
NS	0121L01402	DECK, SUPPORT CONTROL (M1, M2, M4, M8, M14, M19, M20)	
NS	0121L00321	SMOKE DETECTOR COVER (QTY 2)	

Blower Motor Assembly



Blower Motor Assembly

Ref. Part No:	Ref. Part No:	Description:	Description:
---------------	---------------	--------------	--------------


Image 1:

11	04-01525	BLOWER HOUSING
21	0163L00134	SHEAVE, FIXED AK74H
31	0163M00407	MACHINE KEY, SPECIAL
41	0164L00000	NOTCHED FAN BELT AX51
51	0163L00012	VARIABLE PITCH SHEAVE VL40
61	0270L00015	MOTOR BASE ASSY
71	0163M00045	BOLT 1/4-20 X 4"
81	3225000F	BELT TIGHTENER ANGLE
91	B1446707	SCREW 5/16-18 X 1" (QTY 4)
101	B1393726	ELECT. CONNECTING BUSHING
111	0131L00041	MOTOR 2 HP BELT DRIVE 208-230V (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M23)
111	0131L00043	MOTOR 2HP BELT DRIVE 460V (M9, M10, M11, M17, M18, M19, M22, M24)
111	0131L00042	MOTOR 2HP BELT DRIVE 575V (M12, M25)
121	B1393738	BOLT 1/4-20 X 3/4" (QTY 4)
131	03-77429	BLOWER WHEEL
141	04-11525	BLOWER SHAFT
161	B1392923	WASHER / FLAT (QTY 4)
NS	04-02196	BEARING & FRAME ASSY
NS	0259L00191	HARNES, BELT DRIVE MOTOR



Expanded Model Nomenclature

M1 - DCH090XXX3VDDAA
M2 - DCH090XXX3V DXAA
M3 - DCH090XXX3VWXDAA
M4 - DCH090XXX3V XDXAA
M5 - DCH090XXX3VXXBAA
M6 - DCH090XXX3VXXNAA
M7 - DCH090XXX3VXXXAA
M8 - DCH090XXX3V1DDAA
M9 - DCH090XXX4VFXAA
M10 - DCH090XXX4VHXNAA
M11 - DCH090XXX4VXXXAA
M12 - DCH090XXX7VXXXAA
M13 - DCH0900163VRXAAA
M14 - DCH0900163VDDAA
M15 - DCH0900163VWXLAA
M16 - DCH0900163VWXXAA
M17 - DCH0900164VFXAA
M18 - DCH0900164VHBEAA
M19 - DCH0900164VMDXAA
M20 - DCH0900303VRMMAA
M21 - DCH0900303VWXAAA
M22 - DCH0900304VJXFAA
M23 - DCH102XXX3VXXXAA
M24 - DCH102XXX4VXXXAA
M25 - DCH102XXX7VXXXAA

Control Box Assembly



CONTROL BOX
FOR MODELS
WITH DDC CONTROL



FRONT VIEW

Control Box Assembly

Ref. Part No:	Ref. Part No:	Description:	Description:
Image 1:		Image 1:	
31	0121G00491	VOLTAGE BARRIER	NS 0259L00428 WIRE ASSY (M18)
51	0130M00594	TRANSFORMER (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M23)	NS 0259L00447 WIRE ASSY (M18)
51	0130M00595	TRANSFORMER, 75VA, 480V TO 24V (M9, M10, M11, M17, M18, M19, M22, M24)	NS 0259L00502 WIRE HARNESS
51	0130M00598	TRANSFORMER, 75VA, 575V TO 24V (M12, M25)	NS 0259L00503 WIRE HARNESS (M9, M13, M17, M19, M20)
61	CAP030000440LA	CAPACITOR 3/440V (M12, M25)	NS 0259L00148 WIRE HARNESS ASSY
61	CAP050000370LA	CAPACITOR 5/370V (M1, M2, M3, M4, M5, M6, M7, M8, M13, M14, M15, M16, M20, M21, M22, M23)	NS 0259L00149 WIRE HARNESS ASSY
61	CAP075000370LA	CAPACITOR 7.5/370V (M9, M10, M11, M17, M18, M19, M22, M24)	NS 0259L00150 WIRE HARNESS ASSY
71	20520901	CAPACITOR STRAP (QTY 2)	NS 0259L00151 WIRE HARNESS ASSY
151	PCBDM101	PCB, DEFROST CONTROL	NS 0259L00152 WIRE HARNESS ASSY
161	0130M00038	TERMINAL BOARD (M1, M2, M3, M4, M5, M6, M7, M8, M10, M11, M12, M14, M15, M16, M18, M21, M22, M23, M24, M25)	NS 0259L00156 WIRE HARNESS ASSY
171	0130M00042	BLOCK, POWER	NS 0259L00158 WIRE HARNESS ASSY
181	PCBFM103	PCB, TIME DELAY, EBTDR	NS 0259L00090 WIRE HARNESS-SMOKE DETECTOR (M1, M3, M6, M8, M10, M14, M15)
201	CONT2P040024V	CONTACTOR 40 AMP, 2P, 24V	
221	10135604	RELAY (QTY 4)	
231	0130M00242	24V RELAY (QTY 3)	
411	PCBCG100	DDC Controller (M9, M13, M17, M19, M20)	
421	0130M00274	TERMINAL BOARD (M9, M13, M17, M19, M20)	
431	0130M00275	TERMINAL BOARD (M9, M13, M17, M19, M20)	
451	0259L00368	CURRENT SWITCH WITH TERMS (M9, M13, M17, M19, M20)	
471	0130L00108	OD Air Temp Sensor (M9, M13, M17, M19, M20)	
661	CONT3P025024V	CONTACTOR 25 AMP, 3P, 24V (QTY 4)	
NS	0259L00153	2 SPEED CONTROL HARNESS	
NS	0259L00154	2 SPEED HP HARNESS	
NS	0259L00155	2 SPEED RELAY HARNESS	
NS	0259L00303	COND FAN/TRANSFORMER HARNESS	
NS	0259L00159	DEFROST BOARD HARNESS	
NS	0259L00157	DEFROST RELAY HARNESS	
NS	0130L00112	Duct Temp Sensor (M9, M13, M17, M19, M20)	
NS	0259L00165	ECONOMIZER HARNESS	
NS	0259L00379	HARN, BINARY INPUT, DDC (M9, M13, M17, M19, M20)	
NS	0259L00382	HARN, CNTL PWR, DDC (M9, M13, M17, M19, M20)	
NS	0259L00385	HARN, CNTL, HEAT PLUG INTERCON (M9, M13, M17, M19, M20)	
NS	0259L00383	HARN, CNTL, TR1-TR2-CFC (M9, M13, M17, M19, M20)	
NS	0259L00418	HARN, RELAY OUTPUT, DDC 2 SP (M9, M13, M17, M19, M20)	
NS	0259L00191	HARNESS, BELT DRIVE MOTOR	
NS	0259L00092	HARNESS-SMOKE DETECTOR SENSOR (M1, M3, M6, M8, M10, M14, M15)	
NS	0259L00032	LCM HARNESS, ELECTRIC HEAT	
NS	0130L00105	PHASE MONITOR (M18, M20)	
NS	0130L00107	ROOM SENSOR -OE213-G (M9, M13, M17, M19, M20)	
NS	0259L00415	WIRE ASSY (M20)	
NS	0259L00426	WIRE ASSY (M20)	

Expanded Model Nomenclature


M1 - DCH090XXX3VDDAA
M2 - DCH090XXX3VVDXAA
M3 - DCH090XXX3VWXDAA
M4 - DCH090XXX3VXDAA
M5 - DCH090XXX3VXXBAA
M6 - DCH090XXX3VXXNAA
M7 - DCH090XXX3VXXXAA
M8 - DCH090XXX3V1DDAA
M9 - DCH090XXX4VFXAA
M10 - DCH090XXX4VHXNAA
M11 - DCH090XXX4VXXXAA
M12 - DCH090XXX7VXXXAA
M13 - DCH0900163VRXAAA
M14 - DCH0900163VVDAA
M15 - DCH0900163VWXLAA
M16 - DCH0900163VWXXAA
M17 - DCH0900164VFXAA
M18 - DCH0900164VHBEAA
M19 - DCH0900164VMDXAA
M20 - DCH0900303VRMMAA
M21 - DCH0900303VWXAAA
M22 - DCH0900304VJXFAA
M23 - DCH102XXX3VXXXAA
M24 - DCH102XXX4VXXXAA
M25 - DCH102XXX7VXXXAA

Accessory Parts List


ACCESSORY PARTS LIST

NOTE: NOT ALL OPTIONS AVAILABLE FOR ALL PRODUCTS


1 LOW AMBIENT KITS




2 GFCI CONVENIENCE OUTLET




3 DISCONNECT MODULE (NON-FUSED)




4 SMOKE DETECTORS




5 DDC CONTROL



6 HINGED DOOR ASSEMBLIES



7 PHASE MONITOR



Accessory Parts List

Ref. Part No:	No:	Description:	Ref. Part No:	No:	Description:
Image 1:			Image 1:		
NS	EHK3-16	15 KW 208-230/3 ELECTRIC HEAT (M13, M14, M15, M16)	NS	0130L00043	SHAFT, CUT (M3, M8)
NS	EHK4-16	15 KW 460/3 ELECTRIC HEAT (M17, M18, M19)	NS	0130L00056	SHAFT, CUT (M10, M15, M22)
NS	DDNECNJ90150B	7.5-12.5 TON DFLOW ECON (M1, M2, M3, M14, M15, M16, M21)	NS	0130L00057	SHAFT, CUT (M18, M19)
NS	1036610B	7.5-12.5 TON DFLOW ECONOMIZER (M22)	NS	0130L00049	SHAFT, DISCONNECT (M3, M8, M10, M13, M15, M16, M18, M19, M20, M21, M22)
NS	10366D10B	7.5-12.5T DFLOW ECON, DDC (M9, M13, M17, M20)	NS	D4120	SMOKE DETECTOR, PHOTO 4WIRE (M1, M3, M6, M8, M10, M14, M15)
NS	0121L00316	BRACKET-CONV OUTLET MOUNT (M5, M6, M10, M13, M15, M20, M21, M22)	NS	D4S	SMOKE DETECTOR, SENSOR ONLY (M15)
NS	0121L00768	BRACKET-SMOKE DETECTOR (M1, M3, M6, M8, M10, M14, M15)	NS	ECP400-5	SURVEYOR ECP (M8)
NS	0130M00065	CIRCUIT BREAKER, CONVENIENCE OUTLET (M5, M6, M10, M20)	NS	0130L00027	SWITCH-DISCONNECT 100A (M10, M15, M22)
NS	0121L00973NG	DISCONNECT SWITCH COVER (M3, M8, M10, M13, M15, M16, M18, M19, M20, M21, M22)	NS	0130L00033	SWITCH-DISCONNECT 200A (M3, M8)
NS	0121L01406NG	DOOR FRAME, CONTROL (M1, M2, M4, M8, M14, M19, M20)	NS	0130L00046	SWITCH-DISCONNECT 60A (M18, M19)
NS	0121L02480NG	DOOR, SERVICE, FRONT, BLOWER (M1, M2, M4, M8, M14, M19, M20)	NS	0130M00061	TRANSFORMER, CONVENIENCE OUTLET (M5, M6, M10, M20)
NS	EHK3-30	ELECTRIC HEATER KIT (M20, M21)	NS	0259L00557	WIRE HARNESS (M8)
NS	EHK4-30	ELECTRIC HEATER KIT (M22)	Expanded Model Nomenclature		
NS	0130L00012	GANG BOX-GFCI OUTLET (M5, M6, M10, M13, M15, M20, M21, M22)	M1 - DCH090XXX3VVDAA		
NS	0130L00039	HANDLE, ROTARY (M3, M8, M10, M13, M15, M18, M19, M20, M21, M22)	M2 - DCH090XXX3VVDXAA		
NS	0163M00307	HINGE, LEFT HAND (M1, M2, M4, M8, M14, M19, M20)	M3 - DCH090XXX3VWXDAA		
NS	0163M00308	HINGE, RIGHT HAND (M1, M2, M4, M8, M14, M19, M20)	M4 - DCH090XXX3VXDAA		
NS	0163M00322	LATCH (M1, M2, M4, M8, M14, M19, M20)	M5 - DCH090XXX3VXXBAA		
NS	0130M00059	LOW AMBIENT KIT (M22)	M6 - DCH090XXX3VXXNAA		
NS	0121L02220NG	PNT, DOOR FRAME FILTER (M1, M2, M4, M8, M14, M19, M20)	M7 - DCH090XXX3VXXXAA		
NS	0121L02481NG	PNT, SERVICE DOOR BACK BLWR (M1, M2, M4, M8, M14, M19, M20)	M8 - DCH090XXX3V1DDAA		
NS	0121L02223NG	PNT, SERVICE DOOR BACK FILTER (M1, M2, M4, M8, M14, M19, M20)	M9 - DCH090XXX4VFXXAA		
NS	0121L02218NG	PNT, SERVICE DOOR FRONT FILTER (M1, M2, M4, M8, M14, M19, M20)	M10 - DCH090XXX4VHXNAA		
NS	0161G00012	POWER OUTLET BOX (M5, M6, M10, M13, M15, M20, M21, M22)	M11 - DCH090XXX4VXXXAA		
NS	0130L00103	RECEPTACLE-GFCI OUTLET (M5, M6, M10, M13, M15, M20, M21, M22)	M12 - DCH090XXX7VXXXAA		
NS	RS400	REMOTE SENSOR (M8)	M13 - DCH0900163VRXAAA		
NS	SP400	SENSOR PACK (M8)	M14 - DCH0900163VVDAA		
NS	0121L01404NG	SERVICE DOOR BACK, CONTROL (M1, M2, M4, M8, M14, M19, M20)	M15 - DCH0900163VWXLAA		
NS	0121L01397NG	SERVICE DOOR FRAME, BLOWER (M1, M2, M4, M8, M14, M19, M20)	M16 - DCH0900163VWXAAA		
NS	0121L01403NG	SERVICE DOOR FRONT, CONTROL (M1, M2, M4, M8, M14, M19, M20)	M17 - DCH0900164VFXXAA		
			M18 - DCH0900164VHBAAA		
			M19 - DCH0900164VMDXAA		
			M20 - DCH0900303VFMMAA		
			M21 - DCH0900303VWXAAA		
			M22 - DCH0900304VJXFAA		
			M23 - DCH102XXX3VXXXAA		
			M24 - DCH102XXX4VXXXAA		
			M25 - DCH102XXX7VXXXAA		